

YASKAWA Electric Corporation
Robot Controller Sample Project File
For YRC1000 / YRC1000micro
Ver.2.11 QVGA Edition

Technical Guide

Revision History

Revision No.	Date	Descriptions
00	28/07/2017	New
01	31/03/2018	<p>Supports YRC1000micro</p> <ul style="list-style-type: none">- 5.1. System configuration<ul style="list-style-type: none">Added YRC1000micro to the figure.- 5.3 Software<ul style="list-style-type: none">Changed creating editor version of sample project to 4.00.000.- 5.4. Connection devices<ul style="list-style-type: none">Added YRC1000micro to the table.- 5.5. Cable wiring<ul style="list-style-type: none">Changing description of communication cable.- 5.6.2. Communication settings for connection devices<ul style="list-style-type: none">Added the following item.<ul style="list-style-type: none">2) Check the parameters3) Setting command remote selection4) Setting batch backup

Table of Contents

1. Overview	1
2. Notes	1
3. Restrictions	1
4. How to use this project file.....	2
5. Device configuration.....	3
5.1. System configuration	3
5.2. Target HMI Devices.....	4
5.3. Software	7
5.4. Connection devices.....	7
5.5. Cable wiring	7
5.6. Communication settings.....	8
5.6.1. GP-Pro EX communication settings	8
5.6.2. Communication settings for connection devices.....	8
5.6.3. Indirect device settings.....	9
6. Screen configuration.....	10
6.1. Screen types.....	10
6.2. Screen transitions.....	12
7. Detailed screen explanation.....	14
7.1. Common	14
7.1.1. Screen overview	14
7.1.2. Screen image (Common)	14
7.1.3. Screen image (Error message).....	15
7.1.4. D Script	16
7.2. Startup screen (B0001).....	16
7.2.1. Screen overview	16
7.2.2. Screen image	16
7.3. Robot Controller List screen (B8600)	17
7.3.1. Screen overview	17
7.3.2. Screen image	17
7.3.3. D Script	18
7.4. Panel Setting List (B8603).....	19
7.4.1. Screen overview	19
7.4.2. Screen image	19
7.4.3. D Script	20
7.5. PANEL Setting screen (B8604 to B8607)	21
7.5.1. Screen overview	21
7.5.2. Screen image	21
7.5.3. D Script	24
7.6. I/O Monitor screens (B8611 to B8614)	24
7.6.1. Screen overview	24
7.6.2. Screen image	24
7.6.3. D Script	25
7.6.4. Text registry (8301 – 8390).....	25

7.7. JOB Monitor screen (B8620).....	26
7.7.1. Screen overview	26
7.7.2. Screen image	26
7.7.3. D Script	27
7.8. JOB List screen (B8622).....	28
7.8.1. Screen overview	28
7.8.2. Screen image	28
7.8.3. Job program selection window	29
7.8.4. D Script	29
7.9. Robot Status monitor screens (B8624 to B8630).....	30
7.9.1. Screen overview	30
7.9.2. Screen image	30
7.9.3. D Script	31
7.10. Servo Monitor screen (B8632 to B8636).....	32
7.10.1. Screen overview.....	32
7.10.2. Screen image.....	32
7.10.3. D Script	32
7.11. Tool Information screen (B8638).....	33
7.11.1. Screen overview.....	33
7.11.2. Screen image.....	33
7.11.3. D Script	33
7.12. System Monitor screen (B8640)	34
7.12.1. Screen overview.....	34
7.12.2. Screen image.....	34
7.13. Alarm Monitor screen (B8642)	35
7.13.1. Screen overview.....	35
7.13.2. Screen image.....	35
7.13.3. Alarm Details window (B8646, B8647)	36
7.13.4. Alarm Message window	37
7.13.5. D Script	37
7.14. Alarm History screen (B8644).....	39
7.14.1. Screen overview.....	39
7.14.2. Screen image.....	39
7.14.3. D Script	40
7.15. Alarm Code Detail window (B8645)	40
7.15.1. Screen overview.....	40
7.15.2. Screen image.....	40
7.15.3. D Script	41
7.16. Predictive Maintenance screen (B8650 to B8652)	41
7.16.1. Screen overview.....	41
7.16.2. Screen image.....	41
7.16.3. D Script	44

7.17. Advanced Setting screen (B8655 to B8656)	45
7.17.1. Screen overview.....	45
7.17.2. Screen image.....	45
7.17.3. D Script	46
7.18. CMOS Backup screen (B8657).....	47
7.18.1. Screen overview.....	47
7.18.2. Screen image.....	47
7.18.3. D Script	48
7.19. Byte Variable Monitor screen (B8850).....	48
7.19.1. Screen overview.....	48
7.19.2. Screen image.....	48
7.19.3. D Script	48
7.20. Integer Variable Monitor screen (B8851).....	49
7.20.1. Screen overview.....	49
7.20.2. Screen image.....	49
7.20.3. D Script	50
7.21. Double Int Variable Monitor screen (B8852).....	50
7.21.1. Screen overview.....	50
7.21.2. Screen image.....	50
7.21.3. D Script	51
7.22. Real Variable Monitor screen (B8855)	52
7.22.1. Screen overview.....	52
7.22.2. Screen image.....	52
7.22.3. D Script	52
7.23. String Variable Monitor screen (B8654)	53
7.23.1. Screen overview.....	53
7.23.2. Screen image.....	53
7.23.3. D Script	54
7.24. Robot Position Variable Monitor screen (B8656)	54
7.24.1. Screen overview.....	54
7.24.2. Screen image.....	54
7.24.3. D Script	56
7.25. Base Position Variable Monitor screen (B8857)	56
7.25.1. Screen overview.....	56
7.25.2. Screen image.....	56
7.25.3. D Script	57
7.26. Station Position Variable Monitor screen (B8858).....	58
7.26.1. Screen overview.....	58
7.26.2. Screen image.....	58
7.26.3. D Script	58
7.27. Register Monitor screen (B8870)	59
7.27.1. Screen overview.....	59

7.27.2. Screen image.....	59
7.27.3. D Script	59
8. Global D script	60
9. Address maps.....	61
9.1. List of internally-used addresses	61
9.2. Symbol variable list	67

1. Overview

This is a sample project connection with the Robot Controller YRC1000 / YRC1000micro manufactured by YASKAWA Electric Corporation. When using the Robot, we provide the following features to help improve understanding.

- ✓ Robot Controller status (such as mode, operation status) can be checked on a GP unit.
- ✓ Up to 4 controllers can be connected.
- ✓ The status of the I/O controller can be monitored in real-time.
- ✓ Displays movement of the robotic arm on a GP unit.
- ✓ The current position of the robotic arm can be displayed in real-time.
- ✓ Details of current alarm and alarm history can be viewed on a GP unit.
- ✓ The variable and address value can be displayed at once, thus making monitoring easier.
- ✓ Predictive Maintenance and CMOS Backup screens are provided as a maintenance function.

2. Notes

1. The intellectual property rights for the files provided by Schneider Electric Japan Holdings Ltd. belong to us.
2. Downloaded files and the data extracted from those files are no guarantees of our product specifications. Please be aware of this fact.
3. The liability for use of this service lies with the customer.
4. In any case, this is not intended as a warranty for any work for a system that makes use of the data on these screens.
5. For models that can operate in this sample project, please refer to the chapter "5.2. Target device with touch panel" in this manual.
6. Any modifications made to this service by a customer are entirely at the responsibility of the customer.
7. Please be aware that we cannot respond to any inquiries for the purpose of modifying these data.
8. The content and information in the data on these screens and documentation are subject to change without prior notification.

3. Restrictions

This screen data is taken from screenshots showing the representative features and functions of the GP4000 Series.

When using the sample project file, be sure to reference our product manual or the connection device manual, including the usage restrictions and safety precautions. In addition, please be aware that we are unable to accept responsibility for damage arising from reasons that cannot be attributable to us, loss of customer opportunity or profit

arising from the malfunction of our product, damage arising from special circumstances regardless of whether or not we had foreknowledge of those circumstances, secondary damage, compensation for accidents, damage to our products, or other business-related guarantees.

4. How to use this project file

When using this project file (henceforth known as "the file"), be sure to confirm the following details:

1) When using the file as-is

Confirm the communication settings.

When using this file as-is, transfer it in GP-Pro EX to a display console with a touch panel.

When connecting, refer to section "4. Device Configuration" of this Instructions for Use.

For networking cables, refer to sections "4.5. Networking cables" and "4.6. Communication settings" of this Instructions for Use.

2) How to combine with other files

In GP-Pro EX, select [Project] → [Utilities] → [Copy from Another Project].

For further details, refer to "Chapter 5 From Startup to Shutdown" in our reference manual.

However, there are issues to be aware of, such as overlapping screen numbers, so also refer to sections 3) and later.

3) Screen numbers when combining

There may be times when things get overwritten, such as when there are duplicate screen numbers.

When combining the file with a file currently being created, be aware of the screen numbers.

Refer to section "5.2. Screen transitions" for screen numbers that are being used by the file.

When combining with 2), it is possible to designate a copy destination screen number before starting to copy. Before combining, be sure to either designate a screen number when copying, or change the screen number in advance.

When changing a screen number, be sure to also change the screen number for the screen replacement switch.

Be aware that if no changes are made to the screen replacement destination screen number, unexpected operations may occur.

4) Changing addresses

When changes are made to the address of a connection device that has been configured on the screen, it will not operate properly.

Do not make changes to these addresses.

5. Device configuration

5.1. System configuration




Figure 5-1 System configuration

NOTES

- ◆ The power source specifications for GP4000 series differ depending on the device type.
- ◆ This sample project supports up to 4 robot controllers, each with one robot, station and base connected.
- ◆ For further details, check the catalogs or hardware manuals.
- ◆ Connection device settings information and operation please refer to each connection device manual.
- ◆ When using Alarm details function please download the Alarm file and save to the SD card.

5.2. Target HMI Devices

The following shows the display device types for use with this sample project file.

Table 5-1 Target HMI Devices

Series	Models	Project target models	
		connection_gp4301_q_YAS-YRC 1000_ml_V211.prx (QVGA)	Notes
GP4000 Series	GP-4104		
	GP-4105		
	GP-4106		
	GP-4107		
	GP-4114T		
	GP-4115T		
	GP-4116T		
	GP-4115T3		Use GP-Pro EX Ver.4.07.300 or later
	GP-4201T	OK*1	
	GP-4201TM (Modular Type)		
	GP-4201TW		
	GP-4203T	OK*1	
	GP-4301T	OK	
	GP-4301TM (Modular Type)		
	GP-4301TW		
	GP-4303T	OK*1	
	GP-4311HT		Use GP-Pro EX Ver.4.06.000 or later
	GP-4401T		
	GP-4401WW		
	GP-4501T (Analog Touch Panel)		
	GP-4501T (Matrix Touch Panel)		
	GP-4501TW		
	GP-4503T		
	GP-4521T		Use GP-Pro EX Ver.4.07.300 or later
	GP-4601T (Analog Touch Panel)		

	GP-4601T (Matrix Touch Panel)		
	GP-4603T		
	GP-4621T		Use GP-Pro EX Ver.4.07.300 or later
	GP-4G01 VGA (640*480)		Use GP-Pro EX Ver.4.07.000 or later
	GP-4G01 SVGA (800*600)		Use GP-Pro EX Ver.4.07.000 or later
	GP-4G01 WVGA (800*480)		Use GP-Pro EX Ver.4.07.000 or later
	GP-4000M (Rear Modular Type)		
LT4000 Series	LT-4201TM (Modular Type DIO)	OK*1	
	LT-4201TM (Modular Type Analog)	OK*1	
	LT-4301TM (Modular Type DIO)	OK*1	
	LT-4301TM (Modular Type Analog)	OK*1	
	LT-4000M (Rear Module DIO)	OK*1	
	LT-4000M (Rear Module Analog)	OK*1	
SP5000 Power Box (SP-5B10)	SP-5500TP VGA (640*480)		
	SP-5500TP SVGA (800*600)		
	SP-5600TP VGA (640*480)		
	SP-5600TP SVGA (800*600)		
	SP-5600TP XGA (1024*768)		
	SP-5660TP VGA (640*480)		
	SP-5660TP SVGA (800*600)		

	SP-5660TP XGA (1024*768)		
	SP-5700TP VGA (640*480)		
	SP-5700TP SVGA (800*600)		
	SP-5700TP XGA (1024*768)		
	SP-5700WC FWXGA (1366*768)		Use GP-Pro EX Ver.4.07.300 or later
	SP-5800WC FWXGA (1366*768)		Use GP-Pro EX Ver.4.07.300 or later
	SP-5400WA WVGA (800*480)		
	SP-5500WA WXGA (1280*800)		
	SP-5600WA WXGA (1280*800)		
	DC Power Supply Adapter SVGA (800*600)		Use GP-Pro EX Ver.4.08.000 or later
	DC Power Supply Adapter XGA (1024*768)		Use GP-Pro EX Ver.4.08.000 or later
SP5000 Open Box (SP-5B40, SP-5B41)	SP-5500TP SVGA (800*600)		
	SP-5600TP SVGA (800*600)		Use GP-Pro EX Ver.4.06.100 or later
	SP-5600TP XGA (1024*768)		
	SP-5660TP SVGA (800*600)		Use GP-Pro EX Ver.4.06.100 or later
	SP-5660TP XGA (1024*768)		
	SP-5700TP SVGA (800*600)		Use GP-Pro EX Ver.4.06.100 or later
	SP-5700TP XGA (1024*768)		
	SP-5700WC FWXGA (1366*768)		Use GP-Pro EX Ver.4.07.300 or later
	SP-5800WC FWXGA (1366*768)		Use GP-Pro EX Ver.4.07.300 or later

	SP-5400WA WVGA (800*480)		
	SP-5500WA WXGA (1280*800)		
	SP-5600WA WXGA (1280*800)		
	DC Power Supply Adapter SVGA (800*600)		Use GP-Pro EX Ver.4.06.300 or later
	DC Power Supply Adapter XGA (1024*768)		Use GP-Pro EX Ver.4.06.300 or later

*1. Usable by making changes to the device type in the project file. But change layout or connection device settings if necessary.

5.3. Software

Table 5-2 Software

No	Manufacturer	Product Name	Model	Comments
1	Schneider Electric Japan Holdings Ltd.	GP-PRO EX	PFXEXEDV40	High Speed Ethernet Server Driver. Ver.1.13.06 or later

These screen samples were created on GP-Pro EX Ver.4.00.000. Update it if the version is before Ver. 4.00.000.

Please download the High Speed Ethernet Server Driver (Ver. 1.13.06) from our website if using versions prior to Ver.1.13.06.

5.4. Connection devices

Table 5-3 Connection devices

No	Manufacturer	Product Name	Series	Model	Comments
1	YASKAWA Electric Corporation	Robot controller	–	YRC1000	High-speed Ethernet server functionality. Ver. DS1.00-00 or later.
2	YASKAWA Electric Corporation	Robot controller	–	YRC1000micro	High-speed Ethernet server functionality. Ver. DS1.00-00 or later.

The "High-speed Ethernet" functionality is needed in order to connect a YRC1000 / YRC1000micro robot controller to a GP4000 series. In addition, there are optional features that cannot be used along with this feature, so please contact the YASKAWA Electric Corporation if you wish to use them.

5.5. Cable wiring

Please use category 5 or more Ethernet cable with shield.

5.6. Communication settings

5.6.1. GP-Pro EX communication settings

Please set the IP address set in the robot controller to the IP address of individual device setting.

It is not necessary to change the IP address of the connected device No. that is not connected.




Figure 5-2 communication settings

Table 5-4 Communication settings

Item	Range	Default
Port No.	1024 - 65535	1024
Auto	OFF - ON	ON
Timeout	1 - 127	20
Retry	0 - 255	2
Wait To Send	0 - 255	0

5.6.2. Communication settings for connection devices

1) Check the IP address

Be sure to configure the IP address on the robot controller console.

Table 5-5 Connection device communication settings

Communication settings	Communication device-side
Model	YRC1000, YRC1000micro
IP Address	192.168.255.1
Port	UDP 10040, 10041

2) Check the parameters

When using high-speed Ethernet, you need to set the parameter value of the robot controller. Check the setting values of the following parameters, and change the setting value if not.

Table 5-6 List of setting parameters

Parameter	Meaning	Setting (Initial value)
RS022	Instance 0 allowed	1
RS029	Job and variable loading during playback	1
RS034	Response waiting timer	200
RS035	End-of-text monitoring timer	200

*NOTE

To use the robot controller with the RS022 Instance 0 allowed parameter set to 0 (disabled), the setting must be changed on the display. Open "PANEL Setting Screen" on the touch panel display, and then disable Instance 0 allowed (RS022) in the setting screen displayed.

3) Setting command remote selection

Activate command remote selection [# 87015] for pseudo input signals.

If this setting is not implemented, the status of the robot will not be displayed correctly.

*NOTE

The address of the pseudo input signal depends on the robot controller model.

DX100, DX200, FS100 . . #82015

YRC1000, YRC1000micro . . #87015

4) Setting batch backup

Select [SETUP] - [AUTO BACKUP SET], and then set "RAMDISK" to the device.

Without this setting, the CMOS backup function of the sample project file cannot be used.

If RAMDISK cannot be selected, check the setting of parameter S2C680.

5.6.3. Indirect device settings

Indirect device settings were used to draw 4 device connection samples for these screen samples.

Indirect device settings can be used to easily connect 5 or more devices. If "Add Indirect Device" and "Update Indirect Device Settings" are selected, and a device designation address is configured onscreen, it will enable support for 5 or more devices.

Refer to Chapter 7.5 of the GP-Pro EX manual.





6. Screen configuration

6.1. Screen types

These sample parts provide the following 8 types of function screens.

Table 6-1 Screen types

Screen Title	Screen Image	Function
Robot Controller List		<ul style="list-style-type: none"> Displays the status of each controller Transitions to individual monitors
Panel Setting List Screen 1 to 4		<ul style="list-style-type: none"> Setting List Settings to change languages Robot type settings Settings for number of controller connections etc.
I/O Monitor		<ul style="list-style-type: none"> IO status display and settings
JOB Monitor		<ul style="list-style-type: none"> Displays the currently selected job <ul style="list-style-type: none"> File name Executing line, step, override Program details Displays registered jobs <ul style="list-style-type: none"> Selects jobs File name Program details

Screen Title	Screen Image	Function
Robot Status		<ul style="list-style-type: none"> • Displays Robot Condition • Displays Servo Monitor • Displays Tool Information • Displays System Information
Alarm Monitor		<ul style="list-style-type: none"> • Displays current alarm • Displays Alarm History • Displays Alarm Detail
Variable Monitor Register Monitor		<ul style="list-style-type: none"> • Variable List • Register List
Maintenance		<ul style="list-style-type: none"> • Grease UP, Battery Change-Out management • Displays power in time • CMOS Backup

6.2. Screen transitions




Figure 6-1 Screen transitions




Figure 6-2 Screen transitions 2

7. Detailed screen explanation

The explanation is based on the GP4000 Series. When using the LT4000 Series, please use USB memory instead of a SD card.

7.1. Common

7.1.1. Screen overview

This content is displayed on all screens, with the exception of the Startup screen, PANEL Setting screen, Robot Controller List screen.

Displays the number and status of a robot controller. Displays a menu.

7.1.2. Screen image (Common)




Figure 7-1 Screen image

Table 7-1 Description of parts

No.	Item	Part	Description
1	Robot number	Data display device	Displays the number of the currently selected robot controller. Allows input of the robot controller number.
2	Mode	Lamp	Displays the mode of the robot controller. (REMOTE/TEACH/PLAY)
3	Operating Mode	Lamp	Displays the operating mode of the robot controller. (STEP/CYCLE/CONSECUTIVE)
4	START	Lamp	Displays the operational status for the robot.
5	HOLD	Lamp	Displays the HOLD status for the robot.
6	SERVO ON	Lamp	Displays the SERVO ON status for the robot.
7	ALARM	Switch and lamp	Displays the error status for the robot. Touching here will switch to the Alarm Monitor screen.

No.	Item	Part	Description
8	MENU	Switch	Touching here once will open the MENU bar, and touching here again will close the MENU bar.
9	I/O	Switch	Opens the I/O Monitor screen submenu.*1
10	JOB	Switch	Opens the JOB Monitor screen submenu.*1
11	Robot	Switch	Opens the Robot Status screen submenu.*1
12	Alarm	Switch	Switches to the Alarm Monitor screen.
13	Maintenance	Switch	Opens the Maintenance screen submenu.*1
14	Variable Monitor Register Monitor	Switch	Opens the variable/register screen submenu.* 1
15	Robot	Switch	Returns to the Robot Controller List screen.

*1: Submenus will automatically close 3 seconds after they are displayed.

7.1.3. Screen image (Error message)




Figure 7-2 Screen image

Table 7-2 Description of parts

No.	Error Message	Content
1	Use REMOTE (programming pendant)	Since the programming pendant is in REMOTE mode, job programs, general input/output comments, and tool information cannot be loaded.
2	File load error	There was an error response from the robot controller when loading a job program, general input/output comments, or tool information.
3	Operation error (programming pendant)	There is an error on the programming pendant.
4	JOB program reading range over	JOB program exceeded the reading range (100 lines).

7.1.4. D Script

- ID00005 Initial setting [Screen display completion falling bit]

Displays a menu bar.

7.2. Startup screen (B0001)

7.2.1. Screen overview

This is the screen sample startup screen.

7.2.2. Screen image



Figure 7-3 Screen image

Table 7-3 Description of parts

No.	Item	Part	Description
1	Draw version	Data display device	Displays the version of the draw data.
2	Switch screens	Switch	Switches screens to the Robot Controller List screen.

7.3. Robot Controller List screen (B8600)

7.3.1. Screen overview

Displays the status of a robot controller.

Switches screens to each of the separate robot controller monitor screens.

7.3.2. Screen image



Figure 7-4 Screen image

Table 7-4 Description of parts

No.	Part		Description
1	Robot 1	–	Content displayed is the currently running job program name and status for Robot 1 (refer to the shared screen).
1	Switch screens	Hidden switch	Switches to the screen for robot controller 1.
2	Robot 2	–	Content displayed is the currently running job program name and status for Robot 2 (refer to the shared screen).
2	Switch screens	Hidden switch	Switches to the screen for robot controller 2.
3	Robot 3	–	Content displayed is the currently running job program name and status for Robot 3 (refer to the shared screen).
3	Switch screens	Hidden switch	Switches to the screen for robot controller 3.
4	Robot 4	–	Content displayed is the currently running job program name and status for Robot 4 (refer to the shared screen).
4	Switch screens	Hidden switch	Switches to the screen for robot controller 4.

No.	Part		Description
5	Robot controller usage settings	Switch	Sets the robot controllers listed on the Robot Controller List screen to be used or not used. If a robot controller is not used, it will not communicate. ○: Used Blank: Not used
6	Switch screens	Switch	Switches to the PANEL Setting screen.
7	Switch screens	Switch	Switches to the Panel Setting List screen.

NOTE: For robot controllers 1 through 4, the number of devices set on the PANEL setting screen is displayed.

7.3.3. D Script

- ID0000 Robot connection setting [when updating the robot connection setting]

Configures the robot controller to connect to, in accordance with the set number of controller connections.

- ID00001 Select robot [When the select robot button]

Selected settings. → Current settings.

7.4. Panel Setting List (B8603)

7.4.1. Screen overview

Settings are displayed on a single screen.

7.4.2. Screen image




Figure 7-5 Screen image

Table 7-5 Description of parts

No.	Item	Part	Description
1	RC Connect Setting	Switch	Select the number of robot controllers to connect to. Setting screen is displayed by selecting
2	Robot Type Setting	Switch	Display Robot controller type Setting screen is displayed by selecting
3	Robot Use Setting	Switch	Display current status for Robot Use Setting Setting screen is displayed by selecting
4	BASE	Switch	Display current status for Robot Struct BASE Setting screen is displayed by selecting
5	STATION	Switch	Display current status for Robot Struct STATION Setting screen is displayed by selecting

No.	Item	Part	Description	
6	Language Setting	Switch	Display current status Setting screen is displayed by selecting	
7	CMOS Backup	Switch	Display current status Setting screen is displayed by selecting	
8	SD Card	Switch	Display current status Setting screen is displayed by selecting	
9	FILE READ	Switch	Display current status Setting screen is displayed by selecting	
10	JOB SCROLL	Switch	Display current status Setting screen is displayed by selecting	
11	Instance0/Allow(RS022)	Switch	Display current status Setting screen is displayed by selecting	
12	Alarm/Details View	Switch	Display current status Setting screen is displayed by selecting	
13	PANEL Setting	Switch	Change to the PANEL Setting screen.	
14	Switch screens	Switch	Returns to the Robot Controller List screen.	

7.4.3. D Script

- ID0000 Robot connection setting [when updating the robot connection setting]

Configures the robot controller to connect to, in accordance with the set number of controller connections.

7.5. PANEL Setting screen (B8604 to B8607)

7.5.1. Screen overview

Screen settings are performed on this screen.

7.5.2. Screen image




Figure 7-6 Screen image 1




Figure 7-7 Screen image 2




Figure 7-8 Screen image 3




Figure 7-9 Screen image 4

Table 7-6 Description of parts

No.	Item	Part	Description
1	RC Connect Setting	Data display device	Selects the number of robot controllers to connect to. The set number of devices is displayed on the Robot Controller List screen. Setting range: 1 – 4 Default: 1
2	Robot Type Setting	Switch	Selects Robot type Select YRC1000 also for YRC1000micro.
3	Dual-arm	Switch	ON if the robot is dual-arm. OFF: - (default) ON: Dual-arm robot

No.	Item	Part	Description
4	Robot Use Setting	Selector switch	Performs settings in accordance with the type of robot to connect to. General (default) / Arc Welding / Spot Welding / Handling
5	Robot Struct BASE	Selector switch	Set when using BASE. Default: No
6	Robot Struct STATION	Selector switch	Set when using STATION. Default: No
7	Language Setting	Selector switch	Switches between Japanese, English, and Chinese languages.
8	CMOS Backup	Selector switch	Enables or disables CMOS backup. Disable: CMOS backup disabled Enable: CMOS backup enabled (default value)
9	SD card setting	Switch	Sets whether or not SD cards are to be used. OFF: Do not use SD cards (default) ON: Use SD cards NOTE: If OFF, the Alarm Details window will not display. Also, CMOS Backup is disabled.
10	File Read Invalid	Selector switch	Performs settings that disable loading of job programs, general input/output comments, and tool information. OFF: Enable file loading (default) ON: Disable file loading
11	JOB SCROLL	Selector switch	Sets whether or not to synchronize screens to the actual job, in the event everything cannot be displayed on one JOB Monitor screen. OFF: Do not synchronize (default) ON: Synchronize
12	Alarm detail	Selector switch	Disable or Enable for Alarm detail screen Disable: (default value) Enable:
13	Instance 0 Specified permit	Selector switch	Allow instance 0 or Not allow instance 0 Settings of the RS022 parameter in the Ethernet high-speed servers. Allow (1) : Allow instance 0 (default value) Not Allow (0) : Not allow instance 0
14	Switch screens	Switch	Returns to the Robot Controller List screen.
15	Switch screens	Switch	Returns to the previous page
16	Switch screens	Switch	Go to the next page

7.5.3. D Script

- ID0000 Robot connection setting [when updating the robot connection setting]

Configures the robot controller to connect to, in accordance with the set number of controller connections

7.6. I/O Monitor screens (B8611 to B8614)

7.6.1. Screen overview

Monitors the controller I/O status.

7.6.2. Screen image




Figure 7-10 Screen image

Table 7-7 Description of parts

No.	Item	Part	Description
1	Refresh	Switch	Read I/O comment.
2	I/O number	Data display device	Displays the current I/O status. NOTE: 8 I/O points will display on 1 screen.
3	I/O status display	Lamp	Shows the I/O number being displayed.
4	Comment	Character string display	Displays the character string that corresponds to the I/O number. General Input and Output comments are loaded directly via the robot controller. Specific Inputs and Outputs are displayed out to registered content on the text screen.

No.	Item	Part	Description
5	Scroll	Switch	<p>Switches the displayed I/O screen page.</p> <p>TOP: Returns to the top screen.</p> <p>△ : Switches to the previous screen.</p> <p>▽ : Switches to the next page.</p> <p>JUMP : Switches to the entered number</p> <p>*In order to read up to 8 units, the number specified must not be at the beginning.</p>
6	JUMP	Switch	<p>Display keyboard type you want to switch to I/O</p> <p>*increments of 8 bits</p> <p>(Example): 1,9,17,25....</p>

7.6.3. D Script

- ID00000 File load setting [While comment file load flag is ON]

The comment file (IONAME.DAT) is loaded via the robot controller.

- ID00001 File load setting [While comment file load flag is ON]

The comment file (IONAME.DAT) is loaded via the robot controller.

- ID00002 I/O data storage [Always run]

Loads I/O number and I/O data.

- ID00003 Page UP [While next page PB is depressed]

Switches to the next page of the currently displayed job program.

- ID00004 Page DOWN [While previous page PB is depressed]

Switches to the previous page of the currently displayed job program.

- ID00005 JUMP Dataset [While jump PB is depressed]

Contains the first number in the display.

- ID00006 JUMP Execute [When the value is set]

Change display starting with set number.

7.6.4. Text registry (8301 – 8390)

The text registry is used in order to display Specific I/O comments.

The content of this registry can be changed. (The line numbers correspond to display variables)

Table 7-8 Description of parts

	YRC1000 / YRC1000micro
Specific Input (shared)	8301 ~ 8302
(general)	8311 ~ 8314
(arc)	8315 ~ 8318
(spot)	8319 ~ 8322
(handling)	8323 ~ 8326
(Reserve)	8327 ~ 8330

	YRC1000 / YRC1000micro
Specific Output (shared)	8341 ~ 8343
(general)	8351 ~ 8358
(arc)	8359 ~ 8366
(spot)	8367 ~ 8374
(handling)	8375 ~ 8382
(Reserve)	8383 ~ 8390

7.7. JOB Monitor screen (B8620)

7.7.1. Screen overview

Monitors the currently executing job on the robot controller.

7.7.2. Screen image




Figure 7-11 Screen image

Table 7-9 Description of parts

No.	Item	Part	Description
1	JOB NAME	–	Displays the status of currently running jobs. - Names of the currently executing job programs - Currently executing LINE No. - Currently executing STEP No. - OVERRIDE
2	JOB READ	Switch	Loads a job program.
3	Job sync setting	Selector switch	Sets whether or not to synchronize, in accordance with the actual job. Async. : Do not synchronize (default) Sync. : Synchronize

No.	Item	Part	Description
4	JOB Monitor	Character string display	<ul style="list-style-type: none"> - Displays the currently executing job programs. - The executing line is highlighted in blue. - Operations will differ depending upon the job sync settings. <ol style="list-style-type: none"> 1) If job sync setting is set to "Sync.": The job program will automatically load, and will scroll in accordance with the operation. 2) If job sync setting is set to "Async.": Press the JOB READ switch to load a job program, and manually scroll.
5	Scroll	Switch	<p>Displays if the job sync setting is "Async.". Operates if the line before and after the currently displayed job program is displaying.</p> <p>TOP: Returns to the top screen. Δ : Displays the previous page. ∇ : Displays the next page.</p>

NOTES:

- ◆ If the sync setting is ON, the program will display the job lines of up to 100 job programs, specifying the line 100 or higher, a warning will be displayed at the bottom, and the display area will be blank.
- ◆ If the file load settings are OFF, the job program will not display.

7.7.3. D Script

- ID00000 Initial setting [Screen display completion falling bit]
Initializes the display.
- ID00001 JOB_Read [While job load flag is ON]
Loads a program job file (*.JBI).
- ID00002 Job display [Always run]
Displays the executing line, and the loaded job program.
- ID00003 Job comparison [Always run]
Compares the name of the currently displayed job program with the currently executing job program. If the names are different, it will set a job program load flag.
- ID00004 Page UP [While next page PB is depressed]
Switches to the next page of the currently displayed job program.
- ID00005 Page DOWN [While previous page PB is depressed]
Switches to the previous page of the currently displayed job program.
- ID00006 Page Top [While TOP PB is depressed]
Change display starting with first line of the JOB program.

- ID00007 Synchronize Setting [When the Job sync setting is changed]
 - Refresh display JOB program.

- ID00008 Reload JOB program [While JOB READ PB is depressed]
 - Reload JOB program

7.8. JOB List screen (B8622)

7.8.1. Screen overview

Displays a list of job programs and programs from among the robot controllers.

7.8.2. Screen image




Figure7-12 Screen image

Table 7-10 Description of parts

No.	Item	Part	Description
1	JOB NAME	Character string display	Displays the selected job program name.
2	JOB LIST	Switch	Displays a list of job programs being stored in the robot controller. For further details, refer to 7.8.3. "Job program selection window".
3	Job program display		Unrelated to the currently executing job program; displays the selected job program.
4	Scroll	Switch	Operates when switching the currently displayed job program page. TOP: Returns to the top screen. △ : Displays the previous page. ▽ : Displays the next page.

NOTE:

- ◆ If the file load settings are OFF, the job program list and the job program will not display.

7.8.3. Job program selection window



Figure 7-13 Screen Image

Table 7-11 Description of parts

No.	Item	Part	Description
1	JOB NAME	Character string display	Displays the selected job program name from a list.
2	Job program list	Character string display	Displays the folder name stored in the selected program. Programs can be selected by clicking on program names.
2	Job program name storage	Hidden switch	Touching a job program name displayed in the list will store that job program name in a job name.
3	Scroll	Switch	Operates when the job program list is scrolling. TOP: Returns to the top screen. △ : Displays the previous page. ▽ : Displays the next page.
4	SELECT	Switch	Reads out the selected job program. The selected job is not reflected in the robot controller; only the job program is displayed.

7.8.4. D Script

Job List Screen

- ID00000 Initial setting [Screen display completion falling bit]
 - Initializes the display.
- ID00001 JOB_Read [While job load flag is ON]
 - Loads a program job file (*.JBI).
- ID00002 Page UP [While next page PB is depressed]
 - Switches to the next page of the currently displayed job program.
- ID00003 Page DOWN [While previous page PB is depressed]
 - Switches to the previous page of the currently displayed job program.

- ID00004 Job display [Always run]
Displays the loaded job program.
- ID00005 Page TOP [While TOP PB is depressed]
Change display starting with first line of the JOB program.

Job program selection window

- ID00000 File name storage [When file selection is complete]
Stores a job program name.
- ID00001 File selection [When job program list is selected]
Selects a file name.
- ID00002 JOBLIST load (OPEN) [When job program selection window is OPEN]
Loads a job program list.
- ID00003 JOBLIST load (execute) [When the job program list load flag is ON]
Loads a job program list.
- ID00004 Page UP [While next page PB is depressed]
Switches to the next page of the currently displayed job program list.
- ID00005 Page DOWN [While previous page PB is depressed]
Switches to the previous page of the currently displayed job program list.

7.9. Robot Status monitor screens (B8624 to B8630)

7.9.1. Screen overview

Monitors robot positional data.

Switches between coordinate data and pulse data for monitoring.

7.9.2. Screen image




Figure 7-14 Screen image (coordinate data)




Figure 7-15 Screen image (Pulse data)

Table 7-12 Description of parts

No.	Item	Part	Description
1	Switch displays	Switch	<p>Switches the Robot Condition information being displayed.</p> <ul style="list-style-type: none"> - Robot (Coordinate data) - Robot (Pulse data) - BASE (Pulse data) - STATION (Pulse data) <p>NOTE: BASE and STATION are robot structures on the PANEL Setting screen. If BASE and STATION are set, a switch will be displayed.</p>
2	Axis information	Character string display	Displays the name of the robot coordinates.
3	Robot Condition information	Data display device	Displays robot coordinate data, Configuration, and Tool Information.
4	Axis information	Character string display	Displays the robot axis name.
5	Robot Condition information	Data display device	Displays the pulse data for each axis.

NOTES:

- ◆ When selecting a dual-arm robot, information for both robot 1 and 2 will be displayed.
- ◆ If axis doesn't exist (axis information: blank current position: 0)
- ◆ This project file supports only one axis of "BASE" and "STATION".

7.9.3. D Script

None

7.10. Servo Monitor screen (B8632 to B8636)

7.10.1. Screen overview

Monitors the servo information for each axis.

7.10.2. Screen image




Figure 7-16 Screen image

Table 7-13 Description of parts

No.	Item	Part	Description
1	Switch displays	Switch	<p>Switches the Robot Condition information being displayed.</p> <ul style="list-style-type: none">- Robot (Pulse data)- BASE (Pulse data)- STATION (Pulse data) <p>NOTE: BASE and STATION are robot structures on the PANEL Setting screen. If BASE and STATION are set, a switch will be displayed.</p>
2	Axis information	Character string display	Displays the robot axis name.
3	Location Deviation	Data display device	Displays the positional deviation for each axis.
4	Torque	Data display device	Displays the torque value for each axis.

NOTES:

- ◆ When selecting a dual-arm robot, information for both robot 1 and 2 will be displayed.
- ◆ If axis doesn't exist (axis information: blank current position: 0)
- ◆ This project file supports only one axis of "BASE" and "STATION".

7.10.3. D Script

None

7.11. Tool Information screen (B8638)

7.11.1. Screen overview

Monitors tool information.

7.11.2. Screen image




Figure 7-17 Screen image

Table 7-14 Description of parts

No.	Item	Part	Description
1	TOOL No.	Data display device	Inputs a TOOL No. to be displayed. TOOL No. (0 – 63)
2	Tool Information	-	Displays the Tool Information for the designated TOOL No. - TOOL NAME - Tool positional information

NOTE: If the file load settings are OFF, the Tool Information will not display.

7.11.3. D Script

- ID00000 File load setting [When tool number input is complete]

Tool Information is loaded via the TOOL.CND file.

7.12. System Monitor screen (B8640)

7.12.1. Screen overview

Displays the system information of the robot controller.

7.12.2. Screen image




Figure 7-18 Screen image

Table 7-15 Description of parts

No.	Item	Part	Description
1	System Monitor	Character string display	<p>Displays the System Information of the robot controller.</p> <ul style="list-style-type: none">- SYSTEM SOFTWARE Ver.- MACHINE TYPE- PARAMETER No.- USE

7.13. Alarm Monitor screen (B8642)

7.13.1. Screen overview

Displays the currently generated error. (Maximum of 4 errors)

7.13.2. Screen image




Figure 7-19 Screen image

Table 7-16 Description of parts

No.	Item	Part	Description
1	Emergency Stop status	Lamp	<p>Displays the Emergency Stop input status of the robot controller.</p> <ul style="list-style-type: none"> - Emergency Stop (P.P.) - Emergency Stop (PANEL) - Emergency Stop (Door)
2	Alarm display	Character string display	<p>Displays the currently generated alarm. A maximum of 4 alarms can be displayed at the same time.</p> <ul style="list-style-type: none"> - Date - Code - SUB Code - Alarm Message <p>*Data format displays only decimal (DEC).</p>
2	Alarm details	Hidden switch	<p>Displays an Alarm Details window when the generated alarm is touched. NOTE: Valid if the SD card setting is ON.</p>
3	ALARM RESET	Switch	Clears the currently generated alarm.
4	Switch screens	Switch	Switches to the Alarm History screen.
5	Sub Code Detail	Switch	Displays the sub code detail message

7.13.3. Alarm Details window (B8646, B8647)




Figure 7-20 Screen Image (Detail screen1)




Figure 7-21 Description of parts (Detail screen 2)

Table 7-17 Description of parts

No.	Item	Part	Description
1	Alarm information	–	Displays information about the selected alarm. For further details, refer to 6.13. "Alarm Monitor"
2	Alarm details	Character string display	Displays detailed information about the selected alarm. - Meaning - Cause - Measure
3	Change screen	Switch	Display the Detail screen 2
4	Change screen	Switch	Return to the Detail screen 1

NOTES:

The Alarm Details display loads information from a SD card.

When using the Alarm Details display, be sure to pre-set the following items, in order:

- A) Download the Alarm data file from our website.
- B) Extract the compressed file.
- C) Save the alarm data file to a SD card
- D) Set the SD card to a display device
- E) Set the SD card setting to ON in the PANEL Setting screen

7.13.4. Alarm Message window




Figure 7-22 Screen Image

Table 7-18 Description of parts

No.	Item	Part	Description
1	Alarm Additional Information	-	Display Alarm information - Alarm Message - Additional information - Sub Code Detail Message
2	Change screen	Switch	Closes the window

7.13.5. D Script

Alarm Monitor screen

- ID00003 Alarm Storage [Always run]

Store internal memory when the alarm is occurring.

- ID00000 Alarm Detail window available [Always run]

Check the details window to view or not view.

- ID00001 Alarm information reload [When alarm run]

Read the selected alarm information

- ID00002 Initial setting [When switching displays]
 - Define Alarm sub code detail button for initial setting
- ID00004 Detail button [When the Detail button is depressed]
 - Change sub code detail message display.
- ID00005 Interlock Control [Always run]
 - Control the enable / disable button detail view.
 - If an alarm isn't listed, details won't be displayed even when touched

Alarm Details window

- ID00000 FILE READ(Cause) [Alarm Detail (Hidden SW) is depressed]
 - Read alarm detail from CSV-file in SD card.
- ID00001 cause(NEXT) [While NEXT PB is depressed]
 - Display next cause (MAX 5pages)
- ID00002 FILE READ [When job program selection window is OPEN]
 - Read alarm detail from CSV-file in SD card. (language difference)
- ID00003 cause(BACK) [While BACK PB is depressed]
 - Display previous cause.
- ID00004 FILE_READ_RESET [Timer every 1 second]
 - flag clear
- ID00005 Contents(DW) [While DOWN(content) PB is depressed]
 - Description of contents scroll down (MAX 10lines)
- ID00006 Contents(UP) [While UP(content) page PB is depressed]
 - Description of contents scroll up
- ID00007 Meaning(DW) [While DOWN(Meaning) PB is depressed]
 - Description of Meaning scroll down (MAX 10lines)
- ID00008 Meaning (UP) [While UP(Meaning) PB is depressed]
 - Description of Meaning scroll up
- ID00009 Measure(DW) [While DOWN(Measure) PB is depressed]
 - Description of Remedy scroll down (MAX 10lines)
- ID00010 Measure (UP) [While UP(Measure) PB is depressed]
 - Description of Remedy scroll up
- ID00012 Alarm Message [When the Alarm Details window is OPEN]
 - Store alarm message number

7.14. Alarm History screen (B8644)

7.14.1. Screen overview

Displays the past error history. (Displays a maximum of 100 errors)

7.14.2. Screen image




Figure7-23 Screen image

Table 7-19 Description of parts

No.	Item	Part	Description
1	Switch displays	Switch	Switches the Alarm History items to be displayed. - Major Alarm - Minor Alarm - System Alarm - User Alarm - OFFLINE Alarm
2	Alarm History		Displays the Alarm History stored in a robot controller. (Each item stores 100 histories) - Date & Time - Code - SUB Code - Alarm Message <small>*Data format displays only decimal (DEC).</small>
2	Switch screen	Hidden switch	Display alarm detail message window Refer to 6-13-4
3	Scroll	Switch	Operates when the displayed alarm history scrolls. TOP: Returns to the top screen. △ : Displays the previous page. ▽ : Displays the next page.

7.14.3. D Script

- ID00000 Initial setting [Screen display completion falling bit]
 - Initializes the display.
- ID00001 Alarm number storage [Always run]
 - Stores a number used for display.
- ID00002 Page UP [While next page PB is depressed]
 - Switches to the next page of the currently displayed Alarm History.
- ID00003 Page DOWN [While previous page PB is depressed]
 - Switches to the previous page of the currently displayed Alarm History.
- ID00004 Alarm storage [When switching displays]
 - Immediately load the alarm history data.
- ID00005 Detail button [When the Detail button is depressed]
 - Change sub code detail message display.
- ID00006 TOP button [When the TOP button is depressed]
 - Change displayed Alarm History to TOP page.

7.15. Alarm Code Detail window (B8645)

7.15.1. Screen overview

Enters Alarm code, Subcode and displays Alarm Detail screen.

7.15.2. Screen image




Figure 7-24 Screen image

Table 7-20 Description of parts

No.	Item	Part	Description
1	Alarm code	Data display device	Enter the necessary alarm code to display required details.

No.	Item	Part	Description
2	Subcode	Data display device	Enter the necessary Subcode to display required details.
3	Detail View	Switch	Go to the alarm detail screen The alarm detail screen displays the code detail which was set up "1" and "2".

7.15.3. D Script

None

7.16. Predictive Maintenance screen (B8650 to B8652)

7.16.1. Screen overview

Displays Grease up and Battery Change-Out for maintenance.

7.16.2. Screen image

7.16.2.1. Predictive Maintenance screen (Grease up)




Figure 7-25 Screen image (Grease up)

Table 7-21 Description of parts

No.	Item	Part	Description
1	Switch screens	Switch	Switches to the selected screen. - Battery Change-Out - Robot Operating Hours
1	Predictive Maintenance item 1	Lamp	Displays the execution state of the predictive maintenance (Grease UP) While the green light is active
3	Robot Condition	Data display	Displays the elapsed time since the Predictive

No.	Item	Part	Description
		device	Maintenance (Grease UP) was executed. Displays in time units.
4	Graph display	Graph	Displays the elapsed time as a bar graph (in yellow). Displays in red if the warning range on the Advanced Setting screen is exceeded.
5	Last Installment	Data display device	Displays the date of the Last Installment.
6	Installment	Switch	Press the Installment switch for 2 or more seconds when performing Grease UP. The time the switch was pressed during the last installment will be stored, and the Robot Condition will be cleared. NOTE: When initially brought into use, there will be no set starting time, so the Installment switch should be pressed first. NOTE: If Grease UP is ON on the Advanced Setting screen, this switch will be enabled.

7.16.2.2. Predictive Maintenance screen (Battery Change-Out)




Figure 7-26 Screen image (Battery Change-Out)

Table 7-22 Description of parts

No.	Item	Part	Description
1	Switch screens	Switch	Switches to the selected screen. - Battery Change-Out - Robot Operating Hours
1	Predictive	Lamp	Displays the execution state of the predictive

No.	Item	Part	Description
	Maintenance item 1		maintenance (Grease UP) While the green light is active
3	Robot Condition	Data display device	Displays the elapsed time since the Predictive Maintenance (Grease UP) was executed. Displays in time units.
4	Graph display	Graph	Displays the elapsed time as a bar graph (in yellow). Displays in red if the warning range on the Advanced Setting screen is exceeded.
5	Last Installment	Data display device	Displays the date of the Last Installment.
6	Installment	Switch	Press the Installment switch for 2 or more seconds when performing Grease UP. The time the switch was pressed during the last installment will be stored, and the Robot Condition will be cleared. NOTE: When initially brought into use, there will be no set starting time, so the Installment switch should be pressed first. NOTE: If Grease UP is ON on the Advanced Setting screen, this switch will be enabled.

7.16.2.3. Predictive Maintenance scree (Robot Operating Hours)




Figure 7-27 Screen image (Robot Operating Hours)

Table 7-23 Description of parts

No.	Item	Part	Description
1	Switch screens	Switch	Switches to the selected screen. - Battery Change-Out - Robot Operating Hours

No.	Item	Part	Description
2	Robot Operating Hours	Data display device	<p>Displays the Robot Operating Hours. (hh:mm:ss)</p> <ul style="list-style-type: none"> - Time of Control Power In - Time of Servo Power In - Time of Play Back - Running Time - Working Hours

7.16.3. D Script

- ID00000 Compute elapsed time [Always run]

Computes the time elapsed from the Last Installment to the current time.

- ID00001 Working Installment 1 [When the working Installment switch is depressed]

Stores the current date in the Last Installment, and clears the elapsed time.

- ID00002 Working Installment 2 [When the working Installment switch is depressed]

Stores the current date in the Last Installment, and clears the elapsed time.

- ID00003 Mainte1_Lamp [Always run]

Copy the bit status of mainte1

- ID00004 Mainte2_Lamp [Always run]

Copy the bit status of mainte2

7.17. Advanced Setting screen (B8655 to B8656)

7.17.1. Screen overview

Performs settings to manage maintenance information (Predictive Maintenance).

7.17.2. Screen image

7.17.2.1. Advanced Setting screen (Grease UP)




Figure 7-28 Screen image (Grease UP)

Table 7-24 Description of parts

No.	Item	Part	Description
1	Switch screens	Switch	Switches to the selected screen. The selected screen will display in yellow. - Battery Change-Out
2	Advanced Setting item 1	Selector switch	Performs Advanced Setting (Grease UP). OFF: Do not perform Advanced Setting (Grease UP) ON: Perform Advanced Setting (Grease UP) NOTE: If OFF, clear the Last Installment date
3	Max Value	Data display device	Sets the Max Value of the elapsed time for Advanced Setting (Grease UP). Sets in time units.
4	Min Value	Data display device	Sets the Min Value of the elapsed time for Advanced Setting (Grease UP). Sets in time units. (Normally 0)
5	Alarm Area	Data display device	Sets an alarm time for the elapsed time of the Advanced Setting (Grease UP). Sets in time units.

7.17.2.2. Advanced Setting screen (Battery Change-Out)




Figure 7-29 Screen image (Battery Change-Out)

Table 7-25 Description of parts

No.	Item	Part	Description
1	Switch screens	Switch	Switches to the selected screen. The selected screen will display in yellow. - Battery Change-Out
2	Advanced Setting item 2	Selector switch	Performs Advanced Setting (Battery Change-Out). OFF: Do not perform Advanced Setting (Battery Change-Out) ON: Perform Advanced Setting (Battery Change-Out) NOTE: If OFF, clear the Last Installment date
3	Max Value	Data display device	Sets the Max Value of the elapsed time for Advanced Setting (Battery Change-Out). Sets in time units.
4	Min Value	Data display device	Sets the Min Value of the elapsed time for Advanced Setting (Battery Change-Out). Sets in time units. (Normally 0)
5	Alarm Area	Data display device	Sets an alarm time for the elapsed time of the Advanced Setting (Battery Change-Out). Sets in time units.

7.17.3. D Script

- ID00000 Mainte1_Set [When Advanced Setting Selector switch 1 is ON selected]

Set the bit status of mainte1

- ID00001 Mainte1_Lamp [Always run]

Copy the bit status of mainte1

- ID00002 Mainte2_Set [When Advanced Setting item 2 is ON selected]

- Set the bit status of mainte2
- ID00003 Mainte2_Lamp [Always run]
 - Copy the bit status of mainte2
- ID00004 Mainte1_Reset [Always run]
 - Clear the elapsed time of mainte1
- ID00005 Mainte1_Rese2 [Always run]
 - Clear the elapsed time of mainte2

7.18. CMOS Backup screen (B8657)

7.18.1. Screen overview

This screen saves the CMOS backup file (CMOSBK.BIN) on the controller to storage.

To load the CMOS backup file on the controller, rename it to CMOS.BIN and copy it to USB memory.

This screen cannot be used when the SD card setting is off.

*This process takes a long time to complete (it may take well over 10 or 20 minutes).

*Please note that the screen cannot be operated when acquiring the file.

7.18.2. Screen image




Figure 7-30 Screen image

Table 7-26 Description of parts

No.	Item	Part	Description
1	Last Saving Time	Character string display	Displays the last backup time. Only a separate time is saved to the file, not the timestamp of the file. Therefore, the time is not displayed correctly when the SD card is replaced.
2	Backup	Switch	Executes the backup.

7.18.3. D Script

- ID00000 Initialization [When switching screens]

Get and display the timestamp of the last saved file.

- ID00001 Start saving [When the Start save button is depressed]

Execute the backup process.

- ID00002 Backup button [When the Backup button is depressed]

Display the confirmation window

7.19. Byte Variable Monitor screen (B8850)

7.19.1. Screen overview

This screen displays a list of byte variables. The variables cannot be written to.

7.19.2. Screen image




Figure 7-31 Screen image

Table 7-27 Description of parts

No.	Item	Part	Description
1	Switch pages	Switch	Changes the starting variable number to 0 or 20.
2	Data display	Data display device	Displays 20 variables worth of data from the starting variable number. The display range is 0 to 99.
3	Switch monitor	Switch	Switch the monitor to display the window.

7.19.3. D Script

- ID00000 Initial setting [When switching screens]

Initialize the display memory.

- ID00001 Store variable data [Always]
Batch get byte variable data and set to the display area.
- ID00002 0-19 [When No. 0-19 is depressed]
Initialize the display memory and switch the starting number.
- ID00003 20-39 [When No. 20-39 is depressed]
Initialize the display memory and switch the starting number.
- ID00004 40-59 [When No. 40-59 is depressed]
Initialize the display memory and switch the starting number.
- ID00005 60-79 [When No. 60-79 is depressed]
Initialize the display memory and switch the starting number.
- ID00006 80-99 [When No. 80-99 is depressed]
Initialize the display memory and switch the starting number.

7.20. Integer Variable Monitor screen (B8851)

7.20.1. Screen overview

This screen displays a list of integer variables. The variables cannot be written to.

7.20.2. Screen image




Figure7-32 Screen image

Table 7-28 Description of parts

No.	Item	Part	Description
1	Switch pages	Switch	Changes the starting variable number to 0 or 20.
2	Data display	Data display device	Displays 20 variables worth of data from the starting variable number. The display range is 0 to 99.

No.	Item	Part	Description
3	Switch monitor	Switch	Switch the monitor to display the window.

7.20.3. D Script

- ID00000 Initial setting [When switching screens]

Initialize the display memory.

- ID00001 Store variable data [Always]

Batch get integer variable data and set to the display area.

- ID00002 0-19 [When No. 0-19 is depressed]

Initialize the display memory and switch the starting number.

- ID00003 20-39 [When No. 20-39 is depressed]

Initialize the display memory and switch the starting number.

- ID00004 40-59 [When No. 40-59 is depressed]

Initialize the display memory and switch the starting number.

- ID00005 60-79 [When No. 60-79 is depressed]

Initialize the display memory and switch the starting number.

- ID00006 80-99 [When No. 80-99 is depressed]

Initialize the display memory and switch the starting number.

7.21. Double Int Variable Monitor screen (B8852)

7.21.1. Screen overview

This screen displays a list of double integer variables. The variables cannot be written to.

7.21.2. Screen image




Figure 7-33 Screen image

Table 7-29 Description of parts

No.	Item	Part	Description
1	Switch pages	Switch	Changes the starting variable number to 0 or 20.
2	Data display	Data display device	Displays 20 variables worth of data from the starting variable number. (10 variables per page.) The display range is 0 to 99.
3	Switch monitor	Switch	Switch the monitor to display the window.
4	Switch page	Switch	If the second page is displayed, the first page will be displayed.
5	Switch page	Switch	If the first page is displayed, the second page will be displayed.

7.21.3. D Script

- ID00000 Initial setting [When switching screens]

Initialize the display memory.

- ID00001 Store variable data [Always]

Batch get Double Int Variable data and set to the display area.

- ID00002 0-19 [When No. 0-19 is depressed]

Initialize the display memory and switch the starting number.

- ID00003 20-39 [When No. 20-39 is depressed]

Initialize the display memory and switch the starting number.

- ID00004 40-59 [When No. 40-59 is depressed]

Initialize the display memory and switch the starting number.

- ID00005 60-79 [When No. 60-79 is depressed]

Initialize the display memory and switch the starting number.

- ID00006 80-99 [When No. 80-99 is depressed]

Initialize the display memory and switch the starting number.

- ID00007 Interlock control [Always]

Control the interlock page switching.

7.22. Real Variable Monitor screen (B8855)

7.22.1. Screen overview

This screen displays a list of real variables. The variables cannot be written to.

7.22.2. Screen image




Figure 7-34 Screen image

Table 7-30 Description of parts

No.	Item	Part	Description
1	Switch pages	Switch	Changes the starting variable number to 0 or 20.
2	Data display	Data display device	Displays 20 variables worth of data from the starting variable number. (10 variables per page.) The display range is 0 to 99.
3	Switch monitor	Switch	Switch the monitor to display the window.
4	Switch page	Switch	If the second page is displayed, the first page will be displayed.
5	Switch page	Switch	If the first page is displayed, the second page will be displayed.

7.22.3. D Script

- ID00000 Initial setting [When switching screens]

Initialize the display memory.

- ID00001 Store variable data [Always]

Batch get Real Variable data and set to the display area.

- ID00002 0-19 [When No. 0-19 is depressed]

Initialize the display memory and switch the starting number.

- ID00003 20-39 [When No. 20-39 is depressed]

Initialize the display memory and switch the starting number.

- ID00004 40-59 [When No. 40-59 is depressed]
Initialize the display memory and switch the starting number.
- ID00005 60-79 [When No. 60-79 is depressed]
Initialize the display memory and switch the starting number.
- ID00006 80-99 [When No. 80-99 is depressed]
Initialize the display memory and switch the starting number.
- ID00007 Interlock control [Always]
Control the interlock page switching.

7.23. String Variable Monitor screen (B8654)

7.23.1. Screen overview

This screen displays a list of string variables. The variables cannot be written to.

7.23.2. Screen image




Figure 7-35 Screen image

Table 7-31 Description of parts

No.	Item	Part	Description
1	Switch pages	Switch	Changes the starting variable number to 0 or 20.
2	Data display	Data display device	Displays 20 variables worth of data from the starting variable number. (10 variables per page.) The display range is 0 to 99.
3	Switch monitor	Switch	Switch the monitor to display the window.
4	Switch page	Switch	If the second page is displayed, the first page will be displayed.
5	Switch page	Switch	If the first page is displayed, the second page will be displayed.

7.23.3. D Script

- ID00000 Initial setting [When switching screens]
 - Initialize the display memory.
- ID00001 Store variable data [Always]
 - Batch get String Variable data and set to the display area.
- ID00002 0-19 [When No. 0-19 is depressed]
 - Initialize the display memory and switch the starting number.
- ID00003 20-39 [When No. 20-39 is depressed]
 - Initialize the display memory and switch the starting number.
- ID00004 40-59 [When No. 40-59 is depressed]
 - Initialize the display memory and switch the starting number.
- ID00005 60-79 [When No. 60-79 is depressed]
 - Initialize the display memory and switch the starting number.
- ID00006 80-99 [When No. 80-99 is depressed]
 - Initialize the display memory and switch the starting number.
- ID00007 Interlock Control [Always]
 - Control the interlock page switching.

7.24. Robot Position Variable Monitor screen (B8656)

7.24.1. Screen overview

This screen displays the robot position variables. The variables cannot be written to.

* When an undefined number is specified, an error message is displayed on the screen.

7.24.2. Screen image




Figure 7-36 Screen image (Robot position)




Figure 7-37 Screen image (Others)

Table 7-32 Description of parts

No.	Item	Part	Description
1	Switch pages	Switch	<p>The single arrow buttons increase or decrease the variable number by one. The double arrow buttons increase or decrease the number by ten.</p> <p>You can also directly enter a number by tapping the number display box.</p> <p>The maximum is 127.</p>
2	Data display	Switch	<p>Displays the data for the variable with the specified number.</p> <ul style="list-style-type: none"> The displayed items differ according to the data type. <p>Data Type:</p> <ul style="list-style-type: none"> Pulse, Base position, Robot position, Tool position, User position <ul style="list-style-type: none"> For Pulse, displays only 1 to 8 position data. The item names for the position data are acquired from the controller and displayed according to the data type. Acquired values are displayed for the Tool No., User No., and Config. (Exp.). Configuration displays characters according to bit values.
3	Switch monitor	Switch	Switch the monitor to display the window.

No.	Item	Part	Description
4	Switch page	Switch	If the first page is displayed, the second page will be displayed.

7.24.3. D Script

- ID00005 Initial setting [When switching screens]

Initialize the display memory.

- ID00000 Instance switching [Move button number is depressed]

Switch the display number.

- ID00002 Store variable data [Always]

Batch get robot position variable data and set to the display area.

7.25. Base Position Variable Monitor screen (B8857)

7.25.1. Screen overview

This screen displays the base position variables. The variables cannot be written to.

If the setting screen displays no base no change will occur.

* When an undefined number is specified, an error message is displayed on the screen.

7.25.2. Screen image




Figure 7-38 Screen image

Table 7-33 Description of parts

No.	Item	Part	Description
1	Switch pages	Switch	The single arrow buttons increase or decrease the variable number by one. The double arrow buttons increase or decrease the number by ten. You can also directly enter a number by tapping the number display box. The maximum is 127.

No.	Item	Part	Description
2	Data display	Switch	<p>Displays the data for the variable with the specified number.</p> <ul style="list-style-type: none"> The displayed items differ according to the data type. <p style="padding-left: 2em;">Data Type:</p> <p style="padding-left: 2em;">Pulse, Base position</p> <ul style="list-style-type: none"> Displays only 1 to 8 position data for both Pulse and Base position. The item names for the position data are acquired from the controller and displayed according to the data type.
3	Switch monitor	Switch	Switch the monitor to display the window.

7.25.3. D Script

- ID00000 Initial setting [When switching screens]

Initialize the display memory.

- ID00001 Store variable data [Always]

Batch get base axis position variable data and set to the display area.

- ID00002 Instance switching [Move button number is depressed]

Switch the display number.

7.26. Station Position Variable Monitor screen (B8858)

7.26.1. Screen overview

This screen displays the station position variables. The variables cannot be written to.

If the setting screen displays no base no change will occur.

* When an undefined number is specified, an error message is displayed on the screen.

7.26.2. Screen image




Figure 7-39 Screen image

Table 7-34 Description of parts

No.	Item	Part	Description
1	Switch pages	Switch	The single arrow buttons increase or decrease the variable number by one. The double arrow buttons increase or decrease the number by ten. You can also directly enter a number by tapping the number display box. The maximum is 127.
2	Data display	Switch	Displays the data for the variable with the specified number. <ul style="list-style-type: none">• The data type is Pulse only.• Displays only the 1 to 8 position data.• The item names for the position data are acquired from the controller and displayed.
3	Switch monitor	Switch	Switch the monitor to display the window.

7.26.3. D Script

- ID00000 Initial setting [When switching screens]

Initialize the display memory.

- ID00001 Store variable data [Always]

Batch get Station Position Variable data and set to the display area.
- ID00002 Instance switching [Move button number is depressed]

Switch the display number.

7.27. Register Monitor screen (B8870)

7.27.1. Screen overview

This screen displays a list of registers. The registers cannot be written to.

7.27.2. Screen image




Figure 7-40 Screen image

Table 7-35 Description of parts

No.	Item	Part	Description
1	Switch pages	Switch	Determine the starting instance using the tabs and buttons.
2	Data display	Switch	Displays 50 instances from the starting instance. The instance range is 1 to 999.

7.27.3. D Script

- ID00000 Initial setting [When switching screens]

Initialize the display memory.
- ID00001 Store variable data [Always]

Batch get register data and set to the display area.
- ID00002 InstanceSW1 [Instance button is depressed]

Switches the initialization of display memory and first instance.
- ID00003 Tab change [Tab button is depressed]

Switch the button instance.

8. Global D script

Executed on all screens when the touch panel is started up.

The items executed are as follows:

- ID00000 Initial setting [Immediately after powering on]
Initializes the robot connection settings.
- ID00001 Close alarm detail window [When switching BASE screens]
Close alarm detail window.
- ID00002 Error reset [When switching BASE and window screens]
Clears error flags.
- ID00004 Communication error [When storing the file load command error code]
Sets the file load error flag to ON.
- ID00003 JOB Error clear [When close JOB Monitor screen]
Clear error flag.

9. Address maps

9.1. List of internally-used addresses

Table 9-1 Address maps

Address	Type	Description
LS955200 to LS955207	bit	Robot controller 1 to 8 SCAN ON/OFF
USR00000 to USR00012	16bit	File load control Address
USR00020 to USR00025	16bit	Current time B8672
USR12000 to USR12399	32bit/ String	Alarm current value acquisition area B8660
USR12500 to USR13486	32bit/ String	Alarm History acquisition B8661
USR13500 to 13558	String	Sub code detail message B8660, B8661
USR13000 to USR13007	16bit	Time data acquisition B8672
USR13870 to USR13879	String	Time stamp display B8672
USR12000 to USR12099	32bit	Variable data acquisition area B8690 to B8693, B8697
USR13500 to USR13652	32bit/ String	Variable screen, variable value display area B8690 to B8693, B8697
USR13800 to USR13849	16bit	Variable screen, variable number display area B8690 to B8693, B8697
USR12000 to USR12099	32bit	Axis position variable data acquisition and display area B8694 to B8696
USR13500 to USR13505	16bit	Axis position variable, Window display use B8694 to B8696
USR14000 to	String	Job program load area (105 lines x 50 characters) 3000 Word
USR17000 to	String	Job program load area (102 lines x 50 characters) 3000 Word
USR2000000 to USR2000007	bit	I/O Lamp NO.1 to NO.8
USR2000200 to USR2000207	bit	I/O Lamp NO.9 to NO.16
USR2000400 to USR2000407	bit	I/O Lamp NO.17 to NO.24

Address	Type	Description
USR2000600 to USR2000607	bit	I/O Lamp NO.25toNO.32
USR20030 to USR20061	16bit	Exclusive input/output Screen Starting line No.1 to No.32
USR20065 to USR20096	bit	I/O number No.1toNo.32
USR20100 to USR20419	String	I/O comment No.1 to No.32 10 Word
USR20450 to USR20481	16bit	Exclusive input/output Screen Text number No.1 to No.32
USR21000 to USR21016	16bit	Job LINE No.
USR21040	16bit	STEP NO. storage
USR21041	16bit	Screen scroll No.
USR2105000 to USR2105014	bit	LINE No. Lamp
USR21060 to	String	Job program name (Storage) 32 characters
USR21100 to	String	Job program name Load area 32 characters
USR21120 to	String	Job program name Word->Byte conversion 32 characters
USR21160 to	String	Job program name Added extension 32 characters
USR21200 to	String	Job program name Load area 32 characters
USR21220 to	String	Job program name Selection 32 characters
USR21300	16bit	Robot Position Window OPEN
USR21301	16bit	Robot Position Window No.
USR21302	16bit	Robot Position Window Xcoordinate
USR21303	16bit	Robot Position Window Ycoordinate
USR21310	16bit	Servo monitor Window OPEN
USR21311	16bit	Servo monitor Window No.
USR21312	16bit	Servo monitor Window Xcoordinate
USR21313	16bit	Servo monitor Window Ycoordinate
USR21320 to USR21335	String (DW)	Axis name 1 to 8
USR21340 to USR21355	String (DW)	Axis name 1to8(Dual-arm)
USR21360	String	External axis (Dual-arm)
USR21361	String	"
USR2138000 to USR2138007	bit	Positional data 1 to 8 Display / not display

Address	Type	Description
USR2138100 to USR2138107	bit	Positional data 1 to 8(Dual-arm) Display / not display
USR21400	16bit	Tool number
USR21410 to	String	Tool name 20 characters
USR21420 to USR21445	32bit	Tool information 1 to 13
USR21500 to	String	Job program name (Executing job) 32 characters
USR21516	32bit	Line No.
USR21530 to	String	Job program name (Master job) 32 characters
USR21600 to	String	Job program name Temporary Storage 32 characters
USR21632 to	String	Job program name Re-storage 32 characters
USR21700 to USR21844	String	Job program List 1 to 8
USR22000 to USR22425	String	Job program 17 line
USR24000 to	String	Alarm detail (Content)
USR25000 to	String	Alarm detail (Meaning)
USR26000 to	String	Alarm detail (Cause)
USR26040 to	String	Alarm detail (Measure)
USR27000	16bit	Robot Controller No.
USR27030	32bit	Alarm code (No.1)
USR27032	32bit	Alarm sub-code (No.1)
USR27034	32bit	Alarm sub-code Type (No.1)
USR27036 to	String	Date generated 16 characters (No.1)
USR27044 to	String	Alarm message 32 characters (No.1)
USR270760	32bit	Alarm code (No.2)
USR27062	32bit	Alarm sub-code (No.2)
USR27064	32bit	Alarm sub-code Type (No.2)
USR27066 to	String	Date generated 16 characters (No.2)
USR27074 to	String	Alarm message 32 characters (No.2)
USR27090	32bit	Alarm code (No.3)
USR27092	32bit	Alarm sub-code (No.3)
USR27094	32bit	Alarm sub-code Type (No.3)
USR27096 to	String	Date generated 16 characters (No.3)
USR27120	String	Alarm message 32 characters (No.3)
USR27122	32bit	Alarm code (No.4)
USR27124	32bit	Alarm sub-code (No.4)
USR27126 to	32bit	Alarm sub-code Type (No.4)

Address	Type	Description
USR27134 to	String	Date generated 16 characters (No.4)
USR27300	32bit	Alarm code
USR27302	32bit	Alarm sub-code
USR27304	32bit	Alarm sub-code Type
USR27306 to	String	Date generated 16 characters
USR27314 to	String	Alarm message 32 characters
USR27350	16bit	Alarm detail (Content) offset
USR27351	16bit	Alarm detail (Meaning) offset
USR27352	16bit	Alarm detail (Measure) offset
USR27400 to USR27429	32bit	Alarm History No.1to15
USR27500 to USR27949	String	No.1toNo.15 Alarm 30 Word
USR28000	32bit	Predictive maintenance1 Current elapsed time
USR28002	32bit	Predictive maintenance1 Elapsed calculation (Year)
USR28004	32bit	Predictive maintenance1 Elapsed calculation (Month)
USR28006	32bit	Predictive maintenance1 Elapsed calculation (Day)
USR28008	32bit	Predictive maintenance1 Elapsed calculation (Hour)
USR28010	32bit	Predictive maintenance1 Elapsed calculation (Day) addition
USR28020	32bit	Predictive maintenance2 Current elapsed time
USR28022	32bit	Predictive maintenance2 Elapsed calculation (Year)
USR28024	32bit	Predictive maintenance2 Elapsed calculation (Month)
USR28026	32bit	Predictive maintenance2 Elapsed calculation (Day)
USR28028	32bit	Predictive maintenance2 Elapsed calculation (Hour)
USR28030	32bit	Predictive maintenance2 Elapsed calculation (Day) addition
USR28900 to USR28909	String	Message send data
USR29000	32bit	Last work installation 1 (Year) No.1
USR29002	32bit	Last work installation 1 (Month) No.1
USR29004	32bit	Last work installation 1 (Day) No.1
USR29006	32bit	Last work installation 1 (Hour) No.1
USR29008	32bit	Last work installation 1 (Minute) No.1
USR29010	32bit	Last work installation 2 (Year) No.1
USR29012	32bit	Last work installation 2 (Month) No.1
USR29014	32bit	Last work installation 2 (Day) No.1
USR29016	32bit	Last work installation 2 (Hour) No.1
USR29018	32bit	Last work installation 2 (Minute) No.1

Address	Type	Description
USR29020 to	32bit	Last work installation 1 No.2
USR29030 to	32bit	Last work installation 2 No.2
USR29040 to	32bit	Last work installation 1 No.3
USR29050 to	32bit	Last work installation 2 No.3
USR29060 to	32bit	Last work installation 1 No.4
USR29070 to	32bit	Last work installation 2 No.4
USR29080 to	32bit	Last work installation 1 No.5
USR29090 to	32bit	Last work installation 2 No.5
USR29100 to	32bit	Last work installation 1 No.6
USR29110 to	32bit	Last work installation 2 No.6
USR29120 to	32bit	Last work installation 1 No.7
USR29130 to	32bit	Last work installation 2 No.7
USR29140 to	32bit	Last work installation 1 No.8
USR29150 to	32bit	Last work installation 2 No.8
USR29320	32bit	Predictive maintenance1 (Upper limit) No.1
USR29322	32bit	Predictive maintenance1 (Lower limit) No.1
USR29324	32bit	Predictive maintenance1 (Alarm range) No.1
USR29326	32bit	Predictive maintenance2 (Upper limit) No.1
USR29328	32bit	Predictive maintenance2 (Lower limit) No.1
USR29330	32bit	Predictive maintenance2 (Alarm range) No.1
USR29332	32bit	Predictive maintenance1 (Upper limit) No.2
USR29334	32bit	Predictive maintenance1 (Lower limit) No.2
USR29336	32bit	Predictive maintenance1 (Alarm range) No.2
USR29338	32bit	Predictive maintenance2 (Upper limit) No.2
USR29340	32bit	Predictive maintenance2 (Lower limit) No.2
USR29342	32bit	Predictive maintenance2 (Alarm range) No.2
USR29344	32bit	Predictive maintenance1 (Upper limit) No.3
USR29346	32bit	Predictive maintenance1 (Lower limit) No.3
USR29348	32bit	Predictive maintenance1 (Alarm range) No.3
USR29350	32bit	Predictive maintenance2 (Upper limit) No.3
USR29352	32bit	Predictive maintenance2 (Lower limit) No.3
USR29354	32bit	Predictive maintenance2 (Alarm range) No.3
USR29356	32bit	Predictive maintenance1 (Upper limit) No.4
USR29358	32bit	Predictive maintenance1 (Lower limit) No.4
USR29360	32bit	Predictive maintenance1 (Alarm range) No.4
USR29362	32bit	Predictive maintenance2 (Upper limit) No.4
USR29364	32bit	Predictive maintenance2 (Lower limit) No.4

Address	Type	Description
USR29366	32bit	Predictive maintenance2 (Alarm range) No.4
USR29368	32bit	Predictive maintenance1 (Upper limit) No.5
USR29370	32bit	Predictive maintenance1 (Lower limit) No.5
USR29372	32bit	Predictive maintenance1 (Alarm range) No.5
USR29374	32bit	Predictive maintenance2 (Upper limit) No.5
USR29376	32bit	Predictive maintenance2 (Lower limit) No.5
USR29378	32bit	Predictive maintenance2 (Alarm range) No.5
USR29380	32bit	Predictive maintenance1 (Upper limit) No.6
USR29382	32bit	Predictive maintenance1 (Lower limit) No.6
USR29384	32bit	Predictive maintenance1 (Alarm range) No.6
USR29386	32bit	Predictive maintenance2 (Upper limit) No.6
USR29388	32bit	Predictive maintenance2 (Lower limit) No.6
USR29390	32bit	Predictive maintenance2 (Alarm range) No.6
USR29392	32bit	Predictive maintenance1 (Upper limit) No.7
USR29394	32bit	Predictive maintenance1 (Lower limit) No.7
USR29396	32bit	Predictive maintenance1 (Alarm range) No.7
USR29398	32bit	Predictive maintenance2 (Upper limit) No.7
USR29400	32bit	Predictive maintenance2 (Lower limit) No.7
USR29402	32bit	Predictive maintenance2 (Alarm range) No.7
USR29404	32bit	Predictive maintenance1 (Upper limit) No.8
USR29406	32bit	Predictive maintenance1 (Lower limit) No.8
USR29408	32bit	Predictive maintenance1 (Alarm range) No.8
USR29410	32bit	Predictive maintenance2 (Upper limit) No.8
USR29412	32bit	Predictive maintenance2 (Lower limit) No.8
USR29414	32bit	Predictive maintenance2 (Alarm range) No.8
USR29990	32bit	Alarm Message Offset
USR29992	16bit	Maintenance Menu Window control address
USR29997	16bit	Variable monitor display window No setting
USR29998	16bit	Transition address for current value screen
USR29999	16bit	Transition address for servo monitor screen

9.2. Symbol variable list

Table 9-2 Variable list

Symbol variable	Data Type	Content	Hol
Act_Check	Bit variable	Work complete check	
Act_Ready	Bit variable	Robot designation	
Alarm_Cause_BACK	Bit variable	Alarm cause previous page	
Alarm_Cause_NEXT	Bit variable	Alarm cause next page	
Alarm_Cause_Read	Bit variable	Alarm cause read	
Alarm_Cont_DW	Bit variable	Alarm content scroll down	
Alarm_Cont_UP	Bit variable	Alarm content scroll up	
ALARM_File_Read	Bit variable	Alarm detail CSVfile read	
ALARM_H_DW	Bit variable	Alarm History previous page	
ALARM_H_Read	Bit variable	Alarm History read	
ALARM_H_UP	Bit variable	Alarm History next page	
Backup_PB	Bit variable	CMOS button	
Backup_Error_End	Bit variable	CMOS backup abend	
Backup_Normal_End	Bit variable	CMOS backup normal end	
Alarm_Detail_Allow	Bit variable	Alarm detail display allow/ deny button	Yes
Alarm_Detail_Btn	Bit variable	Alarm detail button interlock	
ALARM_H_TOP	Bit variable	Alarm history TOP	
Alarm_Mean_DW	Bit variable	Alarm Meaning scroll down	
Alarm_Mean_UP	Bit variable	Alarm Meaning scroll up	
Alarm_Measure_DW	Bit variable	Alarm Measure scroll down	
Alarm_Measure_UP	Bit variable	Alarm Measure scroll up	
ALARM_Open_Enable[0]	Bit variable	Alarm detail window open enable 1	
ALARM_Open_Enable[1]	Bit variable	Alarm detail window open enable 2	
ALARM_Open_Enable[2]	Bit variable	Alarm detail window open enable 3	
ALARM_Open_Enable[3]	Bit variable	Alarm detail window open enable 4	
ALARM_Window	Bit variable	Alarm detail window open	
Allow_Instance0	Bit variable	Instance 0 setting	Yes
CMOS_Backup_Flag	Bit variable	CMOS backup enabled/disabled	Yes
CF_Card_Set	Bit variable	CF card setting	Yes
Confirm_Window	Bit variable	CMOS backup confirmation window	Yes
Confirm_Button	Bit variable	CMOS backup button	Yes
CTL_Enable[0]	Bit variable	Robot Controller Enable Setting No.1	
CTL_Enable[1]	Bit variable	Robot Controller Enable Setting No.2	
CTL_Enable[2]	Bit variable	Robot Controller Enable Setting No.3	
CTL_Enable[3]	Bit variable	Robot Controller Enable Setting No.4	

Symbol variable	Data Type	Content	Hol
CTL_Enable[4]	Bit variable	Robot Controller Enable Setting No.5	
CTL_Enable[5]	Bit variable	Robot Controller Enable Setting No.6	
CTL_Enable[6]	Bit variable	Robot Controller Enable Setting No.7	
CTL_Enable[7]	Bit variable	Robot Controller Enable Setting No.8	
Cycle_Set	Bit variable	Operating mode set	
Dual_ARM_Set	Bit variable	Dual-arm robot setting	
Err_Kind[4]	Bit variable	Bit error message	
FILE_LIST_Dw	Bit variable	File list Next page	
FILE_LIST_Up	Bit variable	File list Previous page	
File_Read_Disable	Bit variable	File read setting	Yes
FILE_Read_NG	Bit variable	File read error	
Instance_Input	Bit variable	Axis position variable screen keypad	
IO_No_DEC	Bit variable	IO NO scroll down	
IO_No_INC	Bit variable	IO NO scroll up	
IO_No_Jump	Bit variable	IO NO JUMP	
IO_No_Set	Bit variable	IO NO SET	
IO_Read_Set_IN	Bit variable	General input comment read	
IO_Read_Set_OUT	Bit variable	General output comment read	
JOB(ACT)_Check	Bit variable	Job program set check	
JOB(ACT)_Set	Bit variable	Executing job program set	
JOB(MAST)_Check	Bit variable	Master job set check	
JOB(MAST)_Set	Bit variable	Master job program set	
JOB_Exec_Check	Bit variable	Job execution set	
JOB_Exec_Set	Bit variable	Job execution	
JOB_Line_OFF	Bit variable	Job execution line OFF	
JOB_MON_PageNo_TOP	Bit variable	Job program monitor TOP page	
JOB_Read	Bit variable	Job program read	Yes
JOB_Read_Over	Bit variable	Job Program Read area over	
JOB_Sync_Set	Bit variable	Sync setting	Yes
JOBFILe_Read	Bit variable	Job program read (list)	
JOBFILe_Set	Bit variable	Selected job file name storage	
JOBLIST_Open	Bit variable	Job list open	
JOBLIST_Open1	Bit variable	Job Setting list open	
JOBLIST_Read	Bit variable	Job list read	
JOBLIST_Select_Set	Bit variable	Job program file select	
JOBMON_DW	Bit variable	Job monitor Previous page	
JOBMON_UP	Bit variable	Job monitor Next page	

Symbol variable	Data Type	Content	Hol
Mainte_Set1	Bit variable	Work implementation 1	
Mainte_Set2	Bit variable	Work implementation 2	
Mainte1_Lamp	Bit variable	Preventative maintenance display 1	
Mainte1_ON[0]	Bit variable	Preventative maintenance display 1 controller 1	Yes
Mainte1_ON[1]	Bit variable	Preventative maintenance display 1 controller 2	Yes
Mainte1_ON[2]	Bit variable	Preventative maintenance display 1 controller 3	Yes
Mainte1_ON[3]	Bit variable	Preventative maintenance display 1 controller 4	Yes
Mainte1_ON[4]	Bit variable	Preventative maintenance display 1 controller 5	Yes
Mainte1_ON[5]	Bit variable	Preventative maintenance display 1 controller 6	Yes
Mainte1_ON[6]	Bit variable	Preventative maintenance display 1 controller 7	Yes
Mainte1_ON[7]	Bit variable	Preventative maintenance display 1 controller 8	Yes
Mainte1_SW	Bit variable	Preventative maintenance setting 1	Yes
Mainte2_Lamp	Bit variable	Preventative maintenance display 2	
Mainte2_ON[0]	Bit variable	Preventative maintenance display 2 controller 1	Yes
Mainte2_ON[1]	Bit variable	Preventative maintenance display 2 controller 2	Yes
Mainte2_ON[2]	Bit variable	Preventative maintenance display 2 controller 3	Yes
Mainte2_ON[3]	Bit variable	Preventative maintenance display 2 controller 4	Yes
Mainte2_ON[4]	Bit variable	Preventative maintenance display 2 controller 5	Yes
Mainte2_ON[5]	Bit variable	Preventative maintenance display 2 controller 6	Yes
Mainte2_ON[6]	Bit variable	Preventative maintenance display 2 controller 7	Yes
Mainte2_ON[7]	Bit variable	Preventative maintenance display 2 controller 8	Yes
Mainte2_SW	Bit variable	Preventative maintenance setting 2	Yes
Menu_No_Set.X[0]	Bit variable	Menu select No.1	
Menu_No_Set.X[1]	Bit variable	Menu select No.2	
Menu_No_Set.X[2]	Bit variable	Menu select No.3	
Menu_No_Set.X[3]	Bit variable	Menu select No.4	
Menu_No_Set.X[4]	Bit variable	Menu select No.5	
Menu_No_Set.X[5]	Bit variable	Menu select No.6	
Menu_Open	Bit variable	Menu open	
Mode_Error	Bit variable	PP (REMOTE) Error	
Mode_Set	Bit variable	Mode setting	
Mode1_Check	Bit variable	Mode 1 Check	
Mode2_Check	Bit variable	Mode 2 Check	
Moniter_Open	Bit variable	Variables window menu OPEN	
Msg_Set	Bit variable	Massage Setting	
PageDownLock	Bit variable	Page switch button Interlock	
PageUpLock	Bit variable	Page switch button Interlock	

Symbol variable	Data Type	Content	Hol
Pulse_On	Bit variable	Axis position variable screen pulse display flag	
RB_MON_OPEN	Bit variable	Servo monitor open	
RB_POS_OPEN	Bit variable	Position monitor open	
Robot_Base	Bit variable	Robot structure setting (BASE)	Yes
Robot_Station	Bit variable	Robot structure setting (Station)	Yes
TEMP1	Bit variable	Temp	
Visible_Flag	Bit variable	Variable hidden flag	
Window_Displ_Bak	Bit variable	Previous CMOS save execution window flag value	
Window_Displ_Flag	Bit variable	CMOS save execution window flag	
Window_Open_Err	Bit variable	Error message window OPEN	
WinPage	Bit variable	Variable Monitor page switching flag	
Action_Set	Integer variable	Operation action (HOLD, SERVO ON)	
Alarm_Detail_Lamp	Integer variable	Alarm sub code detail button display	
Alarm_Detail_Lock	Integer variable	For alarm sub code detail button interlock	
Alram_Detail_No	Integer variable	Alarm sub code detail button selection number	
Alarm_Detail_No_Bak	Integer variable	Retain alarm sub code detail button selection number	
ALARM_H_Mode_Tmp	Integer variable	Alarm history Mode (storage)	
ALARM_No	Integer variable	Alarm number	
Mainte_Offset_Data1	Integer variable	Preventative mainte 1 Last Installment offset data	
Mainte_Offset_Data2	Integer variable	Preventative mainte 2 Last Installment offset data	
Mainte1_Alarm	Integer variable	Preventative maintenance 1 Alarm range	Yes
Mainte1_Alarm_Data	Integer variable	Preventative maintenance 1 Flag alarm value	
Mainte1_Lower	Integer variable	Preventative maintenance 1 Lower limit	Yes
Mainte1_Upper	Integer variable	Preventative maintenance 1 Upper limit	Yes

Mainte2_Alarm	Integer variable	Preventative maintenance 2 Alarm range	Yes
Mainte2_Alarm_Data	Integer variable	Preventative maintenance 2 Flag alarm value	
Mainte2_Lower	Integer variable	Preventative maintenance 2 Lower limit	Yes
Mainte2_Upper	Integer variable	Preventative maintenance 2 Upper limit	Yes
Menu_No_Set	Integer variable	Menu number set	
Robot_Use	Integer variable	Setting robot use	Yes
Alarm_Cause_CNT	Integer variable	Alarm cause scroll line number	
Alarm_Cont_CNT	Integer variable	Alarm content scroll line number	
ALARM_H_Mode	Integer variable	Alarm history Mode	
ALARM_H_No	Integer variable	Alarm history Current page number	
ALARM_H_PageNo	Integer variable	Alarm history Switch page number	
Alarm_Mean_CNT	Integer variable	Alarm meaning scroll line number	
Alarm_Measure_CNT	Integer variable	Alarm measure scroll line number	
ALARM_MSG_No	Integer variable	Alarm details Text number	
CTL_No_Max	Integer variable	Maximum number of robot controller connections	Yes
CTL_No_Min	Integer variable	Minimum number of robot controller connections	
CTL_No_Temp	Integer variable	Robot controller number (storage)	
CursorNo	Integer variable	Job program monitor current page number (display)	
Dumy	Integer variable	Temporary area	

FILE_LIST_No_START	Integer variable	Job program list TOP	
GP_Type	Integer variable	GP type setting	Yes
Instance_Lamp	Integer variable	Variable number specification button lamp	
Instance_No	Integer variable	Variable number specification	
Instance_No_Bak	Integer variable	Variable number specification previous value	
IO_No	Integer variable	IO number	
IO_No_Temp	Integer variable	IO number (storage)	
JOB_MEM_No	Integer variable	JOB program monitor display first number	
JOB_MON_No	Integer variable	JOB program monitor current page number	
JOB_MON_PageNo	Integer variable	JOB program monitor target page number	
JOB_MON_PageNo_Total	Integer variable	JOB program monitor target page number MAX	
JOB_Read_TOP_Address	Integer variable	JOB program monitor read first number	
JOB_SET	Integer variable	Job setting window selection	
JOBLIST_Select	Integer variable	Job program list select	
Language_Set	Integer variable	Language setting	Yes
Mode1_Select	Integer variable	Model selection	
Mode2_Select	Integer variable	Operation mode select	
Robot_Type	Integer variable	Robot type setting	YES
Tab_Disp	Integer variable	Variable screen tab display	

Tab_No	Integer variable	Variable screen tab selection number	
Tab_No_Bak	Integer variable	Variable screen tab selection number previous value	
Variable_No_Interlock	Integer variable	Axis position variable button interlock	
Variable_No_Mov_PB	Integer variable	Axis position variable screen selection number	