


SoMachine

Packaging Application Functions Packaging Library Guide

06/2017

EIO0000000195.09

www.schneider-electric.com



The information provided in this documentation contains general descriptions and/or technical characteristics of the performance of the products contained herein. This documentation is not intended as a substitute for and is not to be used for determining suitability or reliability of these products for specific user applications. It is the duty of any such user or integrator to perform the appropriate and complete risk analysis, evaluation and testing of the products with respect to the relevant specific application or use thereof. Neither Schneider Electric nor any of its affiliates or subsidiaries shall be responsible or liable for misuse of the information contained herein. If you have any suggestions for improvements or amendments or have found errors in this publication, please notify us.

You agree not to reproduce, other than for your own personal, noncommercial use, all or part of this document on any medium whatsoever without permission of Schneider Electric, given in writing. You also agree not to establish any hypertext links to this document or its content. Schneider Electric does not grant any right or license for the personal and noncommercial use of the document or its content, except for a non-exclusive license to consult it on an "as is" basis, at your own risk. All other rights are reserved.

All pertinent state, regional, and local safety regulations must be observed when installing and using this product. For reasons of safety and to help ensure compliance with documented system data, only the manufacturer should perform repairs to components.

When devices are used for applications with technical safety requirements, the relevant instructions must be followed.

Failure to use Schneider Electric software or approved software with our hardware products may result in injury, harm, or improper operating results.

Failure to observe this information can result in injury or equipment damage.

© 2017 Schneider Electric. All Rights Reserved.

Table of Contents



	Safety Information	11
	About the Book	15
Part I	Packaging Library System Requirements	19
Chapter 1	System Requirements	21
	Packaging System Requirements	22
	Function Block Location in the Packaging Library	25
Part II	PickAndPlace	27
Chapter 2	MoveJog: Manual Control of a Single Axis in Different Modes	29
2.1	Functional and Machine Overview	30
	Functional Overview	31
	Machine Overview	33
2.2	Architecture	34
	Hardware Architecture	35
	Software Architecture	36
2.3	Function Block Description	37
	MoveJog Function Block	38
	Operating Modes	40
2.4	Pin Description	44
	Input Pin Description	45
	Structured Parameter	48
	Input/Output Pin Description	50
	Output Pin Description	51
2.5	Quick Reference Guide	53
	Function Block Visualization	54
	Quick Commissioning Procedure	55
	Troubleshooting	59
Chapter 3	XYPickAndPlace: Moving X- and Y-Axis in a Plane Coordinate System	61
3.1	Functional and Machine Overview	62
	Functional Overview	63
	Machine Overview	66

3.2	Architecture	67
	Hardware Architecture	68
	Software Architecture	69
3.3	Function Block Description	70
	XYPickAndPlace Function Block	71
	Axis Movement: General Description	72
	Axis Movement: Non-Optimized Mode Without Approach Point	74
	Axis Movement: Optimized Mode Without Approach Point	75
	Axis Movement	76
	Function Block Operation: Semi-Auto Mode	77
	Function Block Operation: Auto Mode	79
3.4	Pin Description	81
	Input Pin Description	82
	Detailed Input Pin Description	84
	Input: i_stXYPara	85
	Input: i_stPitPara	88
	Input: i_xShiftFrstY	89
	Input: i_uiStepNb	91
	Input: i_uiNbLayr	92
	Input: i_stXYPara.udiApprDist	93
	Input/Output Pin Description	95
	Output Pin Description	96
3.5	Quick Reference Guide	98
	Function Block Visualization	99
	Quick Commissioning Procedure	100
	Troubleshooting	102
Part III	TensionControl	105
Chapter 4	DigitalTensionControl: Controlling Consistent Film Tension Between Two Digital Sensors	107
4.1	Functional and Machine Overview	108
	Functional Overview	109
	Machine Overview	111
4.2	Architecture	114
	Hardware Architecture	115
	Software Architecture	117
4.3	Function Block Description	118
	DigitalTensionControl Function Blocks	118

4.4	Pin Description	120
	Input Pin Description	121
	Input: i_stDiaAct1	123
	Input: i_stUnwd	125
	Input/Output Pin Description	126
	Output Pin Description	127
4.5	Quick Reference Guide	129
	Function Block Visualization	130
	Quick Commissioning Procedure	131
	Troubleshooting	135
Chapter 5	AnalogTensionControl: Controlling Consistent Film Tension Depending on Analog Sensor Feedback	137
5.1	Functional and Machine Overview	138
	Functional Overview	139
	Machine Overview	141
5.2	Architecture	142
	Hardware Architecture	143
	Software Architecture	145
5.3	Function Block Description	146
	AnalogTensionControl Function Blocks	146
5.4	Pin Description	148
	Input Pin Description	149
	Input/Output Pin Description	151
	Output Pin Description	152
5.5	Quick Reference Guide	153
	Function Block Visualization	154
	Quick Commissioning Procedure	155
	Troubleshooting	157
Part IV	TemperatureControl	159
Chapter 6	TemperatureControl: Monitoring and Controlling of Temperature-Dependent Packaging Processes	161
6.1	Functional and Machine Overview	162
	Functional Overview	163
	Machine Overview	165
6.2	Architecture	166
	Hardware Architecture	167
	Software Architecture	168

6.3	Function Block Description.	169
	TemperatureControl Function	169
6.4	Pin Description	173
	Input Pin Description	174
	Input: i_stPid	175
	Input: i_stTempCtrl	179
	Output Pin Description	182
	Output: q_sAttnStat	185
	Output: q_stPid	186
6.5	Quick Reference Guide	187
	Function Block Visualization	188
	Quick Commissioning Procedure	189
	Internal Process Diagram	192
Chapter 7	TemperatureControl_Easy: Monitoring and Simplified Controlling of Temperature-Dependent Packaging Processes.	193
7.1	Functional and Machine Overview	194
	Functional Overview	195
	Machine Overview	197
7.2	Architecture	198
	Hardware Architecture	199
	Software Architecture	200
7.3	Function Block Description.	201
	TemperatureControl_Easy Function	201
7.4	Pin Description	203
	Input Pin Description	204
	Input/Output Pin Description	209
	Output Pin Description	212
7.5	Quick Reference Guide	215
	Function Block Visualization	216
	AutoTuning and Starting the TemperatureControl_Easy	217
	Manual Tuning	223
	Options If You Get Great Overshoot	224
	Program Example TemperaturControl_Easy Function Block	226
	Troubleshooting	227

Part V	LateralPositionControl	229
Chapter 8	LateralPositionControl: Controlling Correct Lateral Film Position with Two Digital Sensors	231
8.1	Functional and Machine Overview	232
	Functional Overview	232
8.2	Architecture	235
	Software Architecture	235
8.3	Function Block Description	236
	LateralPositionControl Function Block	237
	Automatic Mode	239
	Managing Detected Errors	242
8.4	Pin Description	244
	Input Pin Description	245
	Output Pin Description	247
8.5	Quick Reference Guide	248
	Function Block Visualization	249
	Quick Commissioning Procedure	250
	Commissioning Procedure in Manual Mode	251
	Commissioning Procedure in Auto Mode With Symmetric Sensors ..	252
	Commissioning Procedure in Auto Mode and Left Placed Sensors ..	254
	Commissioning Procedure in Auto Mode and Right Placed Sensors ..	256
	Troubleshooting	258
Part VI	RotaryKnife	259
Chapter 9	RotaryKnife_Motion: Synchronization of a Linear Axis and a Rotary Axis to Perform On The Fly Operations	261
9.1	Functional and Machine Overview	262
	Functional Overview	263
	Machine Overview	264
9.2	Architecture	265
	Hardware Architecture	266
	Software Architecture	269
9.3	Function Block Description	271
	RotaryKnife_Motion Function Block	271
9.4	Pin Description	277
	Input Pin Description	278
	Output Pin Description	281
	Input/Output Pin Description	282
	Structured Parameter	283

9.5	Operating Modes	288
	Operating Mode 0: Continuous Product	289
	Operating Mode 1: Continuous Product with Mark Compensation	291
	Operating Mode 2: Non Continuous Product (Cut on Mark)	295
	Selection of the Capture Mode	298
9.6	Start, Stop and Starting Modes	299
	Start and Stop	300
	Starting Modes	303
	Cold Start	304
	Warm Start	305
9.7	Special Modes	315
	Immediate Cut	316
	Offset Mode	317
	Oblique Cut	318
	Shift Function	319
9.8	Quick Reference Guide	322
	Visualization	323
	Troubleshooting	325
Part VII	FlyingShear	329
Chapter 10	FlyingShear_Motion: Synchronization of 2 Linear Axis to Perform On The Fly Operations	331
10.1	Functional and Machine Overview	332
	Functional Overview	333
	Machine Overview	334
10.2	Architecture	335
	Hardware and Software Architecture	335
10.3	Function Block Description	336
	FlyingShear_Motion Function Block	336
10.4	Pin Description	338
	Pin Description	338
10.5	Operating Modes	339
	Operating Modes	339
10.6	Start, Stop and Starting Modes	340
	Start, Stop and Starting Modes	340
10.7	Special Modes	341
	Special Modes	342
	Interruption of the Synchronous Phase	343

10.8	Quick Reference Guide	344
	Visualization	345
	Troubleshooting	347
Part VIII	Grouping/Ungrouping	349
Chapter 11	Grouping - Ungrouping: Synchronization of Linear Axes to Organize Products on a Conveyor	351
11.1	Functional and Machine Overview	352
	Functional Overview	353
	Machine Overview	354
11.2	Architecture	360
	Software Architecture	361
	Hardware Architecture	363
Chapter 12	GroupingAccumulator_Motion	367
12.1	Function Block Description	368
	GroupingAccumulator_Motion Function Block	368
12.2	Pin Description	369
	Input Pin Description	370
	Output Pin Description	372
	Input/Output Pin Description	374
	Structured Parameter	375
Chapter 13	GroupingStripper_Motion	377
13.1	Function Block Description	378
	GroupingStripper_Motion Function Block	378
13.2	Pin Description	381
	Input Pin Description	382
	Output Pin Description	384
	Input/Output Pin Description	387
	Structured Parameter	388
Chapter 14	Operation Description	391
14.1	Operating Modes	392
	General Description	393
	Geared Mode	394
	Triggered Timed Pulsed Mode	396
	Periodic Geared Pulsed Mode	397
	Triggered Geared Pulsed Mode	398

14.2	Start, Stop and Special Modes	399
	Start and Resume Modes	400
	Stop and Resume Modes	401
	Cold Start - GroupingAccumulator_Motion	402
	Cold Start - GroupingStripper_Motion	404
	Warm Start	406
	Special Modes	408
Chapter 15	Quick Reference Guide	411
	Visualization	412
	Troubleshooting	413
Part IX	Clamping	415
Chapter 16	Clamping_Motion: Logical Sequence of Product	
	Clamping with Torque Limitation	417
16.1	Functional and Machine Overview	418
	Functional Overview	418
16.2	Architecture	419
	Software Architecture	419
16.3	Function Block Description	422
	Clamping_motion Function Block	422
16.4	Pin Description	423
	Input Pin Description	424
	Output Pin Description	425
	Input/Output Pin Description	427
	Structured Parameter	428
16.5	Operating Mode	430
	Selection of the Capture Mode	430
16.6	Quick Reference Guide	432
	Visualization	432
Glossary	435
Index	441

Safety Information



Important Information

NOTICE

Read these instructions carefully, and look at the equipment to become familiar with the device before trying to install, operate, service, or maintain it. The following special messages may appear throughout this documentation or on the equipment to warn of potential hazards or to call attention to information that clarifies or simplifies a procedure.



The addition of this symbol to a “Danger” or “Warning” safety label indicates that an electrical hazard exists which will result in personal injury if the instructions are not followed.



This is the safety alert symbol. It is used to alert you to potential personal injury hazards. Obey all safety messages that follow this symbol to avoid possible injury or death.

DANGER

DANGER indicates a hazardous situation which, if not avoided, **will result in** death or serious injury.

WARNING

WARNING indicates a hazardous situation which, if not avoided, **could result in** death or serious injury.

CAUTION

CAUTION indicates a hazardous situation which, if not avoided, **could result in** minor or moderate injury.

NOTICE

NOTICE is used to address practices not related to physical injury.

PLEASE NOTE

Electrical equipment should be installed, operated, serviced, and maintained only by qualified personnel. No responsibility is assumed by Schneider Electric for any consequences arising out of the use of this material.

A qualified person is one who has skills and knowledge related to the construction and operation of electrical equipment and its installation, and has received safety training to recognize and avoid the hazards involved.

BEFORE YOU BEGIN

Do not use this product on machinery lacking effective point-of-operation guarding. Lack of effective point-of-operation guarding on a machine can result in serious injury to the operator of that machine.

WARNING

UNGUARDED EQUIPMENT

- Do not use this software and related automation equipment on equipment which does not have point-of-operation protection.
- Do not reach into machinery during operation.

Failure to follow these instructions can result in death, serious injury, or equipment damage.

This automation equipment and related software is used to control a variety of industrial processes. The type or model of automation equipment suitable for each application will vary depending on factors such as the control function required, degree of protection required, production methods, unusual conditions, government regulations, etc. In some applications, more than one processor may be required, as when backup redundancy is needed.

Only you, the user, machine builder or system integrator can be aware of all the conditions and factors present during setup, operation, and maintenance of the machine and, therefore, can determine the automation equipment and the related safeties and interlocks which can be properly used. When selecting automation and control equipment and related software for a particular application, you should refer to the applicable local and national standards and regulations. The National Safety Council's Accident Prevention Manual (nationally recognized in the United States of America) also provides much useful information.

In some applications, such as packaging machinery, additional operator protection such as point-of-operation guarding must be provided. This is necessary if the operator's hands and other parts of the body are free to enter the pinch points or other hazardous areas and serious injury can occur. Software products alone cannot protect an operator from injury. For this reason the software cannot be substituted for or take the place of point-of-operation protection.

Ensure that appropriate safeties and mechanical/electrical interlocks related to point-of-operation protection have been installed and are operational before placing the equipment into service. All interlocks and safeties related to point-of-operation protection must be coordinated with the related automation equipment and software programming.

NOTE: Coordination of safeties and mechanical/electrical interlocks for point-of-operation protection is outside the scope of the Function Block Library, System User Guide, or other implementation referenced in this documentation.

START-UP AND TEST

Before using electrical control and automation equipment for regular operation after installation, the system should be given a start-up test by qualified personnel to verify correct operation of the equipment. It is important that arrangements for such a check be made and that enough time is allowed to perform complete and satisfactory testing.

WARNING

EQUIPMENT OPERATION HAZARD

- Verify that all installation and set up procedures have been completed.
- Before operational tests are performed, remove all blocks or other temporary holding means used for shipment from all component devices.
- Remove tools, meters, and debris from equipment.

Failure to follow these instructions can result in death, serious injury, or equipment damage.

Follow all start-up tests recommended in the equipment documentation. Store all equipment documentation for future references.

Software testing must be done in both simulated and real environments.

Verify that the completed system is free from all short circuits and temporary grounds that are not installed according to local regulations (according to the National Electrical Code in the U.S.A, for instance). If high-potential voltage testing is necessary, follow recommendations in equipment documentation to prevent accidental equipment damage.

Before energizing equipment:

- Remove tools, meters, and debris from equipment.
- Close the equipment enclosure door.
- Remove all temporary grounds from incoming power lines.
- Perform all start-up tests recommended by the manufacturer.

OPERATION AND ADJUSTMENTS

The following precautions are from the NEMA Standards Publication ICS 7.1-1995 (English version prevails):

- Regardless of the care exercised in the design and manufacture of equipment or in the selection and ratings of components, there are hazards that can be encountered if such equipment is improperly operated.
- It is sometimes possible to misadjust the equipment and thus produce unsatisfactory or unsafe operation. Always use the manufacturer's instructions as a guide for functional adjustments. Personnel who have access to these adjustments should be familiar with the equipment manufacturer's instructions and the machinery used with the electrical equipment.
- Only those operational adjustments actually required by the operator should be accessible to the operator. Access to other controls should be restricted to prevent unauthorized changes in operating characteristics.

About the Book



At a Glance

Document Scope

This document describes the functions of the Packaging Library.

Validity Note


This document has been updated with the release of SoMachine V4.3.

Related Documents

Title of Documentation	Reference Number
SoMachine - Miscellaneous Functions, Toolbox Library Guide	EIO0000000096

You can download these technical publications and other technical information from our website at <http://www.schneider-electric.com/en/download>

Product Related Information

 WARNING
<p>LOSS OF CONTROL</p> <ul style="list-style-type: none">• The designer of any control scheme must consider the potential failure modes of control paths and, for certain critical control functions, provide a means to achieve a safe state during and after a path failure. Examples of critical control functions are emergency stop and overtravel stop, power outage and restart.• Separate or redundant control paths must be provided for critical control functions.• System control paths may include communication links. Consideration must be given to the implications of unanticipated transmission delays or failures of the link.• Observe all accident prevention regulations and local safety guidelines.¹• Each implementation of this equipment must be individually and thoroughly tested for proper operation before being placed into service. <p>Failure to follow these instructions can result in death, serious injury, or equipment damage.</p>

¹ For additional information, refer to NEMA ICS 1.1 (latest edition), "Safety Guidelines for the Application, Installation, and Maintenance of Solid State Control" and to NEMA ICS 7.1 (latest edition), "Safety Standards for Construction and Guide for Selection, Installation and Operation of Adjustable-Speed Drive Systems" or their equivalent governing your particular location.

WARNING

UNINTENDED EQUIPMENT OPERATION

- Only use software approved by Schneider Electric for use with this equipment.
- Update your application program every time you change the physical hardware configuration.

Failure to follow these instructions can result in death, serious injury, or equipment damage.

Terminology Derived from Standards

The technical terms, terminology, symbols and the corresponding descriptions in this manual, or that appear in or on the products themselves, are generally derived from the terms or definitions of international standards.

In the area of functional safety systems, drives and general automation, this may include, but is not limited to, terms such as *safety*, *safety function*, *safe state*, *fault*, *fault reset*, *malfunction*, *failure*, *error*, *error message*, *dangerous*, etc.

Among others, these standards include:

Standard	Description
EN 61131-2:2007	Programmable controllers, part 2: Equipment requirements and tests.
ISO 13849-1:2008	Safety of machinery: Safety related parts of control systems. General principles for design.
EN 61496-1:2013	Safety of machinery: Electro-sensitive protective equipment. Part 1: General requirements and tests.
ISO 12100:2010	Safety of machinery - General principles for design - Risk assessment and risk reduction
EN 60204-1:2006	Safety of machinery - Electrical equipment of machines - Part 1: General requirements
EN 1088:2008 ISO 14119:2013	Safety of machinery - Interlocking devices associated with guards - Principles for design and selection
ISO 13850:2006	Safety of machinery - Emergency stop - Principles for design
EN/IEC 62061:2005	Safety of machinery - Functional safety of safety-related electrical, electronic, and electronic programmable control systems
IEC 61508-1:2010	Functional safety of electrical/electronic/programmable electronic safety-related systems: General requirements.
IEC 61508-2:2010	Functional safety of electrical/electronic/programmable electronic safety-related systems: Requirements for electrical/electronic/programmable electronic safety-related systems.
IEC 61508-3:2010	Functional safety of electrical/electronic/programmable electronic safety-related systems: Software requirements.
IEC 61784-3:2008	Digital data communication for measurement and control: Functional safety field buses.

Standard	Description
2006/42/EC	Machinery Directive
2014/30/EU	Electromagnetic Compatibility Directive
2014/35/EU	Low Voltage Directive

In addition, terms used in the present document may tangentially be used as they are derived from other standards such as:

Standard	Description
IEC 60034 series	Rotating electrical machines
IEC 61800 series	Adjustable speed electrical power drive systems
IEC 61158 series	Digital data communications for measurement and control – Fieldbus for use in industrial control systems

Finally, the term *zone of operation* may be used in conjunction with the description of specific hazards, and is defined as it is for a *hazard zone* or *danger zone* in the *Machinery Directive (2006/42/EC)* and *ISO 12100:2010*.

NOTE: The aforementioned standards may or may not apply to the specific products cited in the present documentation. For more information concerning the individual standards applicable to the products described herein, see the characteristics tables for those product references.

Part I

Packaging Library System Requirements

Chapter 1

System Requirements

At a Glance

This chapter describes the system requirements for the Packaging Library function blocks.

What Is in This Chapter?

This chapter contains the following topics:

Topic	Page
Packaging System Requirements	22
Function Block Location in the Packaging Library	25

Packaging System Requirements

Overview

This chapter describes the hardware and the software requirements, and user interface compatibility for packaging library functions.

For environments, refer to individual function block chapters.

System Requirements

This table describes the system requirements for the following application function blocks:

Application Function Block	Requirements
<ul style="list-style-type: none"> ● TemperatureControl ● TemperatureControl_Easy ● LateralPositionControl 	<ul style="list-style-type: none"> ● Logic Controller or ● Motion Controller
<ul style="list-style-type: none"> ● MoveJog ● XYPickAndPlace 	<ul style="list-style-type: none"> ● Logic Controller ● Lexium servo drive
<ul style="list-style-type: none"> ● DigitalTensionControlATV ● AnalogTensionControlATV 	<ul style="list-style-type: none"> ● Logic Controller ● Lexium servo drive ● Altivar variable speed drive
<ul style="list-style-type: none"> ● DigitalTensionControlATV_Motion ● AnalogTensionControlATV_Motion 	<ul style="list-style-type: none"> ● Motion Controller ● Lexium servo drive ● Altivar variable speed drive
<ul style="list-style-type: none"> ● RotaryKnife_Motion ● FlyingShear_Motion ● GroupingAccumulator_Motion ● GroupingStripper_Motion ● Clamping_Motion ● AnalogTensionControlILXM_Motion 	<ul style="list-style-type: none"> ● Motion Controller ● Lexium servo drive

The targeted controller for the segment Packaging are:

- M258 Logic Controller
- LMC058 Motion Controller
- LMC078 Motion Controller

The preferred drives are:

- LXM32 Lexium servo drive
- ATV32 Altivar variable speed drive
- ATV71 Altivar variable speed drive

Communication Interface

This table describes the communication interface requirements for the following application function blocks:

Application Function Block	Requirements
<ul style="list-style-type: none"> ● TemperatureControl ● TemperatureControl_Easy ● LateralPositionControl 	No communication interface required.
<ul style="list-style-type: none"> ● MoveJog ● XYPickAndPlace 	CANopen protocol is used for communication with servo drives.
<ul style="list-style-type: none"> ● DigitalTensionControlATV ● AnalogTensionControlATV 	CANopen protocol is used for communication with variable speed drive and servo drive.
<ul style="list-style-type: none"> ● DigitalTensionControlATV_Motion ● AnalogTensionControlATV_Motion 	CANopen protocol is used for communication with variable speed drive and CANmotion or Sercos protocol is used for communication with servo drive.
<ul style="list-style-type: none"> ● Clamping_Motion 	CANmotion protocol is used for communication with servo drives.
<ul style="list-style-type: none"> ● RotaryKnife_Motion ● FlyingShear_Motion ● GroupingAccumulator_Motion ● GroupingStripper_Motion ● AnalogTensionControlILXM_Motion 	CANmotion or Sercos protocol is used for communication with servo drives.

NOTE: The LMC078 Motion Controller is using the third generation of Sercos.

User Interface

All parameters can be supplied and modified using Magelis HMI which can be used optionally.

Using the Library

WARNING

UNINTENDED EQUIPMENT OPERATION

- Verify the SoMachine libraries contained in your program are the correct version after updating SoMachine software.
- Verify that the library versions updated are consistent with your application specifications.

Failure to follow these instructions can result in death, serious injury, or equipment damage.

For more detailed information, see Schneider Electric Libraries.

For IEC 61131-3 compatibility, the ability to add the EN/ENO input/output automatically to Function Blocks of certain programming languages is available to the programmer. However, for certain applications that require the complex interaction of multiple function blocks, the use of the IEC 61131-3 input to disable a function block in a series of interrelated functions affecting a process may lead to unintended operation of the system as a whole. For the functions contained in the Library that is the topic of the current document, this is especially true.

The EN/ENO inputs and outputs as defined by IEC 61131-3 are maladapted to, and therefore inappropriate for, the targeted application of these functions. Suddenly disabling one function by a falling edge on the EN input would require all outputs of the function block to immediately fall to their default states, and such an unanticipated action would cause in abrupt change to the entire process. The implication is that such an event would have deleterious results that may invoke undesirable consequences. Therefore, the EN/ENO inputs/outputs as defined by IEC 61131-3 are incompatible with the functions contained within this library.

WARNING

UNINTENDED MACHINE OPERATION

Do not use the EN/ENO functionality defined by IEC 61131-3 to control the behavior of the Application Function blocks.

Failure to follow these instructions can result in death, serious injury, or equipment damage.

NOTE: Verify that the EN/ENO option is disabled in the compiler options menu of SoMachine.

Function Block Location in the Packaging Library

Function Block Location in the Packaging Library of SoMachine

Folder	Sub-Folder	Application Function Block
Clamping		Clamping_Motion
FlyingShear		FlyingShear_Motion
Grouping Ungrouping		GroupingAccumulator_Motion GroupingStripper_Motion
LateralPositionControl		LateralPositionControl
PickAndPlace		MoveJog XYPickAndPlace
RotaryKnife		RotaryKnife_Motion
TemperatureControl		TemperatureControl TemperatureControl_Easy
TensionControl	AnalogTensionControl	AnalogTensionControlATV AnalogTensionControlATV_Motion AnalogTensionControlLXM_Motion
	DigitalTensionControl	DigitalTensionControlATV DigitalTensionControlATV_Motion

Part II

PickAndPlace

What Is in This Part?

This part contains the following chapters:

Chapter	Chapter Name	Page
2	MoveJog: Manual Control of a Single Axis in Different Modes	29
3	XYPickAndPlace: Moving X- and Y-Axis in a Plane Coordinate System	61

Chapter 2

MoveJog: Manual Control of a Single Axis in Different Modes

What Is in This Chapter?

This chapter contains the following sections:

Section	Topic	Page
2.1	Functional and Machine Overview	30
2.2	Architecture	34
2.3	Function Block Description	37
2.4	Pin Description	44
2.5	Quick Reference Guide	53

Section 2.1

Functional and Machine Overview

What Is in This Section?

This section contains the following topics:

Topic	Page
Functional Overview	31
Machine Overview	33

Functional Overview

Functional Description

The MoveJog function block controls a single axis while operating in Manual mode.

Usage of MoveJog Function Block

The MoveJog function is required for moving a single axis in speed mode, position mode and to home the axis.

Solution with the MoveJog Function Block

The MoveJog function provides the following modes for operating a single axis in Manual mode:


- Speed mode
- Position mode
- Homing mode

Design & Realization Constraints and Assumptions

- Modulo Axis is run as infinite rotation with the Rotary Axis setting at the controller configuration and there is no hardware/software limit checking.
- Homing is possible when Modulo Axis is selected.


Functional View for Linear axis

Functional view for linear servo axis on CANopen:



Machine Overview

Machine View



Section 2.2

Architecture


What Is in This Section?

This section contains the following topics:

Topic	Page
Hardware Architecture	35
Software Architecture	36


Hardware Architecture

Hardware Architecture Overview



Software Architecture

DataFlow Overview



Section 2.3

Function Block Description

What Is in This Section?

This section contains the following topics:

Topic	Page
MoveJog Function Block	38
Operating Modes	40

MoveJog Function Block

Pin Diagram



Function Block Description

The MoveJog function block is used for manual control of a single Axis.

This function block includes three modes:

- Speed Mode: the direction and movement commands are given using a single Jog Button. The axis moves continuously in a specified direction as long as the Jog command is active.
- Position Mode: the direction and movement commands are given using a single Jog button. The axis moves up a specified distance with a specified direction.

NOTE: Axis must be homed using Homing mode before the MoveJog function block can be used in Position Mode.

- Homing Mode: after a start Homing command, the axis moves according to the Homing method selected.

NOTE: Select correct Homing method and parameter for the application. Improper setup or cabling may cause unintended equipment action.

 **WARNING**

UNINTENDED EQUIPMENT OPERATION

Verify that all configuration parameters are correct and validate cabling before commissioning.

Failure to follow these instructions can result in death, serious injury, or equipment damage.

Operating Modes


Speed Mode: `i_byOpMode=0`

In Speed Mode, when the function block is enabled, enabling one of the directional inputs `i_xJogFwd` or `i_xJogRev` starts the axis of motion in the desired direction. The specified axis is then accelerated at the specified acceleration `i_diJogAcc` to the specified velocity `i_iJogVel`. As long as there are no changes in the state of the direction inputs, the axis moves in the corresponding direction. The motion is stopped by a falling edge at the respective direction input.

After `i_tTimeSwcVelHigh` has elapsed in the speed jog mode, the normal `i_iJogVel` and `i_diJogAcc` are increased to `i_iJogVelHigh` and `i_diJogAccHigh` as shown in cycle 2 in the Timing diagram figure below.

If both the direction inputs `i_xJogFwd` and `i_xJogRev` are TRUE at same time then the axis is stopped and displays a detected error. The detected error resets only when one or both of the direction input is FALSE and the rising edge of `i_xAlrmRst` is given to function block as shown in cycle 4 in the timing diagram figure below.

This figure shows the timing diagram for MoveJog function block in Speed Mode:




Position Mode: $i_byOpMode=1$

In Position Mode, when the function block is enabled, an enable signal at one of the direction bits $i_xJogFwd$ or $i_xJogRev$ results in a single motion over a defined path $i_diJogDist$ in the desired direction. The motion is accelerated at the specified acceleration $i_diJogAcc$ up to the level $i_iJogVel$.

The motion is aborted by a falling edge at the respective direction bit before reaching distance as shown in cycle 3 in the timing diagram figure below.

If both the direction inputs $i_xJogFwd$ and $i_xJogRev$ are TRUE at same time then the axis does not move and the function block displays a detected error. The detected error is reset only when one or both of the direction inputs is FALSE and rising edge of $i_xAlrmRst$ is given to function block as shown in cycle 4 in the timing diagram figure below.

This figure shows the timing diagram for the MoveJog function block in Position Mode:



Homing Mode: `i_byOpMode=2`

In Homing Mode, `i_xHmngStrt` starts the Homing operation according to the Homing method. After the completion of the Homing operation, the output `q_xAxisHome` is set to TRUE. During Homing, additional rising edge at `i_xHmngStrt` results in a detected Axis error.

NOTE: In Homing Mode, Jog command is not applicable.

Section 2.4

Pin Description

What Is in This Section?

This section contains the following topics:

Topic	Page
Input Pin Description	45
Structured Parameter	48
Input/Output Pin Description	50
Output Pin Description	51

Input Pin Description

Input Pin Description

Input	Data Type	Description
i_xEn	BOOL	TRUE: Enables function block and the parameters are validated. FALSE: Disables function block and all outputs are set to zero. The axis movement is stopped.
i_xJogFwd	BOOL	TRUE: The jog motion starts in the positive/forward direction. FALSE: During jog in forward direction the axis movement is stopped. <ul style="list-style-type: none"> • i_xJogFwd must be TRUE up to the required position. • This input is only applicable to Speed and Position modes. • When i_xJogFwd and i_xJogRev are TRUE at the same time, the q_xAlrm is TRUE and the axis is stopped with a detected error.
i_xJogRev	BOOL	TRUE: Negative/reverse direction FALSE: During jog in reverse direction the axis movement is stopped. <ul style="list-style-type: none"> • i_xJogRev must be TRUE up to the desired position. • This input is only applicable in Speed and Position modes. • When i_xJogFwd and i_xJogRev are TRUE at the same time, the q_xAlrm is TRUE and the axis is stopped with a detected error.
i_iJogVel	INT	In position mode, the axis moves only with i_iJogVel velocity. In Speed Mode the axis moves with i_iJogVel velocity until the i_tTimeVelHigh elapses. Range: 0...32000 RPM Factory setting: 20
i_iJogVelHigh	INT	Jog velocity after the timer elapsed (i_tTimeVelHigh) Range: 0...32000 RPM Factory setting: 20 NOTE: Only applicable in Speed Mode

Input	Data Type	Description
i_diJogAcc	DINT	In position mode, the axis moves with i_diJogAcc acceleration. In Speed Mode, the axis moves with i_diJogAcc acceleration until the i_tTimeVelHigh elapses. Range: 30...3000000 RPM/s Factory setting: 100
i_diJogDec	DINT	The axis stops with deceleration time Range: 750...3000000 RPM/s Factory setting: 900
i_diJogAccHigh	DINT	The axis moves with i_diJogAcc acceleration after the i_tTimeVelHigh elapses. Range: 30...3000000 RPM/s Factory setting: 300 NOTE: This is only applicable in Speed Mode
i_tTimeVelHigh	TIME	This is the time to switch from i_iJogVel to i_iJogVelHigh and from i_diJogAcc to i_diJogAccHigh. Range: 0...4194967295 ms 0: disables timer function Factory setting: 10 s <ul style="list-style-type: none"> • i_tTimeVelHigh is applicable for Speed Mode. • i_tTimeVelHigh timer is reset after Jog command FALSE or i_xEn is FALSE. • When i_tTimeVelHigh = 0, axis moves only with i_iJogVel and i_diJogAcc.
i_diJogDist	DINT	Jog distance value Range: 1...2147483647 user unit <ul style="list-style-type: none"> • i_diJogDist is only applicable in position mode. • Jog distance should be more than zero. If i_diJogDist is zero, then axis will not move and position output q_xDone is TRUE.
i_byOpMode	BYTE	0: Speed Mode 1: Positioning Mode 2: Homing Mode
i_xHmngStrt	BOOL	TRUE: Starts the homing operation according to homing type selected. After the completion of homing operation, the output q_xAxisHome is set to zero. <ul style="list-style-type: none"> • In homing mode, Jog command is not applicable. • Homing is not possible with modulo axis.
i_xLsEn	BOOL	TRUE: Enables the hardware limit switch functionality inside the function block.

Input	Data Type	Description
i_xLsFwd	BOOL	<p>TRUE: Forward / positive direction hardware limit switch (factory setting) If enabled and forward / positive direction hardware limit switch goes low, then axis stops with positive hardware limit switch active notification.</p> <p>NOTE: Limit switch is configured as normally closed.</p>
i_xLsRev	BOOL	<p>TRUE: Reverse / negative direction hardware limit switch (factory setting) If enabled and reverse / negative direction hardware limit switch goes low, then axis stops with negative hardware limit switch active notification.</p> <p>NOTE: Limit switch is configured as normally closed.</p>
i_xAxisMode	BOOL	<p>TRUE: Modulo axis configuration is selected and hardware/software limit switch functionality is disabled. FALSE: Linear axis configuration is selected (factory setting).</p> <p>Procedure for axis configuration:</p> <ul style="list-style-type: none"> ● i_xEn input must be TRUE ● Drive must be in ready state ● Change the i_xAxisMode input as per the requirements ● Set drive to run mode and move the axis.
i_xAlrmRst	BOOL	TRUE: Reset the detected alarm on a rising edge.
i_stHmngPara	HomPara	Structure for homing parameter Refer to i_stHmngPara (<i>see page 48</i>).

Structured Parameter

i_stHmngPara

This table describes the mandatory parameters for the `i_stHmngPara` inputs of the `MoveJog` function block:

Structure Parameter	Data Type	Description
diPos	DINT	Absolute position when the reference signal is detected In Homing mode, after successful reference movement, this position value is automatically set at the axis stop position. Range: 1...2147483647 User Unit
uiHmngMode	UINT	Select Homing method See description in table below
uiHmngVel	UINT	Velocity for search of reference switch Range: 1...13200 RPM
uiHmngVelOut	UINT	Velocity for movement back to edge of reference switch Range: 1...3000 RPM
diHmngPosOut	DINT	Maximum distance for movement back to edge of reference switch Range: 0...2147483647 User Unit NOTE: The hardware limit switch must be disabled again inside this run-off; otherwise the reference movement is aborted.
diHmngDistPos	DINT	Positioning from edge of reference switch Range: 1...2147483647 User Unit NOTE: After leaving the switch, the drive is still positioned in the working range for defined path and this position is defined as a reference point.

uiHmngMode

This table describes the methods supported by the `MoveJog` function block:

Method Number	Description
1	Limit switch Negative with index pulse
2	Limit switch Positive with index pulse
7	Search Reference switch in Positive direction with index pulse, invert direction in switch, index pulse/distance outside Switch

Method Number	Description
8	Search Reference switch in Positive direction with index pulse, invert direction in switch, index pulse/distance inside Switch
9	Search Reference switch in Positive direction with index pulse, direction in switch not inverted, index pulse/distance inside Switch
10	Search Reference switch in Positive direction with index pulse, direction in switch not inverted, index pulse/distance outside Switch
11	Search Reference switch in Negative direction with index pulse, invert direction in switch, index pulse/distance outside Switch
12	Search Reference switch in Negative direction with index pulse, invert direction in switch, index pulse/distance inside Switch
13	Search Reference switch in Negative direction with index pulse, direction in switch not inverted, index pulse/distance inside Switch
14	Search Reference switch in Negative direction with index pulse, direction in switch not inverted, index pulse/distance outside Switch
17	Search Limit switch Negative
18	Search Limit switch Positive
23	Search Reference switch in Positive direction, invert direction in switch, index pulse/distance outside Switch
24	Search Reference switch in Positive direction, invert direction in switch, index pulse/distance inside Switch
25	Search Reference switch in Positive direction, direction in switch not inverted, index pulse/distance inside Switch
26	Search Reference switch in Positive direction, direction in switch not inverted, index pulse/distance outside Switch
27	Search Reference switch in Negative direction, invert direction in switch, index pulse/distance outside Switch
28	Search Reference switch in Negative direction, invert direction in switch, index pulse/distance inside Switch
29	Search Reference switch in Negative direction, direction in switch not inverted, index pulse/distance inside Switch
30	Search Reference switch in Negative direction, direction in switch not inverted, index pulse/distance outside Switch
33	Reference movement to the index pulse in Negative direction
34	Reference movement to the index pulse in Positive direction
35	Set dimensions (Direct Homing without movement and set required position to current position)

Input/Output Pin Description

Input/Output Pin Description

Input/Output	Data Type	Description
iq_stAxis	SEM_LXM.Axis_Ref_LXM	Servo-axis reference structure

Output Pin Description

Output Pin Description

Output	Data Type	Description
q_xEn	BOOL	TRUE: Function block enabled. If input i_xEn is TRUE, then output q_xEn is TRUE.
q_xBusy	BOOL	TRUE: Axis is accelerating or decelerating.
q_xDone	BOOL	Only in position mode. TRUE: Axis moved by jog distance.
q_xVelRchd	BOOL	Only in speed mode. TRUE: Velocity reaches jog velocity (i_iJogVel) or jog velocity high (i_iJogVelHigh).
q_diPosActl	DINT	Actual position of the axis.
q_xAxisHome	BOOL	Only in homing mode. TRUE: Axis homing operation is complete and, after that, q_xAxisHome is TRUE in all modes. NOTE: This resets after a controller power on/off or a detected axis error.
q_xCmdAbort	BOOL	TRUE: Command aborted In the event that the motion is aborted due to external command (for example: detected communication error, Stop command issued before the completion of a movement, function block disabled while axis homing) i_xCmdAbort is set to TRUE.
q_xAlrm	BOOL	TRUE: Detected alarm FALSE: No alarm
q_uiAlrmId	UINT	ID detected alarm Range: 0, 1, 10, 30, 101, 102, 103, 105, 350-359. Refer to Notification table (see page 52).
q_sAlrmMsge	STRING	Refer to Notification table (see page 52).
q_sOpMode	STRING	Output displays the function block current operating mode.

Notifications

Detected Alarm ID	Notification
0	Okay
1	Internal function block detected alarm
10	Detected Axis alarm
30	PLCopen function block detected alarm
101	Invalid Acceleration Parameter
102	Invalid Deceleration Parameter
103	Invalid Velocity Parameter
105	Invalid Target Position Parameter
350	Invalid Operation Mode parameter
351	Invalid Absolute Position Parameter
352	Invalid Homing Mode Parameter
353	Invalid Reference Searching Velocity Parameter
354	Invalid Reference Out Velocity Parameter
355	Invalid Maximum Distance Parameter
356	Invalid Distance from Reference Parameter
357	Jog Positive and Jog Negative are Active
358	Positive Limit Switch Active
359	Negative Limit Switch Active

Alarm message:

q_sAlrmMsge: Axis not Homed! Position Mode not Allowed

Section 2.5

Quick Reference Guide

What Is in This Section?


This section contains the following topics:

Topic	Page
Function Block Visualization	54
Quick Commissioning Procedure	55
Troubleshooting	59

Function Block Visualization

Visualization

This figure shows the visualization of the MoveJog function block:



Quick Commissioning Procedure

Configuration Procedure

This table explains the procedure to configure the MoveJog function blocks:

Step	Action
1	Add the supporting Packaging Library into the application program.
2	Configure the axis on CANopen Master.
3	Enter all parameters in controller configuration.
4	Use MC_Power_LXM for powering up the drive and MC_Reset_LXM for resetting an axis error (both included in Lexium library based on PLCopen).
5	Load the MoveJog function application on controller.
6	Power on the axis.
7	Enable MC_Power_CAN and MoveJog function blocks and enter all parameters as per requirements within range in the following tables.
8	In Speed mode, directly give the jog command for movement.
9	For Position mode, first complete the homing operation of axis in homing mode.
10	Start the FB.

Parameterizing in Speed Mode

This table lists the suggested parameters for speed mode:

Parameter	Example Value
i_xEn	TRUE
i_xJogFwd	TRUE
i_xJogRev	FALSE
i_iJogVel	100
i_iJogVelHigh	500
i_diJogAcc	100
i_diJogDec	1000
i_diJogAccHigh	500
i_tTimeVelHigh	1000
i_diJogDist	0
i_byOpMode	0
i_xHmngStrt	FALSE
i_xLsEn	TRUE
i_xLsFwd	TRUE
i_xLsRev	TRUE
i_xAxisMode	FALSE
i_xAlrmRst	FALSE

NOTE: The above values were tested in laboratory conditions and are for illustrative purposes only. Appropriate values should be entered as per the actual machine setup.

Parameterizing in Position Mode

This table lists the suggested parameters for position mode:

Parameter	Example Value
i_xEn	TRUE
i_xJogFwd	TRUE
i_xJogRev	FALSE
i_iJogVel	100
i_iJogVelHigh	500
i_diJogAcc	100
i_diJogDec	1000
i_diJogDist	10000
i_byOpMode	1
i_xHmngStrt	FALSE
i_xLsEn	TRUE
i_xLsFwd	TRUE
i_xLsRev	TRUE
i_xAxisMode	FALSE
i_xAlrmRst	FALSE

NOTE: The above values were tested in laboratory conditions and are for illustrative purposes only. Appropriate values should be entered as per the actual machine setup.

Parameterizing in Homing Mode

This table lists the suggested parameters for homing mode:

Parameter	Example Value
i_xEn	TRUE
i_byOpMode	2
i_xHmngStrt	FALSE
i_xAxisMode	FALSE
i_xAlrmRst	FALSE
i_stHmngPara.diPos	0
i_stHmngPara.uiHmngMode	17
i_stHmngPara.uiHmngVel	50
i_stHmngPara.uiHmngVelOut	20
i_stHmngPara.diHmngPosOut	0
i_stHmngPara.diHmngDistPos	100

NOTE: The above values were tested in laboratory conditions and are for illustrative purposes only. Appropriate values should be entered as per the actual machine setup.

Troubleshooting

Troubleshooting

This table shows some general issues and their solutions:

Issue	Cause	Solution
Parameter invalid	Function block detected error.	1.Remove cause of detected error and acknowledge with <code>i_xAlrmRst</code> 2.Restart the function block.
Inputs invalid	The axis movement is stopped and the detected error output is set.	1.Remove cause of detected error and acknowledge with <code>i_xAlrmRst</code>
Axis error detected	The axis movement is stopped and the detected error output is set.	1.Remove cause of detected error 2.Execute the axis reset using <code>MC_Reset</code> function block. 3.Restart the function block.
<code>q_uiAlrmId = 1</code>	Internal detected error	Detected error other than the ones above. Restart the function block.
<code>q_uiAlrmId = 10</code>	Axis detected alarm	Verify the servo drive detected error and remove the cause of the detected error.
<code>q_uiAlrmId = 30</code>	PLCopen detected alarm	Reset the function block. Give the power cycle to the controller if a detected error remains.
<code>q_uiAlrmId = 101</code>	Invalid acceleration parameter	Verify that the acceleration parameter is within the specified range.
<code>q_uiAlrmId = 102</code>	Invalid deceleration parameter	Verify that the deceleration parameter is within the specified range.
<code>q_uiAlrmId = 103</code>	Invalid velocity parameter	Verify that the speed parameter is within the specified range.
<code>q_uiAlrmId = 105</code>	Invalid target position parameter	Verify that the position parameter is within the specified range.
<code>q_uiAlrmId = 350</code>	Invalid operation mode parameter	Verify that the operation parameter is within the specified range.
<code>q_uiAlrmId = 351</code>	Invalid absolute position Parameter	Verify that the absolute position is within the specified range.
<code>q_uiAlrmId = 352</code>	Invalid homing mode parameter	Verify that the homing mode is within the specified range.

Issue	Cause	Solution
q_uiAlrmId = 353	Invalid ref. searching velocity parameter	Verify that the ref. searching velocity is within the specified range.
q_uiAlrmId = 354	Invalid ref. out velocity parameter	Verify that the ref. out velocity is within the specified range.
q_uiAlrmId = 355	Invalid max. distance parameter	Verify that the max. distance is within the specified range.
q_uiAlrmId = 356	Invalid distance from reference parameter	Verify that the distance from reference is within the specified range.
q_uiAlrmId = 357	Jog positive and Jog negative are active	Verify that only one input is ON at a time.
q_uiAlrmId = 358	Positive limit switch active	Verify the positive limit switch position.
q_uiAlrmId = 359	Negative limit switch active	Verify the negative limit switch position.

Chapter 3

XYPickAndPlace: Moving X- and Y-Axis in a Plane Coordinate System

What Is in This Chapter?

This chapter contains the following sections:

Section	Topic	Page
3.1	Functional and Machine Overview	62
3.2	Architecture	67
3.3	Function Block Description	70
3.4	Pin Description	81
3.5	Quick Reference Guide	98

Section 3.1

Functional and Machine Overview

What Is in This Section?

This section contains the following topics:

Topic	Page
Functional Overview	63
Machine Overview	66

Functional Overview

Functional Description

XYPickAndPlace function is required in the consumer products industry for a wide variety of product transfer applications. The machine basically takes a product or products from machines such as wrappers, cartoners or fillers, and stacks them into a case, which is then ready for palletizing or shipment.

Usage of XYPickAndPlace Function Block

XYPickAndPlace Application involves two functions, one is for the picking and placing of material and the other is for movement of this material in the XY plane.


The XYPickAndPlace function block involves two linear axes that move the manufactured part from one assembly station to another station or from a conveyor to pallet.

Solution with the XYPickAndPlace Function Block

Moving the part to the target location can be accomplished in three separate moves:

- Picking the part along the Z axis.
- Moving the part in the XY plane to the target position.
- Placing the part along the Z axis.

This figure shows the PickAndPlace assembly:




The function block is used to reduce process time, increase productivity and efficiency in packaging.

NOTE: Z Axis Operation is not controlled by the function block.

Design & Realization Constraints and Assumptions


- The Shift (Skip) Position is applicable only in the Semi-Auto Mode. This option is not allowed in Auto Mode.
- In Semi Auto Mode the trigger for each cycle is done by the rising edge of the `i_xExe`, but the parameter change is done only with the `i_xEn`; this is to avoid parameter change during the cycle.
- New cycle is started once all the boxes (box shifting is counted) in the current cycle are placed as per the defined matrix. The message "Layer Completed with Skipped Box" is then displayed.
- Presently done: Skipped box can be either manually placed (by operator) or a new semi-automatic cycle can be started by resetting the Box Count `i_xBoxCntRst` input and giving respective skip number through `i_uiStepNb` to directly reach the box which needs to be placed (Box or any obstacle on the way to reach this previously skipped box position is not considered in this FB since Z axis is not controlled).
- If function block is disabled and enabled and the parameters (Direction of Placing, Number of elements in X and Y, Target, Approach and Start Position) are changed, then the box count is reset and a fresh cycle is started. If no parameter is changed, then old cycle is continued.
- Direction of Placing, Number of elements in X and Y, Target, Approach and Start Position cannot be changed when a cycle is running. New values are affected only on the Rising edge of the `i_xEn` (FB enable).

Functional View



Machine Overview

Machine View



Section 3.2

Architecture


What Is in This Section?

This section contains the following topics:

Topic	Page
Hardware Architecture	68
Software Architecture	69


Hardware Architecture

Hardware Architecture Overview



Software Architecture

DataFlow Overview



Section 3.3

Function Block Description

What Is in This Section?


This section contains the following topics:

Topic	Page
XYPickAndPlace Function Block	71
Axis Movement: General Description	72
Axis Movement: Non-Optimized Mode Without Approach Point	74
Axis Movement: Optimized Mode Without Approach Point	75
Axis Movement	76
Function Block Operation: Semi-Auto Mode	77
Function Block Operation: Auto Mode	79

XYPickAndPlace Function Block

Pin Diagram

The XYPickAndPlace function block encapsulates all necessary functions for controlling the position of two axes in the XY plane.



Axis Movement: General Description

At a Glance

The axis are moved in a coordinated linear movement by calculating the ratio of distances travelled in the X axis and Y axis. The axis with the shorter move is multiplied by this ratio so that the axes move with the same ratio of velocity, acceleration and deceleration at any point in time.

Approach Point Rules

Selecting the approach point permits decreasing the axes velocity when they reach the approach position.

If the selected mode is 0, 1 or 2, the resulting axis trajectory is done without an approach point, the axis moves to the target position in one move.

Following are the 5 modes of axis movement:


- 0 Non-optimized mode without approach point
- 1 Optimized mode without approach point
- 2 Strict optimized mode without approach point
- 3 Optimized mode with approach point
- 4 Strict optimized mode with approach point

NOTE: Improper setup or cabling may cause unintended equipment action.

 WARNING
UNINTENDED EQUIPMENT OPERATION
Verify that all configuration parameters are correct and validate cabling before commissioning.
Failure to follow these instructions can result in death, serious injury, or equipment damage.

Linear Axis Movement

This figure shows linear axis movement by starting and stopping both axes at the same time to achieve a high level of linearity:



Axis Movement: Non-Optimized Mode Without Approach Point

Description


The non-optimized mode without approach point is selected when `i_byAxisMovSel` input is 0.

In this mode, if the calculated Acceleration and Deceleration of the short distance move is less than the lower limit of 30 and 750 respectively, then the Acceleration and Deceleration is set to 30 and 750 and an alarm message of "Non Optimized Mode" is ON and the straight line trajectory is not assured.

NOTE:

- All calculations are done before the movement of the axes. The mode selection needs to be done prior to the start of the axis movement.
- In this Mode, the user needs to select the appropriate Acceleration and Deceleration to prevent from going below the limit required to achieve straight line trajectory.

Axis Movement



Axis Movement: Optimized Mode Without Approach Point


Description

For axis movement, optimized mode without approach point is selected when `i_byAxisMovSel` input is 1.

In this mode, if the short distance movement axis calculated acceleration and deceleration is less than the lower limit of 30 and 750 respectively then acceleration and deceleration of a long distance movement axis is increased accordingly to achieve the straight line trajectory.

During this Alarm message "Auto Correction ON" is ON.

Axis Movement



Acceleration and Deceleration are in units/ sec²
 Acceleration and Deceleration increase is only upto `diMaxAcc` and `diMaxDec`

NOTE:

- All the calculations are done before the movement of the axes. The mode selection needs to be done prior to the start of the axis movement.
- In this mode, the user must set the Maximum Acceleration (**diAccMax**) and Maximum Deceleration (**diDecMax**) so that the calculated Acceleration and Acceleration (of the longer axis) stays within the acceptable operating limits of the machine.
- In this scenario, the alarm message "Auto Correction On with Acc / Dec Limited" is set and the straight line trajectory can not be assured.
- In this mode, there is always a movement in X- and in Y- direction and accordingly delta X and delta Y cannot be zero.

Axis Movement

Strict Optimized Mode without Approach Point

For axis movement, the Strict Optimized Mode without approach point is selected when `i_byAxisMovSel` is 2. In this mode, if the short distance movement axis calculated acceleration and deceleration is less than the lower limit of 30 and 750 respectively, then function block shows "Acceleration Value too Low" and "Deceleration Value too Low" respectively and there is no axis movement.

Strict Optimized Mode with Approach Point

For axis movement, the Strict Optimized Mode with approach point is selected when `i_byAxisMovSel` input is 4. In this mode, if the short distance movement axis calculated acceleration and deceleration is less than the lower limit of 30 and 750 respectively, then function block shows "Acceleration Value too Low" and "Deceleration Value too Low" respectively and there is no axis movement.

Optimized Mode with Approach Point

For axis movement, the Optimized Mode with approach point is selected when `i_byAxisMovSel` input is 3. In this mode, if the short distance movement axis calculated acceleration and deceleration is less than the lower limit of 30 and 750 respectively, then acceleration and deceleration of the long distance movement axis is increased accordingly to achieve a straight line trajectory. During this, the Alert message "Auto Correction ON" is ON.

NOTE: All calculations are done before the movement of the axis and the mode selection must be done before the axis starts to move.

Function Block Operation: Semi-Auto Mode

Description

In Semi-Automatic mode (`i_xAutoMode=FALSE`), after enabling `i_xEn` input, the function block is activated and the structure parameters are validated. After enabling the function block, the first rising edge of the `i_xExe` input moves the axis to `XYPara.diPosStrtX` and `XYPara.diPosStrtY`.

Approach Distance

If the approach distance is greater or equal to the target position, then the rising edge of `i_xExe` moves the axis to the target positions with `XYPara.udiApprVel`, `XYPara.udiApprAcc` and `XYPara.udiApprDec` from the start position.

If the approach distance is less than the target position then the rising edge of `i_xExe` moves the axis to the target positions with `XYPara.udiTrgtVel`, `XYPara.udiTrgtAcc` and `XYPara.udiTrgtDec` from the start position.

When the axis is at the end position, the rising edge of `i_xExe` moves the axis to `XYPara.diPosStrtX` and `XYPara.diPosStrtY`.

NOTE: Movement from the start position to the end position or vice versa happens only on the rising edge of `i_xExe` input.

NOTE: Improper setup of acceleration, deceleration, speed parameters, or the approach point is too close to the target position may cause a position overshoot.

WARNING


TARGET POSITION OVERSHOOT

Verify and validate that the parameters of acceleration, deceleration, speed and approach distance are correct before executing the function.

Failure to follow these instructions can result in death, serious injury, or equipment damage.

Timing Chart

This figure shows a timing chart in the Semi-Auto mode:



Function Block Operation: Auto Mode

Description

In Automatic mode (`i_xAutoMode = TRUE`), after enabling `i_xEn` input, the function block is activated and the structure parameters are validated. In Auto mode, `i_xExe` input must be `TRUE`. After enabling the function block, the first rising edge of the `i_xMoveStrt` input moves the axis from any position to `XYPara.diPosStrtX` and `XYPara.diPosStrtY`.

Approach Distance

If the approach distance is greater or equal to the target position then a rising edge of `i_xMoveStrt` moves the axis to the target positions with `XYPara.udiApprVel`, `XYPara.udiApprAcc` and `XYPara.udiApprDec` from the start position.

If the approach distance is less than the target position then a rising edge of `i_xMoveStrt` moves the axis to the target positions with `XYPara.udiTrgtVel`, `XYPara.udiTrgtAcc` and `XYPara.udiTrgtDec` from the start position.

When the axis is at the end position, the rising edge of the `i_xMoveStrt` moves the axis to `XYPara.diPosStrtX` and `XYPara.diPosStrtY`.

NOTE: Movement from the start position to the end position or vice versa happens only on a rising edge of the `i_xMoveStrt` input. During this movement, the `i_xExe` input must be `TRUE`.

NOTE: When `i_xExe` is `FALSE` while the axis is in motion, the axis stops after completing the current operation.

NOTE: Improper setup or cabling may cause unintended equipment action.

WARNING


UNINTENDED EQUIPMENT OPERATION

Verify that all configuration parameters are correct and validate cabling before commissioning.

Failure to follow these instructions can result in death, serious injury, or equipment damage.

Timing Chart

This figure shows a timing chart in Auto mode:



Section 3.4

Pin Description

What Is in This Section?

This section contains the following topics:

Topic	Page
Input Pin Description	82
Detailed Input Pin Description	84
Input: <code>i_stXYPara</code>	85
Input: <code>i_stPItPara</code>	88
Input: <code>i_xShiftFrstY</code>	89
Input: <code>i_uiStepNb</code>	91
Input: <code>i_uiNbLayr</code>	92
Input: <code>i_stXYPara.udiApprDist</code>	93
Input/Output Pin Description	95
Output Pin Description	96

Input Pin Description

Input Pin Description

Input	Data Type	Description
i_xEn	BOOL	TRUE: Enables function block and the parameters are validated. FALSE: Disables function block and all outputs are set to zero. The axis movement is stopped.
i_xExe	BOOL	TRUE: Axis moves to desired position. Rising edge enables the Operating Mode selected. FALSE: If in motion, axis completes the current action and then stops.
i_xAutoMode	BOOL	TRUE: Auto Mode, cycle executes for defined layers. FALSE: Semi-Auto mode.
i_xMoveStrt	BOOL	TRUE: Starts the Pick and Place cycle in Auto mode. Executes on rising edge of input.
i_xShiftFrstY	BOOL	TRUE: Boxes are placed first in Y direction. FALSE: Boxes are placed first in X direction. Refer to box placement (<i>see page 89</i>).
i_xEnStepAdd	BOOL (*)	TRUE: The boxes are shifted by i_iStepNb position NOTE: The functionality is only applicable in Semi-Auto mode.
i_uiStepNb	UINT (*)	Number of boxes to be shifted with reference to the last placed box. Range: $0 \dots (i_stPltPara.uiElemNbX * i_stPltPara.uiElemNbY)$ NOTE: This input is applicable only in Semi-Auto mode and when i_xEnStepAdd input is TRUE.
i_uiNbLayr	UINT	Number of layers to be executed Range: 0...65535 Refer to layer description (<i>see page 92</i>).
i_xCyclNbRst	BOOL	TRUE: Resets the number of layers executed. Reset occurs only when axis is in start position.
i_xBoxCntRst	BOOL	TRUE: Resets the number of box counts. Reset occurs only when axis is in start position.
i_xAlrmRst	BOOL (*)	TRUE: Resets the detected alarm (rising edge)
* Optional according to the application mode		

Input	Data Type	Description
i_byAxisMovSel	BYTE	Mode selection for Axis movement: 0: Non optimized mode without approach point 1: Optimized mode without approach point 2: Strict optimized mode without approach point 3: Optimized mode with approach point. 4: Strict optimized mode with approach point. All calculations are done before movement of axis and mode selection must be done before the axis starts to move.
i_stXYPara	XYPara	Structure for XY parameters
i_stPltPara	PltPara	Structure for pallet parameters
* Optional according to the application mode		

Detailed Input Pin Description

Input: `i_xExe`

Rising edge enables the selected operating mode (Auto / Semi-Auto).

In Auto mode, `i_xExe` must be TRUE for mode operation. If falling edge of `i_xExe` is detected during axis movement, the current operation will be executed and the operation will be stopped.

In Semi-Auto mode, rising edge of `i_xExe` is required in each cycle to move the axis from start position to target position or vice versa.

NOTE: After enabling the function block in Semi-Auto mode, the first `i_xExe` trigger will move the axis to start position.

Input: `i_xMoveStrt`

In Auto mode, if `i_xExe` is TRUE, the function block waits for `i_xMoveStrt` rising edge to move the axis to `i_stXYPara.diPosStrtX` or `i_stXYPara.diPosStrtY`.

NOTE: `i_xMoveStrt` input is not applicable in Semi-Automatic mode. After enabling the function block in Auto mode, the `i_xExe` trigger is required to select the Auto mode and the first `i_xMoveStrt` trigger will move the axis to the start position

Input: i_stXYPara

Input Pin Description

Input	Data Type	Description
diPosStrtX	DINT	Starting point X Range: 0...diPosStrtX < diPosEndX Refer to axis movement figure (see page 87)
diPosStrtY	DINT	Starting point Y Range: 0...diPosStrtY < diPosEndY Refer to axis movement figure (see page 87)
diPosEndX	DINT	Ending point X Range: 0...2147483647 Refer to axis movement figure (see page 87)
diPosEndY	DINT	Ending point Y Range: 0...2147483647 Refer to axis movement figure (see page 87)
udiApprVel	UDINT	Velocity from starting point to approach point Range: 0...3200 units/sec Factory setting: 20 Refer to axis movement figure (see page 93)
udiApprAcc	UDINT	Acceleration from starting point to approach point Range: 30...3000000 units/sec ² Factory setting: 20 Refer to axis movement figure (see page 93)
udiApprDec	UDINT	Deceleration from starting point to approach point Range: 750...3000000 units/sec ² Factory setting: 30 Refer to axis movement figure (see page 93)
udiApprDist	UDINT	Approach distance Range: 0...2147483647 Refer to axis movement figure (see page 87)
udiTrgtVel	UDINT	Velocity from approach point to target point Range: 0...3200 units/sec Factory setting: 20 Refer to axis movement figure (see page 93)
udiTrgtAcc	UDINT	Acceleration from approach point to target point Range: 30...3000000 units/sec ² Factory setting: 30 Only if udiTrgtVel is higher than udiApprVel Refer to axis movement figure (see page 87)
* Optional according to the applicable mode		

Input	Data Type	Description
udiTrgtDec	UDINT	Deceleration from approach point to target point Range: 750...3000000 units/sec ² Factory setting: 750 Refer to axis movement figure (<i>see page 87</i>)
xCyclEnd	BOOL	This pin changes the behavior of cycle count (layer count). If xCyclEnd is FALSE then q_udiCycINbCmpl will be incremented with the last box of the layer on the target position. If xCyclEnd is TRUE then q_udiCycINbCmpl will be incremented with the last box of the layer on the start position. Factory setting: FALSE
* Optional according to the applicable mode		


NOTE: All values for distance, velocity and deceleration/acceleration are depending on the amount of pulses per one motor revolution. According to this the minimum/maximum values are given by the following equations:

Acceleration /*min*/= (30 * Motor pulses per revolution)/60
 Acceleration /*max*/= (3000000 * Motor pulses per revolution)/60
 Deceleration /*min*/= (750 * Motor pulses per revolution)/60
 Deceleration /*max*/= (3000000 * Motor pulses per revolution)/60

NOTE: xCyclEnd input status is only latched into internal bit of function block when box count is 0 (q_uiBoxCnt = 0) and can be considered as initial instantiation of the function block. That means, internal bit is NOT changed during power cycle or disabling of the function block.

Axis Movement

This figure shows axis movement with `udiApprDist`:



NOTE: Improper setup or cabling may cause unintended equipment action.

WARNING

UNINTENDED EQUIPMENT OPERATION

Verify that all configuration parameters are correct and validate cabling before commissioning.

Failure to follow these instructions can result in death, serious injury, or equipment damage.


Input: i_stPitPara

Input Pin Description

Input	Data Type	Description
diShiftX	DINT	Distance of shifting in X direction Range: 0...2147483647 Refer to the pallet parameters in figure below.
diShiftY	DINT	Distance of shifting in Y direction Range: 0...2147483647 Refer to the pallet parameters in figure below.
uiElemNbX	UINT	Total number of boxes in X direction Range: 0...10000 Refer to the pallet parameters in figure below.
uiElemNbY	UINT	Total number of boxes in Y direction Range: 0...10000 Refer to the pallet parameters in figure below.

Pallet Parameters

This figure shows the different pallet parameters:



Input: `i_xShiftFrstY`

Description


The `i_xShiftFrstY` input determines whether the boxes are placed first in Y axis by setting this input to TRUE.

As this prioritization for the Y axis can only be accepted at the beginning of an empty pallet layer, following pre-conditions need to be fulfilled:


1. X and Y axis are at the start (pick) position.
2. The box count of the actual layer is zero (`q_uiBoxCnt = 0`)

After both conditions have been met a rising edge on `i_xExe` is required to enable this setting.


Box placement: X or Y Axis



Box Placement: Y Axis



Box Placement: X Axis




Input: `i_uiStepNb`


Description

The `i_uiStepNb` input refers to the number of positions to be shifted with reference to the last placed box.

Box Placement Without Shifting



Box Placement With Shifting




Input: `i_uiNbLayr`

Description

The `i_uiNbLayr` input refers to the number of layers to be executed.

This figure shows 4 layers:




NOTE: When layer is completed with skipping, an alarm message "Layer completed with skipping" will be displayed. Empty space of the layer can be filled manually.

Input: `i_stXYPara.udiApprDist`

Description

The approach distance is the distance for which the axes will travel with Target Velocity (usually less velocity than the `i_stXYPara.udiApprVel`), Target Acceleration and Target Deceleration.


Target Distance Calculation




Approach With Normal Values

This figure shows normal and high value approach examples:

Normal Approach Deceleration, Normal Approach Velocity & Normal Approach Distance



High Approach Deceleration, High Approach Velocity & Low Approach Distance



Input/Output Pin Description

Input/Output Pin Description

Input/Output	Data Type	Description
iq_stXaxis	SEM_LXM.Axis_Ref_LXM	Servo axis reference structure
iq_stYaxis	SEM_LXM.Axis_Ref_LXM	Servo axis reference structure

Output Pin Description

Output Pin Description

Output	Data Type	Description
q_xEn	BOOL	TRUE: function block enabled If input i_xEn is TRUE, then output q_xEn is TRUE.
q_xBusy	BOOL	TRUE: Axis in accelerating/decelerating phase
q_xPosStrtRchd	BOOL	TRUE: Axis in start point q_xPosStrtRchd output is TRUE when the both X and Y axis are in pick / start position
q_xPosTargRchd	BOOL	TRUE: Axis in target point q_xPosTrgtRchd output will be TRUE when the both X and Y axis are in place / end position
q_udiCyclNbCmpl	UDINT	The number of cycles completed will be incremented on target position if i_stXYPara.xCyclEnd is FALSE. If i_stXYPara.xCyclEnd is TRUE the number of cycles will be incremented on start position. Range: 0...i_uiNbLayer
q_xCyclNbDone	BOOL	TRUE: Number of cycle reached q_xCyclNbDone output is TRUE when all layers are completed in auto mode
q_uiBoxCnt	UINT	Number of boxes placed
q_xAlrm	BOOL	TRUE: Alarm detected Refer to Notifications (see page 97).
q_uiAlrmId	UINT	Alarm ID Range: 0, 1, 11, 12, 30, 101...103, 105...107, 336, 340...349 Refer to Notifications (see page 97).
q_sAlrmMsge	STRING	Notification Refer to Notifications (see page 97).
q_uiAlrtId	UINT	Alert ID Range: 0...9 Refer to Alert messages (see page 97).
q_sAlrtMsge	STRING	Alert message Refer to Alert messages (see page 97).

Notifications

Detected Alarm ID	Notification
0	Okay
1	Internal alarm detected
11	Axis X alarm detected
12	Axis Y alarm detected
30	PLCopen alarm detected
101	Invalid acceleration parameter
102	Invalid deceleration parameter
103	Invalid velocity parameter
107	Invalid approach distance parameter
336	Starting point lies further outside the end point
340	Invalid step number parameter
343	Invalid number of elements in XY
345	Invalid axis movement parameter
348	usr/RPM scaling for both the axes is not same
349	Starting point lies inside the XY pallet

Alert Messages

Alert ID	Alert Message
0	No alert
2	Layer completed with skipping
3	Skip out of bounds
5	Disable and enable function block
6	Verify layer to be stack
7	No optimized mode
8	Auto correct on
9	Auto correction on with acceleration / deceleration limited

Section 3.5

Quick Reference Guide

What Is in This Section?

This section contains the following topics:

Topic	Page
Function Block Visualization	99
Quick Commissioning Procedure	100
Troubleshooting	102

Function Block Visualization

Visualization

This figure shows a visualization of the XYPickAndPlace function block:

XYPickAndPlace

Instance: Main_PRG_PAP.PickAndPlace

	FB INPUTS	XY PARAMETERS
<div style="border: 1px solid gray; padding: 2px; margin-bottom: 2px;">i_xEn</div> <div style="border: 1px solid gray; padding: 2px; margin-bottom: 2px;">SemiAuto i_xAutoMode</div> <div style="border: 1px solid gray; padding: 2px; margin-bottom: 2px;">Direction X i_xShiftFirstY</div> <div style="border: 1px solid gray; padding: 2px; margin-bottom: 2px;">i_xEnStepAdd</div> <div style="border: 1px solid gray; padding: 2px; margin-bottom: 2px;">i_xBoxCntRst</div> <div style="border: 1px solid gray; padding: 2px; margin-bottom: 2px;">i_xCyclNbRst</div> <div style="border: 1px solid gray; padding: 2px; margin-bottom: 2px;">i_stXYPara. xMapPosEn</div> <div style="border: 1px solid gray; padding: 2px; margin-bottom: 2px;">i_stXYPara. xCyclEnd</div> <div style="border: 1px solid gray; padding: 2px; margin-bottom: 2px;">i_xAlmRst</div>	<div style="background-color: #ccccff; padding: 2px; margin-bottom: 2px;">FB INPUTS</div> <div style="border: 1px solid gray; padding: 2px; margin-bottom: 2px;">i_uiStepNb 0</div> <div style="border: 1px solid gray; padding: 2px; margin-bottom: 2px;">i_uiNbLayr 3</div> <div style="border: 1px solid gray; padding: 2px; margin-bottom: 2px;">i_byAxisMovSel 3</div> <div style="background-color: #ccccff; padding: 2px; margin-bottom: 2px;">PALLET PARAMETERS</div> <div style="border: 1px solid gray; padding: 2px; margin-bottom: 2px;">i_stPkPara.udiShiftX 53528 [Units]</div> <div style="border: 1px solid gray; padding: 2px; margin-bottom: 2px;">i_stPkPara.udiShiftY 53528 [Units]</div> <div style="border: 1px solid gray; padding: 2px; margin-bottom: 2px;">i_stPkPara.uiBemNbX 3</div> <div style="border: 1px solid gray; padding: 2px; margin-bottom: 2px;">i_stPkPara.uiBemNbY 3</div> <div style="background-color: #ccccff; padding: 2px; margin-bottom: 2px;">FB OUTPUTS</div> <div style="border: 1px solid gray; padding: 2px; margin-bottom: 2px;">q_xEn</div> <div style="border: 1px solid gray; padding: 2px; margin-bottom: 2px;">q_xBusy</div> <div style="border: 1px solid gray; padding: 2px; margin-bottom: 2px;">q_xPosStrtRchd</div> <div style="border: 1px solid gray; padding: 2px; margin-bottom: 2px;">q_xPosTangRchd</div> <div style="border: 1px solid gray; padding: 2px; margin-bottom: 2px;">q_xCyclNbDone</div> <div style="border: 1px solid gray; padding: 2px; margin-bottom: 2px;">q_uiBoxCnt: 0</div> <div style="border: 1px solid gray; padding: 2px; margin-bottom: 2px;">q_udiCyclNbCmpl: 0</div>	<div style="border: 1px solid gray; padding: 2px; margin-bottom: 2px;">i_stXYPara.diPosStrtX 66813 [Units]</div> <div style="border: 1px solid gray; padding: 2px; margin-bottom: 2px;">i_stXYPara.diPosStrtY 11408 [Units]</div> <div style="border: 1px solid gray; padding: 2px; margin-bottom: 2px;">i_stXYPara.diPosEndX 487013 [Units]</div> <div style="border: 1px solid gray; padding: 2px; margin-bottom: 2px;">i_stXYPara.diPosEndY 223763 [Units]</div> <div style="border: 1px solid gray; padding: 2px; margin-bottom: 2px;">i_stXYPara.udiApprDist 87750 [Units]</div> <div style="border: 1px solid gray; padding: 2px; margin-bottom: 2px;">i_stXYPara.udiApprVel 163840 [Units/sec]</div> <div style="border: 1px solid gray; padding: 2px; margin-bottom: 2px;">i_stXYPara.udiTrgtVel 122880 [Units/sec]</div> <div style="border: 1px solid gray; padding: 2px; margin-bottom: 2px;">i_stXYPara.udiApprAcc 409600 [Units/sec²]</div> <div style="border: 1px solid gray; padding: 2px; margin-bottom: 2px;">i_stXYPara.udiApprDec 204800 [Units/sec²]</div> <div style="border: 1px solid gray; padding: 2px; margin-bottom: 2px;">i_stXYPara.udiTrgtAcc 245760 [Units/sec²]</div> <div style="border: 1px solid gray; padding: 2px; margin-bottom: 2px;">i_stXYPara.udiTrgtDec 204800 [Units/sec²]</div> <div style="border: 1px solid gray; padding: 2px; margin-bottom: 2px;">i_stXYPara.diPosActIX 0 [Units]</div> <div style="border: 1px solid gray; padding: 2px; margin-bottom: 2px;">i_stXYPara.diPosActIY 0 [Units]</div>
<div style="background-color: #00ff00; padding: 5px; display: inline-block; border: 1px solid black;">q_xAlm</div>	<div style="border: 1px solid gray; padding: 2px; margin-bottom: 2px;">q_uiAlmId: 0</div> <div style="border: 1px solid gray; padding: 2px; margin-bottom: 2px;">q_xAlmMsg: 0</div>	<div style="border: 1px solid gray; padding: 2px; margin-bottom: 2px;">q_sAlmMsg: 0</div> <div style="border: 1px solid gray; padding: 2px; margin-bottom: 2px;">q_sAlmMsg: 0</div>

Quick Commissioning Procedure

Process Description

This table describes the quick commissioning procedure for the XYPickAndPlace function block:

Step	Action
1	Add following supporting libraries into the application program: <ul style="list-style-type: none"> ● Packaging Library
2	Configure the axis on CANopen Master.
3	Enter all parameters in controller configuration.
4	Use MC_Power_CAN for powering up the drive. For homing the axis, one MoveJog FB per axis can be used also.
5	Load the XYPickAndPlace function application on the controller.
6	Power on axis.
7	Enter desired parameter and enable the function block. Refer to parametrizing table.
8	Select application mode.
9	Start the application.

Parameterizing

This table lists the input parameters to be entered:

Input	Auto Mode	Semi-Auto Mode
i_xEn	TRUE	TRUE
i_xExe	TRUE	TRUE (Rising Edge)
i_uiNbLayer	2	2
i_xAutoMode	TRUE	FALSE
i_xEnStepAdd	FALSE	FALSE
i_iStepNb	0	0
i_xShiftFrstY	TRUE	FALSE
i_xMoveStrt	TRUE (Rising Edge)	FALSE
i_stXYPara.diPosStrtX	16380	16380
i_stXYPara.diPosStrtY	86100	86100
i_stXYPara.diPosEndX	32760	32760
i_stXYPara.diPosEndY	270600	270600
i_stXYPara.udiApprDist	10000	10000
i_stXYPara.udiApprVel	1000	1000

Input	Auto Mode	Semi-Auto Mode
i_stXYPara.udiApprAcc	3000	3000
i_stXYPara.udiApprDec	4000	4000
i_stXYPara.udiTrgtVel	88	88
i_stXYPara.udiTrgtAcc	2000	2000
i_stXYPara.udiTrgtDec	3000	3000
i_stPltPara.uiElemNbX	4	4
i_stPltPara.uiElemNbY	4	4
i_stPltPara.udiShiftX	8190	8190
i_stPltPara.udiShiftY	24600	24600

NOTE: The above values were tested in laboratory conditions and are for sample only. Appropriate values should be entered as per the actual machine setup.

Troubleshooting

Troubleshooting

This table describes some general issue and their solutions:

Issue	Cause	Solution
Parameter invalid	Function block error detected	<ol style="list-style-type: none"> 1. Remove cause of detected error and acknowledge with input <code>i_xAlrmRst</code>. 2. Reset the function block with <code>i_xEn</code>.
Inputs invalid	The axis movement is stopped and the detected error output is set.	Remove cause of detected error and acknowledge with <code>i_xAlrmRst</code> .
Axis error detected	The axis movement is stopped and the detected error output is set.	<ol style="list-style-type: none"> 1. Remove cause of detected error. 2. Execute the axis reset using <code>MC_Reset</code> function block. 3. Restart the function block.
Although the input <code>i_xShiftFrstY</code> is set to TRUE the boxes continue getting placed in X axis first.	Preconditions for enabling of box placement in Y axis first are not met.	Verify that X and Y axis are at the start (pick) position and the box count is zero (<code>q_uiBoxCnt = 0</code>) and give a rising edge on input <code>i_xExe</code> .
<code>q_uiAlrmID = 1</code>	Internal alarm detected	Restart the function block.
<code>q_uiAlrmID = 11</code>	Alarm detected in X Axis	Verify axis power.
<code>q_uiAlrmID = 12</code>	Alarm detected in Y Axis	Verify axis power.
<code>q_uiAlrmID = 30</code>	PLCopen alarm detected	Reset the function block. Give the power cycle to the controller if a detected error remains.
<code>q_uiAlrmID = 101</code>	Invalid acceleration parameter	Verify that the acceleration parameter is within the specified range.
<code>q_uiAlrmID = 102</code>	Invalid deceleration parameter	Verify that the deceleration parameter is within the specified range.
<code>q_uiAlrmID = 103</code>	Invalid approach distance parameter	Verify that the approach distance parameter is not greater than the distance between pick position and place position.
<code>q_uiAlrmID = 105</code>	Invalid target position parameter	Verify that the end parameter is within the specified range.
<code>q_uiAlrmID = 106</code>	Invalid start position parameter	Verify that the start parameter is within the specified range.

Issue	Cause	Solution
q_uiAlrmID = 107	Invalid approach distance parameter	Verify that the approach distance parameter is not greater than the distance between pick position and place position.
q_uiAlrmID = 336	Invalid starting point	Verify that the starting point is below the target position.
q_uiAlrmID = 340	Invalid step number parameter	Verify that the step number is within the specified range.
q_uiAlrmID = 341	Invalid approach parameter	Verify that the approach parameter is within the specified range.
q_uiAlrmID = 342	Invalid shift boxes parameter	Verify that the shift boxes parameter is within the specified range.
q_uiAlrmID = 343	Invalid number of elements in XY	Verify that the number of elements in XY is within the specified range
q_uiAlrmID = 345	Invalid axis movement parameter	Verify that the axis movement selection parameter is within the specified range.
q_uiAlrmID = 346	Acceleration value too low	Verify the acceleration value and modified as per the axis movement mode selection.
q_uiAlrmID = 347	Deceleration value too low	Verify the deceleration value and modified as per the axis movement mode selection.
q_uiAlrmID = 348	Axis scaling not the same for both axes	Verify that the scaling in terms of drive user units or RPM scaling is the same for both axes.
q_uiAlrmID = 349	Invalid starting point	Verify that the starting point is not placed inside the pallet.

NOTE: The function block is based on the standard PLCopen library, relying mainly on SDO communications of CANopen.

Part III

TensionControl

Purpose of This Part

This part explains the functionality and implementation of the `DigitalTensionControl` and the `AnalogTensionControl` function block in the packaging industry.

What Is in This Part?

This part contains the following chapters:

Chapter	Chapter Name	Page
4	DigitalTensionControl: Controlling Consistent Film Tension Between Two Digital Sensors	107
5	AnalogTensionControl: Controlling Consistent Film Tension Depending on Analog Sensor Feedback	137

Chapter 4

DigitalTensionControl: Controlling Consistent Film Tension Between Two Digital Sensors

Overview

This chapter describes the following function blocks:

- DigitalTensionControlATV
- DigitalTensionControlATV_Motion

What Is in This Chapter?

This chapter contains the following sections:

Section	Topic	Page
4.1	Functional and Machine Overview	108
4.2	Architecture	114
4.3	Function Block Description	118
4.4	Pin Description	120
4.5	Quick Reference Guide	129

Section 4.1

Functional and Machine Overview

What Is in This Section?

This section contains the following topics:

Topic	Page
Functional Overview	109
Machine Overview	111

Functional Overview

Why Use the DigitalTensionControl Function Block?

When the film reel is unwound, there is a possibility of inconsistent speed or tension variation. This would result in variation in tension, shifting of film and film cut.

Solution with the DigitalTensionControl Function Block

The purpose of the function block is to control the consistent film tension by the Altivar slave speed between two digital sensors. The position of the tension arm is controlled and kept constant to maintain constant film tension.

The position of tension arm is known with the help of two digital sensors:

- SensorArmDown
- SensorArmUp

The function block can be used for both modes, namely slave driven through surface roller and slave driven axially.

Applications

The function block is applicable for:


- Horizontal bagging machine
- Vertical bagging machine
- Labeling machine

Design & Realization Constraints and Assumptions

- Normally Diameter calculator requires filter for line speed and roll speed needs to be externally added.
- Speed gradient is in range of 1 to 5000 RPM.
- Diameter calculation is done by the relation $Dact (\%) = Dmin (\%) * (Line Speed (\%) / Motor Speed (\%))$
- Hardware (Sensors) Faults are not considered in the Program
- If the Task cycle time less than 5 ms, the velocity of the Slave axis can not be updated after every scan. In this case, the velocity command to the Slave axis is updated after 3 scans.

NOTE: The tension control function is suitable for a continuous film feeding machine.

Functional View



Machine Overview

Purpose

During the film unwinding operation, the arm tends to go towards the SensorArmDown sensor located at down position (see the machine view figure). The goal of this application function block template is to maintain the tension of the film between two limits, and this is achieved by controlling the position of the tension arm.

Synchronization Process

This application function block provides the synchronization between a slave axis (typically the film roller "machine view figure: motor M1") and a master axis (the pulling film or feeder "machine view figure: motor M2) with the help of digital sensors. Based on digital sensor inputs, the angular velocity will be varied to maintaining the position of the tension arm between the two sensors.


This application function block commands the speed of an axis as slave coupled to a master axis. The master axis can be a physical or virtual axis.

Roll Diameter Control

Since the roll diameter decreases as material unwinds, the linear speed of the film will decrease. Hence, the slave axis needs to speed up to maintain the constant linear speed.


When the SensorArmDown or SensorArmUp is activated, the function block adjusts the angular velocity of the roller to maintain the position of tension arm between the sensors which in turn maintain the film tension.

Machine View



Horizontal Bagging Machine

This figure shows a horizontal bagging machine in which the function block can be used for tension control:



Section 4.2

Architecture


What Is in This Section?

This section contains the following topics:


Topic	Page
Hardware Architecture	115
Software Architecture	117

Hardware Architecture

Hardware Architecture Overview



This figure shows a hardware architecture:



Environment

Based on the axes configuration the `DigitalTensionControlATV` has the following types of architecture:

Master	Slave	Sensor Wiring
Lexium (LXM) on CANopen	Altivar (ATV) on CANopen	to the Logic Controller through a digital input module (embedded, expansion or external)

Based on the axes configuration the `DigitalTensionControlATV_Motion` has the following types of architecture:

Master	Slave	Sensor Wiring
Lexium (LXM) on <ul style="list-style-type: none"> ● CANmotion or ● Sercos 	Altivar (ATV) on CANopen	to the Motion Controller through a digital input module (embedded, expansion or external)

Axial Driven

The slave axis is driven directly from the axis.


Surface Driven

The slave axis is driven directly from the surface.

NOTE: The function block is applicable only for Altivar drives as slave.

Software Architecture

DataFlow Overview



Section 4.3

Function Block Description

DigitalTensionControl Function Blocks

Pin Diagram of DigitalTensionControlATV



Pin Diagram of DigitalTensionControlATV_Motion



Function Block Description

In a packaging process, the packaging system must be equipped with an efficient tension control system to ensure that there is a smooth unwinding of the film reel. There must be constant tension on the film reel when it is unwound. The function block controls the speed of the slave axis, relative to the master axis to maintain the constant tension on the web.

Operating Modes

The function block works in two different modes:

- Slave driven through surface roller
- Slave driven axially

Section 4.4

Pin Description

What Is in This Section?

This section contains the following topics:


Topic	Page
Input Pin Description	121
Input: i_stDiaAct1	123
Input: i_stUnwd	125
Input/Output Pin Description	126
Output Pin Description	127

Input Pin Description

Input Pin Description

Input	Data Type	Description
i_xEn	BOOL	TRUE: Enables function block and parameters are validated FALSE: Disables function block and all outputs are set to zero
i_xSenUp	BOOL	TRUE: Arm up sensor sensed. If the input is active, the arm is at up position. It means that the slave speed is less than the master speed, the slave speed will be increased by the correction factor. Refer to i_dwCycl (see page 122)
i_xSenDown	BOOL	TRUE: Arm down sensor sensed. If the input is active, the arm is at down position. It means that slave speed is more than master speed, slave speed will be decreased by the correction factor. Refer to i_dwCycl (see page 122)
i_rMotRollDia	REAL	Motor roll diameter (surface roller) Range: 1.0...2000.0 mm This parameter will be used only when the surface driven (i_xSurfMode) mode is selected. Refer to film roll setup (see page 122) figure
i_rSpdGdnt	REAL	Speed gradient Range: 1.0...5000.0 RPM Speed Gradient input parameter with which the slave speed will be corrected to maintain the constant tension on the film.
i_dwCycl	DWORD	Task execution time for speed correction Range: 1...1000 ms
i_rLineSpd	REAL	Actual line speed Range: 0.0...DiaAct.i_rLineSpdMax in m/min
i_xSurfMode	BOOL	TRUE: Surface driven FALSE: Axial driven Driven mode must be selected only while function block is disabled. Mode change is not allowed.
i_stDiaAct1	DiaAct	Structure for diameter calculation Refer to i_stDiaAct1 (see page 123) description.
i_stUnwd	Unwd	Structure for unwinder details Refer to i_stUnwd (see page 125) description.

Film Roll Setup



Input: `i_rSpdGdnt`

Slave Axis Speed increase or decrease are calculated based on this value. The Speed correction is done only if the sensor is active for 60 seconds.

Example:

1000 RPM needs to be decreased or increased according the sensor arm position. For details, refer below for `i_dwCycl` description.

Input: `i_dwCycl`

For effective speed correction, this input should be same as the Target cycle time. This parameter decides the speed correction per scan.

Example:

$i_rSpdGdnt = 1000 \text{ RPM}$ and $i_dwCycl = 10 \text{ ms}$, then Speed Correction = $(1000/60000)*10 = 0.166$ revolutions will be added or subtracted from the slave speed.

Input: `i_stDiaAct1`

Description

This structure is used for the diameter calculation.

When the machine is started with a new film roll, its actual diameter needs to be entered in `i_stDiaAct1.rDia` and `i_stDiaAct1.xDiaSet` needs to be set TRUE.

Then initially, the slave will start with the speed as per the entered diameter.

Speed ratio (`i_stDiaAct1.rSpdRto`) is the gearing factor for the slave motor. If gear is not used, set the `i_stDiaAct1.rSpdRto` to 1.0.

NOTE: Whenever the slave speed (actual speed of the drive) is below `i_stDiaAct1.rSpdMin` and actual Line speed is below `i_stDiaAct1.rLineSpdMin`, then the actual diameter calculation will stop.

Mathematical Background

$$\text{Diameter Actual (\%)} = \frac{(\text{Line Speed (\%)} * \text{Minimum Diameter (\%)})}{\text{Un-winder Speed (\%)}}$$

$$\text{Un-winder Speed (rpm)} = \frac{(\text{Speed ratio} * \text{Line Speed (m/min)} * 1000)}{(3.14 * \text{Diameter Actual (mm)})}$$

Example

If the line speed is 50 % (250 m/min) of the maximum speed (500 m/min), the minimum diameter is 10 % (100 mm of the maximum diameter (1000 mm) and the un-winder speed is 40 % (636.94 RPM) of the maximum un-winder speed (1592.35 RPM))

Un-winder speed (Max) = $(1 * 500 * 1000) / (3.14 * 100) = 1592.35 \text{ RPM}$.

Where Speed Ratio = 1, Line Speed (Max) = 500 m/min, Minimum Diameter = (100 mm).

Then the actual diameter value can be calculated as:

Diameter Actual (%) = $(50 * 10) / 40 = 12.5\%$ of the maximum diameter.

Diameter Actual (mm) = $(250) / (3.14 * 636.94) = 0.125 \text{ m} = 125 \text{ mm}$

NOTE: `i_rLineSpdMax` structure parameter is common for surface and axial mode, other structure parameters of `i_stDiaAct1` are used only for the axial driven mode. The reset of the diameter calculation in axial driven mode is mandatory in case the film reel is changed. This will be executed by resetting the internal state machine of the function block by disabling and enabling the function block.

Structured Parameters

Structured Parameter	Data Type	Description
i_rDiaMin	REAL	Minimum diameter value Range: 1.0...i_rDiaMax in mm
i_rDiaMax	REAL	Maximum diameter value Range: 1.0...10000.0 mm
i_xDiaSet	BOOL	TRUE: Set diameter
i_rDia	REAL	Set diameter value Range: i_rDiaMin...i_rDiaMax in mm
i_rSpdMin	REAL	Minimum slave speed to calculate the diameter Range: 1.0...100.0 RPM
i_rLineSpdMin	REAL	Minimum line speed to calculate diameter Range: 1.0...100.0 m/min
i_rLineSpdMax	REAL	Maximum line speed Range: 1.0...1000.0 m/min

NOTE: The axis status of the drives can be read via using PLCopen FB (MC_ReadStatus_ATV & MC_ReadStatus_LXM or MC_ReadStatus). Before starting the machine in axial driven mode, actual diameter value of unwinder roll (i_stDiaAct1.rDia) must be passed to the function block and this value will be accepted only on the rising edge of i_stDiaAct1.xDiaSet.

If the **real diameter** of the roll is **much greater** than the parameter setting **more** material might be unwound after first cycles and film tension may be too low.

If the **real diameter** of the roll is **much smaller** than the parameter setting **less** material might be unwound after first cycles and film tension may be too high.

The film might tear or the tension arm might be pulled by the tightened film into its mechanical end position.

NOTICE

INCORRECT DIAMETER SETTINGS

Be sure that the actual diameter value of the un-winder roll is established (i_stDiaAct1.rDia) before starting the machine in axial driven mode.

Failure to follow these instructions can result in equipment damage.

Input: `i_stUnwd`

Description

This structure is used for setting the following unwinding parameters:

- acceleration time (`i_stUnwd.diAcc`)
- deceleration time (`i_stUnwd.diDec`)
- unwinder minimum diameter (`i_stUnwd.rUnwdDiaMin`) to initiate notification
- time for detecting the film end (`i_stUnwd.dwFilmTimeEnd`) when the sensor arm is down

The speed ratio (`i_rSpdRto`) is the ratio to calculate the slave speed in surface driven mode.

Mathematical Background

$$\text{Un- winder Speed (RPM)} = \frac{\text{Speed Ratio} * \text{Line Speed (m/min)} * 1000}{3.14 * \text{Motor Roll Diameter (mm)}}$$

Structured Parameters

Structured Parameter	Data Type	Description
<code>rSpdRto</code>	REAL	Ratio to calculate to slave speed Range: 0.01...100.0
<code>diAcc</code>	DINT	Acceleration time for the slave Range: 1...6000 Unit: x X Sec Remarks: X scaling factor
<code>diDec</code>	DINT	Deceleration time for the slave Range: 1...6000 Unit: x X Sec Remarks: X scaling factor
<code>rUnwdDiaMin</code>	REAL	Minimum diameter to initiate notification Range: 1.0...300.0 mm
<code>dwFilmTimeEnd</code>	DWORD	Wait time for film end notification Range: 1...10000 ms

NOTE: `i_stUnwd.diAcc` and `i_stUnwd.diDec` scaling factor (X) is in the drive parameter setting. Factory setting is 0.1. If `i_stUnwd.diAcc` is 100 s, then drive interpreted time is 10 s.

Input/Output Pin Description

Input/Output Pins of DigitalTensionControlATV

Input/Output	Data Type	Description
iq_stAxisLxmMstr	SEM_LXM.AXIS_REF_LXM	Servo axis reference structure
iq_stAxisAtvSlav	SE_ATV.Axis_Ref_ATV	ATV axis reference structure

Input/Output Pins of DigitalTensionControlATV_Motion

Input/Output	Data Type	Description
iq_stAxisLxmMstr	SM3_Basic.AXIS_REF_SM3	Servo axis reference structure
iq_stAxisAtvSlav	SE_ATV.Axis_Ref_ATV	ATV axis reference structure

NOTE: The Master's line speed is always interpreted as absolute value. The direction of rotation for the Slave will not be changed by inverting the line speed of the Master.

Output Pin Description

Output Pin Description

Output	Data Type	Description
q_xEn	BOOL	TRUE: Function block enabled. If input i_xEn is TRUE, then output q_xEn is TRUE.
q_xAlrm	BOOL	TRUE: Alarm detected FALSE: No alarm Remark: If true, after resetting detected alarm, rising edge of i_xEn is required to restart the function block.
q_uiAlrmId	UINT	0: Okay >0: Alarm detected Range: 0, 1, 11, 12, 20, 30, 40, 101, 102, 116...127 Refer to detailed Notifications (see page 128) description.
q_xFlmEnd	BOOL	TRUE: Film end Remarks: Film end will trigger a notification. Refer to detailed q_xFlmEnd (see page 127) description.
q_xFlmStat	BOOL	TRUE: Min diameter reminder FALSE: No reminder
q_sAlrmMsge	STRING	Status of function block display Refer to detailed Notifications (see page 128) description.
q_sAlrtMsge	STRING	Alert message display

Output: q_xFlmEnd

If the line speed is above dead band and if down sensor remains sensed for a predefined time (i_stUnwd.dwFlmTimeEnd), then the output (q_xFlmEnd) is set TRUE.

NOTE: DeadBand has a constant value of 1.3 m/min in the function block. When the i_xSenDown is FALSE, the q_sErrMsge will be reset.

Notifications

Detected Alarm ID	Notification
0	Okay
1	Internal alarm detected
11	Master axis alarm detected
12	Slave axis alarm detected
20	Invalid cycle time
30	PLCopen internal alarm detected
40	Incorrect sensor state
101	Invalid acceleration parameter
102	Invalid deceleration parameter
116	Invalid motor roll diameter limit parameter
117	Invalid speed gradient limit parameter
118	Invalid speed ratio value parameter
119	Invalid minimum unwinder diameter parameter
120	Invalid film end time parameter
121	Invalid minimum diameter value parameter
122	Invalid maximum diameter value parameter
123	Invalid set diameter value parameter
124	Invalid minimum unwinder speed value parameter
125	Invalid line speed value parameter
126	Invalid maximum line speed value parameter
127	Invalid minimum line speed value parameter

Alarm Messages

The following alarm message will be displayed as and when required:

"SLAVE POSITIVE FREQ LIMIT REACHED" - When the slave frequency reaches the maximum frequency set in the drive.

"SLAVE MINIMUM FREQ LIMIT REACHED" - When the slave frequency reaches the minimum frequency set in the drive.

"DIAMETER SETTING REQUIRED OR MINIMUM DIAMETER REACHED" - When internal diameter is less than minimum diameter or diameter setting is not done.

Section 4.5

Quick Reference Guide

What Is in This Section?

This section contains the following topics:

Topic	Page
Function Block Visualization	130
Quick Commissioning Procedure	131
Troubleshooting	135

Function Block Visualization

Visualization

This figure shows the HMI visualization for DigitalTensionControl function block:

DigitalTensionControlATV																												
Instance: %s																												
<input type="text" value="i_xEn"/> <input type="text" value="i_xSurfMode (Axial)"/> <input type="text" value="xDiaSet"/>	<table border="1"> <thead> <tr> <th colspan="2">DIAMETER CALCULATIONS</th> </tr> </thead> <tbody> <tr> <td>rDiaMin</td> <td>%s [mm]</td> </tr> <tr> <td>rDiaMax</td> <td>%s [mm]</td> </tr> <tr> <td>rDia</td> <td>%s [mm]</td> </tr> <tr> <td>rLineSpdMax</td> <td>%s [m/min]</td> </tr> <tr> <td>rLineSpdMin</td> <td>%s [m/min]</td> </tr> <tr> <td>rSpdMin</td> <td>%s [RPM]</td> </tr> </tbody> </table>	DIAMETER CALCULATIONS		rDiaMin	%s [mm]	rDiaMax	%s [mm]	rDia	%s [mm]	rLineSpdMax	%s [m/min]	rLineSpdMin	%s [m/min]	rSpdMin	%s [RPM]	<table border="1"> <thead> <tr> <th colspan="2">UNWINDER PARAMETERS</th> </tr> </thead> <tbody> <tr> <td>diAcc</td> <td>%s [xXsec]</td> </tr> <tr> <td>diDec</td> <td>%s [xXsec]</td> </tr> <tr> <td>rSpdRto</td> <td>%s</td> </tr> <tr> <td>rUnwrdDiaMin</td> <td>%s [mm]</td> </tr> <tr> <td>dwFilmTimeEnd</td> <td>%s [ms]</td> </tr> </tbody> </table>	UNWINDER PARAMETERS		diAcc	%s [xXsec]	diDec	%s [xXsec]	rSpdRto	%s	rUnwrdDiaMin	%s [mm]	dwFilmTimeEnd	%s [ms]
DIAMETER CALCULATIONS																												
rDiaMin	%s [mm]																											
rDiaMax	%s [mm]																											
rDia	%s [mm]																											
rLineSpdMax	%s [m/min]																											
rLineSpdMin	%s [m/min]																											
rSpdMin	%s [RPM]																											
UNWINDER PARAMETERS																												
diAcc	%s [xXsec]																											
diDec	%s [xXsec]																											
rSpdRto	%s																											
rUnwrdDiaMin	%s [mm]																											
dwFilmTimeEnd	%s [ms]																											
<table border="1"> <thead> <tr> <th colspan="2">FB INPUTS</th> </tr> </thead> <tbody> <tr> <td>i_rMotRollDia</td> <td>%s [mm]</td> </tr> <tr> <td>i_rSpdGdnt</td> <td>%s</td> </tr> <tr> <td>i_dwCycl</td> <td>%s [ms]</td> </tr> <tr> <td>i_rLineSpd</td> <td>%s 2.1f [m/min]</td> </tr> </tbody> </table>	FB INPUTS		i_rMotRollDia	%s [mm]	i_rSpdGdnt	%s	i_dwCycl	%s [ms]	i_rLineSpd	%s 2.1f [m/min]	<table border="1"> <thead> <tr> <th colspan="2">SENSOR STATUS</th> </tr> </thead> <tbody> <tr> <td>Sensor Up</td> <td><input type="radio"/></td> </tr> <tr> <td>Sensor Down</td> <td><input type="radio"/></td> </tr> </tbody> </table>	SENSOR STATUS		Sensor Up	<input type="radio"/>	Sensor Down	<input type="radio"/>											
FB INPUTS																												
i_rMotRollDia	%s [mm]																											
i_rSpdGdnt	%s																											
i_dwCycl	%s [ms]																											
i_rLineSpd	%s 2.1f [m/min]																											
SENSOR STATUS																												
Sensor Up	<input type="radio"/>																											
Sensor Down	<input type="radio"/>																											
<table border="1"> <thead> <tr> <th colspan="3">FB OUTPUTS</th> </tr> </thead> <tbody> <tr> <td><input type="text" value="q_xEn"/></td> <td><input type="text" value="q_xFilmEnd"/></td> <td><input type="text" value="q_xFilmStat"/></td> </tr> <tr> <td><input type="text" value="q_xAlrm"/></td> <td colspan="2"><input type="text" value="q_sAlrmMsge: %s"/></td> </tr> <tr> <td><input type="text" value="q_uiAlrmId: %s"/></td> <td colspan="2"><input type="text" value="q_sAlrmMsge: %s"/></td> </tr> </tbody> </table>			FB OUTPUTS			<input type="text" value="q_xEn"/>	<input type="text" value="q_xFilmEnd"/>	<input type="text" value="q_xFilmStat"/>	<input type="text" value="q_xAlrm"/>	<input type="text" value="q_sAlrmMsge: %s"/>		<input type="text" value="q_uiAlrmId: %s"/>	<input type="text" value="q_sAlrmMsge: %s"/>															
FB OUTPUTS																												
<input type="text" value="q_xEn"/>	<input type="text" value="q_xFilmEnd"/>	<input type="text" value="q_xFilmStat"/>																										
<input type="text" value="q_xAlrm"/>	<input type="text" value="q_sAlrmMsge: %s"/>																											
<input type="text" value="q_uiAlrmId: %s"/>	<input type="text" value="q_sAlrmMsge: %s"/>																											

NOTE: The calculation of the remaining, actual diameter of the unwinding film reel works sensor-less and based therefore on a mathematical model.

Due to this the following factors describe the limiting effects on reliable results:

- The calculation requires a constant line speed of the film. If the digital tension control function block is operated in intermittent mode no accurate values can be evaluated.
- In addition to a constant line speed a continuous movement of the unwinding Variable Speed Drive (VSD) is necessary. As long as the VSD goes into standstill or a setpoint speed close to 0 Hz (high motor slip on asynchronous machines) during operation is caused to regulate the tension, no appropriate value can be calculated.
- The first calculation of diameter results will be provided after the speed of the VSD has been monitored and averaged over a certain period. How long this period will last depends on the mechanical parameters (film reel diameter plus motor/gearbox configuration) and cannot be given in an absolute time frame in general.

Quick Commissioning Procedure

Commissioning Procedure

This table describes the commissioning procedure for the `DigitalTensionControl` function block:

Step	Action
1	Add the supporting libraries into the application program: <ul style="list-style-type: none"> ● Load the Packaging Library for using the <code>DigitalTensionControl</code> function block in your application.
2	Select the unwinding type: <ul style="list-style-type: none"> ● Surface driven (Surface Drv) ● Axial driven (Axial Drv)
3	Define the different input parameters for the <code>DigitalTensionControl</code> function block from the visualization screen. Refer to: <ul style="list-style-type: none"> ● mandatory inputs (<i>see page 132</i>) and parameter example (<i>see page 133</i>) for surface-driven mode and ● mandatory inputs (<i>see page 132</i>) and parameter example (<i>see page 134</i>) for axial-driven mode.
4	Define the speed of the master and power on the master.
5	Power on the slave drive and enable the <code>DigitalTensionControl</code> block.
6	If axial-driven mode is selected, set the initial diameter by pressing Set Diameter once.
7	Start the master in velocity mode.

Mandatory Inputs in Surface-Driven Mode

The following inputs are mandatory in surface-driven mode:

Input	Description
i_xEn	Enable or disable the function block
i_xSenUp	Sensor arm up sensor is to be connected here.
i_xSenDown	Sensor arm down sensor is to be connected here.
i_rMotRollDia	The motor roll diameter in terms of millimeter
i_rSpdGdnt	The parameter with which the slave speed will be corrected to maintain the constant tension on the Film. Example: i_rSpdGdnt is 1000 RPM and i_dwCycl is 10 ms, then Speed Correction = $(1000 / 60000) * 10 \Rightarrow 0.166$ revolutions will be added to or subtracted from the slave speed as per SensorArmUp or SensorArmDown signal.
i_dwCycl	Target execution time for speed correction
i_rLineSpd	Actual line speed of machine in meters per minute
i_xSurfMode	If TRUE then Surface Driven mode is selected
i_stUnwd.rSpdRto	Ratio to calculate slave speed
i_stUnwd.diAcc	Acceleration time for the slave
i_stUnwd.diDec	Deceleration time for the slave
i_stUnwd.rUnwdDiaMin	Minimum diameter to raise notification
i_stUnwd.dwFilmTimeEnd	Wait time for film end notification
i_stDiaActl.rLineSpdMax	Maximum line speed limit

Mandatory Inputs in Axial-Driven Mode

The following inputs are mandatory in axial-driven mode:

Input	Description
i_xEn	Enable or disable the function block
i_xSenUp	Sensor arm up sensor is to be connected here.
i_xSenDown	Sensor arm down sensor is to be connected here.
i_rSpdGdnt	The parameter with which the slave speed will be corrected to maintain the constant tension on the film
i_dwCycl	Target execution time for speed correction
i_rLineSpd	Actual line speed of machine in meters per minute
i_xSurfMode	If FALSE then Axial Driven mode is selected.

Input	Description
i_stUnwdr.rSpdRto	Ratio to calculate slave speed
i_stUnwd.diAcc	Acceleration time for the slave
i_stUnwd.diDec	Deceleration time for the slave
i_stUnwd.rUnwdDiaMin	Minimum diameter to raise notification
i_stUnwd.dwFilmTimeEnd	Wait time for film end notification
i_stDiaActl.rDiaMin	Minimum diameter value
i_stDiaActl.rDiaMax	Maximum diameter value
i_stDiaActl.xDiaSet	To set the diameter initially
i_stDiaActl.rDia	Set diameter value
i_stDiaActl.rSpdMin	Minimum slave speed to calculate diameter
i_stDiaActl.rLineSpdMin	Minimum line speed to calculate diameter
i_stDiaActl.rLineSpdMax	Maximum line speed limit

Parameter Example for Surface-Driven Mode

This table shows a parameterization example of the function block in surface-driven mode:

Input	Description
i_xEn	TRUE
i_xSenUp	TRUE
i_xSenDown	FALSE
i_rMotRollDia	200.00 mm
i_rSpdGdnt	100.00 RPM
i_dwCycl	10 ms
i_xSurfMode	TRUE
i_stUnwdr.rSpdRto	5
i_stUnwd.diAcc	100 s
i_stUnwd.diDec	100 s
i_stUnwd.rUnwdDiaMin	100.00 mm
i_stUnwd.dwFilmTimeEnd	10000 ms
i_stDiaActl.rLineSpdMax	300.00 m/min
i_stDiaActl.rLineSpdMin	10.00 m/min

NOTE: The above values were tested in laboratory conditions and are for sample only. Appropriate values should be entered as per the actual machine setup.

Parameter Example for Axial-Driven Mode

This table shows a parameterization example of the function block in axial-driven mode:

Input	Description
i_xEn	TRUE
i_xSenUp	TRUE
i_xSenDown	FALSE
i_rMotRollDia	200.00 mm
i_rSpdGdnt	100.00 RPM
i_dwCycl	5 ms
i_xSurfMode	FALSE
i_stUnwd.rSpdRto	5
i_stUnwd.diAcc	100 s
i_stUnwd.diDec	100 s
i_stUnwd.rUnwdDiaMin	100.00 mm
i_stUnwd.dwFilmTimeEnd	10000 ms
i_stDiaActl.rLineSpdMax	300.00 m/min
i_stDiaActl.rLineSpdMin	10.00 m/min
i_stDiaActl.rDiaMin	50.00 mm
i_stDiaActl.rDiaMax	1000.00 mm
i_stDiaActl.rDiaSet	TRUE
i_stDiaActl.rDia	900.00 mm

NOTE: The above values were tested in laboratory conditions and are for sample only. Appropriate values should be entered as per the actual machine setup.

Troubleshooting

Troubleshooting

This table describes some general issues and their solutions:

Issue	Cause	Solution
Error detected at output	Invalid parameter or drive error detected	1. Verify the detected error ID and read the corresponding notification. 2. Restart the function block.
System not responding	Invalid value	Restart the function block.
Slave not responding	Due to CANopen bus traffic / PLCopen function block error detected	Disable the function block, power off master, slave and restart the system.
Slave axis unwinds too much material.	LSP setting is above set point speed	Reduce LSP settings or adjust value to 0.0 Hz.
Slave axis doesn't stop, even if set point frequency is 0.0 Hz.	LSP setting is above set point speed	Reduce LSP settings or adjust value to 0.0 Hz.
	Altivar VSD parameters are not properly set	Verify the Altivar <code>CHCF</code> parameter for the correct setting: command and reference must not be separated.
Slave frequency doesn't follow the master.	Changing of axial/surface driven mode on the fly.	On the fly mode change is not allowed. For accepting the new drive mode, restart the function block again.
<code>q_uiAlrmId = 1</code>	Internal alarm detected	Restart the function block.
<code>q_uiAlrmId = 11</code>	Master axis alarm detected	Verify axis power.
<code>q_uiAlrmId = 12</code>	Slave axis alarm detected	Verify axis power.
<code>q_uiAlrmId = 20</code>	Invalid cycle time	Verify that the <code>i_dwCycl</code> parameter is within the specified range.
<code>q_uiAlrmId = 30</code>	PLCopen alarm detected	Reset the function block. Give the power cycle to the controller if a detected error remains.
<code>q_uiAlrmId = 40</code>	Incorrect sensor state	Verify that the sensor setup parameter is done according to the physical configuration on the machine.
<code>q_uiAlrmId = 101</code>	Invalid acceleration parameter	Verify that the acceleration parameter is within the specified range.
<code>q_uiAlrmId = 102</code>	Invalid deceleration parameter	Verify that the deceleration parameter is within the specified range.
<code>q_uiAlrmId = 116</code>	Invalid motor roll diameter limit parameter	Verify that the <code>i_rMotRollDia</code> parameter is within the specified range.

Issue	Cause	Solution
q_uiAlrmId = 117	Invalid speed gradient limit parameter	Verify that the i_rSpdGdnt parameter is within the specified range.
q_uiAlrmId = 118	Invalid speed ratio value parameter	Verify that the i_stUnWd.rSpdRto parameter is within the specified range.
q_uiAlrmId = 119	Invalid minimum unwinder diameter parameter	Verify that the i_stUnWd.rUnwdDiaMin parameter is within the specified range.
q_uiAlrmId = 120	Invalid film end time parameter	Verify that the i_stUnwd.dwTimeFilmEnd parameter is within the specified range.
q_uiAlrmId = 121	Invalid minimum diameter value parameter	Verify that the i_stDiaActl.rDiaMin parameter is within the specified range.
q_uiAlrmId = 122	Invalid maximum diameter value parameter	Verify that the i_stDiaActl.rDiaMax parameter is within the specified range.
q_uiAlrmId = 123	Invalid Set Diameter value parameter	Verify that the i_stDiaActl.rDia parameter is within the specified range.
q_uiAlrmId = 124	Invalid minimum unwinder speed value parameter	Verify that the i_stDiaActl.rSpdMin parameter is within the specified range.
q_uiAlrmId = 125	Invalid line speed value parameter	Verify that the i_rLineSpd parameter is within the specified range.
q_uiAlrmId = 126	Invalid maximum line speed value limit parameter	Verify that the i_stUnwd.rLineSpdMax parameter is within the specified range.
q_uiAlrmId = 127	Invalid minimum line speed value limit parameter	Verify that the i_stUnwd.rLineSpdMin parameter is within the specified range.

Chapter 5

AnalogTensionControl: Controlling Consistent Film Tension Depending on Analog Sensor Feedback

Overview

This chapter describes the following function blocks:

- AnalogTensionControlATV
- AnalogTensionControlLXM_Motion
- AnalogTensionControlATV_Motion

What Is in This Chapter?

This chapter contains the following sections:

Section	Topic	Page
5.1	Functional and Machine Overview	138
5.2	Architecture	142
5.3	Function Block Description	146
5.4	Pin Description	148
5.5	Quick Reference Guide	153

Section 5.1

Functional and Machine Overview

What Is in This Section?

This section contains the following topics:

Topic	Page
Functional Overview	139
Machine Overview	141

Functional Overview

Functional Description

Analog tension control makes use of an analog sensor to provide tension feedback to the control system. The linear speed of the film is determined by the Master axis. Analog feedback from a film tension sensor is used to adjust the slave axis speed to maintain the desired film tension.

Compatibility

The Function Block is applicable to the following types of packaging machines:

- Vertical bagging machine
- Horizontal bagging machine
- Labeling machine

NOTE: FB_PID is necessary to use with analog tension control applications.

NOTE: Master axis is not controlled by this function block

Solution With the AnalogTensionControl Function Block

The function block controls the velocity of unwinder.


The function block works as a variable gear box between the master and the unwinder. The unwinder axis unwinds the film roll in packaging machines.

FB_PID can be used to take tension sensor feedback and generate the variable gear ratio for this function block.

Design & Realization Constraints and Assumption

1. The configuration of OTB on CANopen is not part of these function blocks. It is assumed that application developer will do the required configuration and read the analog value of tension sensor.
2. It is assumed that application developer will do the scaling of analog value of tension sensor and set point if required.

Functional View




The function block calculates the velocity of a feeder according to the film velocity and the dancer position of the unwinder axis.

Depending on the machine, the motor can be located directly on the shaft of the feeder. This means a large diameter of the roller has a low velocity, whereas a small diameter has a high velocity.

If the diameter of the roller is not measured by using a dedicated sensor in this the average diameter of the roller can be specified. The velocity must be completely regulated using the dancer, from the largest diameter to the smallest diameter.

Machine Overview

Horizontal Bagging Machine



Section 5.2

Architecture

What Is in This Section?


This section contains the following topics:

Topic	Page
Hardware Architecture	143
Software Architecture	145


Hardware Architecture

Hardware Architecture Overview


The figure shows the hardware architecture with a Logic Controller, servo drive and a variable speed drive on CANopen.



The figure shows the hardware architecture with a Motion Controller, servo drive on CANmotion or Sercos and a variable speed drive on CANopen.



The figure shows the hardware architecture with a Motion Controller and servor drives on CANmotion or Sercos.



Hardware Environments

This table describes the architecture types based on the axes configuration of the AnalogTensionControlATV function block:

Master	Slave	Sensor Wiring
Lexium (LXM) on CANopen	Altivar (ATV) on CANopen	to the Logic Controller through an <ul style="list-style-type: none"> ● analog input module (embedded, expansion or external) or <ul style="list-style-type: none"> ● analog input on drives

This table describes the architecture types based on the axis configuration of the AnalogTensionControlATV_Motion function block:

Master	Slave	Sensor Wiring
Lexium (LXM) on <ul style="list-style-type: none"> ● CANmotion or ● Sercos 	Altivar (ATV) on CANopen	to the Motion Controller through an <ul style="list-style-type: none"> ● analog input module (embedded, expansion or external) or <ul style="list-style-type: none"> ● analog input on drives

This table describes the architecture types based on the axis configuration of the AnalogTensionControlLXM_Motion function block:


Master	Slave	Sensor Wiring
Lexium (LXM) on <ul style="list-style-type: none"> ● CANmotion or ● Sercos 	Lexium (LXM) on <ul style="list-style-type: none"> ● CANmotion or ● Sercos 	to the Motion Controller through an <ul style="list-style-type: none"> ● analog input module (embedded, expansion or external) or <ul style="list-style-type: none"> ● analog input on drives

Software Architecture

DataFlow Overview

In analog tension control, actual tension is measured by a tension sensor which is an analog input in the form of voltage (0-10 V) or current (0-20 mA, 4-20 mA).

The function block acts as a variable gear box between master and slave axis.




Section 5.3

Function Block Description

AnalogTensionControl Function Blocks

Pin Diagram of AnalogTensionControlATV



Pin Diagram of AnalogTensionControlATV_Motion



Pin Diagram of AnalogTensionControlLXM_Motion



Function Block Description

During operation, the Slave axis follows the Master according to the calculated gear ratio. If there is any detected parameter error or drive error, then the function block decelerates the Slave axis to stop and indicates the detected error status and error message.

NOTE: If the Gear Ratio is high, there can be unwanted movement in the Slave Axis even if the Master Axis appears to be at standstill. This is due to the nonzero instantaneous feedback values from the Master Axis.

Slave velocity = (master velocity * gear ratio).

Section 5.4

Pin Description

What Is in This Section?

This section contains the following topics:

Topic	Page
Input Pin Description	149
Input/Output Pin Description	151
Output Pin Description	152

Input Pin Description

Input Pin Description

The following table describes the input pin description for AnalogTensionControlATV:

Input	Data Type	Description
i_xEn	BOOL	TRUE: Enables function block and parameters are validated. FALSE: Disables function block and all outputs are set to zero.
i_xCnstGrMode	BOOL	TRUE: Gear ratio = $i_rCnstGr$ FALSE: Gear ratio = $(i_rDeltGr * i_rIputCtrl) + i_rGearOfSt$
i_rIputCtrl	REAL	This pin accepts variable gear ratio. Range: ≤ 0 PID output will be connected to this input.
i_rCnstGr	REAL (*)	Gear ratio between master axis and slave axis when i_xCnstGrMode is TRUE.
i_rDeltGr	REAL	Scaling factor applicable when i_xCnstGrMode is FALSE. $-1 \leq i_rDeltGr < 0$ and $0 < i_rDeltGr \leq 1.0$ Factory setting: 0.1 0.0 is not allowed.
i_rGearOfSt	REAL (*)	Offset factor applicable when i_xCnstGrMode is FALSE. Factory setting: 0.0 Example: If $i_rIputCtrl = 1.5$, $i_rDeltGr = 0.8$ and $i_rGearOfst = 2.0$, then Gear ratio = $(1.5 * 0.8) + 2 = 3.2$
i_diAccLim (AnalogTensionControlATV)	DINT	The acceleration limit is used to limit the acceleration when the control input (i_rIputCtrl) changes according to step function. This will help to reduce stress on the mechanical system of the machine. This parameter is applicable to slave axis. Range: 0...6000 (multiplied by X) Factory setting: 10 X depends on the drive parameter (Inr) of ramp increment (x0.01, x0.1 or x1) Unit: s
i_diDecLim (AnalogTensionControlATV)	DINT	A deceleration ramp or braking ramp can be set independently of one another using ramp-down time. This allows a controlled movement of axis when the control input (i_rIputCtrl) is changed. Range: 0...6000 (multiplied by X) Factory setting: 10 X depends on the drive parameter (Inr) of ramp increment (x0.01, x0.1 or x1) Unit: s $0 < i_rDecLim \leq 6000 \times X \text{ s}$; Factory setting: 100 Unit: RPM/s
* Optional according to applicable mode		

The following table describes the input pin description for motion blocks:

Input	Data Type	Description
i_rAccLim (AnalogTensionControlLXM_Motion)	REAL	The acceleration limit is used to limit the acceleration when the control input (i_rIputCtrl) changes according to step function. This will help to reduce stress on the mechanical system of the machine. This parameter is applicable to slave axis. 0 < i_rAccLim; Factory setting: 100 Unit: RPM/s
i_rDecLim (AnalogTensionControlLXM_Motion)	REAL	A deceleration ramp or braking ramp can be set independently of one another using ramp-down time. This allows a controlled movement of axis when the control input (i_rIputCtrl) is changed. 0 < i_rDecLim; Factory setting: 100 Unit: RPM/s
i_diAccLim (AnalogTensionControlATV_Motion)	DINT	The acceleration limit is used to limit the acceleration when the control input (i_rIputCtrl) changes according to step function. This will help to reduce stress on the mechanical system of the machine. This parameter is applicable to slave axis. Range: 0...6000 (multiplied by X) Factory setting: 10 X depends on the drive parameter (Inr) of ramp increment (x0.01, x0.1 or x1) Unit: s
i_diDecLim (AnalogTensionControlATV_Motion)	DINT	A deceleration ramp or braking ramp can be set independently of one another using ramp-down time. This allows a controlled movement of axis when the control input (i_rIputCtrl) is changed. Range: 0...6000 (multiplied by X) Factory setting: 10 X depends on the drive parameter (Inr) of ramp increment (x0.01, x0.1 or x1) Unit: s

NOTE: i_rIputCtrl, i_rDeltGr and i_rGearOfSt is applicable only when i_xCnstGrMode = FALSE. To reset a detected error, a rising edge of i_xEn is required.

NOTE: i_diAccLim and i_diDecLim scaling factor (X) is in the drive parameter setting. Factory setting is 0.1. In case i_diAccLim is a value of 100, then drive interpreted time is 10.0 s.

NOTE: To change from Auto Gear mode to Fixed Gear mode and vice versa is possible by using the input i_xCnstGrMode.

Input/Output Pin Description

Input/Output Pins of AnalogTensionControlATV

Input/Output	Data Type	Description
iq_stAxisLxmMstr	SEM_LXM.AXIS_REF_LXM	Servo axis reference structure
iq_stAxisAtvSlav	SE_ATV.Axis_Ref_ATV	ATV axis reference structure

NOTE: Both described In/Outputs are mandatory because these inputs link the function block to the controlled axis.

Input/Output Pins of AnalogTensionControlLXM_Motion

Input/Output	Data Type	Description
iq_stAxisLxmMstr	SM3_Basic.AXIS_REF_SM3	Servo axis reference structure
iq_stAxisLxmSlav	SM3_Basic.AXIS_REF_SM3	Servo axis reference structure

Input/Output Pins of AnalogTensionControlATV_Motion

Input/Output	Data Type	Description
iq_stAxisLxmMstr	SM3_Basic.AXIS_REF_SM3	Servo axis reference structure
iq_stAxisAtvSlav	SE_ATV.Axis_Ref_ATV	Servo axis reference structure

NOTE: The Master's line speed is always interpreted as absolute value. The direction of rotation for the Slave will not be changed by inverting the line speed of the Master.

Output Pin Description

Output Pin Description

This table describes the output pins of the AnalogTensionControlATV function block:

Output	Data Type	Description
q_xEn	BOOL	TRUE: function block enabled. If input i_xEn is TRUE, then output q_xEn is TRUE.
q_xBusy	BOOL	TRUE: Function block active and no alarm detected FALSE: Function block disabled or alarm detected
q_xAlrm	BOOL	TRUE: Function block detects alarm FALSE: No alarm detected
q_uiAlrmId	UINT	Notification when detected alarm output is set. Refer to Notification (see page 152).
q_sAlrmMsge	STRING	Notification
q_sAlrtMsge	STRING	Alert message This shows the alert message pertaining to slave axis but does not stop the axis. Alert message 'Slave frequency limit reached'.

NOTE: "Slave Maximum Frequency Reached" alarm is generated as soon as the command frequency goes beyond the nominal frequency of the slave axis.

NOTE: The LSP and HSP of the slave axis should be taken into consideration and modified as per the requirement of the application. It is recommended to set LSP value to 0.0 Hz.

Notifications

This table describes the detected alarm IDs and notifications of the function block:

Detected Alarm ID	Notification
0	Okay
1	Internal alarm detected
11	Master axis alarm detected
12	Slave axis alarm detected
30	PLCopen internal alarm detected
31	PLCopen command aborted
108	Invalid gear ratio parameter
110	Invalid acceleration and deceleration parameter
111	Invalid gear ratio calculation parameter (Only AnalogTensionControlLMX_Motion)
112	Invalid delta gear ratio parameter

Section 5.5

Quick Reference Guide

What Is in This Section?


This section contains the following topics:

Topic	Page
Function Block Visualization	154
Quick Commissioning Procedure	155
Troubleshooting	157

Function Block Visualization

Visualization

This figure shows a visualization for the AnalogTensionControlATV function block:



Quick Commissioning Procedure

Quick Commissioning Procedure

This table describes the steps for configuring the AnalogTensionControlATV function block:

Step	Action
1	Add the Toolbox library into the application program.
2	Load the FB_PID from Toolbox library and AnalogTensionControlATV function block in your application.
3	Verify that each CANopen Manager, Master and Slave axis have different node numbers and same baud rate.
4	Define the different input parameters for the AnalogTensionControlATV function block from SoMachine Visualization screen or from HMI. Refer to: <ul style="list-style-type: none"> parameterizing in fixed gear mode parameterizing in auto gear mode
5	Power on the Master axis and enter its speed.
6	Power on the Slave axis and enable the AnalogTensionControlATV function block.
7	Start the master in velocity mode.

Parameterizing in Fixed Gear Mode

This table describes the applicable parameters in fixed gear mode:

Input	Description	Example
i_xEn	Enables function block	TRUE
i_xCnstGrMode	Enables fixed gear mode	TRUE
i_rCnstGr	Value of fix gear ratio	2.0
i_diAccLim	Value of acceleration	10 Unit: xX sec
i_diDecLim	Value of deceleration	10 Unit: xX sec
iq_stAxisLxmMstr	Specify Master axis in function block	
iq_stAxisAtvSlav	Specify Slave axis in function block	

NOTE: The above values were tested in laboratory conditions and are for illustrative purposes only. Appropriate values should be entered as per the actual machine setup.

Parameterizing in Auto Gear Mode

This table describes the applicable parameter values in fixed gear mode:

Input	Description	Example
i_xEn	Enables function block	TRUE
i_xCnstGrMode	Enables fixed gear mode	FALSE
i_rIputCtrl	Tension sensor feedback	1.0
i_rDeltGr	Value of delta gear	0.2
i_rGearOfst	Value of offset gear ratio	1.00
i_diAccLim	Value of acceleration	10 Unit: xX sec
i_diDecLim	Value of deceleration	10 Unit: xX sec
iq_stAxisLxmMstr	Specify Master axis in function block	
iq_stAxisAtvSlav	Specify Slave axis in function block	

NOTE: The above values were tested in laboratory conditions and are for illustrative purposes only. Appropriate values should be entered as per the actual machine setup.

Troubleshooting

Troubleshooting

This table describes some general issues and their solutions:

Issue	Cause	Solution
Alarm is raised	Invalid parameter or drive alarm detected	Please verify the detected alarm ID and read the corresponding notification.
Slave not responding	Due to CANopen bus traffic / PLCopen function block detected alarm	Disable the function block, switch power off Master, Slave and restart the system.
System not responding	Possible invalid value	Disable and enable the function block.
Slave axis unwinds too much material.	LSP setting is above set point speed	Reduce LSP settings or adjust value to 0.0 Hz.
Slave axis unwinds less material.	HSP setting is below set point speed	Increase HSP setting
Slave axis doesn't stops, even if set point frequency is 0.0 Hz	LSP setting is above set point speed	Reduce LSP settings or adjust value to 0.0 Hz.
	Altivar parameters are not properly set	Verify the Altivar <code>CHCF</code> parameter for the correct setting: command and reference must not be separated.
<code>q_uiAlrmId = 1</code>	Internal alarm detected	Reset the function block.
<code>q_uiAlrmId = 11</code>	Master axis alarm detected	Verify for detected alarm in Master axis.
<code>q_uiAlrmId = 12</code>	Slave axis alarm detected	Verify for alarms in Slave axis.
<code>q_uiAlrmId = 30</code>	PLCopen internal alarm detected	Reset the function block. Give the power cycle to the controller if a detected alarm remains.
<code>q_uiAlrmId = 31</code>	PLCopen command aborted	Reset the axis.
<code>q_uiAlrmId = 108</code>	Invalid variable gear ratio parameter	Verify the parameter <code>i_rIputCtrl</code> is in the specified range.
<code>q_uiAlrmId = 110</code>	Invalid acceleration and deceleration parameter	Verify the parameter <code>i_diAccLim</code> / <code>i_rAccLim</code> and <code>i_diDecLim</code> / <code>i_rDecLim</code> are in the specified range.
<code>q_uiAlrmId = 112</code>	Invalid delta gear ratio parameter.	Verify the parameter <code>i_rDeltGr</code> is in the specified range.

Part IV

TemperatureControl

Purpose of This Part

This part explains the functionality and implementation of the `TemperatureControl` function block in the packaging industry.

What Is in This Part?

This part contains the following chapters:

Chapter	Chapter Name	Page
6	TemperatureControl: Monitoring and Controlling of Temperature-Dependent Packaging Processes	161
7	TemperatureControl_Easy: Monitoring and Simplified Controlling of Temperature-Dependent Packaging Processes	193

Chapter 6

TemperatureControl: Monitoring and Controlling of Temperature-Dependent Packaging Processes

Overview

This chapter explains the functionality and implementation of the `TemperatureControl` function block in the packaging industry.

What Is in This Chapter?

This chapter contains the following sections:

Section	Topic	Page
6.1	Functional and Machine Overview	162
6.2	Architecture	166
6.3	Function Block Description	169
6.4	Pin Description	173
6.5	Quick Reference Guide	187

Section 6.1

Functional and Machine Overview

What Is in This Section?

This section contains the following topics:

Topic	Page
Functional Overview	163
Machine Overview	165

Functional Overview

Why Use the TemperatureControl Function Block?

The Packaging machines require precise temperature control. For more accurate control of temperature, Proportional, Integral and Derivative functions (PID) should be applied.

The TemperatureControl function block incorporates a PID control algorithm for more accurate temperature control in packaging machines.

Solution with the TemperatureControl Function Block

The TemperatureControl function block is equipped with an AutoTuning algorithm to find the initial parameters for PID loop. The temperature can be effectively controlled by the PID control algorithm when the AutoTuning fixes the parameters.

TemperatureControl uses FB_PID to generate the control value. FB_PID is equipped with an anti reset windup which holds the integral component when PID output reaches the maximum limit.


NOTE: The TemperatureControl function block was developed for heating purpose only.

Application

The TemperatureControl function block is applicable to the following machines:


- Horizontal bagging machine
- Vertical bagging machine
- Shrinking machine
- Thermoforming machine

Functional View



Machine Overview

Horizontal Bagging Machine



Section 6.2 Architecture


What Is in This Section?

This section contains the following topics:

Topic	Page
Hardware Architecture	167
Software Architecture	168

Hardware Architecture

Hardware Architecture Overview



Software Architecture

Mathematical Background

The `FB_PID` function block operates according to the transfer function:


$$G(s) = e(s) \times \left(Kp \left(1 + \frac{1}{Tn \times s} + \frac{Tv \times s}{1 + Td \times s} \right) \right)$$

The `SetPointGenerator` generates "SetPoint1" (temperature setting point) and "SetPoint2" (standby set value). Internally it uses a `RampGenerator` to ramp the setpoint.

The `PWM` function block transforms `FB_PID` output into a pulse train with a constant period by modulating the pulse width. Optionally, digital filters are used to reduce the noise in the process value.

The `AutoTuning` function block operates on the Ziegler-Nichols inflectional tangent method. This function block evaluates the process and provides calculated parameters to the `FB_PID` function block.

DataFlow Overview




Section 6.3

Function Block Description

TemperatureControl Function

Pin Diagram



Function Block Description

The TemperatureControl function block is designed for monitoring and controlling a wide variety of temperature dependant processes. It includes the functionality of AutoTuning and the FB_PID function block with anti-reset windup.

The function block has three modes of operation:

- Automatic mode (closed loop with PID control or OnOff control)
- Manual mode (open loop)
- Auto tuning mode

In Automatic mode, the control output is generated by FB_PID.

In Manual mode, the control output is the desired value entered by you.

In Autotuning mode, only the autotuning function is executed and all other function except the filters are disabled.

Temperature Measurement

A thermocouple or a resistance thermometer (for example, Pt100) is used to measure the process temperature. The set value for the `FB_PID` function block is limited by SetPoint high and low value, and it can be ramped optionally. The control output is available in the form of an analog output and a PWM output.

AutoTuning Algorithm

The AutoTuning algorithm is based on the Ziegler-Nichols inflectional tangent method. With this method, the maximum response rate and dead time of the process is calculated. After calculating the time constant, the PID parameters are calculated. There are different monitoring parameters which conditions can be monitored as follows:

- Temperature Low Low
- Temperature Low
- Temperature High High
- Temperature High

Integrated Sub Functions

The TemperatureControl function has the following integrated sub functions:

- **AutoTuning**
- **Digital Filter**
- **PWM**

Auto Tuning

- **Functional Description**

AutoTuning once enabled disables the PID action or output from the Process.


A step signal is applied through AutoTuning the process value will be sampled and checked for the steady state by comparing the process value stability within tolerance limits.

Once the process value reaches the steady state, then the dead time, delay time and the response rate are calculated.

Based on these values the PID parameters are calculated. These PID values calculated through AutoTuning can be accepted / rejected for executing the PID.

- **Time Constant Function**

This figure shows AutoTuning calculating the time constant:



- **PID Parameter Calculation**

The PID parameters K_p , T_n and T_v will be calculated by the conditions measured during autotuning phase.

PID Parameters	Formula
K_p	$0.60 [\text{TimeConstant}/(\text{Dead Time} \cdot K_s)]$
T_n	$1.00 \cdot \text{TimeConstant}$
T_v	$0.50 \cdot \text{TimeConstant}$

Digital Filter


This function incorporates the functionality of digital filter to reduce the noise at the input.

PWM

The internal PWM Heating function generates pulse width modulation output ($q_x\text{Pwm}$) based on the FB_PID output and FB_PID maximum limit.

$$ONTime = \left(\left(\frac{i_{rPidMv}}{i_{rPidValMax}} \right) \times i_{tTimePerd} \right)$$

This figure shows the timing diagram for the PWM Heating function block:



NOTE: If time period = 5 s and PID output is 20 % (PID high limit = 100) then the q_xPwm is high for 1 s and low for 4 s.

Section 6.4

Pin Description

What Is in This Section?

This section contains the following topics:

Topic	Page
Input Pin Description	174
Input: i_stPid	175
Input: i_stTempCtrl	179
Output Pin Description	182
Output: q_sAttnStat	185
Output: q_stPid	186

Input Pin Description

Input Pin Description

Input	Data Type	Description
i_xEn	BOOL (All modes)	TRUE: Enables function block and parameters are validated. FALSE: Disables function block and all outputs are set to zero
i_xExe	BOOL	TRUE: Accepts new input parameters at the rising edge. FALSE: Does not accept new input parameters.
i_xSpSel	BOOL(*) (Auto and Manual modes)	TRUE: Selects i_rSp2 FALSE: Selects i_rSp1
i_rSp1	REAL (Auto and Manual modes)	Value of the actual SetPoint1. The actual setpoint is the temperature that needs to be maintained in the system. Range: i_rLowSp...i_rHighSp Factory setting: 0.0 user temperature unit
i_rSp2	REAL(*) (Auto and Manual modes)	Value of SetPoint 2 in standby mode. The standby setpoint is used to reduce the temperature of the system when the actual temperature control operation is not running. Range: i_rLowSp...i_rSp1 Factory setting: 0.0 user temperature unit
i_rPv	REAL (Auto and Manual modes)	Temperature value from the process. Range: 0.0 .. 3.4 e ⁺³⁸
i_xAlrmRst	BOOL (Auto and Manual modes)	This pin is used to reset the detected errors. To perform the reset you have to change the parameter value which caused the detected error and then initiate a rising edge at this pin. After reset, the rising edge of i_xExe is not required to accept the parameter change. TRUE: Detected error is reset on rising edge FALSE: Detected error is not reset
i_stTempCtrl	stTempCtrl	Includes various parameters needed for temperature control Refer to i_stTempCtrl (see page 179) table.
i_stPid	PidParameters	Includes all the PID parameters Refer to i_stPid (see page 175) table.
(*) Optional, according to the applicable mode.		

Input: i_stPid**Input: i_stPid**

This structured input consists of PID and AutoTuning parameters. This table describes the input details:

Structure Parameter	Data Type	Description
xHold	BOOL ^(*) (Auto and Manual modes)	TRUE: Holds the FB_PID action. FALSE: Resumes the FB_PID action.
rKp	REAL (Auto mode)	Proportional Gain for heating or hysteresis value if On Off Control is active. Range: 0.0...3.4e ⁺³⁸ Factory setting: 8.0
rTn	REAL (Auto mode)	Integral time for heating Range: 0.0...3.4e ⁺³⁸ s Factory setting:152
rTv	REAL (Auto mode)	Derivative time for heating Range: 0.0...3.4e ⁺³⁸ s Factory setting: 32
rTd	REAL (Auto mode)	Damping time for heating Range: CycleTime...3.4e ⁺³⁸ s Factory setting: 3
xManMode	BOOL ^(*) (Manual mode)	TRUE: Enables Manual mode FALSE: Disables Manual mode
rManVal	REAL ^(*) (Manual mode)	Manual mode PID output Range: 0...rHighLim Factory setting: 0.0
rTargCyclTime	REAL (All modes)	Cycle time of controller Range: 0...60000 ms Factory setting: 20 ms
rLowLim	REAL (Auto and Manual modes)	Low limit of FB_PID output. This value is generally configured to the analog output module specifications. Range: 0.0...less than rHighLim
rHighLim	REAL (Auto and Manual modes)	High limit of FB_PID output. This value is generally configured to the analog output module specifications. Range: Greater than rLowLim...3.4e ⁺³⁸
rInerWdo	REAL (Auto and Manual modes)	Inner window for reduced I-part Range: 0.0...less than rOterwdo
rOterWdo	REAL (Auto and Manual modes)	Outer window for disabling I-part Range: Greater than rInerWdo...3.4e ⁺³⁸

Structure Parameter	Data Type	Description
rDbnd	REAL(*) (Auto mode)	Deadband for detected error and is generally used to make the PID output to settle down. Range: 0.0...100.0 Factory setting: 0.0 NOTE: Any deadband value higher than 0 negatively influences the precision of temperature control.
xAttn	BOOL(*) (Auto tuning mode)	TRUE: Enables AutoTuning FALSE: Disables AutoTuning Range: 0...1
rTnce	REAL	Tolerance value for checking the initial steady state to enter Auto tuning procedure. Range: 0...3.4e ⁺³⁸ Factory setting: 10.0
uiCycl	UINT	Number of cycles to a sample the process value during Auto Tuning Range: 0...65535 Factory setting: 200
xAcptPara	BOOL(*) (Auto tuning mode)	TRUE: Accepts new PID parameters given by AutoTuning. FALSE: No action
xRjctPara	BOOL(*) (Auto tuning mode)	TRUE: Rejects new PID parameters given by AutoTuning. FALSE: No action
xOnOffCtrl	BOOL	TRUE: OnOff control is active. Factory setting: FALSE NOTE: If xOnOffCtrl is TRUE, the rKp parameter become the hysteresis value.
tPwmTimePrd	TIME	In time period for PWM, the heater remains steadily switched on as the process temperature is below the set point temperature. Range: i_stPid.rTarg...4194967295 ms Factory setting: 5 s
rPwmTimeOnMin	REAL	If this pin has been set to at least 1 ms, the binary output will be switched on for at least this time. The controller will still attempt to keep to the defined PWM cycle time, but the minimum rPwnMinOnTime will have priority. Range: 0...4194967295 s Factory setting: 0.0 s
rPwmTimeOnMax	REAL	If this pin has been set to less than tPwmTimePeriod, the binary output will be switched on for at least this time. Range: 0...4194967295 s Factory setting: 5.0 s

(*) Optional, according to the applicable mode.

- r_{Kp} : The proportional term of PID changes the output proportional to process error. The proportional output is adjusted by multiplying the process error with gain K_p . The value of gain is defined at the pin r_{Kp} .
- r_{Tn} : The integral term contribution to PID output is proportional to both the magnitude of process error and duration of process error. Integral term will sum the process error over time (Integrate the process error). The integrated value of process error is divided by integral time. The magnitude of integral output is adjusted by Proportional gain. The value of integral time is defined in variable r_{Tn} .
- r_{Tv} : Derivative term determines the rate of change of process error over time and multiplying it with derivative time is the derivative output. The derivative term output is adjusted by derivative time. The value of derivative time is defined at the pin r_{Tv} .

NOTE: The value of T_d should not be less than `cycletime`. If it is less than `cycletime` then T_d value will be overwritten with the value of `cycletime`. Parameters `uiCycl` or `rTargCyclTime` have an influence on the calculated results of the PID parameters. If parameters `uiCycl` or `rTargCyclTime` will be changed afterwards a new execution of the AutoTuning process is mandatory.

- $r_{InerWdo}$: If the absolute value of the process error is less than $r_{InerWdo}$ then integral calculations are scaled by factor $[ABS(\text{process error value}) / \text{Inner Window}]$. The process error value is the difference between the setpoint and the actual process value. If process error value is greater than $r_{InerWdo}$ and less than $r_{OterWdo}$, normal integral calculations are performed. This window slows down the change in `FB_PID` output caused by integral part. Process error value = Set Point - Process value
- $r_{OterWdo}$: If the absolute value of the process error is greater than $r_{OterWdo}$, integral calculations are stopped and integral output is held at the last value. This prevents the integral part from winding up too high and helps to avoid overshoot and oscillation of the controlled system.

Example: With $r_{InerWdo}=10$ and $r_{OterWdo}=200$.

If Setpoint=250 and Process value=100, then process error value=150 and it is within the range mentioned by window parameters, so normal integral calculation is executed.

If Setpoint=250 and Process value=245, then process error value=5 and it is less than $r_{InerWdo}$, so integral calculation is scaled.

If Setpoint=250 and Process value=30, then process error value=220 which is above $r_{OterWdo}$, so integral calculation is hold with the previous value.

NOTE: The $r_{InerWdo}$ and $r_{OterWdo}$ parameters should not be configured to have the same value. If these parameters values are configured equally, then the FB will generate a configuration error. The corresponding Error ID is 16 and the notification is `INVALID I WINDOW PARAMETER`.


- `i_xAcptPara`, `i_xRjctPara`: These inputs are used to accept or reject the PID parameters calculated by the `AutoTuning` function block. To accept the parameters, you have to enable `i_xAcptPara` followed by a rising edge signal on the `i_xExe` pin. Then the `FB_PID` function block will generate an output based on the new PID parameters. To reject the parameters, enable the `i_xRjctPara` pin followed by the rising edge signal on the `i_xExe` pin. The `FB_PID` function block will generate an output based on the PID parameters provided by the user.

NOTE: Once the parameters are accepted, the `PID` function block uses the new parameters calculated by `Auto Tuning` function block. After this if for any other parameter change, execute rising edge is given then `PID` will use parameters provided through `i_stPid.rKp`, `i_stPid.rTn`, `i_stPid.rTv`.

`xOnOffCtrl`

If `xOnOffCtrl` is true, the `PID` is ignored and the control output of the heater system is based on On Off control. The `Kp` parameter became the hysteresis of On Off control.

An On Off control function acts like a thermostat. If the process is below the setpoint, it closes the output contact, and the heating runs at full power. If the setpoint is reached, the power is set to 0%, i.e. switched off. If the process value now falls, when it goes below the level (setpoint minus switching differential hysteresis), the output will be switched on again.



If a On Off control is operated in a first order process, then the heating is switched on if the actual temperature of the system is less than the setpoint. Since there is only one component to store the heater energy, the temperature will instantly start to rise. If the setpoint is reached, the power is set to 0%, i.e. switched off, and the process value will not go above the setpoint.

Theoretically, the process value instantly starts to fall and after a certain time it will have fallen to the lower switching point.

The heating is switched on again, and the process value starts to rise again. In the first order process, the process value moves within the band defined by the switching differential. The switching frequency is higher and the controlled becomes faster as the hysteresis is set smaller.

Input: i_stTempCtrl**Input: i_stTempCtrl**

This structured input consists of function block parameters other than PID and AutoTuning:

Input	Data Type	Description
rSpHigh	REAL (Auto mode)	High limit for setpoint Range: > rSpLow2...3.4e ⁺³⁸ user temperature unit Factory setting: 0.0 user temperature unit
rSpLow	REAL (Auto mode)	Low limit for setpoint Range: 0.0...rSpHigh user temperature unit Factory setting: 0.0 user temperature unit
xStup	BOOL ^(*) (Manual mode)	TRUE: Enables startup function FALSE: Disables startup function
rStupVal	REAL ^(*) (Manual mode)	Percentage of output to the process when startup function is enabled Range: 0.0...100.0% Factory setting: 0.0 %
tStupTime	TIME ^(*) (Manual mode)	Startup function active for this time Range: 0...4194967295 ms Factory setting: 0 ms
xRampEn	BOOL ^(*) (Auto mode)	TRUE: Enables RampGenerator FALSE: Disables RampGenerator
rRampGdntRise	REAL ^(*) (Auto mode)	Value in temperature units/s of ramping time from a lower value to high value Range: 1.0...i_rSp1 or 1.0...i_rSp2 if i_xSelSp is TRUE. Factory setting: 0.0 degree per second
rRampGdntFall	REAL ^(*) (Auto mode)	Value in temperature units/s of ramping time from a higher value to low value. Range: 1.0...i_rSp1 or 1.0...i_rSp2 if i_xSelSp is TRUE. Factory setting: 0.0 degree per second
rFltrTime	REAL	Filter Time for the Digital Filter (Noise reduction) in ms. If no value is given the filter is not activated. Range: 0.0...3.4e+38 Factory setting: 0.0

Input	Data Type	Description
rTempLow	REAL (Auto and Manual modes)	Low value of temperature in inner band given in user temperature unit. This limit is related to the actual setpoint and represents the delta below the setpoint value. Example: If i_rSp1=100 degree and rTempLow=10 degree then the low temperature limit will be 90 degree. Range: 0.0...rTempLL Factory setting: 10.0
rCnst	REAL	The constant for the Digital Filter (Noise reduction) is without any unit. The filter is deactivated if no value given for rFltrTime. Increasing of rCnst will reduce noise level but will slow down the change rate of the filtered process value. Range: 1.0...3.4e+38 Factory setting: 1.0
rTempLL	REAL (Auto and Manual mode)	Low (LL) value of temperature in outer band given in user temperature unit. This limit is related to the actual setpoint and represents the LL delta below the setpoint value. Example: If i_rSp1=100 degree and rTempLow=20 degree then the low temperature limit will be 80 degree. Range: r_TempLow...3.4e+38 Factory setting: 20.0
rTempHigh	REAL (Auto and Manual mode)	High value of temperature in outer band given in user temperature unit. This limit is related to the actual setpoint and represents the delta above the setpoint value. Example: If i_rSp1=100 degree and rTempHigh=10 degree then the high (HH) temperature limit will be 110 degree. Range: 0.0..rTempHH Factory setting: 10.0
rTempHH	REAL (Auto and Manual mode)	High (HH) value of temperature in outer band given in user temperature unit. This limit is related to the actual setpoint and represents the HH delta above the setpoint value. Example: If i_rSp1=100 degree and rTempHH=20 degree then the high (HH) temperature limit will be 120 degree. Range: rTempHigh...3.4e+38 Factory setting: 20.0

Input	Data Type	Description
xAlrtSel2	BOOL	TRUE: The function block will confirm the value of TempAbsLow and rTempAbsHigh. FALSE: The function block will confirm the value of rTempAbsLow. The value of rTempAbsLow and rTempAbsHigh is Alarm 1 and Alarm 2 in the visualization.
rTempAbsLow	REAL (Auto and Manual mode)	Low value of absolute temperature Range: 0.0...3.4e ⁺³⁸ user temperature unit
rTempAbsHigh	REAL (Auto and Manual mode)	High value of absolute temperature Range: 0.0...3.4e ⁺³⁸ user temperature unit
(*) Optional, according to the applicable mode.		

NOTE: User temperature units can be in Celsius, Fahrenheit, or Kelvin.

rSpHigh, rSpLow

These values decide the range of *i_rSp1*. These values will be decided with the minimum and maximum temperature which can be applied to the process, so that it acts as a safeguard to stop the temperature from increasing or decreasing than the desired limits.

xStup, tStupTime

xStup enables the startup function. When this is enabled the percentage of output mentioned in *rStupVal* is applied to the process till *tStupTime*. This functionality is used at the initial stage to maintain the temperature at lower level before the actual setpoint is effective. During the startup function FB_PID is in manual mode.

rRampGdntRise, rRampGdntFall

These pins are used for RampGenerator function. RampGenerator changes its internal setpoint from any present value at the input of *i_rPv* until the selected setpoint, given by *i_rSp1* or *i_rSp2* is reached. The value is incremented/decremented once per second by *rRampGdntRise* for increasing ramp or *rRampGdntFall* for decreasing ramp.

Ramping functionality is used to increase or decrease the set point gradually so that there will not be sudden increase or decrease in the control value.

Output Pin Description

Output Pin Description

Output	Data Type	Description
q_xEn	BOOL	TRUE: Function block enabled, if input i_xEn is TRUE, then output q_xEn is TRUE.
q_rAna	REAL	Analog form of FB_PID output Range: i_rPidHighLim...i_rPidLowLim Factory setting: 0.0
q_xPwm	BOOL	This is the digital form of FB_PID output TRUE: PWMHeating output high FALSE: PWMHeating output low
q_xAlrm	BOOL	TRUE: Alarm detected in temperature control FALSE: No alarm detected (factory setting)
q_uiAlrtId	UINT	This gives the alert status of TemperatureControl function block and the unique number for alert. Range: [1...10] Factory setting: 0
q_xAlrt	BOOL	TRUE: Presence of alert in temperature control FALSE: No alerts (factory setting)
q_uiAlrmId	UINT	Gives unique notification for detected alarms. Range: [0...340] Factory setting: 0
q_sAlrmMsge	STRING	Displays the notification according to the detected alarm ID.
q_sAlrtMsge	STRING	Displays the alert message according to the alert ID.
q_sAttnStat	STRING	This is the string output which gives the status message of the Auto Tuning process. Refer to structured output q_sAttnStat (<i>see page 185</i>) table. factory setting string: Inactive
q_iAttnStat	INT	This gives the AutoTuning status. Range: 0...8 Factory setting: 0
q_stPid	stNewPmts	This structured input includes the PID parameters calculated by Auto Tuning. Refer to structured output q_stPid (<i>see page 186</i>) table.

Notifications

This structured output provides the detected alarm status of TemperatureControl function block:

Detected Alarm ID	Notification
0	Okay
1	INTERNAL ALARM
20	INVALID CYCLETIME
115	INVALID DEADBAND VALUE
200	INVALID PID PARAMETER
202	INVALID I WINDOW PARAMETER
203	INVALID PID LIMIT PARAM
204	ALL PID PARAMETERS ARE ZERO
300	PWM TIME PERIOD INVALID
301	PWM MINIMUM ONTIME INVALID
302	PWM MAXIMUM ONTIME INVALID
310	RAMP GDNT RISE GREATER THAN SP1 OR SP2 OR EQUAL TO ZERO
311	RAMP GDNT FALL GREATER THAN SP1 OR SP2 OR EQUAL TO ZERO
320	SETPOINT HIGH LIMIT VALUE LESS THAN LOW SETPOINT
322	STARTUP TIME INVALID
323	STARTUP VALUE INVALID
331	TEMP LOWLOW VALUE INVALID
332	TEMP HIGH VALUE INVALID

Alert Messages

This structured output provides the alert status of TemperatureControl function block:

Alert ID	Alert Message
1	SETPOINT1 GREATER THAN HIGH SETPOINT
2	SETPOINT1 LESS THAN LOW SETPOINT
3	SETPOINT2 GREATER THAN SETPOINT1 OR LESS THAN LOW SETPOINT
4	TEMP ABS LOW AND HIGH VALUES INVALID
5	ABSOLUTE TEMPERATURE LOW
6	ABSOLUTE TEMPERATURE HIGH
7	TEMPERATURE LOW LOW
8	TEMPERATURE LOW
9	TEMPERATURE HIGH
10	TEMPERATURE HIGH HIGH
11	STARTUP FUNCTION CANNOT BE ENABLED AT THIS TIME.

Output: q_sAttnStat**Output: q_sAttnStat**

This is the string output which gives the status message of the AutoTuning process:

q_iAttnStat	q_sAttnStat	Description
0	NO ERROR DETECTED	AutoTuning is checking the steady
1	FB ERROR DETECTED AUTOTUNING COULD NOT PROCEED	AutoTuning is not running due to detected FB error
2	CHECKING THE STEADY STATE	AutoTuning is checking the steady state of process before going to apply step output to the process
3	TIME OUT	Process is not in steady state
4	WAIT	AutoTuning is calculating the PID parameters
5	CANCELLED	New steady state not reached
6	READY	AutoTuning has calculated the PID parameters
7	OK	The new PID parameters are accepted by the user
8	PARAMETERS ARE NOT ACCEPTED	The new PID parameters are rejected by the user

NOTE: If the status message is displayed as "CANCELLED" and "TIME OUT", then to restart AutoTuning, you have to disable and enable the FB.

Output: `q_stPid`**Output: `q_stPid`**

This structured output includes the PID parameters calculated by AutoTuning. The structure details are explained in the given table:

Output	Data Type	Description
<code>rKp</code>	REAL	Value of proportional gain calculated by AutoTuning Range: 0.0...3.4e ⁺³⁸ Factory setting: 0.0
<code>rTn</code>	REAL	Value of integral time calculated by AutoTuning Range: 0.0...3.4e ⁺³⁸ Scaling/unit: s Factory setting: 0.0
<code>rTv</code>	REAL	Value of derivative time calculated by AutoTuning Range: 0.0...3.4e ⁺³⁸ Scaling/unit: s Factory setting: 0.0

NOTE: In the event of a detected error, the function block will be initialized. To execute the function block again, correct the detected error and enable `i_xRst`.

Structure elements `i_stPid.uiCycl` or `i_stPid.rTargCyclTime` have an influence on the calculated results of the PID parameters. If parameters `uiCycl` or `rTargCyclTime` will be changed afterwards a new execution of the AutoTuning process is mandatory.

Section 6.5

Quick Reference Guide

What Is in This Section?

This section contains the following topics:

Topic	Page
Function Block Visualization	188
Quick Commissioning Procedure	189
Internal Process Diagram	192

Function Block Visualization

Introduction

In the following figures, you will see the visualization of the function block in the software:

The screenshot displays the 'TemperatureControl' function block interface. At the top, the title 'TemperatureControl' is centered in a green bar, accompanied by a logo on the right. Below the title, the instance name 'Instance:POU.Temp' is shown. The interface is divided into several sections:

- Control Panel (Left):** A vertical stack of buttons including 'Enable', 'Execute', 'SpSel', 'ManualMode', 'Hold', 'Alarm Reset', and 'Adv Para Screen'.
- Setpoints and Constants (Top Middle):** Fields for 'Sp1: 1000.0 Unit', 'Sp2: 600.0 Unit', 'Fv: 0.0 Unit', 'Constant: 0.0', 'Man Value: 0.0', 'FiltTime: 0.0 ms', 'SpHigh: 1500.0 Unit', and 'SpLow: 0.0 Unit'.
- PID Parameters (Top Right):** A section titled 'PID' containing fields for 'PropGain: 8.0', 'LowLim: 0.0', 'IntegTime: 152.0 s', 'HighLim: 200.0', 'DevTime: 32.0 s', and 'CyclTime: 20.0 ms'. It also includes 'DampTime: 3.0 s', 'Accept Param', 'AutoTune', 'Reject Param', and 'PID/On-Off Ctrl' with '2 Alarms'.
- Output and Alarms (Bottom Middle):** Fields for 'PID output: 0.0', 'Pwm', 'Enable Out', 'Alarm', 'Alert', 'AlarmId: 0', 'AlertId: 0', and 'AttnStatId: 0'.
- Auto Tune Parameters (Bottom Right):** Fields for 'PropGain: 0.0', 'DevTime: 0.0 s', and 'IntegTime: 0.0 s'.

The screenshot displays the 'TemperatureControl' function block interface, showing a different set of parameters. The title and instance name are the same as in the previous screenshot.

- Control Panel (Left):** A vertical stack of buttons including 'Enable', 'Execute', 'SpSel', 'ManualMode', 'Hold', 'Alarm Reset', and 'Main Screen'.
- Startup and Ramping Parameters (Top Middle):** Fields for 'InerWdow: 5.0', 'OterWdow: 10.0', 'Alarm1: 20.0 Unit', 'Alarm2: 1000.0 Unit', 'TempLL: 20.0 Unit', 'TempH: 10.0 Unit', 'TempL: 10.0 Unit', and 'TempHt: 20.0 Unit'.
- Startup and Ramping Parameters (Top Right):** Fields for 'SmpCycl: 200', 'Tolerance: 10.0', 'StartupVal: 0.0 %', 'PWMPerd: T#5s', 'StartupTime: T#0ms', 'MinOnTime: 0.0 s', 'RampRise: 1.0 Unit/s', 'MaxOnTime: 5.0 s', 'RampFall: 1.0 Unit/s', and 'DeadBand: 0.0'. It also includes 'En Startup' and 'En Ramping' buttons.
- Output and Alarms (Bottom Middle):** Fields for 'PID output: 0.0', 'Pwm', 'Enable Out', 'Alarm', 'Alert', 'AlarmId: 0', 'AlertId: 0', and 'AttnStatId: 0'.
- Auto Tune Parameters (Bottom Right):** Fields for 'PropGain: 0.0', 'DevTime: 0.0 s', and 'IntegTime: 0.0 s'.

Quick Commissioning Procedure

Commissioning Procedure

This table describes the quick commissioning procedure for the `TemperatureControl` function block:

Step	Action
1	Add the Packaging Library into the application program.
2	Load the <code>TemperatureControl</code> function block in your application.
3	Enter all parameters in the controller configuration.
4	Connect to the function block input <code>i_rPv</code> the variable assigned to the temperature sensor.
5	Connect the function block output <code>q_xPwm</code> to the variable assigned to the heater module.
6	Enable the function block with <code>i_xEn</code> .
7	Enable AutoTuning with parameter <code>i_stPid.xAttn</code> .
8	Accept all new inputs with a rising edge signal on <code>i_xExe</code> .
9	AutoTuning is running. The status must be verified at the output <code>q_iAttnStat</code> and <code>q_sAttnStat</code> .
10	After AutoTuning has calculated the PID parameter (state 6), you have to accept (<code>i_stPid.xAcptPara</code>) or reject (<code>i_stPid.xRjctPara</code>) them, followed by a rising edge signal on the <code>i_xExe</code> pin.
11	Disable the parameter <code>i_stPid.xAttn</code> and <code>i_stPid.xAcptPara</code> .
12	After verification of the Auto Tuning result, use the calculated PID parameter at <code>q_stPid</code> as the input parameter for <code>i_stPid</code> .

NOTE: For commissioning, it is helpful to use the function block visualization and also to create a trace with the parameter `i_rSp1`, `i_rPV`, `q_rAna` and `q_xPwm`.

Parameterizing

This table lists the input parameters to be entered:

Parameter	Example Value
i_xSpSel	FALSE
i_rSp1	145
i_rSp2	120
i_stTempCtrl.xAlrtSel2	TRUE
i_stTempCtrl.rSpHigh	200
i_stTempCtrl.rSpLow	20
i_stTempCtrl.xStup	FALSE
i_stTempCtrl.rStupVal	0
i_stTempCtrl.tStupTime	0
i_stTempCtrl.xRampEn	FALSE
i_stTempCtrl.rRampGdntRise	1
i_stTempCtrl.rRampGdntFall	1
i_stTempCtrl.rFltrTime	0
i_stTempCtrl.rCnst	1
i_stTempCtrl.rTempLow	5
i_stTempCtrl.rTempLL	10
i_stTempCtrl.rTempHigh	5
i_stTempCtrl.rTempHH	10
i_stTempCtrl.rTempAbsLow	10
i_stTempCtrl.rTempAbsHigh	180
i_stPid.xHold	FALSE
i_stPid.xOnOffCtrl	FALSE
i_stPid.rKp	8
i_stPid.rTn	152
i_stPid.rTd	3
i_stPid.xManMode	FALSE
i_stPid.rManVal	0
i_stPid.rTargCyclTime	20
i_stPid.rLowLim	0
i_stPid.rHighLim	100
i_stPid.rInerWdow	0
i_stPid.rOterWdow	0


Parameter	Example Value
<code>i_stPid.rDbnd</code>	0
<code>i_stPid.uiCycl</code>	200
<code>i_stPid.rTnce</code>	10
<code>i_stPid.xAcptPara</code>	FALSE
<code>i_stPid.xRjctPara</code>	FALSE
<code>i_stPid.tPwmTimePrd</code>	10 000
<code>i_stPid.rPwmTimeOnMin</code>	0
<code>i_stPid.rPwmTimeOnMax</code>	10

NOTE: The values above were tested under laboratory conditions and are for illustrative purposes only. Appropriate values should be entered as per the actual machine setup. It is important that the task cycletime is given to `i_stPid.rTargCyclTime`. Otherwise, the calculation of the PID output will be imprecise (I-part).

Internal Process Diagram

Execution Order of TemperatureControl Function Block

This figure shows the execution order of internal functions in TemperatureControl function block:



Chapter 7

TemperatureControl_Easy: Monitoring and Simplified Controlling of Temperature-Dependent Packaging Processes

Overview

This chapter explains the functionality and implementation of the `TemperatureControl_Easy` function block in the packaging industry.

What Is in This Chapter?

This chapter contains the following sections:

Section	Topic	Page
7.1	Functional and Machine Overview	194
7.2	Architecture	198
7.3	Function Block Description	201
7.4	Pin Description	203
7.5	Quick Reference Guide	215

Section 7.1

Functional and Machine Overview

What Is in This Section?

This section contains the following topics:

Topic	Page
Functional Overview	195
Machine Overview	197

Functional Overview

Why Use the TemperatureControl_Easy Function Block?

The packaging machines require precise temperature control. For more accurate control of temperature, proportional, integral, and derivative functions (PID) should be applied.

The TemperatureControl_Easy function block incorporates a PID control algorithm for more accurate temperature control in packaging machines.

Solution with the TemperatureControl_Easy Function Block

TemperatureControl_Easy uses FB_PID to generate the control value. FB_PID is equipped with an anti reset windup which holds the integral component when PID output reaches the maximum limit.


NOTE: The TemperatureControl_Easy function block was developed for heating purpose only.

Application

The TemperatureControl_Easy function block is applicable to the following machines:

- Horizontal bagging machine
- Vertical bagging machine
- Shrinking machine
- Thermoforming machine

Functional View




Machine Overview


Introduction

The TemperatureControl_Easy function block is applicable to the following machines:


Horizontal Bagging Machine



Vertical Bagging Machine



Shrinking Machine



Section 7.2

Architecture


What Is in This Section?

This section contains the following topics:

Topic	Page
Hardware Architecture	199
Software Architecture	200

Hardware Architecture

Hardware Architecture Overview



Software Architecture

Mathematical Background


The `FB_PID` function block, from the Toolbox library (*see SoMachine, Miscellaneous Functions, Toolbox Library Guide*), operates according to the transfer function:

$$G(s) = e(s) \cdot (Kp) + e(s) \cdot (Ki) \left(1 + \frac{1}{Tn \cdot s} \right) + Kp \cdot e(s) \cdot \left(\frac{Tv \cdot s}{1 + Td \cdot s} \right)$$

The `PWM` function block transforms `FB_PID` output into a pulse train with a constant period by modulating the pulse width. Optionally, digital filters are used to reduce the noise in the process value.

The `AutoTuning` function block operates on the relay method. This function block evaluates the process and provides calculated parameters to the `FB_PID` function block.

DataFlow Overview




Section 7.3

Function Block Description

TemperatureControl_Easy Function

Pin Diagram



Function Block Description

The TemperatureControl_Easy function block is designed for monitoring and controlling a wide variety of temperature dependant processes. It includes the functionality of AutoTuning and the FB_PID function block with anti-reset windup.

The function block has three modes of operation:

- Automatic mode (closed loop with PID control)
- Manual mode (open loop)
- AutoTuning mode

In Automatic mode, the control output is generated by FB_PID.

In manual mode, the control output is the desired value entered by you.

In AutoTuning mode, only the AutoTuning function is executed and all other function except the filters are disabled.

Temperature Measurement

A thermocouple or a resistance thermometer (for example, Pt100) is used to measure the process temperature. The set value for the `FB_PID` function block is limited by `SetPoint` high and low value. The control output is available in the form of an analog output and a PWM output.

AutoTuning Algorithm

The `AutoTuning` algorithm is based on the `Relay` method. In this method the process is induced by oscillations. After the completion of three oscillations the `AutoTuning` calculates a set of PID parameters.

Integrated Sub Functions

The `TemperatureControl_Easy` function has the following integrated sub functions:

- **AutoTuning**
- **Digital Filter**
- **PWM**

Section 7.4

Pin Description

What Is in This Section?

This section contains the following topics:

Topic	Page
Input Pin Description	204
Input/Output Pin Description	209
Output Pin Description	212

Input Pin Description

Input Pin Description

Input	Data type	Description
i_xEn	BOOL (All modes)	TRUE: Enables function block and parameters are validated. FALSE: Disables function block and all outputs are set to zero
i_rSp	REAL (Auto and AutoTuning modes)	The SetPoint is the temperature that needs to be maintained by the system. Range: rSpLow ... rSpHigh Factory setting: 0.0 user temperature unit ⁽¹⁾
i_rPv	REAL (Auto and AutoTuning modes)	Temperature value from the process. The process temperature value has to be scaled outside of the function block (for example, by FB_Scaling) ⁽¹⁾ . Range: 0.0.. $3.4 \cdot 10^{38}$
i_xManMode	BOOL (Manual mode)	TRUE: Enables Manual mode FALSE: Disables Manual mode
i_xManVal	REAL (Manual mode)	Manual mode PID output Range: rLowLim ... rHighLim Factory setting: 0.0
i_xRst	BOOL (All modes)	FALSE: Alarm and Alerts were not reset TRUE: Alarm and Alerts are reset on rising edge To perform the reset, modify the parameter which caused the alarm, and then give a rising edge on pin i_xRst.
i_stTempCtrlPara	stTempCtrl_Easy	Includes various parameters needed for temperature control Refer to i_stTempCtrlPara (<i>see page 205</i>) table.
(1) You must use the same unit for the set point (i_rSp) and process value (i_rPv).		

i_stTempCtrlPara

This structured input (using structure `stTempCtrl_Easy`) consists of the following parameters.

Input	Data type	Description
xHold	BOOL	TRUE: Holds the <code>FB_PID</code> action. FALSE: Resumes the <code>FB_PID</code> action.
rHighLim	REAL	High limit of <code>FB_PID</code> output. Range: <code>rLowLim</code> ...100.0% Factory setting: 0.0%
rLowLim	REAL	Low limit of <code>FB_PID</code> output. Range: 0.0%... <code>rHighLim</code> Factory setting: 0.0%
rDbnd	REAL (Auto mode)	Dead band for detected error and is used to make the <code>PID</code> output to settle down. Range: 0.0...100.0 user temperature unit Factory setting: 0.0 user temperature unit NOTE: Any dead band value greater than 0 negatively influences the precision of temperature control.
xAttn	BOOL (AutoTuning mode)	Enables <code>AutoTuning</code> by a rising edge. Going back to FALSE does not stop <code>AutoTuning</code> . Range: Pulse 0...1 Factory setting: FALSE
rPwmTimePeriod	REAL (All modes)	Time period for <code>PWM</code> The Time Period scales the <code>q_rAna</code> to <code>PWM-Output-ON-Time</code> (<code>q_xPwm</code>) Range: 5.0...60.0 s Factory setting: 10.0 s
rSpHigh	REAL (All mode)	High limit for setpoint Range: > <code>rSpLow</code> ... $3.4e^{+38}$ user temperature unit Factory setting: 100.0 user temperature unit
rSpLow	REAL (All mode)	Low limit for setpoint Range: 0.0... <code>rSpHigh</code> user temperature unit Factory setting: 0.0 user temperature unit
rFltrTime	REAL (All modes)	Filter time for the digital filter (Noise reduction) in ms. If no value is given, the filter is not activated. Range: 0.0... $3.4e^{+38}$ ms Factory setting: 0.0 ms

NOTE: The cycle time is calculated internal by the function `SysTimeGetMs`.


NOTE: User temperature units can be in Celsius, Fahrenheit, or Kelvin.

rLowLim, rHighLim

The values at these pins define the range of PID output. These values are configured as per the analog output module specification. The range is 0.0 to 100.0 percent.


rDbnd

The value at this pin gives the limit of the dead band for detected error. This dead band function is used to settle down the PID output.

**rPwmTimePrd**

Example: rPwmTimePrd:=10.0 s, rHighLim:=100.0%, rLowLim:=0.0%, q_rAna:=10.95% (actually)

- PWM Time On: = 1,095 seconds.
- PWM Time Off: = 8,905 seconds.





rSpHigh, rSpLow

These values determine the range of i_rSp . These values are decided with the minimum and maximum temperature which can be applied to the process, so that it stops the temperature from increasing or decreasing then the desired limits.

rFltrTime

If you get a noisy signal of the process value, you have to set the filter time. The filter is active when the filter time is greater than 0.0 ms. When the filter time is set, you get the medium process value for the entered filter time.



Input/Output Pin Description

Input/Output Pin Description

The following table includes the input/output of the function block along with the description.

Structure parameter	Data type	Description
iq_stPid	stPmtsNew_Easy	Includes the PID parameters NOTE: Refer the <code>stPmtsNew_Easy</code> following table.
iq_iCtrlMode	INT	Change the PID parameters: 0= Default Para 1= Manual Para 2= ATR-Para (slow) 3= ATR-Para (medium) 4= ATR-Para (aggressive)

NOTE: ATR= AutoTuning Results (PID-Parameter).

iq_iCtrlMode

Five different control modes can be selected.

Each control mode includes a set of PID parameter (`rKp`, `rTn`, `rTv`, `rTd`)

Value	Control mode	Description
0	Default parameters	<code>rKp:=2.0</code> , <code>rTn:= 200.0</code> , <code>rTv:=0.0</code> , <code>rTd:=0.0</code>
1	Manual mode	You can set parameters, default is the same as control mode 0.
2	Slow control	Conservative variant and reduce the overshoot.
3	Medium control	Medium variant
4	Aggressive control	Aggressive variant reaches faster the set point temperature, but a greater overshoot must be taken into account.

NOTE: After AutoTuning, the calculated parameters are available and control mode 3 is selected automatically.

iq_stPid

This structured input/output (using structure `stPmtsNew_Easy`) consists of PID parameters and is described in the following table:

Structure parameter	Data type	Description
rKp	REAL	Value of proportional gain Range: 0.0...3.4e ⁺³⁸ Factory setting: 2.0
rTn	REAL	Value of integral time Range: 0.0...3.4e ⁺³⁸ s Factory setting: 200 s
rTv	REAL	Value of derivative time Range: 0.0...3.4e ⁺³⁸ s Factory setting: 0.0 s
rTd	REAL	Value of damping time for derivative action Range: CycleTime...3.4e ⁺³⁸ s Factory setting: 0.0 s

NOTE: In runtime, this structure shows the actual set of PID parameter.

rKp

The proportional term of PID changes the output proportional to process error. The proportional output is adjusted by multiplying the process error (difference between setpoint and actual process value) with gain K_p . The value of gain is defined at the pin `rKp`.

rTn

The integral term contribution to PID output is proportional to both the magnitude of process error and duration of process error. Integral term will sum the process error over time (Integrate the process error). The integrated value of process error is divided by integral time. The magnitude of integral output is adjusted by proportional gain. The value of integral time is defined in variable `rTn`.


rTv

Derivative term determines the rate of change of process error over time and multiplying it with derivative time is the derivative output. The derivative term output is adjusted by derivative time. The value of derivative time is defined at the pin `rTv`.

rTd

Damping time reduce the influence of the derivate term proportionally.

NOTE: In systems with dead time (see figure below), rTv and rTd should be 0.0. The value of Td should not be less than cycletime. If it is less than cycletime, then Td value is overwritten with the value of cycletime. If all of these input parameters are configured as zero and if `AutoTuning` has not calculated the values, then the default parameters are set after a reset of the alarm.



Output Pin Description

Output Pin Description

Output	Data type	Description
q_xEn	BOOL	TRUE: Function block enabled, if input i_xEn is TRUE, then output q_xEn is TRUE. FALSE: Function block disabled
q_rAna	REAL	Analog form of FB_PID output or manual value (in manual mode) Range: rLowLim ... rHighLim Factory setting: 0.0
q_xPwm	BOOL	PWM (ON/OFF) signal according to q_rAna TRUE: PWMHeating on FALSE: PWMHeating off
q_xAttnEn	BOOL	FALSE: AutoTuning inactive TRUE: AutoTuning active
q_iAttnStat	INT	This gives the AutoTuning status. Range: 0...4 Factory setting: 0
q_sAttnStat	STRING	This is the string output which gives the status message of the AutoTuning process. Refer to table AutoTuning state. (see page 213) Factory setting string: Tuning inactive
q_xAlrm	BOOL	TRUE: Alarm FALSE: No alarm
q_uiAlrmId	UINT	Gives unique notification for alarms. Range: Refer to table Notifications (see page 213). Factory setting: 0
q_sAlrmMsge	STRING	Displays the notification according to the alarm ID.
q_xAlrt	BOOL	TRUE: Alert FALSE: No alerts
q_uiAlrtId	UINT	Gives unique alert ID for alerts. Range: Refer to table Alert messages (see page 214). Factory setting: 0
q_sAlrtMsge	STRING	Displays the alert message according to the alert ID.
q_stPidPara	ARRAY [0...4] stPmtsNew_Easy	This array of structured PID parameters includes the Default, Manual and by AutoTuning calculated values. Refer to Array of PID Parameters (see page 214) table.

AutoTuning State

This table list the AutoTuning state number and the corresponding message.

State number q_iAttnStat	State message q_sAttnStat	Description
0	Tuning inactive	Only default
1	Tuning in progress	–
2	Tuning completed system OK	AutoTuning is finished and the system comparison detected a balanced system.
3	Tuning completed system is oversized	AutoTuning is finished and the system comparison detected an oversized system. In this case the calculated PID parameter could be not applicable. Then enter manual parameter or do AutoTuning again.
4	Tuning completed system is undersized	AutoTuning is finished and the system comparison detected an undersized system. In this case the calculated PID parameter could be not applicable. Then enter manual parameter or do AutoTuning again.

For further information about system comparison, refer to System comparison after AutoTuning ([see page 219](#)).

Notifications

This table list the possible alarm IDs with the corresponding alarm messages.

Alarm ID q_uiAlrmId	Alarm message q_sAlrmMsge
0	Okay (no alarm)
1	INTERNAL ALARM
20	INVALID CYCLETIME
115	INVALID DEAD BAND VALUE
200	INVALID PID PARAMETER
205	GENERAL ALARM FROM FB_PID
206	PID LOW LIMIT IS EQUAL TO HIGH LIMIT
300	PWM TIME PERIOD INVALID
303	INVALID OUTPUT RANGE
304	OUTPUT LOW LIMIT GREATER THAN HIGH LIMIT
305	INVALID FILTER TIME
320	SETPOINT HIGH LIMIT VALUE LESS THAN LOW SETPOINT

NOTE: In case of alarm, `q_xAlrm` is TRUE. Under this condition, the function block is initialized. To execute the function block again, you have to rectify the alarm and enable `i_xRst`. A new AutoTuning is not required.

Alert Messages

This table lists the possible alert IDs and the corresponding alert messages.

Alert ID <code>q_uiAlrtId</code>	Alert Message <code>q_sAlrtMsge</code>
0	NO ALERT
1	SETPOINT GREATER THAN HIGH SETPOINT
2	SETPOINT LESS THAN LOW SETPOINT
12	PARAMETER MODE HIGH OR LOW--> ONLY 0, 1, 2, 3, 4
15	INVALID MANUAL VALUE: out of range <code>rLowLim</code> ... <code>rHighLim</code>

`q_astPidPara` - Array of PID Parameters

This output array consists of five PID parameter sets (using structure `stPmtsNew_Easy`), including the default parameter [0], manual/user parameter [1] and the calculated parameter (slow [2], medium [3] and aggressive [4]) (*see page 220*) by AutoTuning.

The structure details are explained in the given table:

Structure parameter	Data type	Description
<code>rKp</code>	REAL	Value of proportional gain Range: 0.0...3.4e ⁺³⁸ Factory setting: 2.0
<code>rTn</code>	REAL	Value of integral time Range: 0.0...3.4e ⁺³⁸ s Factory setting: 200 s
<code>rTv</code>	REAL	Value of derivative time Range: 0.0...3.4e ⁺³⁸ s Factory setting: 0.0 s
<code>rTd</code>	REAL	Value of damping time for derivative action Range: CycleTime...3.4e ⁺³⁸ s Factory setting: 0.0 s

NOTE: The necessary retained memory you need for AutoTuning parameters are 80 bytes for each `TemperatureControl_Easy` in your program.

Section 7.5

Quick Reference Guide

What Is in This Section?


This section contains the following topics:

Topic	Page
Function Block Visualization	216
AutoTuning and Starting the TemperatureControl_Easy	217
Manual Tuning	223
Options If You Get Great Overshoot	224
Program Example TemperaturControl_Easy Function Block	226
Troubleshooting	227

Function Block Visualization

Introduction

In the following figure, you see the visualization of the function block in the software:



AutoTuning and Starting the TemperatureControl_Easy

Introduction

The relay method of AutoTuning is implemented. When AutoTuning is enabled, it induces oscillations in the process around the set point. After the completion of three oscillations, AutoTuning calculates a set of PI parameters. Enter T_v and T_d if necessary.

Before Starting AutoTuning or Enable the TemperatureControl_Easy

Step	Action
1	Scale the process value by <code>FB_Scaling</code> (toolbox library (<i>see SoMachine, Miscellaneous Functions, Toolbox Library Guide</i>)). Refer to Program Example (<i>see page 226</i>).
2	Verify the plausibility of the process value (<code>i_rPv</code>). You have to ensure, outside of the <code>TemperatureControl_Easy</code> function block, that the process value is plausible. Result: If the <code>i_rPv</code> value is not plausible, deactivate the <code>TemperatureControl_Easy</code> .
3	Verify the set point high and low limit (default 0.0...100.0 user temperature unit).
4	Enable the <code>TemperatureControl_Easy</code> .

If you use the library visualization and the `TemperatureControl_Easy` is enabled, it shows at the process value the value of `i_rPv` or if filter time is greater than 0.0, it shows the filtered `i_rPv` value.

Start AutoTuning

The set point is the only parameter which is required for AutoTuning. The set point has to be given to input `i_rSp`. Start AutoTuning through the pin `i_stCtrl.xAttn`. The oscillation starts and at the end of the third period, the three sets of PI parameters are calculated. Then AutoTuning is completed.

The PI parameters are calculated based on the different measured times and amplitude of the last period.



The calculated PI parameters were given to the array structure element `q_astPidPara`.

NOTE: The set point for AutoTuning should be close to the future process (working) temperature. You have to take into account that during AutoTuning the process temperature will overshoot to the given set point temperature. The value of the overshoot depends on the system used (heating energy vs. capacity) and you have to evaluate before AutoTuning.

After AutoTuning, the control mode is set to `iq_iCtrlMode=3` (medium) automatically.

Status messages are provided to function block output to inform about AutoTuning. For further information, refer to section Output Pin Description (*see page 213*).

The following two figures show when `AutoTuning` is running and in progress. `AutoTuning` will be running/active after the start command and setpoint value, independent if the setpoint value is above or below the actual process value.



Hysteresis During `AutoTuning`

To avoid that one or more oscillations are skipped due to bounces of the process value, there is a hysteresis value used during `AutoTuning`. The hysteresis is 0.2% of the setpoint value to switch on the heating.

Example:


At a setpoint of 200.0°C, the hysteresis is 0.4°C. The temperature distance must be greater, like 0.5°C (for example, temperature resolution is 0.1°C).

Heating switched on at 199.5°C or less

Heating switched off at 200.0°C or greater


Exemplary Sequence of AutoTuning

After the third oscillation, the three PI parameter sets are calculated and control mode 3 (medium) is set automatically.



System Comparison After AutoTuning

































In parallel to the PI parameter calculation the system is compared. This means that, from the last oscillation, the undershoot value is compared with the overshoot value. Due to the result the system is classified as system OK (balanced), oversized or undersized.






Tuning Completed

You can select between five parameter sets by changing `iq_CtrlMode`. For further information, refer to Input/Output Pin Description ([see page 209](#)).

In `q_astPidPara`, all PID parameter sets (rKp, rTn, rTv and rTd) are in one array:

  <code>q_astPidPara</code>	ARRAY [0..4] OF stN...		
  <code>q_astPidPara[0]</code>	stNewPmts		
 <code>rKp</code>	REAL	2	Default
 <code>rTn</code>	REAL	200	
 <code>rTv</code>	REAL	0	
 <code>rTd</code>	REAL	0	
  <code>q_astPidPara[1]</code>	stNewPmts		
 <code>rKp</code>	REAL	3.75	Manual
 <code>rTn</code>	REAL	68	
 <code>rTv</code>	REAL	0	
 <code>rTd</code>	REAL	0	
  <code>q_astPidPara[2]</code>	stNewPmts		
 <code>rKp</code>	REAL	7.990552	Auto tuning slow
 <code>rTn</code>	REAL	189.3105	
 <code>rTv</code>	REAL	0	
 <code>rTd</code>	REAL	0	
  <code>q_astPidPara[3]</code>	stNewPmts		
 <code>rKp</code>	REAL	4.429833	Auto tuning medium
 <code>rTn</code>	REAL	55.9107	
 <code>rTv</code>	REAL	0	
 <code>rTd</code>	REAL	0	
  <code>q_astPidPara[4]</code>	stNewPmts		
 <code>rKp</code>	REAL	5.906444	Auto tuning aggressive
 <code>rTn</code>	REAL	55.9107	
 <code>rTv</code>	REAL	0	
 <code>rTd</code>	REAL	0	

The three AutoTuning parameter [2], [3], [4], have following effects. This is only an example.




Manual Tuning

Manual Tuning

This procedure describes how to get manual PID parameter.

Step	Action
1	Set $iqCtrlMode = 1$ (Manual Para).
2	Set rTn , rTv , and rTd to 0.0.
3	Increase rKp until the system begins to oscillate.
4	Decrease rKp until the system does not oscillate.
5	Decrease rKp by another few points.
6	Set rTn , beginning with a large value for time, for example 300.0 s (system dependent) and make sure that the system does not oscillate.
7	Decrease rTn until the system is stable and without oscillation. Result: In the figure below a typically correct regulation is shown.




Options If You Get Great Overshoot

Reducing the Size of Overshoot

If after `AutoTuning` the message **Tuning completed System oversized** is displayed, the heating element is oversized.

To reduce the size of an overshoot (if needed), the energy to the heating element can be limited with the input `rHighLim` (part of `i_stTempCtrlPara`; structure `stTempCtrl_Easy`).

The input `rHighLim` limits the output `q_rAna`, which is, in turn, a basis for the PWM output `q_xPwm`.



NOTE: The limitation of the output must fit to the system. The `rHighLim` value must be above the steady state value (in this example ~20%).

Position	Description
AutoTuning	AutoTuning with $r_{HighLim} = 25$ AutoTuning is done with a value of 100 at output q_{rAna} (red line).
Use case A	Limitation with $r_{HighLim} = 25$ After AutoTuning, the output (red line) is limited and the overshoot of the temperature (green line) is small. The overshoot is also small if the start temperature is low. However, to reach the setpoint it takes the greatest amount of time (~4.8 time units) in our example.
Use case B	No limitation with $r_{HighLim} = 100$ Start with low temperature. The PID control is not limited and as a result the overshoot is the highest, but the time to reach the setpoint is the least amount of time (~0.8 time units) in our example.
Use case C	Limitation with $r_{HighLim} = 50$ Start with low temperature. The overshoot and the time (~1.4 time units) to reach the setpoint is somewhere between the use cases A and B.

Troubleshooting

Troubleshooting

This table shows some general issues and their solutions:

Issue	Cause	Possible solution
q_uiAlrmlId = 1	The controller is not supported.	Replace the controller.
q_uiAlrmlId = 20	Cycle time out of the valid range	The function block verifies in which interval it is called. Use a valid cycle time (0.0...10000 ms).
q_uiAlrmlId = 115	Invalid dead band value	Enter a valid value (0.0...100.0 unit).
q_uiAlrmlId = 200	Invalid PID parameter (the parameters are 0.0)	Reset for default values.
q_uiAlrmlId = 205	General alarm from FB_PID	Restart the (i_xEn) TemperatureControl_Easy.
q_uiAlrmlId = 206	PID low limit is equal to high limit	Enter a valid value (high limit have to be greater than low limit).
q_uiAlrmlId = 300	Invalid value or cycle time is greater than PWM time period	Enter a valid value (5.0 ... 60.0 s).
q_uiAlrmlId = 303	Invalid output range.	Enter a valid value (0.0 ... 100.0%).
q_uiAlrmlId = 304	Output low limit greater than high limit.	Enter a valid value.
q_uiAlrmlId = 305	Filter time is active (>0.0) and less than cycle time or filter time is less than 0.0 ms.	Enter a valid value.
q_uiAlrmlId = 320	Set point high limit value less than low set point.	Enter a valid value.
q_uiAlrtId = 1	The set point is greater than the set point high limit.	Enter a valid value.
q_uiAlrtId = 2	The set point is less than the set point low limit.	Enter a valid value.
q_uiAlrtId = 12	The value is less than 0 or greater than 4.	Enter a valid value.
q_uiAlrtId = 15	Manual value is outside range	Enter a valid value (rLowLim ... rHighLim).
q_iAttnStat = 3	AutoTuning was finished and the system comparison (see page 219) detected an inhomogeneous system. The heater could be oversized for the working temperature.	If possible, replace the heater. Or, refer to Options if you get great overshoot (see page 224). Or, enter manual PID parameters (see page 223) control mode 1

Issue	Cause	Possible solution
q_iAttnStat = 4	AutoTuning was finished and the system comparison (see page 219) detected an inhomogeneous system. The heater could be undersized.	Verify if the regulation with the calculated PID parameter is sufficient to the customer needs, or enter manual parameters (see page 223) and use control mode 1.
After AutoTuning the calculated PID parameter sets are not plausible (for example, rKP=300.0, rTn=0.4 s).	Noisy signal of the actual process value.	Set the filter (for example, 1000 ms) and start AutoTuning again.
Noisy process value	Issues between sensor and controller input	Verify the installation. Verify the sensor. Set the digital filter (for example, 1000 ms).
You cannot enter manual PID parameter	An invalid control mode is selected	Enter the control mode 1
Several AutoTuning loops on the same system and set point provides not the same calculated PID parameter.	You have started AutoTuning in different ways (for example, first from a low temperature, second from a high temperature).	Verify if the environment temperature and the system are still the same. NOTE: Parameters could have differences up to 15%.
AutoTuning is running for a long time (>1 h).	The system is slow or undersized.	Monitor with a trace. Stop AutoTuning. Set manual PID parameters.
TemperatureControl_Easy regulation do not fulfill the requirement	Unsuitable setting or disturbance from around the heating system.	Verify the process value if it is noisy. Test the different control modes (2..4). Set manual (control mode 1) or default parameters (control mode 0). Verify that the PWM time period (refer to rPwmTimePrd (see page 206)) fit to system.

Part V

LateralPositionControl

Chapter 8

LateralPositionControl: Controlling Correct Lateral Film Position with Two Digital Sensors

Overview

This chapter describes the `LateralPositionControl` function block.

What Is in This Chapter?

This chapter contains the following sections:

Section	Topic	Page
8.1	Functional and Machine Overview	232
8.2	Architecture	235
8.3	Function Block Description	236
8.4	Pin Description	244
8.5	Quick Reference Guide	248

Section 8.1

Functional and Machine Overview

Functional Overview

Why Use the LateralPositionControl Function Block ?

When the film reel is unwound, there is a possibility of a lateral shift in position due to uneven thickness of the film or inconsistent speed and tension variation.

The function block checks the lateral shift and corrects the film position.

Lateral film position correction is required to:

- Avoid a film break-up,
- Have a constant product quality,
- Help increase the cutting accuracy by keeping the print mark detection under the photo cell.

Solution with the LateralPositionControl Function Block

The function block reads film sensor inputs from the field. It checks the sensors' status and generates control outputs (digital or analog) to command the movement of film to its correct position.

Design & Realization Constraints and Assumptions

Constraints

1. The function block does not consider the inoperable state of sensors; it is assumed that sensors are always in healthy state.
2. The function block allows any change in input parameters, as well as the operating mode on the fly. However any errors caused due to this will not be handled by the function block.

Assumptions

1. Sensor inputs are active high when the sensor is detecting the film directly above/below it..
2. A positive value of `q_rOutputAna` output will move the film leftwards and likewise a negative value of `q_rOutputAna` will move the film rightwards.

Application


In packaging machines `LateralPositionControl` function block verifies the correct lateral position of the film.

The function block is applicable to the following types of packaging machines:


- Vertical bagging machine
- Horizontal bagging machine

Functional View

This figure shows the LateralPositionControl function block generating digital outputs:



This figure shows the LateralPositionControl function block generating analog outputs:




Section 8.2

Architecture

Software Architecture

DataFlow Overview



Section 8.3

Function Block Description

What Is in This Section?

This section contains the following topics:

Topic	Page
LateralPositionControl Function Block	237
Automatic Mode	239
Managing Detected Errors	242

LateralPositionControl Function Block

Pin Diagram



Function Block Description

LateralPositionControl system consists of film position sensors and digital or analog actuators (variable speed drives) to control movement of the film reel.

The function block has two operating modes:

- Automatic
- Manual

The output of the function block can be selected to:

- Digital or
- Analog

NOTE: The operating modes as well as the output modes can be changed on-the-fly.

Manual Inputs

In Manual mode with no detected error, manual input `i_xManLeftMove` is used to control the left movement of the film. Similarly, manual input `i_xManRighMove` is used to control right movement of the film.

NOTE: In Manual mode if both `i_xManRighMove` and `i_xManLeftMove` are TRUE, then `i_xManRighMove` is given priority. In Automatic mode, the manual inputs are ignored and only sensor inputs are taken into account.


Lateral Position of Film

Position sensors feed in the current position of the film reel. Based upon this feedback, the function block activates the digital actuators via digital outputs or the analog actuator (example: Altivar variable speed drive) via analog output through CANopen to correct the lateral position of film.


Position Configuration

The function block support 3 sensor position configurations.

This figure shows symmetrically placed sensors:



This figure shows asymmetrically placed sensors:




Automatic Mode

De-bouncing

In Automatic mode of operation, to avoid the sensor signals bouncing due to film vibration, the signals are continuously monitored for inactivity for a time greater than $i_stCmdPara.dwTimeWait$ before the position correction outputs ($q_xFilmLeftMove$, $q_xFilmRightMove$ or $q_rOputAna$) are activated.

This diagram shows the timing diagram for digital output:



Digital Output

While operating in Automatic mode with digital outputs, film position has to be corrected within `i_stCmdPara.dwTimePosCorr` time. If correction is not achieved, the function block displays timeout alarm. The value of `i_stCmdPara.dwPosCorrTime` must be set greater than zero in Automatic mode.


In Manual mode, the `i_stCmdPara.dwPosCorrTime` value can be set to zero to disable the functionality.

NOTE: The value of the `i_stCmdPara.dwRampTime` must be set greater than zero in Automatic mode. If it is not configured greater than zero, then function block detects an error.

Analog Output

The analog output (`q_rOputAna`) from the function block follows a ramp with `i_stCmdPara.dwRampTime` as the ramp time and `i_stCmdPara.rOputAnaMax` as maximum attainable value. To command left movement, `q_rOputAna` is positive and to command right movement, it is negative.

This timing diagram is for analog output:



Managing Detected Errors

Description

Errors detected inside the function block are displayed at the output pin q_xAlrm .


Additionally, the notification ID will be set at the output pin $q_uiAlrmId$ to indicate the type of error detected.

Detected errors are acknowledged with the falling edge of i_xEn input.

An unacknowledged detected error resets all outputs.


Symmetric Sensor External Error Detected

Both sensors are inactive as shown in the figure below.




Asymmetric Sensor External Error Detected

If both sensors are inactive, so there will be left movement of the film. When the film is moving leftwards and the left sensor signal becomes active without right sensor becoming active first.



If both sensors are inactive, so there will be right movement of the film. When the film is moving rightwards and the right sensor signal becomes active without left sensor becoming active first.



NOTE: The `LateralPositionControl` function block allows changes in control parameters while it is enabled. But it is recommended not to explicitly do so on-the-fly this may result in incorrect operation.

NOTICE

MISFEEDS CAUSING MATERIAL DAMAGE

You must ensure that the sensor placement configuration matches the mechanical system.

Failure to follow these instructions can result in equipment damage.

Section 8.4

Pin Description

What Is in This Section?

This section contains the following topics:

Topic	Page
Input Pin Description	245
Output Pin Description	247

Input Pin Description

Input Pin Description

Input	Data Type	Description
i_xEn	BOOL	TRUE: Enables function block and parameters are validated. FALSE: Disables function block and all outputs are set to zero(factory setting)
i_xAutoMode	BOOL	Selects between Automatic and Manual modes. TRUE: Corrects automatically the lateral position of the film depending upon the feedback from the 2 sensors. FALSE: The adjustment of the film position is achieved through input pins i_xManLeftMove and i_xManRighMove.(factory setting)
i_xSenLeft	BOOL (*)Auto mode	Left sensor Input FALSE: No input TRUE: Active high input from sensor
i_xSenRigh	BOOL (*)Auto mode	Right sensor input TRUE: Active high input from sensor FALSE: No input
i_xManLeftMove	BOOL (*)Manual mode	Manual move command to move the film left without checking the sensor feedback. TRUE: Move left command FALSE: No command
i_xManRighMove	BOOL (*)Manual mode	Manual move command to move the film right without checking the sensor feedback. TRUE: Move right command FALSE: No command
i_stCmdPara	CmdParameter FilmPos	Includes various control parameters for sensor position, output selction and position correction. Refer to the structured input CmdParameterFilmPos (see page 246).
(*)Optional according to the application mode		

Input: CmdParameterFilmPos

This table describes the CmdParameterFilmPos structured input:

Structure Element	Data Type	Description
xOputAnaMode	BOOL	Selects between analog and digital output. TRUE: The function block corrects the film position via an analog output <code>q_rOputAna</code> . FALSE: The function block corrects the film position via digital outputs <code>q_xFilmLeftMove</code> and <code>q_xFilmRightMove</code> .
xSenPosSym	BOOL (*)Auto mode	Selects between the two types of sensor position configuration. TRUE: Sensors placed at both sides of the film. FALSE: Both sensors placed at the same side of the film.
xSenPosLeft	BOOL (*)Auto mode	If <code>xSenPosSym = FALSE</code> , this parameter will select which side of the film sensors are placed. TRUE: Sensors located on left. FALSE: Sensors located on right.
rOputAnaMax	REAL (*)Auto mode	Maximum generated value of the analog output at the function block output <code>q_rOputAna</code> Range: $0.0 \dots 1e^{32}$.
dwTimePosCorr	DWORD (*)Auto mode	Time to correct the position of film. Range: $0 \dots 4294967295$ ms. 0: Functionality is disabled. Not allowed in Auto mode with digital outputs.
dwRampTime	DWORD (*)Auto mode	Represents the time in which <code>q_rOputAna</code> should achieve the maximum analog output. Range: $0 \dots 4294967295$ ms. 0: Functionality is disabled. Not allowed in Auto mode with analog output.
dwTimeWait	DWORD (*)Auto mode	Represents the time in which the sensor signal is inactive to start the position correction. Range: $0 \dots 4294967295$ ms.
(*)Optional according to the application mode		

Output Pin Description

Output Pin Description

Output	Data Type	Description
q_xEn	BOOL	TRUE: Function block enabled if input i_xEn is TRUE, then output q_xEn is TRUE.
q_xFilmLeftMove	BOOL	Output to the left actuator TRUE: ON FALSE: OFF
q_xFilmRightMove	BOOL	Output to the right actuator TRUE: ON FALSE: OFF
q_rOputAna	REAL	Value of analog output. Range: - i_stCmdPara.rOputAnaMax . . . + i_stCmdPara.rOputAnaMax
q_xTmot	BOOL	This pin will be set when operating in Automatic mode with: <ul style="list-style-type: none"> digital outputs and film position is not corrected within the specified time, i_stCmdPara.dwPosCorrTime analog output and the film position is not corrected within the specified ramp time i_stCmdPara.dwRampTime. TRUE: Error detected FALSE: Ok
q_xAlrm	BOOL	Indicates that a detected alarm has occurred inside the block TRUE: Alarm detected FALSE: Ok
q_uiAlrmId	UINT	Displays the notification number when the detected alarm output is set, see table q_uiAlrmId and q_sAlrmMsge.
q_sAlrmMsge	STRING(40)	Displays the function block notification message

Notifications

Detected Alarm ID	Notification	Description
0	Okay	Function block is in healthy state
1	Internal alarm detected	Function block in unknown state
40	External alarm detected	Incorrect state or positioning of sensors
70	Time-out alarm detected	Indicates a timeout when film position is not corrected within the specified time in Automatic mode.
100	Invalid parameter	For example: input parameter values to the function block are out of range.

Section 8.5

Quick Reference Guide

What Is in This Section?


This section contains the following topics:

Topic	Page
Function Block Visualization	249
Quick Commissioning Procedure	250
Commissioning Procedure in Manual Mode	251
Commissioning Procedure in Auto Mode With Symmetric Sensors	252
Commissioning Procedure in Auto Mode and Left Placed Sensors	254
Commissioning Procedure in Auto Mode and Right Placed Sensors	256
Troubleshooting	258

Function Block Visualization

Visualization

This figure shows the visualization of the LateralPositionControl function block:



Quick Commissioning Procedure

Commissioning Procedure Overview

This table explains the procedure on how to configure the `LateralPositionControl` function block:

Step	Action
1	Add the <code>Packaging.library</code> in the library manager.
2	Load the <code>LateralPositionControl</code> function block from <code>Packaging</code> library included in your application.
3	Determine the type of sensor position configuration.
4	Connect the outputs to the corresponding output fields.
5	Perform a sensor input test.
6	Start the system.

Commissioning Procedure in Manual Mode

Running in Manual Mode

To run the `LateralPositionControl` function block in Manual mode, configure the following parameters:

- `i_xEn = TRUE`,
- `i_xAutoMode = FALSE`.

Performing a Right Move

To perform a right move operation make

`i_xManRightMove = TRUE`.

The lateral position of film starts moving to the right side while `i_xManRightMove` is `TRUE`.

When `i_xManRightMove = FALSE`, the movement of lateral position of the film is stopped.

Performing a Left Move

To perform a left move operation make

`i_xManLeftMove = TRUE`.

The lateral position of film starts moving to the left side while `i_xManLeftMove` is `TRUE`.

When `i_xManLeftMove = FALSE`, the movement of lateral position of the film is stopped.

Commissioning Procedure in Auto Mode With Symmetric Sensors

Symmetric sensors configuration with digital output

To execute the function block in symmetric sensors configuration, configure the following parameters:

- `i_stCmdPara.xSenPosSym = TRUE`,
- `i_stCmdPara.xOputAnaMode = FALSE`,
- `i_stCmdPara.dwTimePosCorr = 5000ms`,
- `i_stCmdPara.dwTimeWait = 3000ms`.

This figure shows the visualization for the above configuration:

FB PARAMETERS SETTING	
<code>i_stCmdPara.xOputAnaMode: FALSE</code>	<code>i_stCmdPara.dwTimePosCorr: 5000 ms</code>
<code>i_stCmdPara.xSenPosSym: TRUE</code>	<code>i_stCmdPara.dwTimeWait: 3000 ms</code>
<code>i_stCmdPara.xSenPosLeft: FALSE</code>	

Then enable the function block.

In this configuration, both `i_xSenRigh` and `i_xSenLeft` should be always TRUE . If any of the sensor `i_xSenRigh` or `i_xSenLeft` is FALSE, then after `i_stCmdPara.dwTimeWait` the lateral position of the film is moved to the corresponding side by enabling `q_xFilmLeftMove` or `q_xFilmRighMove`.

Symmetric sensors configuration with analog output

To execute the function block in symmetric sensors configuration, configure the following parameters:

- `i_stCmdPara.xSenPosSym = TRUE`,
- `i_stCmdPara.xOputAnaMode = TRUE`,
- `i_stCmdPara.dwTimeWait = 3000ms`,
- `i_stCmdPara.dwRampTime = 5000ms`,
- `i_stCmdPara.rOputAnaMax = 10.0`.

This figure shows the visualization for the configuration:

FB PARAMETERS SETTING	
i_stCmdPara.xOputAnaMode: TRUE	
i_stCmdPara.xSenPosSym: TRUE	i_stCmdPara.dwTimeWait: 3000 ms
i_stCmdPara.xSenPosLeft: FALSE	i_stCmdPara.dwRampTime: 5000 ms
	i_stCmdPara.rOputAnaMax: 10.00

Then enable the function block.

In this configuration both `i_xSenRigh` and `i_xSenLeft` should be always TRUE. If any of the sensor `i_xSenRigh` or `i_xSenLeft` is FALSE, then after `i_stCmdPara.dwTimeWait` the lateral position of the film is moved to the corresponding side by providing analog output through `q_rOputAna`.

Commissioning Procedure in Auto Mode and Left Placed Sensors

Asymmetric left placed sensors configuration with digital output

To execute the function block in asymmetric left sensors configuration, configure the following parameters:

- `i_stCmdPara.xSenPosSym = FALSE`,
- `i_stCmdPara.xSenPosLeft = TRUE`,
- `i_stCmdPara.dwTimePosCorr = 5000ms`,
- `i_stCmdPara.dwTimeWait = 3000ms`.

This figure shows the visualization for the configuration:

FB PARAMETERS SETTING	
<code>i_stCmdPara.xOputAnaMode: FALSE</code>	<code>i_stCmdPara.dwTimePosCorr: 5000 ms</code>
<code>i_stCmdPara.xSenPosSym: FALSE</code>	<code>i_stCmdPara.dwTimeWait: 3000 ms</code>
<code>i_stCmdPara.xSenPosLeft: TRUE</code>	

Then enable the function block.

In this configuration `i_xSenRight` should be `TRUE` and `i_xSenLeft` should be `FALSE`.

If `i_xSenRight` is `FALSE`, then after `i_stCmdPara.dwTimeWait` function block will enable `q_xFilmLeftMove`. If both the sensors are `TRUE`, then after `i_stCmdPara.dwTimeWait` function block will enable `q_xFilmRightMove`.

Asymmetric left placed sensors configuration with analog output

To execute the function block in asymmetric left placed sensors configuration, configure the following parameters:

- `i_stCmdPara.xSenPosSym = FALSE`,
- `i_stCmdPara.xSenPosLeft = TRUE`,
- `i_stCmdPara.xOputAnaMode = TRUE`,
- `i_stCmdPara.dwTimeWait = 3000ms`.
- `i_stCmdPara.dwRampTime = 5000ms`.
- `i_stCmdPara.rOputAnaMax = 10.0`.

This figure shows the visualization for the configuration:

FB PARAMETERS SETTING	
i_stCmdPara.xOputAnaMode: TRUE	
i_stCmdPara.xSenPosSym: FALSE	i_stCmdPara.dwTimeWait: 3000 ms
i_stCmdPara.xSenPosLeft: TRUE	i_stCmdPara.dwRampTime: 5000 ms
	i_stCmdPara.rOputAnaMax: 10.00

Then enable the function block.

In this configuration `i_xSenRigh` should be TRUE and `i_xSenLeft` should be FALSE.

If `i_xSenRigh` is FALSE, then after `i_stCmdPara.dwTimeWait` function block will provide analog output through `q_rOputAna`. In this case, the value of `q_rOputAna` is positive to move the lateral position of the film in left side.

If both the sensors are TRUE, then function block will provide analog output through `q_rOputAna`.

In this case, the value of `q_rOputAna` is negative to move the lateral position of the film in right side.


Commissioning Procedure in Auto Mode and Right Placed Sensors

Asymmetric right placed sensors configuration with digital output

To execute the function block in asymmetric right placed sensors configuration, configure the following parameters:

- `i_stCmdPara.xSenPosSym = FALSE`,
- `i_stCmdPara.xSenPosLeft = FALSE`,
- `i_stCmdPara.xOputAnaMode = FALSE`,
- `i_stCmdPara.dwTimePosCorr = 5000ms`,
- `i_stCmdPara.dwTimeWait = 3000ms`.

This figure shows the visualization for the configuration:



Then enable the function block.

In this configuration `i_xSenRight` should be TRUE and `i_xSenLeft` should be FALSE.

If `i_xSenRight` is FALSE, then after `i_stCmdPara.dwTimeWait` function block will provide analog output through `q_rOputAna`. In this case, the value of `q_rOputAna` is positive to move the lateral position of the film in left side.

If both the sensors are TRUE, then function block will provide analog output through `q_rOputAna`.

In this case, the value of `q_rOputAna` is negative to move the lateral position of the film in right side.

Asymmetric right placed sensors configuration with analog output

To execute the function block in asymmetric right placed sensors configuration, configure the following parameters:

- `i_stCmdPara.xSenPosSym = FALSE`,
- `i_stCmdPara.xSenPosLeft = FALSE`,
- `i_stCmdPara.xOputAnaMode = TRUE`,
- `i_stCmdPara.dwTimeWait = 3000ms`,
- `i_stCmdPara.dwRampTime = 5000ms`,
- `i_stCmdPara.rOputAnaMax = 10.0`.

This figure shows the visualization for the configuration:

FB PARAMETERS SETTING	
i_stCmdPara.xModeAnaOput: TRUE	
i_stCmdPara.xSenPosSym: FALSE	i_stCmdPara.dwWaitTime: 3000 ms
i_stCmdPara.xSenPosLeft: FALSE	i_stCmdPara.dwRampTime: 5000 ms
	i_stCmdPara.rAnaOputMax: 10.0

Then enable the function block.

In this configuration `i_xSenRight` should be FALSE and `i_xSenLeft` should be TRUE.

If `i_xSenLeft` is FALSE, then after `i_stCmdPara.dwTimeWait` function block will provide analog output through `q_rOputAna`. In this case, the value of `q_rOputAna` is negative to move the lateral position of the film in right side.

If both the sensors are TRUE, then function block will provide analog output through `q_rOputAna`.

In this case, the value of `q_rOputAna` is positive to move the lateral position of the film in left side.

Troubleshooting

Troubleshooting

This table shows some general issues and their solutions:

Issue	Cause	Solution
No sensor feedback	Inoperative sensors	Inoperative sensors will not be detected by the function block. The user must verify that the sensors are always in good condition.
Unpredictable behavior leading to improper position correction	Parameter change on-the-fly	You should avoid in this case to explicitly change the control parameters of function block without disabling the function block. To do so, disable the function block, feed new parameter values and then re-enable the function block.
<code>q_uiAlrmlD = 1</code>	Internal alarm detected	Restart the function block.
<code>q_uiAlrmlD = 70</code>	Alarm detected due to <code>q_xTmot</code>	<ol style="list-style-type: none"> 1. Change the input parameters (<code>i_stCmdPara.dwPosCorrTime</code> for digital output mode or <code>i_stCmdPara.dwRampTime</code> for analog output mode) to suitable values. 2. Restart the function block.
<code>q_uiAlrmlD = 100</code>	Parameters such as <code>i_stCmdPara.dwPosCorrTime</code> , <code>i_stCmdPara.dwRampTime</code> , <code>i_stCmdPara.dwWaitTime</code> , <code>i_stCmdPara.rAnaOpotMax</code> is configured less than zero or equal to zero	Configure the value of parameters greater than zero.

Part VI

RotaryKnife

Chapter 9

RotaryKnife_Motion: Synchronization of a Linear Axis and a Rotary Axis to Perform On The Fly Operations

What Is in This Chapter?

This chapter contains the following sections:

Section	Topic	Page
9.1	Functional and Machine Overview	262
9.2	Architecture	265
9.3	Function Block Description	271
9.4	Pin Description	277
9.5	Operating Modes	288
9.6	Start, Stop and Starting Modes	299
9.7	Special Modes	315
9.8	Quick Reference Guide	322

Section 9.1

Functional and Machine Overview

What Is in This Section?

This section contains the following topics:

Topic	Page
Functional Overview	263
Machine Overview	264

Functional Overview

Why Use the `RotaryKnife_Motion` Function Block?

The `RotaryKnife_Motion` function block controls a machine that performs operations on a moving part.

Typical operations can include:

- Cutting
- Sealing
- Marking

Solution with the `RotaryKnife_Motion` Function Block?

The `RotaryKnife_Motion` function is required for moving the operational axis to synchronize it with the forward motion of the part.

This introduces the concept of master and slave axis.


- Master: moves the part forward
- Slave: performs the operation

NOTE: Although the Rotary Knife function can be used for many different applications, the examples shown in this document will refer to a typical cutting application.

Machine Overview

Machine View

The figure below gives an example of a Rotary Knife application. Master axis is a linear axis type whereas the axis slave is a rotary axis.



Rotary Knife

With the application function blocks it is possible to handle Multi Blade Rotary Knife. The condition is to have equidistant knives.

In this case the parameter `lrPeri` is defined as the distance between the blades.

Note

Please also refer to:

- Master Axis ([see page 266](#))
- Slave Axis ([see page 267](#))
- Cutting Tool ([see page 267](#))
- Capture Position of the Product ([see page 267](#))

Section 9.2

Architecture

What Is in This Section?

This section contains the following topics:

Topic	Page
Hardware Architecture	266
Software Architecture	269

Hardware Architecture

Master Axis

NOTE: This architecture is valid for the `RotaryKnife_Motion` and `FlyingShear_Motion` function blocks.

The master axis moves a product forward continuously. It is an infinite axis.

The master axis can be of the following type:


- servo drive (Lexium) on CANmotion or Sercos
- any type of axis (Altivar or Lexium) coupled with a master encoder
- virtual axis

Example: Tube cutting

The forward motion of the tube is managed by the rolling mill and thus by the device which controls it. Therefore the movement of this axis is not controlled by the `RotaryKnife/FlyingShear` functions.


The master and the slave axis can both be on CANmotion or Sercos.

Master and slave on CANmotion or Sercos



If the master axis is not a servo drive on the same CANmotion or Sercos as the slave, then the position of the master is determined by an encoder signal connected to the input of the Motion Controller:

Example of a master axis controlled with an Altivar via CANopen communication protocol



Slave Axis

The slave axis has to be a servo drive on CANmotion/Sercos or stepper drive on CANmotion.

According to the length to cut (input `i_lrLentoCut`), the slave axis synchronizes itself with the master, remains synchronized during the cut (or another operation) and finally returns to its resting position (parameter `lrPosRest`) and/or continues with a new cut.

Synchronization may correspond to:

- A positioning of the slave in relation to the master according to the cutting point. This position is defined as position 0 of the slave.
- A speed of the slave proportional to the speed of the master.

Cutting Tool


If needed, the knife starts its movement after the beginning of the synchronization phase (of the master and the slave). It must have completed its movement before the end of synchronization phase and return to its original position before a new cut is begun.

The movement of the cutting tool is managed by the application, rather than the `RotaryKnife_Motion/FlyingShear_Motion` application function blocks. However, the functions provide a "Beginning of Synchronization" signal (`q_xInSync`) which can be used by the application to control the start of the cutting tool.


Capture Position of the Product

In certain applications the product is not continuous (e.g. individual parts to be labeled), or may not be rigid which presents a possibility of stretching (e.g. plastic film). In these cases, a sensor is placed on the master axis to capture the position of labels on the product.

Rotary Knife: Principle of operation sensor wiring



Flying Shear: Principle of operation sensor wiring



Sensor Wiring

If...	Then...
the master is the encoder input	the sensor may be wired to a Touch Probe input (TP1, TP2...) of the Motion Controller. The TP inputs have an acquisition time of 30µs.
the master is a servo drive on CANmotion or Sercos bus	the sensor may be wired to one of the capture inputs of the drive. (See configuration of capture inputs in documentation of the drive.)

The standard inputs of the Motion Controller can also be used. In this case however, the acquisition time is related to the cycle time of the Motion Controller.

Software Architecture

Requirements for Configuration

NOTE: This architecture is valid for the `RotaryKnife_Motion` and `FlyingShear_Motion` function blocks.

Configuration of the axes with the Motion Controller.

Master:

- Even if the master axis is considered to be a linear axis (e.g. a conveyor) being *infinite*, it must nonetheless be configured as a modulo axis.

NOTICE

UNSATISFACTORY EQUIPMENT OPERATION

Set the `modulo` value higher than the maximum possible length to cut plus Touch Probe distance to the synchronization point (greater than the sum of `max i_lrLentoCut` and `lrTpDistToSypt`).

Failure to follow these instructions can result in equipment damage.

Slave:

- For Rotary Knife:
The slave axis has to be configured as a rotary axis.
- For Flying Shear:
The slave axis has to be configured as a linear axis.


NOTICE

UNSATISFACTORY EQUIPMENT OPERATION

Set the `modulo` value of the slave greater than or equal to than 2 times the distance between the knife blades (perimeter) (greater than or equal to $2 * lrPeri$).

Failure to follow these instructions can result in equipment damage.

The axis type and the modulo is configured in the device configuration.



Configuration of the Slave Axis Servo Drive.

In addition to the communication parameters (addresses on the bus, speed transmission), the following parameter adjustments should be made to the drive in order to optimize the response of the servo drive that controls the slave axis:


- increase the maximum slopes of acceleration and deceleration
- set the parameter `N_ref_Filter` to OFF
- various loop parameters. They include proportional gain speed loop, integral time speed loop and the proportional gain position.

Section 9.3

Function Block Description

RotaryKnife_Motion Function Block

Pin Diagram



Profiles of Master/Slave Positions


The curves (see case 1 and 2) show the position profile of the slave axis in relation to the master during the execution of the Rotary Knife function.

A Rotary Knife cycle consists of 3 phases:


Phase	Description
Start Phase	<p>The slave accelerates up to the master velocity to be synchronized at the beginning of the synchronous phase.</p> <ul style="list-style-type: none"> The start phase distance on the slave is equal to: Slave Start Phase Distance = $ABS(lrPeri - lrPosRest)$ The start phase distance on the master can be calculated with the following formula: Master Start Phase Distance = $(ABS(lrPeri - lrPosRest) / lrM) * 1.875$
Synchronous Phase	The cut (or the operation) is performed. The synchronous phase always starts with position 0 of the slave.
Return Phase	The slave returns, makes a half-turn before it begins a new synchronous phase.

Depending on the length to cut and the perimeter of the Rotary Knife different cases are to be distinguished:


At the end of the synchronous phase, the slave decelerates and enters a new synchronous phase (see figure below).




At the end of the synchronous phase, the slave decelerates, stops at the resting position and awaits a new cut position (see figure below).



At the end of the synchronous phase, the slave accelerates to enter a new synchronous phase as fast as possible (see figure below).



The length to cut is equal to the perimeter of the knife (see figure below).



The distance covered by the master during this cycle corresponds to the length to cut ($i_lrLentoCut$).

The distance covered by the slave during this cycle corresponds to the perimeter of the knife ($lrPeri$).

Backward Movement with a Rotary Knife

Depending upon the machine, a backward movement of the slave (Rotary Knife) is prohibited during the synchronous phase therefore please pay attention to the following information:

Inside the synchronous phase, a backward movement of the slave is possible with the following situations:

- If the master moves backward. In this case the slave will follow the master backward and stop at 0. Do not move the master backward to avoid this situation.
- With warm start mode 1, 2, 4. Use warm start 3 or 5 to avoid this situation.

Outside the synchronous phase, a backward movement of the slave is possible with the following situations:


- If the master moves backward. In this case the slave will follow the master backward and stop at 0. Do not move the master backward to avoid this situation.
- With warm start 1 to 5 outside the synchronous phase
- If the slaves has to return to rest position ($lrPosRest$) when its position is included between $lrPosRest$ and $lrPeri$. This is to prevent the salve to cross the synchronous phase (see figure below).

⚠ CAUTION

ASYNCHRONOUS OPERATION OF CUTTING TOOL

Use additional measures to avoid backward movement of the slave (Rotary Knife) unless the application accounts for such motion.

Failure to follow these instructions can result in injury or equipment damage.



Section 9.4

Pin Description

What Is in This Section?

This section contains the following topics:

Topic	Page
Input Pin Description	278
Output Pin Description	281
Input/Output Pin Description	282
Structured Parameter	283

Input Pin Description

Input Pin Description

Inputs/outputs are linked directly to the application function block interface. The main difference with the parameters is that inputs/outputs are refreshed cyclically, therefore they can be modified on the fly.

NOTE: These inputs are valid for the `RotaryKnife_Motion` and `FlyingShear_Motion` function block.

Input	Data Type	Description	
i_xActv	BOOL	Activate: TRUE: Application function block is activated. FALSE: Application function block is de-activated. Factory setting: FALSE Start and Stop (<i>see page 300</i>)	
i_xExe	BOOL	Execute: TRUE: Movement is started depending on the operating mode and the starting mode. FALSE: Movement is stopped. NOTE: If the slave is inside the synchronous phase, the movement will not be stopped immediately. Factory setting: FALSE Start and Stop (<i>see page 300</i>)	
i_uiStrtMode	UINT	Start mode:	
		0	warm start mode 0
		1	warm start mode 1
		2	warm start mode 2
		3	warm start mode 3
		4	warm start mode 4
		5	warm start mode 5
		Factory setting: 0 Starting Modes (<i>see page 303</i>)	
i_xSyncAbort (for FlyingShear only)	BOOL	Abort synchronization: TRUE: Interruption of the synchronization phase. Factory setting: FALSE Interruption of the Synchronous Phase (<i>see page 343</i>)	

Input	Data Type	Description
i_xSyncImdt	BOOL	Immediate synchronization: TRUE: Synchronize the slave immediately to the master. This input is considered only when the slave is in resting position (<code>lrPosRest</code>). Only significant for operating modes 0. Factory setting: FALSE
i_lrLentoCut	LREAL	Length to cut: Can be modified on the fly. Only significant for operating modes 0 and 1. Factory setting: 0 Range: <code>lrLentoCutMin ≤ .. ≤ 9999999</code> [Master User Unit]
i_xAlrmRst	BOOL	Alarm quit: TRUE: Reset detected alarm. If (and only if) <code>i_xAlrmRst</code> is triggered whereas the function block is OK, it will reset <code>q_diTpAlrmCnt</code> Factory setting: FALSE Troubleshooting (see page 325)
i_xTpUseNext	BOOL	Use next TP: TRUE: The following position capture will be accepted as a valid capture even if it is outside of <code>lrTpWdow</code> . Only significant for operating modes 1. Factory setting: FALSE
i_xTpIputStd	BOOL	TP standard input: Standard input used for the master position capture. Only significant if <code>diCptrNb = 0</code> . Factory setting: FALSE Selection of the Capture Mode (see page 298)
i_lrShift	LREAL	Shift: Value of the shift to apply on the cutting point. Factory setting: 0 Range: <code>-lrPosSyncEnd ≤ .. ≤ +lrPosSyncEnd</code> [Master User Unit]

Input	Data Type	Description	
i_lrShiftStepSize	LREAL	<p>Shift step size: Maximum value of the shift to apply on the cutting point in 1 slave cycle. 0: Shift interruption. The shift of the tool stays constant at the current value even if the final shift: i_lrShift has not been reached.</p> <p>NOTE: If i_lrShiftStepSize is greater than i_lrShift the shift is applied in one step.</p> <p>Factory setting: 0 Range (according to operating mode):</p>	
		Op. mode	Range
		0	$0 \leq \dots \leq (i_lrLentoCut - lrPosSyncEnd / lrM) * 0.9$
		1	$0 \leq \dots \leq (i_lrLentoCut - lrPosSyncEnd / lrM - lrTpWdow / 2) * 0.9$
		2	$0 \leq \dots$ [Master User Unit]

Output Pin Description

Output Pin Description

Inputs/outputs are linked directly to the application function block interface. The main difference with the parameters is that inputs/outputs are refreshed cyclically, therefore they can be modified on the fly.

NOTE: These outputs are valid for the RotaryKnife_Motion and FlyingShear_Motion function blocks.

Output	Data Type	Description
q_xActv	BOOL	Active: TRUE: Application function block is initialized and activated. FALSE: Application function block is inactive.
q_xCoup	BOOL	Coupled: TRUE: Slave is coupled with the master on the Rotary Knife/FlyingShear profile curve.
q_xInSync	BOOL	In synchronization: TRUE: Slave is in synchronous phase of the curve and synchronized to the master.
q_xAlrm	BOOL	Detected Alarm: TRUE: An interruption occurred Troubleshooting (see page 325)
q_diAlrmId	DINT	Detected Alarm ID: Range: 0 ≤ . . ≤ 99999 Troubleshooting (see page 325)
q_xWsPosRchd	BOOL	Warm start position reached: TRUE: Slave has reached the warm start position. Starting Modes (see page 303)
q_diTpAlrmCnt	DINT	TP alarm counter: Number of successive missed position captured. One valid TP will reset q_diTpAlrmCnt Only significant for operating modes 1. Range: 0 ≤ . . ≤ 99999
q_lrShiftAct1	LREAL	Current shift: Current applied shift. Range: Master User Unit

Input/Output Pin Description

Input/Output Pin Description

NOTE: These inputs/outputs are valid for the RotaryKnife_Motion and FlyingShear_Motion function blocks.

Input/Output	Data Type	Description
iq_stDrvMstr	SM3_Basic.AXIS_REF_SM3	master axis reference structure
iq_stDrvSlav	SM3_Basic.AXIS_REF_SM3	slave axis reference structure
iq_stPara	STRUCT ST_FSRK_PARAMETER	block parameters structure

Structured Parameter

iq_stPara

Parameters are entered to the application function block via the structure `iq_stPara`.

The main difference with inputs/outputs is that parameters are only refreshed after activation of the application function block (`i_xActv=TRUE`). Therefore parameters are only taken into account after a re-activation of the application function block.

Inputs - iq_stPara

NOTE: These parameters are valid for the `RotaryKnife_Motion` and `FlyingShear_Motion` function blocks.

Structure Parameter	Data Type	Description
<code>lrPeri</code> (for the Rotary Knife only)	LREAL	Knife Perimeter Perimeter of the Rotary Knife. Distance between the blades for Multi Blade Rotary Knives. Factory setting: 0 Range: $0 \leq \dots \leq 999999$ [Slave User Unit]
<code>lrPosRest</code>	LREAL	Rest Position: Rest position of the slave Factory setting: 0 Range: $-999999 \leq \dots \leq 999999$ [Slave User Unit]
<code>lrSyncPosEnd</code>	LREAL	Synchronization end position: Final position of the synchronous phase (related to the slave axis). Synchronous phase start at position 0 until position <code>lrPosSyncEnd</code> . Factory setting: 0 Range: $0 \leq \dots \leq 999999$ [Slave User Unit]

WARNING

UNINTENDED EQUIPMENT OPERATION

- Set the modulo value of the master axis at least 25 times greater than the `lrSyncPosEnd` parameter.
- Verify that the modulo value of the master axis is as large as possible.

Failure to follow these instructions can result in death, serious injury, or equipment damage.

lrDecStop	LREAL	<p>Stop deceleration: Deceleration ramp to stop the slave in case of:</p> <ul style="list-style-type: none"> detected alarm deactivation of the application function block (falling edge of <code>i_xActv</code>). <p>Factory setting: 1000 Range: $0 \leq \dots \leq \text{max acc of the drive [Slave User Unit]}$</p>	
lrWsdow	LREAL	<p>Warm start window: Tolerance window for warm start. Only significant for warm start mode 2, 3, 4, 5.</p> <p>Factory setting: 30 Range: $0 \leq \dots \leq 999999$ [Master User Unit] Starting Modes (<i>see page 303</i>)</p>	
lrVel	LREAL	<p>Velocity: Slave speed used for the following movement:</p> <ul style="list-style-type: none"> in warm start mode to move to the warm start position in cold start to move to rest position With a falling edge of <code>i_xExe</code> to move to rest position <p>Factory setting: 100 Range: $0 \leq \dots \leq \text{max speed of the drive [Slave User Unit]}$</p>	
lrAccDec	LREAL	<p>Acceleration / Deceleration: Acceleration and deceleration used for the following movement:</p> <ul style="list-style-type: none"> in warm start mode to move to the warm start position during a cold start to move to rest position with a falling edge of <code>i_xExe</code> to move to rest position <p>Factory setting: 1000 Range: $0 \leq \dots \leq \text{max acc of the drive [Slave User Unit]}$</p>	
diCptrNb	DINT	<p>Capture number: Selection of the input for the position capture:</p>	
		0	position capture is made on a standard input. In this case the input has to be wired to input <code>i_xTpInputStd</code>
		1	position capture is made on the Touch Probe 1 (TP1)
		2	position capture is made on the Touch Probe 2 (TP2)
		<p>NOTE: The edge (rising edge or falling edge) can be changed using the configuration dialog of the encoder or by means of the drive setup tool. Factory setting: 0 Range: $0 \leq \dots \leq 2$ Selection of the Capture Mode (<i>see page 298</i>)</p>	

lrTpDistToSypt	LREAL	TP distance to the synchronization point: Distance between the position capture sensor and the starting point of the synchronous phase. Only significant for operating mode 1 and 2. Factory setting: 500 Range: lrTpDistToSyptMin ≤ ... ≤ 999999 [Master User Unit]
lrTpWdow	LREAL	TP Window: Tolerance window of the position capture. For operating mode 1: Range within the captured position are valid. For operating mode 2: Range in which, after an active TP, no other TP will be accepted. Factory setting: 50 Range (for operating mode 1 and 2): lrTpWdow > ((lrPerim-lrPosRest)/lrm)*1,875
diOpMode	DINT	Operating mode: Selection of the operating mode.
		0 continuous product
		1 continuous product with mark compensation
		2 non continuous product (cut on the mark)
		Factory setting: 0 Range: 0 ≤ ... ≤ 2 Operating Modes (<i>see page 288</i>)
diTpMisdMax	DINT	TP missed maximum: Maximum number of captures outside the tolerance window (defined with lrTpWdow). An alarm is generated if q_diTpAlrmCnt > diTpMisdMax. Only significant in operating mode 1 Factory setting: 3 Range: 0 ≤ ... ≤ 999999
lrm	LREAL	RM: Introduce a slope coefficient in the synchronous phase. Allows the definition of a different speed ratio during this phase. Factory setting: 1 Range: 0 ≤ ... ≤ 10
xOfstMode	BOOL	Offset mode: TRUE: Activate offset mode FALSE: Deactivate offset mode Factory setting: FALSE Range: FALSE / TRUE [Slave User Unit]

lrCamOfst	LREAL	<p>CAM offset: Offset added to the original slave profile. Only relevant if offset. Factory setting: 0 Range: $0 \leq \dots \leq \text{lrPosSyncEnd}/2$ [Slave User Unit]</p>
lrPosOfstStrt	LREAL	<p>Offset start position: Slave position from where the offset distance is added. Only relevant if offset mode is activated (<code>xOfstMode=TRUE</code>) Factory setting: 0 Range: $0 < \dots < \text{lrPosOfstStrt}$ [Slave User Unit]</p>
lrPosOfstEnd	LREAL	<p>Offset end position: Slave position where the offset distance is reached. Only relevant if offset mode is activated (<code>xOfstMode=TRUE</code>) Factory setting: 0 Range: $\text{lrPosOfstStrt} < \dots < \text{lrPosSyncEnd}$ [Slave User Unit]</p>

Outputs - iq_stPara

Structure Parameter	Data Type	Description
lrTpDistToSyptMin	LREAL	<p>TP minimum distance: Calculated by the application function block for information. Minimum distance between the position capture sensor and the starting point of the synchronous phase (position 0 of the slave). Only relevant in Operating mode 1 and 2. Calculation for Rotary Knife: <ul style="list-style-type: none"> $\text{lrTpDistToSyptMin} = \text{ABS}(\text{lrPeri} - \text{lrPosRest} / \text{lrM}) * 1.875) + \text{lrTpWdow} / 2$ Calculation for Flying Shear: <ul style="list-style-type: none"> $\text{lrTpDistToSyptMin} = \text{ABS}(\text{lrPosRest} / \text{lrM}) * 1.875) + \text{lrTpWdow} / 2$ Range: [Master Unit]</p>

Structure Parameter	Data Type	Description
lrLentoCutMin	LREAL	<p>Minimum length to cut: Calculated by the application function block. Minimum possible value of length to cut. Calculation for Rotary Knife:</p> <ul style="list-style-type: none"> • in operating mode 0: $lrLentoCutMin = lrPosSyncEnd$ • in operating mode 1: $lrLentoCutMin = lrPosSyncEnd + lrTpWdow / 2$ • in operating mode 2: $lrLentoCutMin = lrPosSyncEnd + ABS((lrPeri - lrPosRest / lrM) * 1.875)$ <p>Calculation for Flying Shear:</p> <ul style="list-style-type: none"> • in operating mode 0: $lrLentoCutMin = lrSyncPosEnd$ • in operating mode 1: $lrLentoCutMin = lrSyncPosEnd + lrTpWdow / 2$ • in operating mode 2: $lrLentoCutMin = lrSyncPosEnd + ABS((lrPosRest / lrM) * 1.875)$ <p>NOTE: This minimum length to cut value is theoretical and cannot be reached. Practically, reducing the length to cut increase the velocity, acceleration and deceleration constraints on the slave axis. Therefore the minimum length to cut depends on the velocity, acceleration and deceleration that the drive and the mechanic can handle.</p> <p>If the maximum master velocity is known as well as the maximum velocity supported by the slave axis then it is possible to calculate the real minimum length to cut with the following formulas: Formula for Rotary Knife:</p> $i_lrLentoCut\ min = \frac{lrSyncPosEnd}{lrM} + \frac{15 \cdot (lrPeri - lrSyncPosEnd)}{8 \cdot \frac{V\ max\ Slave}{V\ max\ Master} + 7 \cdot lrM}$ <p>Formula for Flying Shear:</p> $i_lrLentoCut\ min = \frac{lrSyncPosEnd}{lrM} + \frac{-15 \cdot lrSyncPosEnd}{-8 \cdot \frac{V\ max\ Slave}{V\ max\ Master} + 7 \cdot lrM}$ <p>NOTE: These formulas do not take into account the acceleration. Range: [Master Unit]</p>

Section 9.5

Operating Modes

What Is in This Section?

This section contains the following topics:

Topic	Page
Operating Mode 0: Continuous Product	289
Operating Mode 1: Continuous Product with Mark Compensation	291
Operating Mode 2: Non Continuous Product (Cut on Mark)	295
Selection of the Capture Mode	298

Operating Mode 0: Continuous Product


Overview

NOTE: This operating mode description is valid for the `RotaryKnife_Motion` and `FlyingShear_Motion` function blocks.



Operating mode 0 is used to process products with a constant length. This distance corresponds to the length of one process cycle and is defined via the input variable `i_lrLentoCut`.

The parameter `i_lrLentoCut` can be modified during the movement. The modification is accepted for the next cycle.

Rotary Knife Representation



Flying Shear Representation



Operating Mode 1: Continuous Product with Mark Compensation

Overview

This operating mode description is valid for the `RotaryKnife_Motion` and `FlyingShear_Motion` function blocks.

Operating mode 1 has basically the same functionality as operating mode 0, extended with an automatic correction of the product length, calculated from a position capture.

The product length correction is principally interesting in case of flexible product (with risk of deformation, stretching, etc.). In this case a label or a mark is needed on the product.

The cutting condition is then related to the length to cut parameter (`i_lrLentoCut`) which can be corrected according to the position captured at the time of label detection.

If a mark is detected inside the tolerance window, the measured length is used for cutting. Any mark before the tolerance window will be ignored. If the position leaves the window without seeing a mark, the default length is used and the output `q_diTpAlrmCnt` is incremented by 1.

The parameter `i_lrLentoCut` can be modified during the movement. The modification is accepted for the next the cycle.


The parameter `lrTpDistToSypt` corresponds to the distance between the sensor for position capture and the beginning of the synchronous phase (position 0 of the slave).

Depending upon this distance, several labels may be located between the sensor and the beginning of the synchronous phase. Those captures are stored in a buffer. The `RotaryKnife/FlyingShear` functions allow the storage of up to 15 positions. Over 15 positions an alarm is detected.


To improve the accuracy, `lrTpDistToSypt` has to be reduced to a minimum. However, depending upon the length to cut, this distance must be chosen higher than the minimum value, calculated by the block function and given by parameter output `lrTpDistToSyptMin`.


A tolerance capture window, `lrTpWdow`, can be used to define an interval of valid position.

Rotary Knife Representation



Flying Shear Representation







Tolerance Capture Window (Operating Mode 1)

In help to avoid interfering signals (detection of false labels) or limit the stretching tolerance of elastic products, a tolerance window for capturing can be defined by $lrTpWdow$:

$$i_lrLentoCut - lrTpWdow / 2 < \text{Range of tolerance} < i_lrLentoCut + lrTpWdow / 2$$

Mark inside TP window
 $lrLenghtToCut$ corrected with Δx





If...	Then...
a mark is detected inside this range,	the measured length is used for cutting. Any mark before this range will be ignored.
the position leaves this range without seeing a mark,	the default length is used and the output <code>q_diTpAlrmCnt</code> is incremented by 1.

A maximum number of successive captures outside this range can be configured with the parameter `diTpMisdMax`.

An alarm occurs if `q_diTpAlrmCnt > diTpMisdMax`. The slave is stopped with the ramp `lrDecStop`.

The alarm counter `q_diTpAlrmCnt` is set back to 0 with the following conditions:

- a valid capture signal before an alarm occurs
- the function block is de-activated
- with rising edge of input `i_xAlrmRst` while no alarm is active

With a rising edge of the input `i_xTpUseNext` the next capture signal is valid without any consideration to the `lrTpWdow` and the alarm counter `q_diTpAlrmCnt` is set back to 0.

Operating Mode 2: Non Continuous Product (Cut on Mark)

Overview

This operating mode description is valid for the `RotaryKnife_Motion` and `FlyingShear_Motion` function blocks.

In the operating mode 2, the product arrives on the conveyor in a discontinuous and random way. The size and the format can vary. The cutting condition is started exclusively by the position capture.


The parameter `lrTpDistToSypt` corresponds to the distance between the sensor for position capture and the beginning of the synchronous phase (position 0 of the slave).

Depending upon this distance, several labels may be located between the sensor and the beginning of the synchronous phase. Those captures are stored in a buffer. The `RotaryKnife/FlyingShear` functions allow the storage of up to 15 positions. In case more than 15 positions are detected an alarm will be raised.



`lrTpDistToSypt` has to be higher than the minimum value `lrTpDistToSyptMin` calculated by the function block.

A capture ignorance window can be used to define an interval of valid position.

Rotary Knife Representation




Flying Shear Representation




Capture Ignorance Window (Operating Mode 2)

In order to avoid detection of false signals, a tolerance for position captures can be defined by $lrTpWdow$. The range begins with the previous captured position.

New capture – last captured mark
inside TP window
capture not valid



New capture – last captured mark
outside TP window
capture valid



To be a valid mark, the position has to be greater than the last accepted mark + $lrTpWdow$:
position of previous + $lrTpWdow$.

If a mark is detected inside this range, the product length is calculated depending on this mark.
Any detection outside this range is ignored.

Selection of the Capture Mode

Selection of the Capture Mode

NOTE: This mode description is valid for the `RotaryKnife_Motion` and `FlyingShear_Motion` function blocks.

Position capture is used with operating mode 1 and 2.

According to the architecture and the requirements of precision for the application, several capture modes are possible.

Mode	Description
Detection with standard input	The sensor is wired to a standard input. The capturing is within the cycle of the motion controller.
Detection with fast input	The sensor is wired to a Touch Probe input <ul style="list-style-type: none"> ● TP1, TP2, ... if the master is an external encoder ● a capture input of a servo drive, if the master is a drive

Capture input can be configured with parameter `diCptrNb`:

<code>diCptrNb</code>	<code>i_xTpIputStd</code>
0: Capture is done with a standard input	Associated standard input. If input <code>DI3</code> is used, then <code>DI3</code> is wired to <code>i_xTpIputStd</code> .
1 to 2: Capture is done on Touch Probe 1 to 2	No effect

If a Touch Probe is selected, the edge (rising edge or falling edge) has to be selected outside the application function block.

Section 9.6

Start, Stop and Starting Modes

What Is in This Section?

This section contains the following topics:

Topic	Page
Start and Stop	300
Starting Modes	303
Cold Start	304
Warm Start	305

Start and Stop

Overview

NOTE: This description is valid for the `RotaryKnife_Motion` and `FlyingShear_Motion` function blocks.

The correct sequence for the application function block is as follows:

- activate the application function block (`i_xActv=TRUE`)
- start the movement (`i_xExe=TRUE`)
- de-execute the application function block (`i_xExe=FALSE`)
- de-activate the application function block (`i_xActvFALSE`)

Activate the Application Function Block

The function block is activated with a rising edge of `i_xActv`.

- the input parameters (defined in `iq_stParam`) are confirmed for consistency.
- `q_xActv` is set to TRUE
- in case of incorrect or inconsistent inputs or input parameters, output `q_xAlrm` becomes TRUE. Troubleshooting (*see page 325*)

WARNING

UNINTENDED EQUIPMENT OPERATION

Do not send any other commands to the slave axis when it is under control of the `RotaryKnife_Motion/FlyingShear_Motion` application function blocks.

Failure to follow these instructions can result in death, serious injury, or equipment damage.

Start the Movement

Movement is started with a rising edge of `i_xExe`.

- verify slave axis state (slave has to be standstill)
- inputs are confirmed for validity
- if no alarm occurred, movement is started depending on the following conditions Starting Modes (*see page 303*):
 - with the first rising edge of `i_xExe` after activation of the application application function block (rising edge of `i_xActv`) a cold start is automatically executed. Input `i_uiStrtMode` is ignored.
 - with every following rising edge of `i_xExe` a warm start is executed depending on the input `i_uiStrtMode`
- output `q_xCoup` is set to TRUE when the slave is coupled to the master.
- in case of incorrect or inconsistent inputs, output `q_xAlrm` becomes TRUE. Troubleshooting (*see page 325*)

Stop the Movement

On a falling edge of `i_xExe` the movement is stopped under the following conditions:

- If outside the synchronous phase (`q_xInSync=FALSE`), the slave is uncoupled from the master and returns directly to its rest position (`lrPosRest`).
- If inside the synchronous phase (`q_xInSync=TRUE`), the slave remains coupled with the master until the end of synchronous phase. Then the slave is uncoupled from the master and returns directly to its rest position (`lrPosRest`).

Therefore, `i_xExe= FALSE` does not guarantee that the slave stops immediately or remain stationary. To stop immediately or to block any movement of the slave controlled by the application function block, `i_xActv` has to be `FALSE`.

NOTE: In operating mode 1 and 2 and with a falling edge of `i_xExe`, the application function block continues to capture and buffer positions as long as the application function block is activated.

Other conditions that stop the slave:

- when the slave is coupled with the master (`q_xCoup=TRUE`), the slave stops if the master stops. Nevertheless, the slave remains coupled and restarts if the master restarts.
- on a falling edge of `i_xActv` the slave is stopped with the deceleration ramp `lrDecStop`. The master / slave synchronization is lost.
- if an alarm occurs, the slave is stopped with the deceleration ramp `lrDecStop`. The master / slave synchronization is lost.

De-Activate the Application Function Block

On a falling edge of `i_xActv` the block is de-activated and:

- if moving, the slave is stopped with the deceleration ramp `lrDecStop`
- when the slave is stopped, all outputs are reset
- the current shift is reset (`q_lrShiftAct1`)
- the position capture is stopped and the position capture buffer (for operating mode 1 and 2) is reset.

Slave Movement to Rest Position (`lrPosRest`)

NOTE: For Rotary Knife only.

The slave goes to its rest position in the following situations:

Inside the synchronous phase:

- with a cold start
- with a warm start 0 if the master and slave are uncoupled


Outside the synchronous phase:

- with a cold start
- with a warm start 0 if the master and slave are uncoupled
- with a falling edge of execute input

The following rules are applied:

- In any case the slave does not cross the synchronous phase to move to its rest position (case 1 and 2, see figure below). In case 2 the slave moves backward.
- If the slave is in the synchronous phase, it moves forward to its rest position (case 3, see figure below).

The following figure shows the slave movement to the rest position.



Starting Modes

Overview

NOTE: This description is valid for the `RotaryKnife_Motion` and the `FlyingShear_Motion` function blocks.

There are 2 different types of starting modes:

Mode	Description
Cold Start	is the starting method automatically used for the first execution of the application function block after activation. A cold start is necessary when there is no context coming from a previous execution of the application function block (No position captured inside the buffer, no shift applied, no output information...).
Warm Start	is the starting method used for a re-start of the application function block, following a temporary interruption (with a falling edge on <code>i_xExe</code>), an error-stop or an emergency stop without de-activation of the application function block. In this case the previous context is kept and considered for the re-start of the movement.

Main differences between cold start and warm start:

In operating mode 1 and 2:

- at cold start the position buffered is empty. The first product to be cut will be the first detected product. Therefore, if the position sensor is 5 products before the cutting tool, the 5 intermediate products will not be cut.
- at warm start, the buffer is kept active. Therefore the application can restart immediately without losing any product.

With a rising edge of `i_xExe` the movement is started depending on the following conditions:

- with the first rising edge of `i_xExe` after activation of the application function block (rising edge of `i_xActv`) a cold start is automatically executed. Input `i_uiStrtMode` is ignored
- with every following rising edge of `i_xExe` a warm start is executed depending on the input `i_uiStrtMode`

Cold Start

Overview

NOTE: This description is valid for the RotaryKnife_Motion and the FlyingShear_Motion function blocks.

A cold start is the starting method used for the first execution of the RotaryKnife_Motion/FlyingShear_Motion application function blocks after activation. In other word a cold start is necessary when there is no context coming from a previous execution of the application function block (No position captured inside the buffer, no shift applied, no outputs information...).

Therefore, with the first rising edge of `i_xExe` after activation of the application function block (rising edge of `i_xActv`) a cold start is automatically executed. Input `i_uiStrtMode` is ignored.

At cold start the slave moves to the rest position (`lrPosRest`). When the rest position has been reached, the slave is coupled to the master (using the start phase) depending on the operating mode (`diOpMode`) and the position capture buffer.

Modes	Description
Operating Mode 0	the slave will start immediately the Rotary Knife/FlyingShear profile when the master is started.
Operating Mode 1 and 2	the first product to be cut will be the first detected product. Therefore, if the position capture sensor is placed 5 products before the cutting tool the 5 intermediates products will not be cut.

Warm Start

Overview

NOTE: This description is valid for the `RotaryKnife_Motion` and the `FlyingShear_Motion` function blocks.

A warm start is the starting method used for a re-start of the application function block following a temporary interruption (with a falling edge on `i_xExe`), an error-stop or an emergency stop without de-activation of the application function block.

In this case the previous context is kept (buffer is still active, shift is maintained, outputs are relevant). Therefore in operating mode 1 and 2, the application can restart using valid positions from the buffer.

Six warm start modes are available depending on the application requirements. For each warm start mode there are certain conditions to be fulfilled. Warm start mode is selected with input `i_uiStrtMode`.

How to select a warm start mode:

Mode	Description
Warm Start 0 (<code>i_uiStrtMode=0</code>)	is the only warm start possible with a moving master. has no tolerance window and can be used if warm start 1 to 5 is not possible (if slave is outside the tolerance window...). In this case the slave goes first to the rest position.
Warm Start 1 to 5 (<code>i_uiStrtMode=1 to 5</code>)	only possible if the master is stopped otherwise an alarm is created. is mainly used when there is a mechanical constraint between master and slave during the synchronization phase (a blade into a metal sheet...). In case of accidental de-coupling of the master and slave during the synchronization phase (emergency stop...) the slave can be re-coupled with the master following different conditions.

For warm start modes 1 to 5, output `q_xPosWSRch` indicates that the warm start position has been reached. It signals to the application, that the master can be started.

Warm Start 0 ($i_uiStrtMode = 0$)

NOTE: Warm start 0 is the only warm start possible with a moving master.

With a rising edge of i_xExe :


If...	Then...
the slave is still coupled to the master (ex: $i_xExe=FALSE$ with a master stopped into the synchronous phase)	the slave stays coupled to the master and restarts normally.
the slave is in rest position ($lrPosRest$)	the slave restarts with the next cycle if the distance is long enough to accomplish the start phase.
the slave is not coupled and not in rest position (in or out of the synchronous phase)	the slave goes to rest position and restart with the next cycle if the distance is long enough to accomplish the start phase.

Warm Start 1 ($i_uiStrtMode = 1$)

With a rising edge at i_xExe :

- The slave returns to the curve position regardless where (inside or outside synchronous phase) it has been stopped.

RotaryKnife Representation




Warm start 1 allows backward movement of the slave into the synchronous phase.

⚠ WARNING**UNINTENDED EQUIPMENT OPERATION**

Use warm start mode 3 or 5, if the machine design does not account for a backward movement of the slave (Rotary Knife).

Failure to follow these instructions can result in death, serious injury, or equipment damage.

FlyingShear Representation




Warm Start 2 ($i_uiStrtMode = 2$)

With a rising edge at i_xExe :

RotaryKnife Case	FlyingShear Case	If..	Then..
1 and 2	1	the slave is in the synchronous phase and located inside the tolerance window defined by $lrWsWdow$ <ul style="list-style-type: none"> • slave position \geq curve position - $lrWsWdow / 2$ AND <ul style="list-style-type: none"> • slave position \leq curve position + $lrWsWdow / 2$ 	the slave returns to its curve position.
3	2	the slave is in the synchronous phase and located outside the tolerance window defined by $lrWsWdow$ <ul style="list-style-type: none"> • slave position $>$ curve position + $lrWsWdow / 2$ OR <ul style="list-style-type: none"> • slave position $<$ curve position - $lrWsWdow / 2$ 	the slave remains in position and an alarm is produced. Troubleshooting (<i>see page 325</i>)
4	3	the slave is outside the synchronous phase	the slave returns to its curve position.

RotaryKnife Representation



Warm start 2 allows backward movement of the slave into the synchronous phase.


⚠ WARNING

UNINTENDED EQUIPMENT OPERATION

Use warm start mode 3 or 5, if the machine design does not account for a backward movement of the slave (Rotary Knife).

Failure to follow these instructions can result in death, serious injury, or equipment damage.

FlyingShear Representation



Warm Start 3 ($i_uiStrtMode = 3$)


With a rising edge at i_xExe :

RotaryKnife Case	FlyingShear Case	If..	Then..
1 and 3	1	<p>the slave is in the synchronous phase and located outside the tolerance window defined by l_rWsdow</p> <ul style="list-style-type: none"> ● $LREAL$ position > curve position (see figure RotaryKnife, case 1) <p>OR</p> <ul style="list-style-type: none"> ● $LREAL$ position < curve position - l_rWsdow (see figure RotaryKnife, case 3) 	<p>the slave remains in position and an alarm is detected. Troubleshooting (<i>see page 325</i>)</p>


RotaryKnife Case	FlyingShear Case	If..	Then..
2	2	the slave is in the synchronous phase and located inside the tolerance window defined by $lrWsWdow$ <ul style="list-style-type: none"> • slave position \leq curve position AND <ul style="list-style-type: none"> • slave position \geq curve position - $lrWsWdow$ 	the slave returns to its curve position.
4	3	the slave is outside the synchronous phase (see figure RotaryKnife, case 4)	the slave returns to its curve position.

NOTE: In this warm start mode, the slave can move only in the positive direction in the event of a stop within the synchronous phase.

RotaryKnife Representation



FlyingShear Representation


Warm Start 4 ($i_uiStrtMode = 4$)

With a rising edge at i_xExe :

RotaryKnife Case	FlyingShear Case	If..	Then..
1	2	the slave is in the synchronous phase and located inside the tolerance window defined by $lrWsWdow$ (see figure RotaryKnife, case 2) <ul style="list-style-type: none"> ● $LREAL\ position \leq curve\ position + lrWsWdow$ AND <ul style="list-style-type: none"> ● $LREAL\ position \geq curve\ position$ 	the slave returns to its curve position.
2 and 3	1	the slave is in the synchronous phase and located outside the tolerance window defined by $lrWsWdow$ <ul style="list-style-type: none"> ● $LREAL\ position \geq curve\ position + lrWsWdow$ (see figure RotaryKnife, case 1) OR <ul style="list-style-type: none"> ● $LREAL\ position < curve\ position$ (see figure RotaryKnife, case 3) 	the slave remains in position and an alarm is detected. Troubleshooting (see page 325).
4	3	the slave is outside the synchronous phase (see figure RotaryKnife, case 4)	the slave returns to its curve position.

NOTE: With this warm start mode, the slave can move only in the negative direction in the event of a stop within the synchronous phase.

RotaryKnife Representation



Warm start 4 allows backward movement of the slave into the synchronous phase.


⚠ WARNING

UNINTENDED EQUIPMENT OPERATION

Use warm start mode 3 or 5, if the machine design does not account for a backward movement of the slave (Rotary Knife).

Failure to follow these instructions can result in death, serious injury, or equipment damage.

FlyingShear Representation


Warm Start 5 ($i_uiStrtMode = 5$)

With a rising edge at i_xExe :


RotaryKnife Case	FlyingShear Case	If..	Then..
1 and 4	2	<p>the slave is in the synchronous phase and located outside the tolerance window defined by $lrWsWdow$</p> <ul style="list-style-type: none"> ● $LREAL\ position > curve\ position + lrWsWdow / 2$ (see figure RotaryKnife, case 1) <p>OR</p> <ul style="list-style-type: none"> ● $LREAL\ position < curve\ position - lrWsWdow / 2$ (see figure RotaryKnife, case 4) 	<p>the slave remains in position and an alarm is detected. Troubleshooting (see page 325).</p>
2 and 3	1	<p>the slave is in the synchronous phase and located inside the tolerance window defined by $lrWsWdow$</p> <ul style="list-style-type: none"> ● $LREAL\ position \geq curve\ position - lrWsWdow / 2$ (see figure RotaryKnife, case 2) <p>AND</p> <ul style="list-style-type: none"> ● $LREAL\ position \leq curve\ position + lrWsWdow / 2$ (see figure RotaryKnife, case 3) 	<p>the slave remains on its position and follow the master as with a normal profile until the end of the synchronous phase.</p>
5	3	<p>the slave is outside the synchronous phase (see figure RotaryKnife, case 5)</p>	<p>the slave returns to its curve position.</p>

NOTE: In this warm start mode, the slave keeps its position shift with the master until the end of synchronous phase in the event of a stop within the synchronous phase.

RotaryKnife Representation



FlyingShear Representation



Section 9.7

Special Modes

What Is in This Section?

This section contains the following topics:

Topic	Page
Immediate Cut	316
Offset Mode	317
Oblique Cut	318
Shift Function	319

Immediate Cut

General


NOTE: This description is valid for the `RotaryKnife_Motion` and the `FlyingShear_Motion` function blocks.

With input `i_xSyncImdt` it is possible to engage an immediate cut in operating mode 0.

The slave does not await the end of the cycle in progress. It begins immediately a new cycle with the start phase. The length of this new cycle will be equal to the length `lrLentoCut`.

The input reacts on a rising edge and is considered only if the slave is in `lrPosRest`. This input will be ignored in operating mode 1 and 2.

RotaryKnife Representation



Offset Mode

General


NOTE: This description is valid for the `RotaryKnife_Motion` and the `FlyingShear_Motion` function blocks.

The offset mode:

- allows the shift of the slave axis a certain distance (`lrCamOfst`) during the synchronous phase.
- can only be activated when the application function block is de-activated.
- When activated, the offset mode is applied at every cycle.
- is activated with the parameter input `xOfstMode`.
- does not influence the length of the process cycle.
- value is defined with the parameter input `lrCamOfst`.
- output `q_xInSync` is TRUE during the complete synchronous phase although slave and master are not synchronized during the transition phase needed to apply the offset.

The start and end positions of this transition are defined by the following parameters:

- `lrPosOfstStrt`
- `lrPosOfstEnd`



Oblique Cut

General

NOTE: This description is valid for the `RotaryKnife_Motion` and the `FlyingShear_Motion` function blocks.


With the parameter r_m , it is possible to adjust the ratio of the position between the slave and the master during the synchronous phase.

$$r_m = \Delta Y / \Delta X$$

This coefficient should be used in the applications, in which the paths of master and slave are not parallel.

r_m can only be modified when the application function block is de-activated.

- $r_m = 1$, the speed of slave and master are equal
- $r_m < 1$, slaves moves slower than the master
- $r_m > 1$, slave moves quicker than the master



Shift Function

General

NOTE: This description is valid for the `RotaryKnife_Motion` and the `FlyingShear_Motion` function blocks.

The shift function allows to adjust manually the cut on the product. This shift ($i_lrShift$) is applied to the master position in order to shift the starting point of cutting on the product.


NOTE:

The shift necessarily creates a variation of the $i_lrLentoCut$ during the transition phase:

- a positive shift leads to a shorter product during the transition and moves the start point of the synchronous phase in the direction of the master movement.
- a negative shift leads to a longer product during the transition and moves the start point of the synchronous phase against the direction of the master movement.

In order to limit the $i_lrLentoCut$ variation during the transition phase, it is possible to apply the total shift divided into several steps.

This can be set-up with $i_lrShiftStepSize$.




Example


Example with a positive shift

Length to cut: $i_lrLentoCut = 100$

Steps 1-4 refer to figure below

Step	Description
1	Length of the product = 100, the product is cut normally $i_lrShift = + 10$ user units $i_lrShiftStepSize = 5$ user units NOTE: In this case the total shift will be applied in 2 steps, corresponding to 2 slave cycles.
2	Length of the product = 95, the product is shorter.
3	Length of the product = 95, the product is shorter. The length of the product comes back to the normal length.
4	Length of the product = 100 The product is cut to the normal length but the starting point of the tool has been shifted of 10 user units.





Start Modes

Depending on the start mode (cold start or warm start), the behavior of the shift is different:

If...	Then...
the slave is restarted with a cold start	the current shift is set to zero. No initial shift is applied.
the slave is restarted with a warm start	the current shift is kept and is applied as soon as the slave restarts. The positioning of the slave on the curve (depending on <code>i_uiStrtMode</code>) is done with the shift.

Remarks:

The following positions and distances are not affected by the shift function:

- length to cut
- rest position

The following windows are not affected by the shift function:

- Touch Probe window
- warm start window

NOTE: `i_lrShift` and `i_lrShiftStepSize` are checked with every rising edge on `i_xActv` and `i_xExe`. When the slave is running (AFB active) `i_lrShift` and `i_lrShiftStepSize` are checked at every machine cycle.

Section 9.8

Quick Reference Guide

What Is in This Section?

This section contains the following topics:

Topic	Page
Visualization	323
Troubleshooting	325

Visualization


Overview

Visualization screens are embedded in the Rotary Knife library. They allow to configure and to start the application function block very easily and quickly.

All the inputs/outputs and all the parameters are accessible.

For more information please refer to How to Integrate the Visualization into an Application ([see page 433](#)).

Rotary Knife template visualization



Rotary Knife parameters visualization

Test parameter

Parameter Inputs

Knife Perimeter :	360.00
Rest Position :	270.00
Sync. End position :	180.00
Stop Deceleration :	1000.00
WS Window :	30.00
Velocity :	500.00
Acc. / Deceleration :	10000.00
Capture Number :	1
TP Distance :	739.00
TP Window :	300.00
Operating Mode :	0
TP Missed Max. :	3
RM :	1.00
Offset Mode	
CAM Offset :	10.00
Offset Start Position :	75.00
Offset End Position :	125.00

Parameter Outputs

TPSP Min. Distance :	0.00
Min. Length To Cut :	0.00

Troubleshooting

Troubleshooting

NOTE: This description is valid for the RotaryKnife_Motion and FlyingShear_Motion function blocks.

Issue	q_diAlrmId Offset	Example	Remark
Application function block alarm detection	10000 (Factory setting)	Application function blocks alarm Id 451 ("Length to cut invalid") will be: $q_diAlrmId = 10000 + 451 = 10451$	If several application libraries are used in the same application, this offset can be modified with the global variable: <code>GC_MotionLib_ErrorOffset</code>
Other alarms (SoftMotion, Motion Controller...)	No offset	SoftMotion alarm Id 12 ("The position limits of the axis have been exceeded") will be: $q_diAlrmId = 12$	-

Notification

When an alarm is detected:

- the slave is stopped immediately with the deceleration ramp `lrDecStop`. The master and slave synchronization is lost.
- `q_xAlrm` is set to TRUE
- `q_diAlrmId` display the notification number according to the table below
- detected alarms have to be reset with a rising edge on the input `i_xAlrmRst`

NOTE: Output `q_diAlrmId` only displays the first detected alarm. Therefore a new problem is reported only if the last active problem has been reset.

Detected AlrmId	Notification
14	Slave axis state is not in standstill at execution. Enable slave axis with <code>MC_Power</code> .
50	Invalid capture input (parameter <code>diCptrNb</code>). Verify parameter. Range: $0 \leq diCptrNb \leq 2$
51	Invalid operating mode (parameter <code>diOpMode</code>). Verify parameter. Range: $0 \leq diOpMode \leq 2$
52	Invalid start mode (input <code>i_uiStrtMode</code>) Verify input. Range: $0 \leq i_uiStrtMode \leq 5$

Detected AlrId	Notification
53	Master moved at warm start. Start modes 1 to 5 ($i_uiStrtMode = 1$ to 5) are only possible if the master is stopped. Stop the master or switch to start mode 0.
55	Slave is outside warm start window configured with parameter $lrWsWdow$. Start modes 2 to 5 ($i_uiStrtMode = 2$ to 5) are not possible.
56	Application function blocks runs on wrong controller. This application function block requires a Motion Controller.
129	Invalid deceleration ramp (parameter $lrDecStop$). Verify parameter. Range: $0 \leq lrDecStop$
130	Invalid warm start window (parameter $lrWsWdow$). Verify parameter. Range: $0 \leq lrWsWdow$
131	Invalid velocity (parameter $lrVel$). Verify parameter. Range: $0 \leq lrVel$
132	Invalid acceleration / deceleration (parameter $lrAccDec$) Verify parameter. Range: $0 \leq lrAccDec$
451	Invalid length to cut (input $i_lrLentoCut$). Verify input. Range: $lrLentoCutMin \leq i_lrLentoCut$ Operating mode 0: $lrLentoCutMin = lrSyncPosEnd$ Operating mode 1: $lrLentoCutMin = lrSyncPosEnd + lrTpWdow/2$ Operating mode 2: <ul style="list-style-type: none"> ● For Rotary Knife: $lrLentoCutMin = lrSyncPosEnd + ABS(((lrPeri - lrPosRest) / lrM) * 1.875)$ ● For Flying Shear: $lrLentoCutMin = lrSyncPosEnd + ABS((lrPosRest / lrM) * 1.875)$
452	Invalid synchronization end position (parameter $lrSyncPosEnd$). Verify parameter. Range: $0 \leq lrSyncPosEnd$
453	Invalid TP distance (parameter $lrTpDistToSypt$). Verify parameter. Range: $lrTpDistToSyptMin \leq lrTpDistToSypt$ <ul style="list-style-type: none"> ● For Rotary Knife: $lrTpDistToSyptMin = ABS(((lrPeri - lrPosRest) / lrM) * 1.875) + lrTpWdow/2$ ● For Flying Shear $lrTpDistToSyptMin = ABS((lrPosRest / lrM) * 1.875) + lrTpWdow/2$

Detected AlarmId	Notification
454	Invalid TP window (parameter $lrTpWdow$). Verify parameter. Range: $lrTpWdow > ((lrPerim - lrPosRest) / lrM) * 1,875$
455	There are more than 15 products between the position capture sensor and the knife, the position buffer is full. Reduce the distance between the sensor and the knife.
456	Invalid RM (slope of oblique cut, parameter lrM). Verify parameter. Range: $0 \leq lrM \leq 10$
457	Invalid CAM offset (parameter $lrCamOfst$). Verify parameter. Range: $0 \leq lrCamOfst \leq lrSyncPosEnd / 2$
458	Invalid TP missed max. (parameter $diTpMisdMax$). Verify parameter. Range: $0 \leq diTpMisdMax$
459	Invalid offset start position (parameter $lrPosOfstStrt$). Verify parameter. Range: $0 < lrPosOfstStrt < lrPosOfstEnd$
460	Invalid offset end position (parameter $lrPosOfstEnd$). Verify parameter. Range: $lrPosOfstStrt < lrPosOfstEnd < lrSyncPosEnd$
461	Invalid shift (input $i_lrShift$). Verify input. Range: $- lrSyncPosEnd \leq i_lrShift \leq + lrSyncPosEnd$
462	Invalid shift step size (input $i_lrShiftStepSize$). Verify input. Range: Operating mode 0: $0 \leq i_lrShiftStepSize < (i_lrLentoCut - lrSyncPosEnd / lrM) * 0.9$ Operating mode 1: $0 \leq i_lrShiftStepSize < (i_lrLentoCut - lrSyncPosEnd / lrM - lrTpWdow / 2) * 0.9$ Operating mode 1: $0 \leq i_lrShiftStepSize$
463	Number of missed marks (out of the TP window). Exceeded the maximum value defined by parameter $diTpMisdMax$ ($q_diTpAlarmCnt > diTpMisdMax$) Only for operating mode 1. Verify the product / verify the position sensor / increase parameter $diTpMisdMax$
465 (for Rotary Knife only)	Invalid knife perimeter (input $lrPeri$). Verify input. Range: $lrPeri \geq 0$

Detected AlrmId	Notification
466	Invalid rest position (parameter $lrPosRest$). Verify parameter. Range: <ul style="list-style-type: none">• For Rotary Knife: $lrSyncPosEnd \leq lrPosRest \leq lrPeri$• For Flying Shear: $lrPosRest \leq 0$
467 (for Rotary Knife only)	Invalid Rotary Knife slave axis configuration. Rotary Knife slave axis must be configured as a modulo axis.
468 (for Flying Shear only)	Invalid Flying Shear slave axis configuration. Flying Shear slave axis must be configured as a linear axis, not as a modulo axis
469 (for Rotary Knife only)	Invalid Rotary Knife slave axis configuration. Rotary Knife slave axis must be configured as a modulo axis with a modulo higher than 2 times the knife perimeter (Slave modulo $\geq 2 * lrPeri$).
470	Invalid master axis configuration. Master axis has to be configured as a modulo axis, with a modulo higher than maximum possible length to cut + TP distance to the synchronization point. ($> \max i_lrLentoCut + lrTpDistToSypt$).
471	The function block was interrupted by a PLCOpen function block.

Part VII

FlyingShear

Chapter 10

FlyingShear_Motion: Synchronization of 2 Linear Axis to Perform On The Fly Operations

What Is in This Chapter?

This chapter contains the following sections:

Section	Topic	Page
10.1	Functional and Machine Overview	332
10.2	Architecture	335
10.3	Function Block Description	336
10.4	Pin Description	338
10.5	Operating Modes	339
10.6	Start, Stop and Starting Modes	340
10.7	Special Modes	341
10.8	Quick Reference Guide	344

Section 10.1

Functional and Machine Overview

What Is in This Section?

This section contains the following topics:

Topic	Page
Functional Overview	333
Machine Overview	334

Functional Overview

Why Use the FlyingShear_Motion Function Block?

The FlyingShear_Motion function block controls a machine that performs an operation, on the fly, on a moving part.

Typical operations can include:

- Cutting
- Clamping
- Stamping
- Marking

Solution with the FlyingShear_Motion Function Block

The Flying Shear function is required for moving the operational axis to synchronize it with the forward motion of the part.

This introduces the concept of master and slave axes.


- Master: moves the part forward
- Slave: performs the operation

NOTE: Although the Flying Shear function can be used for many different applications, the examples shown in this document refer to a typical cutting application.

Machine Overview

Machine View

The figure below gives an example of a Flying Shear application. Both master and slave axes are linear axis types.



Note

Please also refer to:

- Master Axis ([see page 266](#))
- Slave Axis ([see page 267](#))
- Cutting Tool ([see page 267](#))
- Capture Position of the Product ([see page 267](#))

Section 10.2

Architecture

Hardware and Software Architecture

Note

For the hardware and software architecture please refer to the Architecture chapter (*see page 265*).

Section 10.3

Function Block Description

FlyingShear_Motion Function Block

Pin Diagram




Profiles of Master/Slave Positions

The curves (see case 1 and 2 below) show the position profile of the slave axis in relation to the master during the execution of the Flying Shear function.

A Flying Shear cycle consists of 3 phases:

Phase	Description
Start Phase	<p>The slave accelerates up to the master velocity to be synchronized at the beginning of the synchronous phase.</p> <ul style="list-style-type: none"> The start phase distance on the slave is equal to: Slave Start Phase Distance = ABS (lrPosRest) The start phase distance on the master can be calculated with the following formula: Master Start Phase Distance = (ABS (lrPosRest) / lrM) * 1.875
Synchronous Phase	<p>The cut (or the operation) is performed. The synchronous phase always starts at position 0 of the slave.</p>
Return Phase	<p>The slave returns and makes a half-turn before it begins a new synchronous phase.</p> <p>According to the length to be cut and the length of the synchronous phase, 2 cases are distinguished.</p>


Case 1: return to resting position (long cut)



When the ratio $i_lrLentoCut / lrSyncPosEnd$ is > 3 , the slave returns, crosses its position of origin (position 0) and stops at its resting position ($lrPosRest$) before it begins a new cycle.

The duration of the stop depends on the length to cut ($i_lrLentoCut$) and the speed of the master.

Case 2: sequence of cuts (short cut)



When the ratio $i_lrLentoCut / lrSyncPosEnd$ is < 3 , the slave returns, crosses its position of origin and begins a new cycle immediately.

The distance covered by the master during this cycle corresponds to the length to cut ($i_lrLentoCut$).

Section 10.4

Pin Description

Pin Description

Notes

For the input pin description, please refer to the Input Pin Description (*see page 278*) of RotaryKnife_Motion function block.

For the output pin description, please refer to the Output Pin Description (*see page 281*) of RotaryKnife_Motion function block.

For input/output pin description, please refer to the Input/Output Pin Description (*see page 282*) of RotaryKnife_Motion function block.

For structured parameter description, please refer to the Structured Parameter (*see page 283*) of RotaryKnife_Motion function block.

Section 10.5

Operating Modes

Operating Modes

Note

For the description of operating modes, please refer to the Operating Modes chapter (*see page 288*).

Section 10.6

Start, Stop and Starting Modes

Start, Stop and Starting Modes

Note

For the descriptions of start, stop and starting modes, refer to the Start, Stop and Starting Modes chapter (*see page 299*).

Section 10.7

Special Modes

What Is in This Section?

This section contains the following topics:

Topic	Page
Special Modes	342
Interruption of the Synchronous Phase	343

Special Modes

Note


For the descriptions of other special modes, refer to the Special Modes chapter (*see page 315*).

Interruption of the Synchronous Phase

Overview

With the input `i_xSyncAbort`, it is possible to prematurely interrupt the synchronous phase of the cycle. Depending upon the length of the return path, the slave returns to its resting position (`lrPosRest`) or begins a new cycle.

The input reacts on a rising edge and is considered only when the cycle is in the synchronous phase.



Section 10.8

Quick Reference Guide

What Is in This Section?

This section contains the following topics:

Topic	Page
Visualization	345
Troubleshooting	347

Visualization


Overview

Visualization screens are embedded in the FlyingShear library. They allow configuring and starting the application function block easily and quickly.

All the inputs/outputs and all the parameters are accessible.

For more information please refer to How to Integrate the Visualization into an Application ([see page 433](#)).

Flying Shear template visualization



Flying Shear parameters visualization

Test parameterParameter Inputs

Knife Perimeter :	360.00
Rest Position :	270.00
Sync. End position :	180.00
Stop Deceleration :	1000.00
WS Window :	30.00
Velocity :	500.00
Acc. / Deceleration :	10000.00
Capture Number :	1
TP Distance :	739.00
TP Window :	300.00
Operating Mode :	0
TP Missed Max. :	3
RM :	1.00
Offset Mode	
CAM Offset :	10.00
Offset Start Position :	75.00
Offset End Position :	125.00

Parameter Outputs

TPSP Min. Distance :	0.00
Min. Length To Cut :	0.00

Troubleshooting

Note

For troubleshooting, please refer to the Troubleshooting section (*see page 325*).

Part VIII

GroupingUngrouping

What Is in This Part?

This part contains the following chapters:

Chapter	Chapter Name	Page
11	Grouping - Ungrouping: Synchronization of Linear Axes to Organize Products on a Conveyor	351
12	GroupingAccumulator_Motion	367
13	GroupingStripper_Motion	377
14	Operation Description	391
15	Quick Reference Guide	411

Chapter 11

Grouping - Ungrouping: Synchronization of Linear Axes to Organize Products on a Conveyor

What Is in This Chapter?

This chapter contains the following sections:

Section	Topic	Page
11.1	Functional and Machine Overview	352
11.2	Architecture	360

Section 11.1

Functional and Machine Overview

What Is in This Section?

This section contains the following topics:

Topic	Page
Functional Overview	353
Machine Overview	354

Functional Overview

Usage of Grouping/Ungrouping Function

Grouping/Ungrouping involves the synchronization of several conveyors to sort and organize products in a predefined way (groups).

Solution with the Grouping/Ungrouping Function

Appropriate function blocks allow a storing and a subsequent delivery of products. A desired distance between the products can be set and be modified at each cycle.

Those function blocks are:

- GroupingAccumulator_Motion
- GroupingStripper_Motion

Function Description

The `Grouping` function blocks can be used separately or together. In combination they form an unsteady product flow into an evenly spaced product flow. This introduces the concept of master and slave.




For further information, refer to Machine Overview ([see page 354](#)).



Machine Overview



Machine View

General Overview:




Principle of Operation

Conveyor	Figure	Product delivery to following conveyor	Description	Controlled by AFB
Input Conveyor		Input conveyor Velocity > Accumulator Velocity	The input conveyor delivers products with a random product flow. The velocity of the input conveyor must be greater than the velocity of a following accumulation conveyor. A too high back pressure however may push the products on the accumulation conveyor.	No
Accumulator Conveyor		Delivery dependent on $iOpMode$ Product Delivery (see page 357)	The accumulation conveyor generates a product jam. Ensure that no gaps occur as they are not managed by the function block. Product delivery to the following conveyor can be set with $iOpMode = 0..3$.	GroupingAccumulator_Motion (see page 368)

Conveyor	Figure	Product delivery to following conveyor	Description	Controlled by AFB
Stripper Conveyor		During delivery: Distance = $i_lrDistTarg$ Velocity = MasterVelocity Product Delivery (see page 357)	The stripper is the master of the accumulator. At the start position of the stripper, the accumulator generates an evenly spaced product flow which is approximately the final target distance. At the end the stripper has corrected these distances to the accurate target distance and delivers the products with a synchronous speed to the target conveyor.	GroupingStripper_Motion (see page 378)
Target Conveyor		-	The target conveyor is the master of the stripper, or the accumulator if no stripper is used. On this conveyor the products must have a defined distance, and/or position where compartments are used.	No

Compartments on the Target Conveyor



If compartments are used on the target conveyor, the position of this conveyor at the beginning of a movement is important for correct product placement. The parameter $lrMstrOfst$ must be determined once before the first start-up.

Its value remains constant if with every restart of the system a reference movement is executed:

- After a system start-up, execute a reference movement of the master (target conveyor) to an arbitrary compartment edge. The position of the target conveyor is then 0.

NOTICE

INOPERABLE EQUIPMENT

For a proper referencing in the controller configuration, set the modulo value of the target conveyor to the value of `i_lrDistTarg`.

Failure to follow these instructions can result in equipment damage.

- Measure the distance x as the distance from the start of delivery position to the first compartment edge on the target conveyor (see figure *Compartments on the Target Conveyor*).

Calculate the `lrMstrOfst` as a function of x and d :


If...	Then...
$x > d$	$rMsterOfst = i_lrDistTarg - x + d$
$x < d$	$rMsterOfst = d - x$
$d =$ desired distance of the product from the compartment edge	

When using compartments, `xCmpt` must be set TRUE. However this parameter is only evaluated with a cold start. Then the virtual encoder is set to the actual position of the target conveyor minus `lrMstrOfst`.

For an accumulator (if no stripper is used), only `iOpMode = 2` (periodic geared pulsed mode) is allowed.

For further information refer to Cold Start Accumulator ([see page 402](#)) and Cold Start Stripper ([see page 404](#)).

Product Delivery (Stripper)



Requirements:

- The stripping conveyor must deliver each product with an accurate distance ($i_lrDistTarg$) to its predecessor.
- For the duration of the delivery, the stripper and the target conveyor must have exactly the same velocity (Velocity = MasterVelocity).


To fulfill both requirements even high-dynamically, the accumulator conveyor must deliver the products to the stripper conveyor with a distance $i_lrDistTarg$.

For this you can select between 4 different delivery modes ($iOpMode = 0..3$).

The stripper only requires the position information (where compartments are on the target conveyor) and velocity information of the target conveyor (using a cam). Therefore, the master can be an encoder.


For further information, refer to Curve Diagrams ([see page 378](#)), Input Pin Description ([see page 382](#)), Output Pin Description ([see page 384](#)) and Parameter ([see page 388](#)).

Sensor for Product Detection (Accumulator, optional)



The sensor becomes active with the arrival of the first product. Therefore, this sensor is relevant only for a cold start. The parameter `lrTpDistToSypt` sets the distance between the touch probe sensor (TP) and the point of delivery (SyncPt) from which a product is started to be delivered to the following stripper and/or target conveyor. The delivery mode can be selected with `iOpMode`.

Sensor for Product Detection (Stripper)



The sensor becomes active with every arrival of a product. The parameter `lrTpDistToSypt` sets the distance between the sensor (TP) and the point of delivery (SyncPt) from which a product is started to be delivered to the following target conveyor.


During the delivery the stripper conveyor moves synchronously with the target conveyor (*see page 420*).

Up to 15 parts may be buffered between TP and SyncPt.

When the distance between the signals is greater than `i_lrTpDistMin`, the product detection is accepted.

For the compartments on the target conveyor: if the signal distance is greater than $i_lrDistTarg + i_lrTpDistMin$, a compartment is left out and the product detected is delivered to a next compartment.

By applying $i_lrTpDistMin$ with the TP detection, the following type of grouping can be accomplished:



Section 11.2

Architecture

What Is in This Section?

This section contains the following topics:


Topic	Page
Software Architecture	361
Hardware Architecture	363

Software Architecture


Configuration of the Axes with the Motion Controller

The master axis must be configured as a rotary axis.

The modulo value must be set higher than the application's maximum `i_lrDistTarg`. The modulo value is a configuration parameter and cannot be modified by the application



All inputs/outputs for position, velocity and acceleration in user units are defined in the controller configuration.



Example:

Gear ratio = 1: 1

1 motor revolution = 360 mm

Configuration of the Slave Axis with the Drive

In addition to the communication parameters (addresses on the bus, speed transmission), the following parameter adjustments should be made to optimize the response of the servo drive that controls the slave axis:

- increase the maximum slopes of acceleration and deceleration.
- set the parameter `N_ref_Filter` to OFF.
- set various loop parameters. They include proportional gain speed loop, integral time speed loop and the proportional gain position.


Hardware Architecture

Hardware Architecture Overview


The target conveyor (master axis) moves the products forward continuously. It is an infinite axis.

The controller of this axis can be of any type (servo drive, variable speed drive, etc.). The movement of this axis is not controlled by a Grouping function block.

Both master and slave may be axes on CANmotion or Sercos:



If the master axis is not a servo drive on the same CANmotion or Sercos as the slave, then the position of the master is determined by an encoder signal connected to the input of the Motion Controller:



Sensor Wiring (Accumulator)

The sensor is evaluated at a cold start and only once with the arrival of the first product.

Sensor wiring (accumulator) is only possible over a standard input by wiring one of the digital inputs to `i_xTpInputStd`.

NOTE: The accuracy depends on the master velocity and the program cycle time and/or the cycle time of the Motion Controller.

Sensor Wiring (Stripper)

Perform the sensor wiring (stripper) over a TP input as follows.

A TP input is used where a short acquisition time is required. The TP position is captured via CANmotion or Sercos. The attainable accuracy is higher than with the capturing over a standard input (see below).

- Set the parameter `xTpMode` to TRUE.
- Connect the sensor to one of the capture inputs (`CAP1` or `CAP2`) of the Lexium servo drive.

NOTE: The TP inputs of the Controller cannot be used as they can only trigger encoder positions (master) and not drive positions.

- Set the parameter `iCptrNb` to 0 or 1.
- The input `i_xTpInputStd` is unused.

The edge to be evaluated must be configured directly in the Lexium drive.

Using for Sercos:

- the `FB_SercosWriteServiceDataAsync`

Using for CANmotion either:

- the `SMC3_CAN_WriteParameter`
- the CAN Drive list in the Controller configuration

Line	Index:Subindex	Name	Value	Bitlength	Abort if error	Jump to line if error	Next line	Comment
1	16#3006:16#07	Scaling1	16#20000	32	<input type="checkbox"/>	<input type="checkbox"/>	0	
2	16#3006:16#08	Scaling2	1	32	<input type="checkbox"/>	<input type="checkbox"/>	0	
3	16#3012:16#08	CTRL_KFP	1000	16	<input type="checkbox"/>	<input type="checkbox"/>	0	
4	16#3006:16#10	IOsigLimP	0	16	<input type="checkbox"/>	<input type="checkbox"/>	0	
5	16#300A:16#04	Cap1Activate	2	16	<input type="checkbox"/>	<input type="checkbox"/>	0	
6	16#300A:16#02	Cap1Config	1	16	<input type="checkbox"/>	<input type="checkbox"/>	0	
7	16#3006:16#0F	IOsigLimN	0	16	<input type="checkbox"/>	<input type="checkbox"/>	0	
8	16#300A:16#05	Cap2Activate	2	16	<input type="checkbox"/>	<input type="checkbox"/>	0	
9	16#300A:16#03	Cap2Config	1	16	<input type="checkbox"/>	<input type="checkbox"/>	0	

- Configure the parameter `Cap1Config` for capture unit 1, or `Cap2Config` for capture unit 2.

Parameter Name HMI menu	Description	Unit Minimum value Default value Maximum value	Data type R/W persistent Expert	Parameter address via fieldbus
Cap1Config	Configuration of capture unit 1 (240)	-	UINT16	CANopen 300A:2h
-	0 / 1->0: position capture with 1->0 switch	0	UINT16	Modbus 2564
-	1 / 0->1: position capture with 0->1 switch	1	R/W	-
-			-	-

The Sercos identification number (IDN) for `Cap1Config` is P-O-3010.0.2

Parameter Name HMI menu	Description	Unit Minimum value Default value Maximum value	Data type R/W persistent Expert	Parameter address via fieldbus
Cap2Config	Configuration of capture unit 2 (240)	-	UINT16	CANopen 300A:3h
-	0 / 1->0: position capture with 1->0 switch	0	UINT16	Modbus 2566
-	1 / 0->1: position capture with 0->1 switch	0	R/W	
		1	-	

The Sercos identification number (IDN) for Cap2Config is P-O-3010.0.3

NOTE: This parameter cannot be saved in the Lexium persistent Memory (EEPROM).

Perform the sensor wiring (stripper) over a standard input as follows:

Alternatively to a TP input, an digital input of the controller may be used. However, in this case the attainable accuracy depends on the master velocity and the program cycle time and/or the cycle time of the Motion Controller. A captured position will be evaluated by the function block.

- sets the parameter `xTpMode` to FALSE.
- wire 1 of the digital inputs to `i_xTpInputStd`.

Chapter 12

GroupingAccumulator_Motion

What Is in This Chapter?

This chapter contains the following sections:

Section	Topic	Page
12.1	Function Block Description	368
12.2	Pin Description	369

Section 12.1


Function Block Description

GroupingAccumulator_Motion Function Block

Pin Diagram

The Accumulator function block is made up of:

- Inputs and outputs (they can be changed on the fly.)
- Parameters of inputs / outputs



Section 12.2

Pin Description

What Is in This Section?

This section contains the following topics:

Topic	Page
Input Pin Description	370
Output Pin Description	372
Input/Output Pin Description	374
Structured Parameter	375

Input Pin Description

Input Pin Description

Input	Data Type	Description
i_xEn	BOOL	<p>TRUE: Enables the function block</p> <ul style="list-style-type: none"> With a rising edge, the parameters are checked for validity and consistency. A falling edge stops a movement with deceleration <code>lrDecEmgy</code>. The parameters defined in <code>iq_stPara</code> are checked. Incorrect or inconsistent input parameters affect the outputs <code>q_xAlrm</code> and <code>q_diAlrmId</code>. <p>FALSE: The current movement stops with <code>lrDecEmgy</code></p> <ul style="list-style-type: none"> The output <code>q_xActv</code> stays TRUE until stopping is finished. While <code>q_xActv = TRUE</code>, the function block must be called cyclically. <p>Factory setting: FALSE</p>
i_xExe	BOOL	<p>TRUE: The movement starts (steady signal required)</p> <ul style="list-style-type: none"> A falling edge stops a movement with deceleration <code>lrAccDecStrt</code>. <p>Factory setting: FALSE</p>
i_xWsSel	BOOL	<p>FALSE: Cold start TRUE: Warm start</p> <p>Different cold and warm start modes are available, see Starting Modes (see page 402)</p> <p>Factory setting: FALSE</p>
i_lrProdLen	LREAL	<p>Length of product</p> <ul style="list-style-type: none"> Must be \ll slave modulo (configured in Controller configuration) Must be \leq <code>i_lrDistTarg</code>, otherwise an interruption is generated. <p>Factory setting: 0</p>

Input	Data Type	Description
i_lrDistTarg	LREAL	<p>Desired distance for products (length of product plus gap) on master (stripper or target conveyor) of accumulator.</p> $\text{Accumulator velocity} = \frac{i_lrProdLen}{i_lrDistTarg} \cdot \text{Target velocity}$ <ul style="list-style-type: none"> • Must be << slave modulo (configuration in Controller configuration). • Must be >= i_lrProdLen, otherwise an interruption is generated <p>Factory setting: 0 Range: > 0</p>
i_xAlrmRst	BOOL	<p>TRUE: Detected alarm is acknowledged, function block leaves alarm state. Factory setting: FALSE</p>
i_xTpIputStd	BOOL	<p>For product detection (first product edge at cold start), see Sensor Wiring (<i>see page 363</i>) Factory setting: FALSE</p>
i_xPulsIput	BOOL	<p>Only with iOpMode = 1 or 3 pulse for product delivery. Factory setting: FALSE</p>
i_lrPrdActlMstr	LREAL	<p>The position period of the master has to be set here as input. The master cannot make any position jumps (because of modulo or set pos) different from this input or the slave can not run. Range: > 0</p>

Output Pin Description

Output Pin Description

Output	Data Type	Description
q_xActv	BOOL	TRUE: Function block is active.
q_xPosStrtRchd	BOOL	TRUE: Cold / warm start position reached. Reset with function block disabled (i_xEn = FALSE)
q_xCyclofSlavActv	BOOL	Only with iOpMode = 1 or 3 TRUE: While a slave cycle is in progress. FALSE: When slave is ready to start a new cycle.
q_lrPrdActlSlav	LREAL	On this output the actual period of the CAM curve is given. If the drive is a master for another drive, this signal has to be given to the control function block of the slave.
q_xAlrm	BOOL	TRUE: Not OK
q_diAlrmId	DINT	Notification number: Troubleshooting (<i>see page 413</i>) Range: 0..99999

Troubleshooting

There are 2 types of notifications given on the output of the function block.

The first types of notifications come from internal (SoftMotion (SM3 library)) function blocks. These notifications are given directly to the output q_diAlrmId. For these notifications see the notifications list of the SoftMotion (SM3 library) function blocks.

The second types of notifications are generated by the function block itself. These notifications are added to the global constant GC_MotionLib_ErrorOffset (standard 1000).

Detected Alarm ID (added to GC_MotionLib_ErrorOffset)	Notification
10	controller axis detected alarm
14	controlled axis in wrong state
15	controlled axis is not a modulo axis
50	invalid capture input
51	invalid iOpMode
52	invalid iWsMode
53	master moved during start
54	warm start not possible
55	position outside warm start window

Detected Alarm ID (added to GC_MotionLib_ErrorOffset)	Notification
129	invalid lrDecEmgy
130	invalid lrWsWdow
453	lrTpDistToSypt < 0
455	FIFO full - too many products detected
501	FIFO empty - no products detected
502	no TP found
504	invalid i_lrSyncLen
505	invalid i_lrTpDistMin
506	invalid i_lrProdLen
507	invalid i_lrDistTarg
508	i_lrProdLen greater i_lrDistTarg
509	i_lrSyncLen greater i_lrDistTarg
510	i_lrSyncLen greater i_lrDistDflt
511	invalid i_lrDistDflt
512	lrTpDistToSypt smaller i_lrDistDflt plus i_lrTpDistMin
513	i_lrTpDistMin smaller i_lrSyncLen
514	invalid iCsMode
515	invalid lrCsDistMax
516	invalid lrVelStrt
517	invalid lrAccDecStrt
519	invalid lrVelOpModel
520	invalid lrAccOpModel
521	invalid lrDecOpModel
522	invalid lrPulsSyncPhas
523	invalid Slop
524	invalid lrVelSts1
525	invalid lrCorrMax
526	invalid lrMstrOfst
527	invalid warm start data

Input/Output Pin Description

Input/Output Pin Description

Input/Output	Data Type	Description
iq_stDrvMstr	AXIS_REF_SM3	Master axis (stripper or target conveyor) reference
iq_stDrvSlav	AXIS_REF_SM3	Slave axis (accumulator) reference
iq_stPara	STRUCT ST_GroupingAccumulatorParameter	Block parameters For further information, refer to Structured Parameters <i>(see page 375)</i> .

Structured Parameter

iq_stPara

Structure Parameter	Data Type	Description
iCsMode	INT	Cold start mode 0: first product is moved to delivery position 1: dimension setting (no movement) Cold Start Mode (<i>see page 402</i>) Factory setting: 0
iWsMode	INT	Selecting warm start mode (<i>see page 406</i>). Factory setting: 0
iOpMode	INT	0: Geared mode (<i>see page 394</i>) 1: Triggered timed pulsed mode (<i>see page 396</i>) 2: Periodic geared pulsed mode (<i>see page 397</i>) 3: Triggered geared pulsed mode (<i>see page 398</i>) Factory setting: 0
lrCsDistMax	LREAL	Maximum position allowed for detecting the first product ($i_xTpIputStd = TRUE$) = 0: no limitation > 0: axis moves maximum this distance Factory setting: 1000
lrWsWdowFwd	LREAL	Only with $iWsMode = 1$ or 4 . Maximum position that the slave is allowed to move forward to return to the cam position. Factory setting: 200
lrWsWdowBack	LREAL	Only with $iWsMode = 1$ or 4 . Maximum position that the slave is allowed to move backwards in order to return to the cam position. Factory setting: 10
lrVelStrt	LREAL	Start velocity Factory setting: 100
lrAccDecStrt	LREAL	Start acceleration / deceleration (also for falling edge at i_xExe) Factory setting: 1000
lrTpDistToSypt	LREAL	Distance between TP (sensor) and SyncPt (start of delivery). Must be greater than master modulo ($i_lrDistTarg$) + $lrMstrOfst$ Factory setting: 180
lrDecEmgy	LREAL	Stop ramp for detected error stop or falling edge at i_xEn . Factory setting: 10000

Structure Parameter	Data Type	Description
lrVelOpModel	LREAL	Only with iOpMode = 1 Maximum velocity for moving to the cam position. Factory setting: 360
lrAccOpModel	LREAL	Only with iOpMode = 1. Maximum acceleration for moving to the cam position. Factory setting: 1000
lrDecOpModel	LREAL	Only with iOpMode = 1. Maximum deceleration for moving to the cam position. Factory setting: 1000
lrSlop	LREAL	Only with iOpMode = 2 or 3. Gear ratio between master and slave during the synchronous phase. Examples: 1: velocity ratio between accumulator and stripper is 1:1. 2: velocity ratio between accumulator and stripper is 2:1 (accumulator delivers the products to the stripper faster than with 1:1). Factory setting: 1
lrPulsSyncPhas	LREAL	Only with iOpMode = 2 or 3. Length of the synchronous phase in percentage of the product length. Factory setting: 80 Range: 0..99%
lrMstrOfst	LREAL	Only with cold start and xCmpt = TRUE. Product distance from a compartment edge. Factory setting: 0
xCmpt	BOOL	Only with cold start TRUE: Target conveyor with compartments. FALSE: Target conveyor without compartments. Compartments on the Target Conveyor (see page 355). Factory setting: FALSE
lrVelSts1	LREAL	Velocity window in which the drive is considered to be standing still. Factory setting: 10

Chapter 13

GroupingStripper_Motion

What Is in This Chapter?

This chapter contains the following sections:

Section	Topic	Page
13.1	Function Block Description	378
13.2	Pin Description	381

Section 13.1


Function Block Description

GroupingStripper_Motion Function Block

Pin Diagram

The Stripper function block is made up of:

- Inputs and outputs (they can be changed on the fly.)
- Parameters of inputs / outputs




Curve Diagrams


Trajectory for correcting the product distance:

The motion profile indicates how products are passed from the stripper to the target conveyor.


The distance of a product to its predecessor measured by the TP sensor of the stripper is corrected. This is done so that the distance is exactly = $i_lrDistTarg$ at the position of delivery to the target conveyor. During the delivery ($i_lrSyncLen$) the stripper (slave) and the target conveyor (master) move synchronously (Velocity = MasterVelocity). The TP sensor may have detected another product (a maximum of 15 are possible) during this time.



Special case: No product on conveyor



Special case: Changing $i_lrDistTarg$ on the fly



Section 13.2

Pin Description

What Is in This Section?

This section contains the following topics:

Topic	Page
Input Pin Description	382
Output Pin Description	384
Input/Output Pin Description	387
Structured Parameter	388

Input Pin Description

Input Pin Description

Input	Data Type	Description
i_xEn	BOOL	<p>TRUE: Enables the function block</p> <ul style="list-style-type: none"> With a rising edge, the parameters are checked for validity and consistency. A falling edge stops a movement with deceleration <code>lrDecEmgy</code>. The parameters defined in <code>iq_stPara</code> are checked. Incorrect or inconsistent input parameters will affect the outputs <code>q_xAlrm</code> and <code>q_diAlrmId</code>. <p>FALSE: The current movement stops with <code>lrDecEmgy</code></p> <ul style="list-style-type: none"> The output <code>q_xActv</code> stays TRUE until a stopping is finished. While <code>q_xActv</code> = TRUE, the function block must be called cyclically. <p>Factory setting: FALSE</p>
i_xExe	BOOL	<p>TRUE: The movement starts (steady signal required)</p> <ul style="list-style-type: none"> A falling edge stops a movement with deceleration <code>lrAccDecStrt</code>. <p>FALSE: Stripper in cyclic (automatic) mode</p> <ul style="list-style-type: none"> The stripper axis stops at the end of the synchronous phase (position > <code>i_rLenSync</code>). If <code>i_xExe</code> goes TRUE again within the same synchronous phase, the previous FALSE will be ignored. <p>Factory setting: FALSE</p>
i_xWsSel	BOOL	<p>FALSE: Cold start TRUE: Warm start</p> <p>Different cold and warm start modes are available, refer Cold Start (<i>see page 404</i>) and Warm Start (<i>see page 406</i>)</p> <p>Factory setting: FALSE</p>

Input	Data Type	Description
i_lrDistTarg	LREAL	Desired distance for products (length of product plus gap) on master (stripper or target conveyor) of accumulator. <ul style="list-style-type: none"> Must be << slave modulo (configured in controller configuration). Factory setting: 0 Range: > 0
i_lrDistDflt	LREAL	Default distance on stripper. It should be equal to i_lrDistTarg of accumulator and is used if a part is missing. Factory setting: 0 Range: > 0
i_lrSyncLen	LREAL	Distance that the slave (stripper) moves synchronously with the master (target conveyor). Factory setting: 0 Range: > 0
i_lrTpDistMin	LREAL	Minimum distance between 2 edges at the TP input. Factory setting: 0 Range: > 0
i_xAlrmRst	BOOL	TRUE: Detected alarm is acknowledged, function block leaves alarm state. Factory setting: FALSE
i_xTpIputStd	BOOL	Standard input is used for product detection if xTpMode = FALSE. Sensor Wiring (<i>see page 364</i>) Factory setting: FALSE
i_lrPrdActlMstr	LREAL	The position period of the master has to be set here as input. The master cannot make any position jumps (because of modulo or set pos) different from this input or the slave can not run. Factory setting: 0 Range: > 0

Output Pin Description

Output Pin Description

Output	Data Type	Description
q_xActv	BOOL	TRUE: Function block is active.
q_xPosStrtRchd	BOOL	TRUE: Cold / warm start position reached. Reset with function block disabling (i_xEn = FALSE)
q_xCorrMax	BOOL	TRUE: The current product would require a correction > lrCorrMax. Instead a backward correction is executed (=> empty place on the target conveyor) and this output q_xCorrMax is set.
q_iTpMisd	INT	Number of consecutive missing parts. Range: 0...n
q_lrPrdActlSlav	LREAL	On this output the actual period of the CAM curve is given. If the drive is a master for another drive, this signal has to be given to the control function block of the slave. E.g. to the input i_lrPrdActlMstr of the Accumulator function block.
q_xAlrm	BOOL	TRUE: Not OK
q_diAlrmId	DINT	Notification number: Notification (<i>see page 413</i>) Range: 0...99999

Troubleshooting

There are 2 types of notifications given on the output of the function block.

The first types of notifications are coming from internal used SoftMotion (SM3 library) function blocks. These notifications are given directly to the output `q_diAlrmId`. For these notifications see the notifications list of the SoftMotion (SM3 library) function blocks.

The second types of notifications are generated by the function block itself. These notifications are added to the global constant `GC_MotionLib_ErrorOffset` (standard 1000).

Detected Alarm ID (added to <code>GC_MotionLib_ErrorOffset</code>)	Notification
10	controlled axis not working
14	controlled axis in wrong state
15	controlled axis is no modulo axis
50	invalid capture input
51	invalid <code>iOpMode</code>
52	invalid <code>iWsMode</code>
53	master moved during start
54	warm start not possible
55	position outside warm start window
129	invalid <code>lrDecEmgy</code>
130	invalid <code>lrWsWdow</code>
453	<code>lrTpDistToSypt < 0</code>
455	FIFO full - too much products detected
501	FIFO empty - no products detected
502	no TP found
504	invalid <code>i_lrSyncLen</code>
505	invalid <code>i_lrTpDistMin</code>
507	invalid <code>i_lrDistTarg</code>
509	<code>i_lrSyncLen</code> greater <code>i_lrDistTarg</code>
510	<code>i_lrSyncLen</code> greater <code>i_lrDistDflt</code>
511	invalid <code>i_lrDistDflt</code>
512	<code>lrTpDistToSypt</code> smaller <code>i_lrDistDflt</code> plus <code>i_lrTpDistMin</code>
513	<code>i_lrTpDistMin</code> smaller <code>i_lrSyncLen</code>
514	invalid <code>iCsMode</code>

Detected Alarm ID (added to GC_MotionLib_ErrorOffset)	Notification
515	invalid lrCsDistMax
516	invalid lrVelStrt
517	invalid lrAccDecStrt
519	invalid lrVelOpModel
520	invalid lrAccOpModel
521	invalid lrDecOpModel
522	invalid lrPulsSyncPhas
523	invalid Slop
524	invalid lrVelSts1
525	invalid lrCorrMax
526	invalid lrMstrOfst
527	invalid warm start data

Input/Output Pin Description

Input/Output Pin Description

Input/Output	Data Type	Description
iq_stDrvMstr	AXIS_REF_SM3	Master axis (stripper or target conveyor) reference
iq_stDrvSlav	AXIS_REF_SM3	Slave axis (accumulator) reference
iq_stPara	STRUCT ST_GroupingStripperParameter	Block parameters For further information refer to Structured Parameters (<i>see page 375</i>).

Structured Parameter

iq_stPara

Changes of parameters are accepted with a positive edge at input `i_xEn`

At the same time the parameters are checked. If their values are invalid or inconsistent, an interruption is generated which affects the outputs `q_xAlrm` and `q_diAlrmId`.

Structure Parameter	Data Type	Description
<code>iWsMode</code>	INT	Selecting warm start mode (<i>see page 406</i>). Factory setting: 0
<code>lrCsDistMax</code>	LREAL	Maximum distance allowed for detecting the first product (<code>i_xTpIputStd = TRUE</code>) = 0: no limitation > 0: axis maximum distance Factory setting: 1000
<code>lrCorrMax</code>	LREAL	Maximum distance for forward correction. If the distance to the next product is to high (correction > <code>lrCorrMax</code>), a place on the target conveyor is left empty. This prevents excessive stripper acceleration and velocity. Factory setting: 20
<code>lrWsWdowFwd</code>	LREAL	Only with <code>iWsMode = 1</code> or <code>4</code> . Maximum distance that the slave is allowed to move forward in order to return to the cam position. Factory setting: 200
<code>lrWsWdowBack</code>	LREAL	Only with <code>iWsMode = 1</code> or <code>4</code> . Maximum distance that the slave is allowed to move backwards in order to return to the cam position. Factory setting: 10
<code>lrVelStrt</code>	LREAL	Start velocity Factory setting: 200
<code>lrAccDecStrt</code>	LREAL	Start acceleration / deceleration (also for falling edge at <code>i_xExe</code>) Factory setting: 1000
<code>xTpMode</code>	BOOL	TRUE: Use TP input (<code>iCptrNb</code>) FALSE: Use standard input (<code>i_xTpIputStd</code>) Factory setting: FALSE

Structure Parameter	Data Type	Description
lrTpDistToSypt	LREAL	Distance between TP (sensor) and SyncPt (start of delivery). Must be greater than master modulo ($i_lrDistTarg$) + lrMstrOfst Factory setting: 500
lrDecEmgy	LREAL	Stop ramp for error stop or falling edge at i_xEn . Factory setting: 5000
lrMstrOfst	LREAL	Only with cold start and $xCmpt = TRUE$. Product distance from a compartment edge. Factory setting: FALSE
xCmpt	BOOL	Only with cold start TRUE: Target conveyor with compartments FALSE: Target conveyor without compartments Compartments of the Target Conveyor (<i>see page 355</i>) Factory setting: FALSE
lrVelStsl	LREAL	Velocity window in which the drive is regarded as standing still Factory setting: 10
iCptrNb	INT	Number of the TP (0 or 1) to be used. Factory setting: 0

Chapter 14

Operation Description

What Is in This Chapter?

This chapter contains the following sections:

Section	Topic	Page
14.1	Operating Modes	392
14.2	Start, Stop and Special Modes	399

Section 14.1

Operating Modes


What Is in This Section?

This section contains the following topics:

Topic	Page
General Description	393
Geared Mode	394
Triggered Timed Pulsed Mode	396
Periodic Geared Pulsed Mode	397
Triggered Geared Pulsed Mode	398

General Description

Overview



$iOpMode$ sets how the products are passed from the accumulator to the stripper (and/or the target conveyor).

$iOpMode$	Name	Principle	Description
0	Geared Mode		Master/slave have constant velocity ratio (during delivery master and slave run with different velocities).
1	Triggered Timed Pulsed Mode		Pulse triggered delivery of one product length (independent of master; no synchronous phase)
2	Periodic Geared Pulsed Mode		Master/slave mode with synchronous phase (during delivery master and slave run with the same velocity). The delivery is triggered cyclically and depends on $i_lrDistTarg$.
3	Triggered Geared Pulsed Mode		Master/slave mode with synchronous phase (as with $iOpMode = 2$). Here a pulse triggers the synchronous phase


Geared Mode

Overview




The accumulator follows its master with the velocity ratio:

$$\text{Accumulator velocity} = \frac{i_lrProdLen}{i_lrDistTarg} \cdot \text{Target velocity}$$



`i_lrProdLen` and `i_lrTargDis` are both inputs of the `GroupingAccumulator_Motion` block.

The master may be a stripper or target conveyor. The change of the velocity is accepted cyclically.



With a rising edge at i_xExe , the accumulator synchronizes with its master axis.

If $i_lrProdLen$ or $i_lrDistTarg$ are changed on the fly (during the movement), a (Poly5) transition cam is used.

Triggered Timed Pulsed Mode

Overview


PulseInput

On a rising edge at $i_xPulsInput$ (and $i_xExe = TRUE$) one product is delivered. I.e., the accumulator is positioned $i_lrProdLen$ forward. There is no synchronization with the master.

Repetitive pulses (rising edges at $i_xPulsInput$) during one cycle are ignored.

The motion of the accumulator is defined by the following parameters:

- $lrVelOpModel$ (velocity)
- $lrAccOpModel$ (acceleration)
- $lrDecOpModel$ (deceleration)



Periodic Geared Pulsed Mode

Overview



When `i_xExe = TRUE`, the accumulator executes a periodic movement. With every master period `i_lrDistTarg` one product is delivered.

Setting the delivery cam.

The accumulator follows its master over an electronic cam:

- X-Factor is `i_lrDistTarg`
- Y-Factor is `i_lrProdLen`


Within a master period (`i_lrDistTarg`) the slave movement is divided into 3 phases:

- acceleration phase
- synchronous phase
- deceleration phase

These curves can be adjusted by `lrPulsSyncPhas` and `lrSlop`. Their values must be consistent. For further informations refer to Special Modes (*see page 408*).

Triggered Geared Pulsed Mode

Overview



On a rising edge at `i_xPulsInput` (and `i_xExe = TRUE`) one product is delivered. The accumulator performs one motion cycle and is positioned `i_lrProdLen` forward. Here if `iOpMode` \neq 1, the motion cycle is defined by an electronic cam.

Repetitive pulses (rising edges at `i_xPulsInput`) during one cycle are ignored.

The delivery movement is the same as with `iOpMode = 2`.

Section 14.2

Start, Stop and Special Modes

What Is in This Section?

This section contains the following topics:

Topic	Page
Start and Resume Modes	400
Stop and Resume Modes	401
Cold Start - GroupingAccumulator_Motion	402
Cold Start - GroupingStripper_Motion	404
Warm Start	406
Special Modes	408

Start and Resume Modes

Start and Resume Modes

When the input `i_xEn` is activated, the parameters defined in `iq_stPara` are checked for consistency. With incorrect or inconsistent input parameters, `q_xAlrm` becomes TRUE. In `q_diAlrmId` the notification number is indicated.

When the input `i_xEn` is activated, the control of the slave is managed by the Grouping function block.

When the input `i_xExe` is activated, the slave is launched according to the start mode defined by the input `i_xWsSel`.

WARNING

UNINTENDED EQUIPMENT OPERATION

Do not send any other commands to the slave axis when it is under control of the Grouping/Ungrouping application function block.

Failure to follow these instructions can result in death, serious injury, or equipment damage.

The start modes describe the slave behavior on a rising edge at `i_xExe`.

For the Accumulator, refer to Cold Start ([see page 402](#)) and Warm Start ([see page 406](#)).

For the Stripper, refer to Cold Start ([see page 404](#)) and Warm Start ([see page 406](#)).

The axes behavior when starting is dependent upon the conditions for stopping, which include:

- Falling edge at input `i_xEn`
- Falling edge at `i_xExe`
- Detected alarm in the block function

For further details, refer to Stop and Resume Modes ([see page 401](#)).

Stop and Resume Modes

Stop and Resume Modes

The stop and resume modes describe the slave behavior according to the cause of the stop.

With normal execution of the function, when the master stops, the slave stops following the master slope.

With the restart of the master (without modification of the block inputs) the slave will follow accordingly.

Other causes for a stop may be:

Cause for Stop	Stop Ramp	Possible Resume Modes
Falling Edge at i_xEn	lrDecEmgy	Cold start or warm start
Falling Edge at i_xExe	lrAccDecStrt	Cold start or warm start
Block Problem	lrDecEmgy	Cold start

In all 3 cases the master (target conveyor and/or stripper) must be stopped immediately.

If this is not possible, the following events may occur:

If...	Then...
conveyors are within SyncPhase	with a standing or moving conveyor, the product currently being delivered may be shifted in an undefined manner.
conveyors are outside SyncPhase	at the next warm start the next product can be pushed onto a standing master conveyor.

Take into consideration the actions and events listed in the following table for a restart.

With an...	Then...
cold start within SyncPhase	you have to remove the products from the delivery position before the cold start, otherwise a collision may occur.
cold start outside SyncPhase	the start can be managed without any specific consideration.
warm start within SyncPhase after the master stopped immediately	the start can be managed without any specific consideration.
warm start within SyncPhase after the master had moved on	the product currently being delivered may be shifted in an undefined manner.
warm start outside SyncPhase after the master stopped immediately	the start can be managed without any specific consideration.
warm start outside SyncPhase after the master had moved on	during the warm start the products may be pushed onto a standing master conveyor.

Cold Start - GroupingAccumulator_Motion

Overview

There are 2 different cold start modes for the behavior of the accumulator (see `iCsMode` in the table below).

When the cold start is finished, `q_xPosStrtRchd` becomes TRUE.

For further informations refer to Warm Start Modes ([see page 406](#)).

Requirements for a Cold Start

A cold start is the first start after switching on the machine. The master (stripper or target conveyor) must wait for the arrival of the first product before moving. Otherwise, at the end of the cold start movement an interrupt is generated.

Settings for a Cold Start

For a cold start, the following inputs and parameters must be set:

Input and/or Parameter	Description	
<code>i_xWsSel</code>	TRUE: Warm start FALSE: Cold start	
<code>iCsMode</code>	Cold start mode	
	Setting	Description
	0	<p>the axis moves until the TP sensor detects the first product (<code>i_xTpInputStd = TRUE</code>). Then the axis moves forward <code>lrTpDistToSypt</code>:</p> <ul style="list-style-type: none"> When exceeding the <code>lrCsDistMax</code> for detecting a product, an alarm is generated. When <code>iOpMode = 1</code> or <code>iOpMode = 3</code> and there is a rising edge at <code>i_xPulsInput</code>, the conveyor moves forward <code>i_lrProdLen</code>. <p>For further informations, refer to Sensor Wiring (see page 363), Geared Mode (see page 394) and Triggered Geared Pulsed Mode (see page 398).</p>
1	<p>setting dimension: the axis is set to a defined start position (constant internal value). There is no movement taking place.</p> <ul style="list-style-type: none"> This mode is used where no TP sensor exists or is taken into account. The user positions the first product at the delivery position. The axis is set to the calculated slave position (<code>iOpMode = 1</code> or <code>iOpMode = 3</code>) and/or to <code>i_lrDistTarg</code> (<code>iOpMode = 0</code> or <code>iOpMode = 2</code>). <p>For further informations, refer to Geared Mode (see page 394), Triggered Timed Pulsed Mode (see page 396), Periodic Geared Pulsed Mode (see page 397) and Triggered Geared Pulsed Mode (see page 398).</p>	

Input and/or Parameter	Description	
lrTpDistToSypt	Measured distance between the sensor (TP) and the synchronous start point (SyncPt, end of conveyor, start of delivery)	
lrCsDistMax	maximum permissible distance for detecting the first product (<i>i_xTpIputStd</i> = TRUE)	
	Setting	Description
	= 0	no limitation
> 0	maximum axis movement	
lrVelStrt	start velocity	
lrAccDecStrt	start acceleration / deceleration	
lrMstrOfst	only if no stripper is used only with <i>xCmpt</i> = TRUE Product distance from a compartment edge	
xCmpt	only if no stripper is used TRUE: Compartments on target conveyor. Refer to Compartments of the Target Conveyor (<i>see page 355</i>) FALSE: No compartments on target conveyor. The synchronization starts immediately.	

Cold Start - GroupingStripper_Motion


Overview

The stripper moves until the TP sensor detects a product. Then `q_xPosStrtRchd` becomes TRUE.

Requirements for a Cold Start

A cold start is the first start after switching on the machine. The position of the products are unknown.

The cold start of the accumulator (if applicable) must be finished, i.e., the accumulator operates in automatic mode. For further information, refer to Cold Start Accumulator ([see page 402](#)) and Sensor Wiring ([see page 364](#)).



The master (target conveyor) must wait for the arrival of the first product.

Otherwise, at the end of the cold start movement an interruption is generated.

If compartments are used, the target conveyor must wait in its start position.

Settings for a Cold Start

For a cold start, the following inputs and parameters must be set:

Input and/or Parameter	Description
i_xWsSel	TRUE: Warm start FALSE: Cold start
lrTpDistToSypt	Measured distance between the sensor (TP) and the synchronous start point (SyncPt, end of conveyor, start of delivery)
lrCsDistMax	maximum permissible distance for detecting the first product (i_xTpInputStd = TRUE)
	Setting Description
	= 0 no limitation
> 0	maximum axis movement
lrVelStrt	start velocity
lrAccDecStrt	start acceleration / deceleration
lrMstrOfst	only with xCmpt = TRUE Product distance from a compartment edge
xCmpt	TRUE: Compartments on target conveyor. Refer to Compartments of the Target Conveyor (<i>see page 355</i>) FALSE: No compartments on target conveyor. The synchronization starts immediately.

Warm Start

Requirements for a Warm Start

You execute a warm start in order to continue an interrupted cycle at the current position of the master (after an emergency stop, for example). The master (stripper or target conveyor) has stopped and its position is known. The slave (accumulator or stripper) usually stops outside of its cam position.

Settings for a Warm Start

- At start of the movement `i_xWsSel` must be TRUE.
- The warm start mode is selected. (see below)
- The master axis must not be moved.
- A warm start is not possible with `iOpMode = 1`. Refer to Triggered Timed Pulsed Mode (*see page 396*)




Warm Start Behavior

- The slave (accumulator) returns to its cam position that depends on the warm start mode.
- When the cam position is reached, `q_xPosStrtRchd` becomes TRUE.

For further informations, refer to Accumulator Cold Start (*see page 402*) and Selecting Warm Start Mode.

Selecting a Warm Start Mode

The parameter `iWsMode` selects between 3 different warm start modes:

<code>iWsMode</code>	Description	Representation
0	<p>The slave moves directly to its cam position.</p> <p>NOTE: The slave may go backwards to reach its cam position.</p>	
1	<p>The slave moves to its cam position only if it is within the range <code>lrWsWdowBack < warm start window < lrWsWdowFwd</code>.</p> <p>If slave position is outside of this warm start window an alarm is generated.</p>	
4	<p>The slave keeps its distance to the cam. A position alarm on target conveyor must be acceptable.</p> <p>The initial slave position must be within the warm start window, otherwise an alarm is generated.</p> <p>This warm start window is the range between <code>lrWsWdowFwd</code> and <code>lrWsWdowBack</code> in relation to the initial master position.</p>	

Special Modes


lrPulsSyncPhas

The length of the synchronous phase is configured by the parameter `lrPulsSyncPhas`, which represents a percentage of `i_lrProdLen`.

The remainder of `i_lrProdLen` is evenly divided between acceleration and deceleration.

Example:

`lrPulsSyncPhas = 80` means that the accumulator conveyor moves synchronously (to be exact: they have the same velocity only if `lrSlop= 1`) with its master for 80% of `i_lrProdLen`. 10% is used for acceleration and 10% for deceleration.




lrSlop

The master/slave velocity ratio during the synchronous phase is configured with the parameter `lrSlop`. The cam may then have a dwell phase. `lrSlop` does not affect the length of the synchronous phase. This is set with `lrPulsSyncPhas`.

Examples:

`lrSlop = 1` means a velocity ratio between accumulator and stripper of 1:1.

`lrSlop = 2` increases this ratio to 2:1. The accumulator delivers the products to the stripper faster.



Chapter 15

Quick Reference Guide

What Is in This Chapter?

This chapter contains the following topics:

Topic	Page
Visualization	412
Troubleshooting	413

Visualization

Overview

Visualization screens are embedded in the Packaging library. They help to configure and to start the application function blocks easily and quickly.

All the inputs/outputs and all the parameters are accessible.

For more information please refer to How to integrate the Visualization into an Application (*see page 433*).

Stripper visualization

FB_Stripper	
i_xEn	q_xActv
i_xExe	q_xPosStrtRchd
i_xWsSel	q_xCorrMax
i_lrSyncLen: 90	q_iTpMisd: 180
i_lrDistDflt: 360	q_lrPrdActlSlav: 360
i_lrTpDistMin: 180	
i_lrDistTarg: 360	
i_xAlrmRst	q_xAlrm
i_xStTp_Input	q_diAlrmltd: 0
i_lrPrdActlMstr: 0	

Troubleshooting

Troubleshooting

This table describes some general issues and their solutions:

Issue	Cause	Solution
The cycle is stopped and detected alarm outputs are set.	Parameter is invalid or inconsistent.	<ul style="list-style-type: none"> ● Correct the parameter. ● Set new rising edge at <code>i_xEn</code>.
	Inputs are invalid or inconsistent.	<ul style="list-style-type: none"> ● Correct the inputs and acknowledge with <code>i_xAlrmRst</code>. ● Set new rising edge at <code>i_xExe</code>.
	Application during operation (general alarm)	<ul style="list-style-type: none"> ● Correct the application and acknowledge with <code>i_xAlrmRst</code>. ● After <code>i_xEn -> FALSE</code>, execute a warm start and/or a cold start. <p>For further information, refer to Starting Modes (see page 402).</p>
The SoftMotion (SM3 library) function block detected alarm is passed on to the alarm outputs of the Grouping function block.	SoftMotion (SM3 library) (e.g., incorrect following)	<ul style="list-style-type: none"> ● Correct the SoftMotion (SM3 library) function block and acknowledge with <code>i_xAlrmRst</code>. ● Restart SoftMotion (SM3 library) function block. ● After <code>i_xEn -> FALSE</code>, execute a warm start and/or a cold start.

Part IX

Clamping

Chapter 16

Clamping_Motion: Logical Sequence of Product Clamping with Torque Limitation

What Is in This Chapter?

This chapter contains the following sections:

Section	Topic	Page
16.1	Functional and Machine Overview	418
16.2	Architecture	419
16.3	Function Block Description	422
16.4	Pin Description	423
16.5	Operating Mode	430
16.6	Quick Reference Guide	432

Section 16.1

Functional and Machine Overview

Functional Overview

Usage of Clamping_Motion Function Block?

The Clamping_Motion function block is required for clamping arbitrary products.

Solution with the Clamping_Motion Function Block

When `i_xClS` is activated, the clamping starts a fast positioning up to a defined position or until the recognition of an input signal. After this, the axis brakes and continues driving slowly until a set reference current or the goal position is reached. With the signal `i_xOpen`, the clamping returns to a specified position.

NOTE: The function block only runs on type S controllers.

NOTE: The closing movement must be in positive direction of the drive.


 CAUTION
UNITENDED EQUIPMENT OPERATION
The Clamping function works only with drives of type Lexium 05 or Lexium 32.
Failure to follow these instructions can result in injury or equipment damage.

Section 16.2


Architecture

Software Architecture


Profile in Principle




Motion Profile



Clamping without Product Detection



Clamping with Product Detection



Section 16.3

Function Block Description

Clamping_motion Function Block

Pin Diagram



Function Block Description

When *i_xEn* is activated, the block is activated. The parameters defined in *iq_stPara* are examined. If the input parameters are incorrect or inconsistent, *q_xAlrm* becomes TRUE. *q_diAlrmId* indicates the alarm number.

When *i_xCls* is activated, the axis is started and moves with *lrVelHigh* until it reaches *lrPosNear*. After this, the axis decelerates and moves with the slow speed *lrVelLow*. When the current specified in *dwCurrLim* is reached, the axis stops. Alternatively, switching to slow speed can be accomplished with a TP input or a standard input (*i_xTpInputStd*).

WARNING

UNINTENDED EQUIPMENT OPERATION

Do not send any other commands to the slave axis when it is under control of the *Clamping_Motion* application function block.

Failure to follow these instructions can result in death, serious injury, or equipment damage.

Section 16.4

Pin Description

What Is in This Section?

This section contains the following topics:

Topic	Page
Input Pin Description	424
Output Pin Description	425
Input/Output Pin Description	427
Structured Parameter	428

Input Pin Description

Input Pin Description

Input	Data Type	Description
i_xEn	BOOL	TRUE: Block is activated Factory setting: FALSE
i_xCls	BOOL	TRUE: Closing block function is started (edge evaluation) Factory setting: FALSE
i_xOpen	BOOL	TRUE: Opening block function is started (edge evaluation) Factory setting: FALSE
i_xTeach	BOOL	TRUE: Start of teach procedure Factory setting: FALSE
i_xAlrmRst	BOOL	TRUE: Alarm reset on rising edge. Factory setting: FALSE
i_xTpIputStd	BOOL	Capture input (standard) of master position. Significant only if xTpMode = FALSE Factory setting: FALSE

Output Pin Description

Output Pin Description

Output	Data Type	Description
q_xActv	BOOL	TRUE: Block is activated
q_xBusy	BOOL	TRUE: Cycle is in progress
q_xCls	BOOL	TRUE: Jaw is in closed position. Torque is constant and product is clamped
q_xInfd	BOOL	TRUE: Axis has reached lrInfdPos position
q_xOutfd	BOOL	TRUE: Axis has reached lrOutfdPos position
q_xPosBhndRchd	BOOL	TRUE: Axis has reached lrPosBhnd position (no product for clamping found)
q_xAlrm	BOOL	TRUE: There is a detected alarm
q_diAlrmId	DINT	Notification number. For detailed information see table below.

Notifications

There are 2 types of notifications numbers given on the output `q_diAlrmId` of the function block.

The first types of notifications are coming from internal used (SoftMotion (SM3 library)) function blocks. These notifications are given directly to the output `q_diAlrmId`. For these notifications see the list of notifications of the SoftMotion (SM3 library) function blocks.

The second types of notifications are generated by the function block itself. These notifications are added to the global constant `GC_MotionLib_ErrorOffset` (standard 1000).

Detected Alarm ID (added to <code>GC_MotionLib_ErrorOffset</code>)	Notification
10	controlled axis not working
14	controlled axis in wrong state
15	controlled axis is no modulo axis
16	invalid drive - the <code>Clamping_Motion</code> function block supports only the LXM05, LXM32A and LXM32M drive
50	invalid capture input
400	teach not possible
401	invalid <code>dwCurrLim</code>
403	invalid <code>lrAccHigh</code>

Detected Alarm ID (added to GC_MotionLib_ErrorOffset)	Notification
404	invalid lrDecHigh
405	invalid lrVelHigh
406	invalid lrAccLow
407	invalid lrDecLow
408	invalid lrVelLow
409	invalid lrPosNear
410	invalid lrAccOpen
411	invalid lrDecOpen
412	invalid lrVelOpen
413	invalid lrPosBhnd
414	invalid teach input
415	close speed too fast
416	close speed too slow
418	lrPosNear reached without detecting TP signal
419	lrTpDistNearPnt greater than lrPosBhnd - lrPosOpen
420	invalid lrInfdPos
421	invalid lrOutfdPos

Input/Output Pin Description

Input/Output Pin Description

Input/Output	Data Type	Description
iq_iTeachPara	INT	Position for the teaching
		0 (none)
		1 OutFeed position
		2 InFeed position
		3 Near position
		4 Open position
iq_stPara	STRUCT ST_ClampingParameter	Block parameters Refer to the input structured parameter iq_stPara (<i>see page 428</i>).
iq_stDrv	SM3_Basic.AXIS_REF_SM3	Axis to be controlled. Axis has to be configured as linear axis.

Structured Parameter

iq_stPara

Input	Data Type	Description
dwCurrLim	DWORD	Value of current limitation during clamping procedure in steps of 1/100 A Factory setting: 25
lrPosOpen	REAL	Position when the clamping is opened Factory setting: 0
lrInfdPos	REAL	Position for display of output q_xInfd (only displayed on opening) Can be used to start infeed of the product. Factory setting: 50
lrOutfdPos	REAL	Position for display of output q_xOutfd (only displayed on opening) Can be used to start outfeed of the product. Factory setting: 80
lrPosBhnd	REAL	Virtual behind position. If this position is reached, $q_xPosBhndRchd$ goes to TRUE and an alarm notification is generated. It means that no product has been found. Factory setting: 240 Range: $>lrPosNear, <lrPosOpen$
lrPosNear	REAL	Near position: position for changeover from fast to slow speed on closing. This parameter is used only when clamping is done without product detection ($xTpUse = FALSE$). Factory setting: 180 Range: $>lrPosOpen$
lrVelHigh	REAL	Speed for fast movements (closing) Factory setting: 100 Range: ≥ 0.1
lrAccHigh	REAL	Acceleration for fast movements (closing) Factory setting: 1000 Range: ≥ 0.1
lrDecHigh	REAL	Brake ramp for fast movements (closing) Factory setting: 1000 Range: ≥ 0.1
lrVelLow	REAL	Speed for slow movements (closing) Factory setting: 10 Range: ≥ 0.1
lrAccLow	REAL	Acceleration for slow movements (closing) Factory setting: 1000 Range: ≥ 0.1

Input	Data Type	Description
lrDecLow	REAL	Brake ramp for slow movements (closing) Factory setting: 1000 Range: >= 0.1
lrVelOpen	REAL	Speed for opening the clamping Factory setting: 500 Range: >= 0.1
lrAccOpen	REAL	Acceleration for opening the clamping Factory setting: 5000 Range: >= 0.1
lrDecOpen	REAL	Brake ramp for opening the clamping Factory setting: 500 Range: >= 0.1
lrDecEmgy	REAL	Brake ramp in case of interruption or block de-selection Factory setting: 5000 Range: >= 0.1
xTpUse	BOOL	TRUE: Clamping with product detection. Use product detection (TP) to start slow approach. Factory setting: FALSE
xTpMode	BOOL	Used only if xTpUse = TRUE FALSE: TP over standard input (i_xTpIputStd) TRUE: TP over TP input Factory setting: FALSE
iCptrNb	INT	Touch Probe number Used only if xTpUse = TRUE and xTpMode = TRUE. Factory setting: 1 Range: 0...1
xTpEdge	BOOL	Used only if xTpUse = TRUE FALSE = negative edge TRUE = positive edge Factory setting: FALSE
lrTpDistNearPnt	REAL	Used only if xTpUse = TRUE Distance between sensor (captor) and slow approach position. Factory setting: 20

If no product detection is used, then due to movement behavior, the parameters have to fulfil the following formulas:

$$lrPosNear - lrPosOpen < lrVelLow^2 / (2 * lrAccHigh)$$

$$lrPosBhnd - lrPosOpen < lrVelLow^2 / (2 * lrAccHigh)$$

Section 16.5

Operating Mode


Selection of the Capture Mode

Overview

According to the architecture and the precision requirements of the application, several capture modes are possible:

Capture Mode	Description
Detection with standard input	The sensor is wired to a standard input. The capturing is done in the cycle of the motion task in which the function block is called.
Detection with special input	The sensor is wired to a special input: <ul style="list-style-type: none"> • The inputs of the controller are captured if the master axis is an encoder. • A input of a servo drive is captured if the master is a servo drive.

xTpMode	iCptrNb	i_xTpInputStd
FALSE: Capturing with standard input	No effect	Associated with the standard input. The digital input has to be connected to the input <code>i_xTpStdInput</code> .
TRUE: Capturing with special input	Touch Probe input number. If TP2 is used, then <code>iCptrNb = 1</code>	No effect



Section 16.6

Quick Reference Guide

Visualization

Overview


Visualization screens are in the Clamping folder. They help to configure and start the application function block easily and quickly. All the inputs/outputs and all the parameters are accessible.


How to start the visualization is described in the following.

How to Integrate the Visualization into an Application

The following table describes the procedure of integrating the visualization into an application:

Step	Action
1	In the Tools Tree right click Application .
2	Select Add Object .
3	Select the Visualization object and give it a name (e.g., MyVisualization) and press Add . Result: The visualization and the Visualization Manager are added to the project.
4	In the screen of MyVisualization add a new frame by selecting Frame in the toolbox. Drag the Frame onto the visualization screen. Result: The Frame Configuration window appears.
5	Select for the visualization ClampingVis and move it with the Add button and press OK .



Step	Action
6	<p>To avoid deformation of the visualization, set the scale type in the properties of the frame to FIXED.</p> <p>To connect the visualization to the project set 3 references to the instances of your project:</p> <ul style="list-style-type: none"> ● refClampingFb -> the instance of the function block Clamping_Motion. ● refClampingParam -> the instance of the structure which is connected to the input iq_stPara of the clamping instance. ● refTeachParam -> the instance of the variable which is connected to the input iq_iTeachPara of the clamping instance.  <p>Result: The visualization is ready to work.</p>



A

AFB

(*application function block*)

analog output

Converts numerical values within the logic controller and sends out proportional voltage or current levels.

application

A program including configuration data, symbols, and documentation.

C

CANmotion

A CANopen-based motion bus with an additional mechanism that provides synchronization between the motion controller and the drives.

CANopen

An open industry-standard communication protocol and device profile specification (EN 50325-4).

closed loop

A closed loop control is a motion control system that used both positional feedback and velocity feedback to generate a correction signal. It does this by comparing its position and velocity to the values of specified parameters. The devices providing the feedback are typically encoders, resolvers, LVTDs, and tachometers.

See also: *open loop*

closing on stack

Process of filling the grab with bulk cargo

configuration

The arrangement and interconnection of hardware components within a system and the hardware and software parameters that determine the operating characteristics of the system.

controller

Automates industrial processes (also known as programmable logic controller or programmable controller).

E

EEPROM

(electrically erasable programmable read-only memory) A type of non-volatile memory to store required data even when power is removed.

element

The short name of the ARRAY element.

equipment

A part of a machine including sub-assemblies such as conveyors, turntables, and so on.

expansion bus

An electronic communication bus between expansion I/O modules and a controller.

F

FB

(function block) A convenient programming mechanism that consolidates a group of programming instructions to perform a specific and normalized action, such as speed control, interval control, or counting. A function block may comprise configuration data, a set of internal or external operating parameters and usually 1 or more data inputs and outputs.

function

A programming unit that has 1 input and returns 1 immediate result. However, unlike FBs, it is directly called with its name (as opposed to through an instance), has no persistent state from one call to the next and can be used as an operand in other programming expressions.

Examples: boolean (AND) operators, calculations, conversions (BYTE_TO_INT)

H

HMI

(human machine interface) An operator interface (usually graphical) for human control over industrial equipment.

HSP

(high speed) The motor frequency at maximum reference of a drive.

I**I/O***(input/output)***ID***(identifier/identification)***input/output**

The index of the ARRAY.

K**Kp**

The proportional gain parameter of a PID controller.

L**LSP**

The motor frequency at minimum reference of a drive.

M**machine**Consists of several *functions* and/or *equipment*.**master/slave**

The single direction of control in a network that implements the master/slave mode.

ms*(millisecond)***N****node**

An addressable device on a communication network.

O

open loop

Open loop control refers to a motion control system with no external sensors to provide position or velocity correction signals.

See also: *closed loop*.

OTB

(*optimized terminal block*) Used in the context of STB I/O distributed modules.

P

pallet

A portable platform, which is used for storing or moving goods.

PID

(*proportional, integral, derivative*) A generic control loop feedback mechanism (controller) widely used in industrial control systems.

PLCopen

For more information, refer to <http://www.plcopen.org/>.

program

The component of an application that consists of compiled source code capable of being installed in the memory of a logic controller.

protocol

A convention or standard definition that controls or enables the connection, communication, and data transfer between 2 computing system and devices.

Pt100/Pt1000

(*platinum 100/1000*) Resistance thermometers, also referred to as resistance temperature detectors, are sensors used to measure temperature by correlating electrical resistance with temperature. As the temperature changes, the resistance to an electrical current passing through them predictably changes likewise. They are characterized by their nominal resistance R0 at a temperature of 0 °C.

- Pt100 (R0 = 100 Ω)
- Pt1000 (R0 = 1 kΩ)

PWM

(*pulse width modulation*) A fast output that oscillates between off and on in an adjustable duty cycle, producing a rectangular wave form (though you can adjust it to produce a square wave).

R

RPM

(*revolutions per minute*)

run

A command that causes the controller to scan the application program, read the physical inputs, and write to the physical outputs according to solution of the logic of the program.

S

scan

A function that includes:

- reading inputs and placing the values in memory
- executing the application program 1 instruction at a time and storing the results in memory
- using the results to update outputs

SDO

(*service data object*) A message used by the field bus master to access (read/write) the object directories of network nodes in CAN-based networks. SDO types include service SDOs (SSDOs) and client SDOs (CSDOs).

Sercos

(*serial real-time communications system*) A digital control bus that interconnects, motion controls, drives, I/Os, sensors, and actuators for numerically controlled machines and systems. It is a standardized and open controller-to-intelligent digital device interface, designed for high-speed serial communication of standardized closed-loop real-time data.

setpoint

In a PID controller, the target value set by the user. The main objective of the PID controller is to ensure that the process value reaches the setpoint.

See also *process value*.

STOP

A command that causes the controller to stop running an application program.

T

task

A group of sections and subroutines, executed cyclically or periodically for the MAST task or periodically for the FAST task.

A task possesses a level of priority and is linked to inputs and outputs of the controller. These I/O are refreshed in relation to the task.

A controller can have several tasks.

TP

(*touch probe*) A position capture that is triggered by a fast input signal (quick sensor). On the rising edge of the touch probe input, the position of an encoder is captured.

For example, this is used for packaging machines to capture the position of a printmark on a film to cut on the same position.

V

variable

A memory unit that is addressed and modified by a program.

VSD

(*variable speed drive*) An equipment that makes a variable and regulates the speed and rotational force, or torque output, of an electric motor.



A

AnalogTensionControlATV, *137*
AnalogTensionControlATV_Motion, *137*
AnalogTensionControlLXM_Motion, *137*

C

Clamping_motion, *417*

D

DigitalTensionControlATV, *107*
DigitalTensionControlATV_Motion, *107*

F

FlyingShear_Motion, *331*

G

grouping - ungrouping, *351*
GroupingAccumulator_Motion, *367*
GroupingStripper_Motion, *377*

L

LateralPositionControl, *231*

M

material movement, *27*
MoveJog, *29*

P

Packaging
AnalogTensionControlATV, *137*
AnalogTensionControlATV_Motion, *137*
AnalogTensionControlLXM_Motion, *137*
Clamping_motion, *417*
DigitalTensionControlATV, *107*
DigitalTensionControlATV_Motion, *107*
FlyingShear_Motion, *331*
function block location in the Packaging library, *25*
grouping - ungrouping, *351*
GroupingAccumulator_Motion, *367*
GroupingStripper_Motion, *377*
LateralPositionControl, *231*
MoveJog, *29*
RotaryKnife_Motion, *261*
system requirements, *22*
TemperatureControl, *161*
TemperatureControl_Easy, *193*
XYPickAndPlace, *61*

R

RotaryKnife_Motion, *261*

S

system requirements, *22*

T

TemperatureControl, *161*
TemperatureControl_Easy, *193*

X

XYPickAndPlace, *61*