




S10V Series Ethernet Driver

1	System Configuration.....	3
2	Selection of External Device	5
3	Example of Communication Setting.....	6
4	Setup Items	12
5	Supported Device.....	16
6	Device Code and Address Code.....	18
7	Error Messages.....	22

Introduction

This manual describes how to connect the Display and the External Device (target PLC).

In this manual, the connection procedure will be described by following the sections below:



1 System Configuration

The following shows the system configuration where the External Device of Hitachi, Ltd. and the Display are connected.

Series	CPU	Link I/F	SIO Type	Setting Example
S10V	LQP510	LQE520	Ethernet (TCP)	Setting Example 1 (page 6)
		LQE720* ¹		
	LQP520* ²	LQE520	Ethernet (TCP)	Setting Example 1 (page 6)
LQE720* ³				
Ethernet I/F on the CPU unit		Ethernet (TCP)	Setting Example 2 (page 8)	
S10VE	LQP600	LQE260-E	Ethernet (TCP)	Setting Example 3 (page 10)
		Ethernet port on the CPU unit	Ethernet (TCP)	Setting Example 3 (page 10)


*1 For LQE720, LQP510 (Revision.H or later) is required.

*2 For LQP520, LQP510 is also required.


*3 For LQE720, LQP520 (Revision.F or later) is required.

■ Connection Configuration


- 1:1 Connection



- 1:n Connection




- n:1 Connection



* To connect 20 units, LQE260-E Revision.B or later is required.


- n:m Connection



* To connect 20 units, LQE260-E Revision.B or later is required.

2 Selection of External Device

Select the External Device to be connected to the Display.



Setup Items	Setup Description
Number of Devices/PLCs	Use an integer from 1 to 4 to enter the number of Devices/PLCs to connect to the display.
Manufacturer	Select the manufacturer of the External Device to be connected. Select "Hitachi, Ltd.".
Series	Select a model (series) of the External Device to be connected and connection method. Select "S10V Series Ethernet". Check the External Device which can be connected in "S10V Series Ethernet" in system configuration. ☞ "1 System Configuration" (page 3)
Port	Select the Display port to be connected to the External Device.
Use System Area	Check this option to synchronize the system data area of the Display and the device (memory) of the External Device. When synchronized, you can use the External Device's ladder program to switch the display or display the window on the Display. Cf. GP-Pro EX Reference Manual "LS Area (Direct Access Method Area)" This feature can also be set in GP-Pro EX or in the Display's offline mode. Cf. GP-Pro EX Reference Manual "System Settings [Display Unit] - [System Area] Settings Guide" Cf. Maintenance/Troubleshooting Guide "Main Unit - System Area Settings"

3 Example of Communication Setting

The following shows examples of communication settings of the Display and the External Device, which is recommended by Digital Electronics Corp.

3.1 Setting Example 1

■ Settings of GP-Pro EX

◆ Communication Settings

To display the setup screen, from the [Project] menu, point to [System Settings] and select [Device/PLC].

Device/PLC 1

Summary [Change Device/PLC](#)

Manufacturer Series Port

Text Data Mode [Change](#)

Communication Settings

Port No. Auto

Timeout (sec)

Retry

Wait To Send (ms)

Device-Specific Settings

Allowable Number of Devices/PLCs [Add Device](#)

No.	Device Name	Settings	Add Indirect Device
<input type="text" value="1"/>	<input type="text" value="PLC1"/>	<input type="text" value="IP Address=192.168.0.001,Port No.=4302"/>	<input type="button" value="Add Indirect Device"/>

◆ Device Setting

To display the [Individual Device Settings] dialog box, from [Device-Specific Settings] in the [Device/PLC] window, select the External Device and click [Settings]. To connect multiple External Devices, from [Device-Specific Settings] in the [Device/PLC] window, click [Add Device] to add another External Device.

Individual Device Settings

PLC1

IP Address

Port No.

■ Setting of External Device

Use the configuration tool (S10V ET.NET SYSTEM) for communication settings of the External Device.

- 1 Set the [MODU No.] rotary switch on the link I/F unit to "2", and then activate the External Device.
- 2 Connect an RS-232C cable from your PC to the CPU unit of the External Device, and then start up the configuration tool.
- 3 Select "RS-232C" from [Setup by module], and then click [OK].
- 4 Click [Set IP Address] in the [Setup by module] dialog box displayed.
- 5 Set the communication settings in the [Set IP Address] dialog box displayed.

Setup Items	Setup Description
Module	ET.NET (Main)
IP Address	192.168.0.1
Subnetmask	255.255.255.0

- 6 Click [Register].

3.2 Setting Example 2

■ Settings of GP-Pro EX

◆ Communication Settings

To display the setup screen, from the [Project] menu, point to [System Settings] and select [Device/PLC].

Device/PLC 1

Summary [Change Device/PLC](#)

Manufacturer Series Port

Text Data Mode [Change](#)

Communication Settings

Port No. Auto

Timeout (sec)

Retry


Wait To Send (ms)

Device-Specific Settings

Allowable Number of Devices/PLCs 16 [Add Device](#)

No.	Device Name	Settings	Add Indirect Device
1	PLC1	IP Address=192.168.0.001,Port No.=4302	<input type="button" value="Add Indirect Device"/>

◆ Device Setting

To display the [Individual Device Settings] dialog box, from [Device-Specific Settings] in the [Device/PLC] window, select the External Device and click [Settings] . To connect multiple External Devices, from [Device-Specific Settings] in the [Device/PLC] window, click [Add Device] to add another External Device.

Individual Device Settings

PLC1

IP Address

Port No.

■ Setting of External Device

Use the configuration tool (S10V BASE SYSTEM) for communication settings of the External Device.

- 1 Set the [ST No.] rotary switch on the CPU unit to "0,0", and then activate the External Device.
- 2 Connect an RS-232C cable from your PC to the CPU unit of the External Device, and then start up the configuration tool.
- 3 Click [ONLINE] of [Connection status].
- 4 Click [Set IP Address] of [CMU].
- 5 Set the communication settings in the [Set IP Address] dialog box displayed.

Setup Items	Setup Description
Module	ET.NET (Main)
IP Address	192.168.0.1
Subnetmask	255.255.255.0

- 6 Restart the External Device.

3.3 Setting Example 3

■ Settings of GP-Pro EX

◆ Communication Settings

To display the setup screen, from the [Project] menu, point to [System Settings] and select [Device/PLC].

Device/PLC 1

Summary [Change Device/PLC](#)

Manufacturer Series Port

Text Data Mode [Change](#)

Communication Settings

Port No. Auto

Timeout (sec)

Retry


Wait To Send (ms)

Device-Specific Settings

Allowable Number of Devices/PLCs 16 [Add Device](#)

No.	Device Name	Settings	<input type="button" value="Add Indirect Device"/>
1	PLC1	IP Address=192.168.0.100,Port No.=4312	<input type="button" value="Add Indirect Device"/>

◆ Device Setting

To display the [Individual Device Settings] dialog box, from [Device-Specific Settings] in the [Device/PLC] window, select the External Device and click [Settings] . To connect multiple External Devices, from [Device-Specific Settings] in the [Device/PLC] window, click [Add Device] to add another External Device.

Individual Device Settings

PLC1

IP Address

Port No.

■ Setting of External Device

Use the configuration tool (BASE SYSTEMS/S10VE) for communication settings of the External Device.

- 1 On the CPU unit, set the rotary switch to "F,F", and then activate the External Device.
- 2 Connect an Ethernet cable from your PC to port 1 on the CPU unit of the External Device, and then start up the configuration tool.
- 3 From [Project], select [New].
- 4 Set the [PCsNo] and [Comment].
- 5 Click [Save].
- 6 From [Online], select [Change PCs].
- 7 Enter the station number "FF" and IP address "192.192.192.1".
- 8 Click [Set].
- 9 Click [Test].
- 10 When the confirmation dialog box appears, click [OK].
- 11 From [Project], select [Set Network].
- 12 Select [Ethernet] or [ET.NET].
- 13 Set the communication settings in the [Set Network] screen.

Setup Items	Setup Description
Select Network	Ethernet1
ST Number	1
IP Address	192.168.0.100
Sub Net Mask	255.255.255.0
Broadcast Address	192.168.0.255
Settings Route Num	0

- 14 Click [Set].
- 15 Click [Write PCs].
- 16 On the CPU unit, set the rotary switch to "0,1".
- 17 Restart the External Device.

4 Setup Items

Set communication settings of the Display with GP-Pro Ex or in offline mode of the Display.

The setting of each parameter must be identical to that of the External Device.

☞ "3 Example of Communication Setting" (page 6)

NOTE • Set the Display's IP address in offline mode.

Cf. Maintenance/Troubleshooting Guide "Ethernet Settings"

4.1 Setup Items in GP-Pro EX

■ Communication Settings


To display the setup screen, from the [Project] menu, point to [System Settings] and select [Device/PLC].


Setup Items	Setup Description
Port No.	Use an integer from "1024 to 65535" to enter the port No. of the Display. If you check [Auto], the port No. will be automatically set.
Timeout	Use an integer from "1 to 127" to enter the time (s) for which the Display waits for the response from the External Device.
Retry	In case of no response from the External Device, use an integer from "0 to 255" to enter how many times the Display retransmits the command.
Wait To Send	Use an integer from "0 to 255" to enter standby time (ms) for the Display from receiving packets to transmitting the next command.

NOTE • Refer to the GP-Pro EX Reference Manual for Indirect Device.

Cf. GP-Pro EX Reference Manual "Changing the Device/PLC at Runtime (Indirect Device)"

■ Device Setting

To display the [Individual Device Settings] dialog box, from [Device-Specific Settings] in the [Device/PLC] window, select the External Device and click [Settings] . To connect multiple External Devices, from [Device-Specific Settings] in the [Device/PLC] window, click [Add Device] to add another External Device.



Setup Items	Setup Description
IP Address	Set the IP address of the External Device. NOTE Check with the network administrator about the IP address. Be sure not to duplicate IP addresses.
Port No.	For S10V Use an integer from "4302 to 4305" to enter the port No. of the External Device. For S10VE Use an integer from "4311" or "4312 to 4315" to enter the port No. of the External Device. IMPORTANT <ul style="list-style-type: none"> • The Display which can be connected to one Port No. is only one. • To use port number 4311, LQE260-E Revision.B or later is required. You can connect a maximum 16 units to port number 4311.

4.2 Setup Items in Offline Mode

NOTE

- Refer to the Maintenance/Troubleshooting manual for information on how to enter offline mode or about the operation.

Cf. Maintenance/Troubleshooting Guide "Offline Mode"

- The number of the setup items to be displayed for 1 page in the offline mode depends on the Display in use. Please refer to the Reference manual for details.

■ Communication Settings

To display the setting screen, touch [Device/PLC Settings] from [Peripheral Settings] in offline mode. Touch the External Device you want to set from the displayed list.

Comm.	Device			
S10V Series Ethernet		[TCP]	Page 1/1	
Port No.	<input type="radio"/> Fixed <input checked="" type="radio"/> Auto	1024 ▼ ▲		
Timeout(s)		3 ▼ ▲		
Retry		0 ▼ ▲		
Wait To Send(ms)		0 ▼ ▲		
Exit		Back		2007/02/08 15:06:51

Setup Items	Setup Description
Port No.	Set the Port No. of the Display. Select either [Fixed] or [Auto]. If you select [Fixed], use an integer from "1024 to 65535" to enter the port No. of the Display. If you select [Auto], the port No. will be automatically assigned regardless of the entered value.
Timeout	Use an integer from "1 to 127" to enter the time (s) for which the Display waits for the response from the External Device.
Retry	In case of no response from the External Device, use an integer from "0 to 255" to enter how many times the Display retransmits the command.
Wait To Send	Use an integer from "0 to 255" to enter standby time (ms) for the Display from receiving packets to transmitting the next command.

■ Device Setting

To display the setting screen, touch [Device/PLC Settings] from [Peripheral Settings]. Touch the External Device you want to set from the displayed list, and touch [Device Settings].

Comm.	Device			
S10V Series Ethernet		[TCP]	Page 1/1	
Device/PLC Name		[PLC1]		
IP Address		192 168 0 1		
Port No.		4302		
Exit		Back		2007/02/08 15:06:56








Setup Items	Setup Description
Device/PLC Name	Select the External Device to set. Device name is a title of the External Device set with GP-Pro EX. (Initial value [PLC1])
IP Address	Set the IP address of the External Device. NOTE Check with the network administrator about the IP address. Be sure not to duplicate IP addresses.
Port No.	Use an integer from "4302 to 4305" to enter the port No. of the External Device. IMPORTANT <ul style="list-style-type: none"> The Display which can be connected to one Port No. is only one.

5 Supported Device

Range of supported device address is shown in the table below. Note that the actually supported range of the devices varies depending on the External Device to be used. Please check the actual range in the manual of your External Device.

 : This address can be specified as system data area.

Device	Bit Address	Word Address	32 bits	Remarks
External Input	X000 - XFFF	XW000 - XWFFF0	H/L	***0 *1, *2, *3
External Output	Y000 - YFFF	YW000 - YWFFF0		***0 *1, *2, *3
Internal Register	R000 - RFFF	RW000 - RWFFF0		***0 *1
Global Link Register	G000 - GFFF	GW000 - GWFFF0		***0 *1
Event Register	E000 - EFFF	EW000 - EWFFF0		***0 *1, *2, *3
Keep Relay	K000 - KFFF	KW000 - KWFFF0		***0 *1
System Register	S000 - SFFF	SW000 - SWFFF0		***0 *1, *2, *3
On-delay Register	T000 - T1FF	TW000 - TW1F0		***0 *1, *2, *3
One-shot Timer	U000 - U0FF	UW000 - UW0F0		***0 *1
Up/Down Counter	C000 - C0FF	CW000 - CW0F0		***0 *1
Transfer Register	J000 - JFFF	JW000 - JWFFF0		***0 *1, *2, *3
Receive Register	Q000 - QFFF	QW000 - QWFFF0		***0 *1, *2, *3
Extended Internal Register	M000 - MFFF	MW000 - MWFFF0		***0 *1, *2, *3
Extended Internal Register	A000 - AFFF	AW000 - AWFFF0		***0 *1
Timer Calculation Value	----	TC000 - TC1FF		*2, *3
Timer Setting Value	----	TS000 - TS1FF		*2, *3
One-shot Timer Calculation Value	----	UC000 - UC0FF		
One-shot Timer Setting Value	----	US000 - US0FF		
Counter Calculation Value	----	CC000 - CC0FF		
Counter Setting Value	----	CS000 - CS0FF		
Work Register	----	FW000 - FWBFF		Bit F
Data Register	----	DW000 - DWFFF		Bit F
Work Register	LB0000 - LBFFFF	LBW0000 - LBWFFF0		***0
Ladder Converter Special Work Register	LR0000 - LR0FFF	LRW0000 - LRW0FF0	***0	

Device	Bit Address	Word Address	32 bits	Remarks
Ladder Converter Special Work Register (Edge)	LV0000 - LV0FFF	LVW0000 - LVW0FFF0	H/L	
Word Special Work Register	----	LWW0000 - LWWFFFFF		
Long Word Special Work Register	----	LLL0000 - LLL1FFF		 *4
Single Precision Floating Decimal Point Work Register	----	LF0000 - LF1FFF		*4, *5
Word Special Work Register (Power-cut Retain)	----	LXW0000 - LXW3FFF		
Long Word Special Work Register (Power-cut Retain)	----	LML0000 - LML1FFF		 *4
Single Precision Floating Decimal Point Work Register (Power-cut Retain)	----	LG0000 - LG1FFF		*4, *5
Direct Memory Address*6	----	DM00000000 - DMFFFFFFFE		 

*1 Based on the specifications of the External Device, 0th bit is assigned as the most significant bit (MSB), and 15th bit as the least significant bit (LSB). Therefore, if you set the 0th bit to ON, 32768 (0x8000) is written into the word device with the bit at the beginning.

If you set X000 to ON when assigning bits to the Display, the bit device X000 on the External Device will be set to ON.

The word device XW000 of the Display and External Device is set to "32768 (0x8000)".

*2 As offset address is not supported when used with 32 bit data, the offset value is ignored.

*3 Multiple point bit write operations from Pro-Server EX are not supported.


*4 32-bit device.

*5 Single-precision floating point device.

*6 Used to access the memory address of the External Device.

IMPORTANT • When you access the External Device using the Direct Memory Address, do not access the memory address that the system uses. If you conduct it, an error may occur. For details concerning the address, refer to the manual attached to the External Device.

NOTE • Please refer to the GP-Pro EX Reference Manual for system data area.
Cf. GP-Pro EX Reference Manual "LS Area (Direct Access Method Area)"

• Please refer to the precautions on manual notation for icons in the table.
 "Manual Symbols and Terminology"

6 Device Code and Address Code

Use device code and address code when you select "Device Type & Address" for the address type in data displays.

Device	Device Name	Device Code (HEX)	Address Code
External Input	X, XW	0080	Value of word address divided by 0x10
External Output	Y, YW	0081	Value of word address divided by 0x10
Internal Register	R, RW	0082	Value of word address divided by 0x10
Global Link Register	G, GW	0083	Value of word address divided by 0x10
Event Register	E, EW	0084	Value of word address divided by 0x10
Keep Relay	K, KW	0085	Value of word address divided by 0x10
System Register	S, SW	0086	Value of word address divided by 0x10
On-delay Register	T, TW	0087	Value of word address divided by 0x10
One-shot Timer	U, UW	0088	Value of word address divided by 0x10
Up/Down Counter	C, CW	0089	Value of word address divided by 0x10
Transfer Register	J, JW	008A	Value of word address divided by 0x10
Receive Register	Q, QW	008B	Value of word address divided by 0x10
Extended Internal Register	M, MW	008C	Value of word address divided by 0x10
Extended Internal Register	A, AW	008D	Value of word address divided by 0x10
Timer Calculation Value	TC	0060	Word Address
Timer Setting Value	TS	0061	Word Address
One-shot Timer Calculation Value	UC	0062	Word Address
One-shot Timer Setting Value	US	0063	Word Address
Counter Calculation Value	CC	0064	Word Address

Device	Device Name	Device Code (HEX)	Address Code
Counter Setting Value	CS	0065	Word Address
Work Register	FW	0001	Word Address
Data Register	DW	0000	Word Address
Work Register	LB, LBW	008E	Value of word address divided by 0x10
Ladder Converter Special Work Register	LR, LRW	008F	Value of word address divided by 0x10
Ladder Converter Special Work Register (Edge)	LV, LVW	0090	Value of word address divided by 0x10
Word Special Work Register	LWW	0002	Word Address
Long Word Special Work Register	LLL	0003	Word Address
Single Precision Floating Decimal Point Work Register	LF	0066	Word Address
Word Special Work Register (Power-cut Retain)	LXW	0004	Word Address
Long Word Special Work Register (Power-cut Retain)	LML	0005	Word Address
Single Precision Floating Decimal Point Work Register (Power-cut Retain)	LG	0067	Word Address
Direct Memory Address (DM00000000 - DM0FFFFFFE)	DM	0007	Value of word address divided by 2
Direct Memory Address (DM10000000 - DM1FFFFFFE)		0008	
Direct Memory Address (DM20000000 - DM2FFFFFFE)		0009	

Device	Device Name	Device Code (HEX)	Address Code
Direct Memory Address (DM30000000 - DM3FFFFFFE)	DM	000A	Value of word address divided by 2
Direct Memory Address (DM40000000 - DM4FFFFFFE)		000B	
Direct Memory Address (DM50000000 - DM5FFFFFFE)		000C	
Direct Memory Address (DM60000000 - DM6FFFFFFE)		000D	
Direct Memory Address (DM70000000 - DM7FFFFFFE)		000E	
Direct Memory Address (DM80000000 - DM8FFFFFFE)		000F	
Direct Memory Address (DM90000000 - DM9FFFFFFE)		0010	
Direct Memory Address (DMA00000000 - DMAFFFFFFE)		0011	
Direct Memory Address (DMB00000000 - DMBFFFFFFE)		0012	
Direct Memory Address (DMC00000000 - DMCFFFFFFE)		0013	
Direct Memory Address (DMD00000000 - DMDFFFFFFE)		0014	

Device	Device Name	Device Code (HEX)	Address Code
Direct Memory Address (DME0000000 - DMEFFFFFFE)	DM	0015	Value of word address divided by 2
Direct Memory Address (DMF0000000 - DMFFFFFFE)		0016	

7 Error Messages

Error messages are displayed on the screen of Display as follows: "No.: Device Name: Error Message (Error Occurrence Area)". Each description is shown below.

Item	Description
No.	Error No.
Device Name	Name of External Device where an error occurs. Name of External Device is a title of External Device set with GP-Pro EX. (Initial value [PLC1])
Error Message	Displays messages related to the error that has occurred.
Error Occurrence Area	Displays IP address or device address of External Device where error occurs, or error codes received from External Device. <div style="border: 1px solid black; padding: 2px; display: inline-block;">NOTE</div> <ul style="list-style-type: none"> • IP address is displayed as "IP address (Decimal): MAC address (Hex)". • Device address is displayed as "Address: Device address". • Received error codes are displayed as "Decimal [Hex]".

Display Examples of Error Messages

"RHAA035: PLC1: Error has been responded for device write command (Error Code: 2[02H])"

NOTE

- Refer to your External Device manual for details on received error codes.
- Please refer to "Display-related errors" of "Maintenance/Troubleshooting Guide" for a common error message to the driver.