

Replacement Book

PS-5811W (Slim Type, Core i3)
→ PS6000 series 19-inch Wide Display +
Standard Box (Core i3)

Preface

This guidebook introduces the procedures to replace PS-5811W with PS6000 series 19-inch Wide Display Module + Standard Box Module. The recommended replacement models are as shown below.

* The PS6000 series 19-inch Wide Display Module is hereinafter called PS6000 19"W and the PS6000 series Standard Box Module is called Standard Box.

| Currently used device | | Recommended replacement model |
|--|---|--|
| PS-5811W (Core i3) Model: PFXPS2KN3D8xxxxN00 | ⇒ | PS6000 19"W + Standard Box (Core i3) Model: PFXP63Gxxxxxxxxx00 |

Safety Information

To properly use the products described in this book, please follow the directions below.

- Be sure to read the manual and the other provided documents before use.
- Only persons with the expertise of electrical equipment construction method and related law and also the adequate skills should be allowed to install, connect, and maintain the products.

We are not responsible for death, serious injury or unintended equipment damage incurred as the result of failure to follow these instructions.

Trademarks

Microsoft® and Windows® are either registered trademarks or trademarks of Microsoft Corporation in the United States and/or other countries.
Intel®, Celeron®, Atom®, Core™2 Duo and Core™ i3/5/7 are trademarks of Intel Corporation.
Other product names used in this manual may be the registered trademarks owned by the respective proprietors.

Models of PS6000 series

PS6000 series are products of CTO (Configure To Order).

Please confirm CTO models on the Web site before placing orders at the time of purchase.

Generate CTO models.

<https://www.proface.com/en/product/ipc/ps6000/configurator>

Product configuration of PS5000 series,

If you know the product model number of PS5000 series, you can access the following Web site and know the product configuration by entering the product model number.

PS5000 Reverse Configurator.



https://www.pro-face.com/otasuke/ps5000_configurator/reverse.html

Table of Contents

| | |
|--|------------------|
| <u>Preface</u> | <u>2</u> |
| <u>Models of PS6000 series</u> | <u>3</u> |
| <u>Product configuration of PS5000 series,</u> | <u>3</u> |
| <u>Table of Contents</u> | <u>4</u> |
| <u>Chapter 1 Specifications Comparison</u> | <u>5</u> |
| 1.1 Comparison of display specifications between PS-5811W and PS6000 19" W | 5 |
| 1.2 Comparison of performance specifications between PS-5811W and Standard Box | 6 |
| 1.3 Comparison of general specifications between PS-5811W and PS6000 19"W + Standard Box | 7 |
| 1.4 Comparison of interface specifications between PS-5811W and PS6000 19"W + Standard Box | 8 |
| <u>Chapter 2 Hardware Compatibility</u> | <u>9</u> |
| 2.1 Serial Interface | 9 |
| 2.2 Option Interface of RS-422/485 isolated type x2 | 9 |
| 2.3 Assigned numbers of COM ports | 10 |
| 2.4 Video output interface | 10 |
| 2.5 USB Type C | 10 |
| 2.6 Watchdog timer | 11 |
| <u>Chapter 3 Compatibility of optional items</u> | <u>11</u> |
| 3.1 Option Interface | 11 |
| 3.2 Drive and Main Memory | 13 |
| 3.3 The other options | 14 |
| <u>Chapter 4 Compatibility of software</u> | <u>15</u> |
| 4.1 Supported OS and language | 15 |
| 4.2 OS login password | 16 |
| 4.3 Recovery media | 16 |
| 4.4 Supported software and utilities | 16 |
| 4.5 Supported features in System Monitor | 17 |
| 4.6 Details of touch operation for every series | 18 |

Chapter 1 Specifications Comparison

1.1 Comparison of display specifications between PS-5811W and PS6000 19" W

| Display Specifications | | | |
|-------------------------------|--|---|--|
| | | PS-5811W | PS6000 19" W |
| | |  |  |
| Display Type | TFT Color LCD (19" Wide) | | |
| Display Resolution | FWXGA (1,366 x 768 pixels) | | UP! FHD (1,920 x 1080 pixels) |
| Display Colors | Approx. 16 million colors | | |
| Backlight | White LED (not user replaceable. When replacement is required, contact customer support.) | | |
| Brightness control | No level adjustment | | UP! 101 levels (adjusted with touch panel or software) |
| Backlight service life | 50,000 hours or more (continuous operation at 25 °C [77 °F]-ambient temperature- before backlight brightness decreases to 25%) | | |
| Touch panel | Type | Projected capacitive touch panel (multitouch, simultaneous touch number-5) | Projected capacitive touch panel (multitouch, simultaneous touch number-2) with optimized noise filter |
| | Mode | None | UP! 3 modes (Changeable - Standard Mode, Water Detection Mode, and Glove Mode) |

1.2 Comparison of performance specifications between PS-5811W and Standard Box

| Performance Specifications | | | |
|-----------------------------|---|---|---------------------|
| | PS-5811W | Standard Box | |
| CPU | Core i3-4010U, 1.7 GHz | UP! Core™ i3-8145UE | |
| | Base frequency | 1.70 GHz | UP! 2.20 GHz |
| | Max turbo boost frequency | 1.70 GHz | UP! 3.90 GHz |
| | L2 cache | 3 MB | UP! 4 MB |
| | Core number | 2 | 2 |
| | Thread number | 4 | 4 |
| Main memory | 8GB DDR3 1600 MHz, SO-DIMM SDRAM | UP! 260-pin SO-DIMM socket x 2, DDR4-2400 (Up to 32GB for 2 sockets) → See 3.2 | |
| Graphics accelerator | Intel HD Graphics 4400 | UP! Intel® UHD Graphics 620 (built-in CPU) | |
| Security chip | Not supported | UP! TPM 2.0 | |
| BIOS | Legacy BIOS | UP! UEFI BIOS | |
| Operating system | <ul style="list-style-type: none"> Windows® 10 IoT Enterprise 64 bit MUI Windows® Embedded 8.1 Industry 64 bit MUI Windows® 7 Ultimate SP1 64 bit MUI Windows® Embedded Standard 7 (WES7P) SP1 64 bit MUI | UP! Windows® 10 IoT Enterprise 2019 LTSC (64bit) UP! Windows® 10 IoT Enterprise 2021 LTSC (64bit) | |
| Watchdog timer | Timeout setting from either 1 to 255 seconds, or 1 to 255 minutes, is possible (set up using API) | New! Timeout setting from either 1 to 255 seconds, or 1 to 255 minutes, is possible (set up using API) → See 2.7 | |
| Buzzer | Yes | | |

1.3 Comparison of general specifications between PS-5811W and PS6000 19"W + Standard Box

| General Specifications | | |
|---------------------------------------|---|---|
| | PS-5811W | PS6000 19"W + Standard Box |
| Panel cut dimensions | W479.3 mm x H300.3 mm | W449.5 mm x H279.5 mm * The panel cut dimensions are different. The optional attachment (PFXZPAT8W1) is required for attaching it. |
| Panel thickness | 2 mm to 6 mm | 1.6 mm to 5 mm |
| External dimensions (including bezel) | W488.0 x H309.0 x D56.7 mm | W463.6 x H293.6 x D85.0 mm * The depth is deeper by 29.7mm. Make sure that the panel space has some margins. |
| Front bezel material | Aluminum | |
| Weight | 7 kg | 7.4 kg or less |
| Cooling method | Natural air circulation (fanless) | |
| Power supply | DC power supply : 24V AC power supply : 100 to 240V (AC power supply needs option.) | DC power supply : 24V AC power supply : 100 to 240V |
| Power consumption | DC | 28 W (standard), 60 W (max) When backlight is off: 41 W No power supplied to outside: 64 W Max: 82 W |
| | AC | - When backlight is off: 50 VA No power supplied to outside: 74 VA Max: 92 VA |
| UPS for battery backup | None | - *Operation tested UPS available →See 2.1 |

1.4 Comparison of interface specifications between PS-5811W and PS6000 19"W + Standard Box

| Interface Specifications | | | |
|---|-----------|---|--|
| | | PS-5811W | PS6000 19"W + Standard Box |
| Serial (D-Sub 9-pin plug) | Main unit | RS-232C x1 RS-232C/422/485 x1 | RS-232C (non-isolated type) x1 → See 2.2 |
| | Option | Select any of the following RS-232C x4 RS-232C isolated type x2 RS-422/485 x4 RS-422/485 isolated type x2 | Select any of the following RS-232C x4 RS-232C isolated type x2 RS-422/485 isolated type x2 → See 2.3 → See 2.4 <i>* No compatibility in case of RS-422 using RTS+/- or CTS+/- . But even in other case, if application or connected device is controlling send/receiving by monitoring RTS or CTS, it could not be communicated. If able to change to software flow control, it is avoidable.</i> |
| Disk | | 2.5" SATA (HDD/SSD) x1 CFast x1 | UP! M.2 SSD SATA x 1 (Disk 0) 2.5" SATA (HDD/SSD) x1 (Disk 1) |
| USB | | USB Type-A x2 (3.0 x2) <i>* There's no front USB.</i> | UP! USB Type-A x4 (ボックス 2.0 x 2、3.0 x 2) UP! USB Type-C x1 (Box 3.0) <i>* There's no front USB.</i> |
| Ethernet | | 10BASE-T/100BASE-TX/1000BASE-T automatic change x2 | IEEE1588, 10 BASE-T/ 100 BASE-TX/1000BASE-T, Wake on LAN (WOL) supported <i>* When status is S4 (hybrid shutdown), Wake on LAN cannot be used.</i> |
| Sound | | Line output | Line input/Line output/Microphone input (Option) |
| Video output → See 2.5 | | HDMI x1 | UP! Display port x1 (Dual mode supported) UP! USB 3.0 (Type C Displayport Alternate mode) x 1 <i>* Same port with above USB line</i> → See 2.6 |
| PCI/PCIe Card Slot | | None | |
| Option Interface Slot | | 1 slot | |

Chapter 2 Hardware Compatibility

2.1 UPS for battery backup

We have operation tested UPS for PS6000 Series.

Schneider Electric: SMT500J - APC Smart - UPS500

Schneider Electric: BVS240XDPDR - Easy UPS


2.2 Serial Interface

For PS6000 series, it's possible to add a serial interface compatible with the communication type, RS-232/422/485 as an option. To add it, please specify at the time of CTO order.


If you want to add it after purchase, purchase the option item and attach it.

2.3 Option Interface of RS-422/485 isolated type x2


An RS-485 interface is connected to the interface cartridge at the time of shipping from the factory. If you want to use an RS-422 interface, remove the RS-485 interface cable from the interface cartridge and replace it with the RS-422 interface cable attached to this product.




Interface Cartridge



RS-485 Interface Cable




RS-422 Interface Cable



2.4 Assigned numbers of COM ports


The COM port numbers of the option interface card are defined with a type of inserted card and which slot is used.



| Option interface card | Slot | | | |
|--|------|---|---|---|
| | 3 | 4 | 5 | 6 |
| RS-232C isolated type x2 and RS-422 x2 | ✓ | ✓ | - | - |
| RS-485 x2 | - | - | ✓ | ✓ |
| RS-232C x4 | ✓ | ✓ | ✓ | ✓ |

2.5 Video output interface

PS6000 series supports 3 video output interfaces. Simultaneous output of all the interfaces is possible.



1: Display Module Interface

2: USB Type C

3: Display Port

| Setting Tool | Duplicate | Extension | Scaling |
|----------------------------------|---------------|---------------|-------------------|
| Windows standard display setting | 2 screens max | 3 screens max | Scaling down only |
| Intel Graphics Command Center | 3 screens max | 3 screens max | Scaling up/down |

| Display Module Interface | USB Type C | Display Port | Details |
|--------------------------|------------|--------------|---|
| Screen A | Screen B | Screen C | 3 – extension display |
| A | B | B | 1-extension display (Display Module), 2-duplication display |
| B | A | B | 1-extension display (USB Type C), 2-duplication display |
| B | B | A | 1-extension display (DisplayPort), 2-duplication display |
| A | A | A | 3-duplication display (Intel Graphics Command Center is required) |

2.6 USB Type C

The USB Type C of PS6000 series supports Alt Mode and USB-PD (Power Delivery). *1

Video output and power feeding are possible with a single USB Type C cable. The amount of power feeding is as follows;

| | PD 12V device | PD 5V device | Without PD device |
|------------------------|----------------------------|----------------------------|-------------------|
| Standard Box | 36W | 15W | 4.5W |
| Standard Box + Display | PD devices cannot be used. | PD devices cannot be used. | 4.5W |

*1: To use the USB-PD feature, a Type-C cable supporting USB PD (Power Delivery) is required.

2.7 Watchdog timer

The watchdog timer is supported by products with the following system version.

- BIOS: WAR02 or later
- OS Base: 2.0 or later

You can check the system version from the Launcher. Refer to System, page 165 in the user manual. To use the watchdog timer on a product with a WAR01 BIOS, and OS Base 1.0, the BIOS and System Monitor must be updated. Follow the steps below to update.

1. BIOS: Contact the customer care center for instructions on how to update.
2. System Monitor: Download the driver (PFXPHMIP6_Driver_Installer_Ver.x.x.zip) and utility (PFXPHMIP6_Utility_Installer_Ver.x.x.zip) from our website and install them.
<https://www.pro-face.com/trans/en/manual/1085.html>

Chapter 3 Compatibility of optional items

3.1 Option Interface

The option interface card of PS5000 series (modular type) is not compatible with PS6000 series. But, some cards with equivalent feature are available for PS6000 series.

| PS5000 series (modular type) | | PS6000 series | |
|---|-----------------|------------------------------------|------------------|
| Product Name | Model | Product Name | Model |
| RS-422/485 isolated type x 2 | PFXZPBMPR42P2 | RS422/485 isolated type x 2 | PFXYP6MPR42P2 *5 |
| RS-422/485 x 4 | PFXZPBMPR44P2 | - | |
| RS-232 x 4 | PFXZPBMPR24P2 | RS-232C x 4 | PFXYP6MPR23P4 |
| RS-232 isolated type x 2 | PFXZPBMPR22P2 | RS-232C isolated type x 2 | PFXYP6MPR23P2 |
| 16DI/8DO and 2-m cable and terminal | PFXZPBMPX16Y82 | 16DI/8DO *1 *2 | PFXYP6MPX16Y8 |
| Analog input x 8 | PFXZPBMPAVI8 | - | |
| Ethernet gigabit IEEE1588 x 1 | PFXZPBMPRE2 | Ethernet (GbE IEEE1588) | PFXYP6MPETH |
| Ethernet gigabit PoE x 2 | PFXZPBMPPE2 | - | |
| EtherCAT (master) | PFXZPBMPPECATM2 | EtherCAT (Master) *3 | PFXYP6MPECAT |
| USB 3.0 x 2 | PFXZPBMPUS2P2 | - | |
| CANopen x 2 | PFXZPBMPCANM2 | - | |
| Profibus DP master (With NVRAM) x 1 | PFXZPBMPPB2 | - | |
| Cellular 3G: GPRS/GSM and antenna | PFXZPBPHMC2 | - | |
| Audio interface for Celeron/Core i7 | PFXZPBPHAU2 | Audio (Mic-IN, Line-IN, Line-OUT) | PFXYP6MPAU |
| Transmitter | PFXZPBMPMX2 | - | |
| DVI-I x 1 | PFXZPBMPDV2 | - | |
| VGA and DVI-D x 2 | PFXZPBMPVGDV2 | - | |
| Cellular for North America 4G and antenna | PFXZPBMP4GU2 | 4G Cellular for US *4 | PFXYP6MP4GU |
| Cellular for Europe/Asia 4G and antenna | PFXZPBMP4GE2 | 4G Cellular for EU, Asia, Japan *4 | PFXYP6MP4GE |
| Cellular for Japan 4G and antenna | PFXZPBMP4GJ2 | | |
| TPM module | PFXZPBTPM22 | Built in as standard | |

*1: Cannot be mounted for shipping as CTO. You can purchase it separately.

*2: PS6000 16DI/8DO interface option's digital output (DO0 to 7) will keep the output status also on the shutdown (system power status S5) or sleep (system power status S3) When replacing from PS5000 16DI/8DO interface option with system loads the default setting while reset, behavior will be different. Need to add process as turn off the digital output by application before shutdown or sleep.

*3: The ambient temperature for use of Advanced Box is limited to the maximum, 40 degree when the option interface of EtherCAT is connected.

*4: PS6000 Option not supporting SMS (Short Message Service). PS5000 Option has been supported.

*5 When Controlling Auto data flow, RS-485 check box on the Port setting by device manager need to be checked (image 1 and 2). The default setting is un-checked.

Image 1





Image 2




3.2 Drive and Main Memory

The drive of PS5000 series (slim type, Core i3) is not compatible with PS6000 series. But, some drives with the equivalent feature are available for PS6000 series. And users can attach and replace main memory by themselves for PS6000 series. Because of it, main memory is added to the option lineup.

| PS5000 series (slim type, Core i3) | | PS6000 series | |
|------------------------------------|---------------|---------------------------------|--------------|
| Product Name | Model | Product Name | Model |
| - | - | M.2 SSD 128 GB (standard) | PFXYP6M2128L |
| - | - | M.2 SSD 128 GB (high endurance) | PFXYP6M2128 |
| - | - | M.2 SSD 256 GB (high endurance) | PFXYP6M2256 |
| - | - | M.2 SSD 512 GB (high endurance) | PFXYP6M2512 |
| HDD 500 GB | PFXZPBHDD502 | - | - |
| HDD 1 TB | PFXZPBHDD1002 | HDD 1 TB | PFXYP6HDD1T |
| SSD 128 GB | PFXZPBSSD122 | SSD 128 GB (high endurance) | PFXYP6SSD128 |
| SSD 256 GB | PFXZPBSSD252 | SSD 256 GB (high endurance) | PFXYP6SSD256 |
| - | - | SSD 512 GB (high endurance) | PFXYP6SSD512 |
| CFast 16 GB | PFXZPECFA162 | - | - |
| CFast 32 GB | PFXZPSCFA322 | - | - |
| - | - | DIMM 4 GB (main memory) | PFXYP6DM4 |
| - | - | DIMM 8 GB (main memory) | PFXYP6DM8 |
| - | - | DIMM 16 GB (main memory) | PFXYP6DM16 |

Replacing main memory

1. Disconnect the power supply from the Box Module.
2. Touch the housing or ground connection (not the power supply) to discharge any electrostatic charge from your body.
3. Remove 5 screws on the rear side of the Box Module and pull out the rear cover
4. Pull out the main memory from the slot.
5. Insert new main memory, then push from above.
6. Place the rear cover of the Box Module and tighten with screws.



3.3 The other options

The options except the option interface, the drive, and the main memory of PS5000 series (slim type, Core i3) are not compatible with PS6000 series, but there are some exceptions.

| PS5000 series (slim type, Core i3) | | PS6000 series |
|---|-----------------|---------------|
| Product Name | Model | Compatibility |
| AC power supply module | PFXZPSPUAC3 | - |
| DC Power Supply Connector (5 pcs) | PFXZPBCNDC2 | |
| Installation Fastener (12 pcs) | PFXZPPAF12P2 | |
| Protection sheet for 15" wide (5 sheets) | PFXZPPDSP152 | |
| Protection sheet for 19" wide (5 sheets) | PFXZPPDSP192 | |
| Drip-proof gasket for 15" wide (1pc) | PFXZPPWG152 | |
| Drip-proof gasket for 19" wide (1pc) | PFXZPPWG192 | |
| M12 connector (power supply, COM, LAN x 2, USB) (environmentally resistant panel only) | PFXZPSCNM122 | |
| DP-DVI converter (DVI-D type) | PFXZPBADCVDPDV2 | |
| USB cable 5 m | FP-US00 | |
| M12 cable for environmentally resistant panel: LAN cable 2 m (6.56 ft) x 2 COM cable 2 m (6.56 ft) x 1 USB cable 1.5 m (4.92 ft) x 1 Power Supply cable 2 m (6.56 ft) x 1 | PFXZPSCBM122 | - |

Chapter 4 Compatibility of software

4.1 Supported OS and language

The supported OS and language differ between PS5000 series and PS6000 series.


| OS | PS5000 series | PS6000 series |
|--|---------------|---------------|
| Windows® Embedded Standard 7(32bit) MUI | Yes | No |
| Windows® Embedded Standard 7(64bit) MUI | Yes | No |
| Windows® 7 Ultimate (64bit) MUI | Yes | No |
| Windows® Embedded 8.1 Industry (64bit) MUI | Yes | No |
| Windows® 10 IoT Enterprise 64 bit MUI | Yes *1 | Yes |

*1: The HORM feature is not supported.

| Language | PS5000 series | PS6000 series |
|----------------------|--|------------------------------------|
| | WES7/Win7/WES8.1/Win 10 IoT Enterprise 2016 LTSC | Win 10 IoT Enterprise 2019 LTSC *2 |
| Chinese(Simplified) | Yes/No *1 | Yes |
| Chinese(Traditional) | Yes/No *1 | Yes |
| English | Yes | Yes |
| French | Yes | Yes |
| German | Yes | Yes |
| Italian | Yes | Yes |
| Japanese | Yes | Yes |
| Portuguese | Yes/No *1 | Yes |
| Russian | Yes/No *1 | Yes |
| Spanish | Yes | Yes |
| Swedish | Yes/No *1 | Yes |

*1: It's necessary to add and install a language from the language pack.

*2: Language that is not shown in the table can be downloaded from the Microsoft web site using the standard language feature of Windows.



4.2 OS login password

For PS6000 series, it's necessary to set a login password at the first boot of the product to reduce the risk of intrusion and infection of malicious software and unauthorized access. Unlike PS5000 series, you cannot configure settings without a password. The conditions of login password are as follows;

The number of characters: 8 or more characters with 3 or more types included from the usable characters as shown below. The character strings used for the account name cannot be used.

Types of usable characters:

- Upper-case characters of European languages (A to Z, diacritical mark, Greek alphabet, Cyrillic alphabet)
- Lower-case characters of European languages (a to z, hash sign, Greek alphabet, Cyrillic alphabet)
- Numbers (0 to 9)
- Characters (special characters) except alphanumeric characters: (~!@#\$\$%^&* _+=`|¥(){}[];:"'<>,.?/) In this policy setting, the currency sign like Euro or British Pound is not counted as special characters
- Unicode characters that are neither upper-case nor lower-case characters though they are categorized in the order of alphabet. Unicode characters of Asian languages are included in this.

4.3 Recovery media

A recovery USB for OS recovery is attached to PS5000 series, but it's an optional item for PS6000 series. Please purchase a recovery USB for PS6000 series for OS recovery.

USB available for each OS. **2019:** PFXYP6RUSW10 **2021:** PFXYP6RUSW1021

Using the recovery tool *2 on our web site *1 makes recovery possible with the backup file created in advance.

*1: The optional recovery USB supports OS recovery only. When system backup after setup is required, use the recovery tool.

*2: <http://www.pro-face.com/trans/en/manual/1085.html>

4.4 Supported software and utilities

The software and utilities supported by PS6000 series are as follows;

| Software | Version |
|------------------------------------|------------------------|
| GP-Pro EX (WinGP) | Ver. 4.09.250 or later |
| Pro-Server EX | Ver. 1.37 or later |
| Pro-face Remote HMI (iOS/Android) | Ver. 1.50 or later *1 |
| Pro-face Remote HMI Server | Ver. 1.11.006 or later |
| Pro-face Remote HMI Client for Win | Ver. 1.42 or later |
| BLUE (BLUE Runtime) | 3.1 Service Pack 1A *2 |
| BLUE Open Studio | V2020 or later |

*1: For earlier than Ver.1.50, PS6000 series (WinGP) is not recognized as a connection destination server.

*2: "IPC or PC/AT" for model setting

| Utility | Descriptions |
|----------------|---|
| Buzzer | Enable or disable the buzzer sound at the time of touch panel operation. |
| Brightness *3 | Sets the backlight brightness. |
| Calibration | Correct touch positions. |
| Front USB | Permit or do not permit use of Front USB on Display Module. |
| Write Filter | Enable or disable the Write Filter feature. |
| HORM | Enable or disable the HORM feature. |
| Shell | Hide the Windows® desktop. Using this custom shell feature allows you to restrain the Windows® features such as Control Panel. |
| Power | Used to operate power supply of this product in a state of custom shell. |
| System | Show the product's firmware, BIOS version, and OS version. |
| Touch Mode | Select from 3 modes (Normal, Water-detected, and Gloves) according to a use environment. |
| System Monitor | Monitor a state of the main unit, for example temperature or voltage, using a dashboard created with Node-RED. |
| Window Locker | Fix a window display position at the time of application boot when an external display is used. |
| Cellular *3 | You can use the optional interface unit and a SIM card to data communication using 3G, 4G, and LTE radio waves. Double-click this icon to make settings for data communication. |

*3: When you use the following system version of the product, or when the icon is unavailable in the Launcher, download the utility (PFXPHMIP6_Utility_Installer_Ver.x.x.zip) from our website and install by following the instructions.
<https://www.pro-face.com/trans/en/manual/1085.html>

System Version:
 OS Base: 2.0 or lower
 OS Patch: None

You can check the system version from the Launcher. Refer to System, page 165 in the user manual.

4.5 Supported features in System Monitor

The difference of supported System Monitor features is as shown below.

| Monitored items | Error Action | PS5000 series | PS6000 series |
|--------------------------|---------------|---------------|---------------|
| Device Management | | | |
| Voltage | LED | - | ✓ |
| | Buzzer | - | - |
| | Popup Message | - | ✓ |
| | Shutdown | - | - |
| | Event Log | ✓ | ✓ |
| | E-mail | ✓ | - |
| Fan | LED | - | - |
| | Buzzer | - | - |
| | Popup Message | - | - |
| | Shutdown | - | - |
| | Event Log | ✓ | - |
| | E-mail | ✓ | - |
| Temperature | LED | - | ✓ |
| | Buzzer | - | - |
| | Popup Message | - | ✓ |
| | Shutdown | - | - |
| | Event Log | ✓ | ✓ |
| | E-mail | ✓ | - |
| SMART | LED | - | - |
| | Buzzer | - | - |
| | Popup Message | - | - |
| | Shutdown | - | - |
| | Event Log | - | - |
| | E-mail | - | - |
| Power | LED | - | - |
| | Buzzer | - | - |
| | Popup Message | - | - |
| | Shutdown | - | - |
| | Event Log | - | - |
| | E-mail | - | - |
| Software | Event Log | ✓ | - |
| | E-mail | ✓ | - |
| Remote Control | | | |
| Remote Reset | | ✓ | - |
| Remote Viewer | | ✓ | ✓ |
| Remote Screen Shot | | ✓ | - |

4.6 Details of touch operation for every series

| Series | Touch Type | Driver | Touch Detection | Behavior when touch and hold | Supports two-point touch |
|---------------------------|----------------|------------------|-----------------|--------------------------------|--------------------------|
| PS5000 | Resistive Film | PenMount Driver | Pen Up | Right Click (Default) | - |
| | Capacitive | | | ✓ | |
| PS5000 + DA *1 | Resistive Film | | | Depend on the Host PC setting. | - |
| | Capacitive | | | ✓ | |
| FP5000 SP5000 + MDA *2 | Resistive Film | Windows Standard | Pen Down | Depend on the Host PC setting. | ✓ |
| PS6000 | Resistive Film | | | Right Click (Default) | ✓ |
| | Capacitive | | | | |
| FP6000 | Resistive Film | | | Depend on the Host PC setting. | |
| | Capacitive | | | | |

*1: Display Adapter

*2: Multi Display Adapter