



Intel® Rapid Storage Technology Release 17.x with Intel® Optane™ Memory

OEM Technical Guide

For the Intel® Rapid Storage Technology Release Version 17.0, 17.2, 17.3, 17.5, 17.7, 17.8 with Intel® Optane™ Memory Support (For OEMs, ODMs, IHVs, ISVs, IBVs, SIs)

Revision 1.3.9

Intel Confidential



You may not use or facilitate the use of this document in connection with any infringement or other legal analysis concerning Intel products described herein. You agree to grant Intel a non-exclusive, royalty-free license to any patent claim thereafter drafted which includes subject matter disclosed herein.

No license (express or implied, by estoppel or otherwise) to any intellectual property rights is granted by this document.

Intel technologies' features and benefits depend on system configuration and may require enabled hardware, software or service activation. Learn more at Intel.com, or from the OEM or retailer.

No computer system can be absolutely secure. Intel does not assume any liability for lost or stolen data or systems or any damages resulting from such losses.

The products described may contain design defects or errors known as errata which may cause the product to deviate from published specifications. Current characterized errata are available on request.

Intel disclaims all express and implied warranties, including without limitation, the implied warranties of merchantability, fitness for a particular purpose, and non-infringement, as well as any warranty arising from course of performance, course of dealing, or usage in trade.

Intel technologies' features and benefits depend on system configuration and may require enabled hardware, software or service activation. Learn more at intel.com, or from the OEM or retailer.

All information provided here is subject to change without notice. Contact your Intel representative to obtain the latest Intel product specifications and roadmaps.

Copies of documents which have an order number and are referenced in this document may be obtained by calling 1-800-548-4725 or visit www.intel.com/design/literature.htm.

By using this document, in addition to any agreements you have with Intel, you accept the terms set forth below.

Contact your local Intel sales office or your distributor to obtain the latest specifications before placing your product order.

Intel, the Intel logo, are trademarks of Intel Corporation in the U.S. and/or other countries.

*Other names and brands may be claimed as the property of others.

Copyright © 2018, Intel Corporation. All rights reserved.



Contents

1	About This Document.....	14
1.1	Purpose and Scope of this Document	14
1.2	Intended Audience.....	14
2	New in Release Version 17.x	15
2.1	What's New in Release 17.0.....	15
2.1.1	Intel® Optane™ Memory H10 (Teton Glacier) Support.....	15
2.1.2	TRIM Support For NAND SSD in Optane™ Volume	15
2.1.3	Bandwidth Aggregation Support for Intel® Optane™ Memory H10 (Teton Glacier) in AC mode	15
2.2	What's New in Release 17.2.....	16
2.2.1	Disable Adaptive D3 for Optane™ Configuration	16
2.2.2	Optane™ Memory Support for Desktop Pentium and Celeron Sku... 16	
2.3	What's New in Release 17.3.....	16
2.3.1	Optane™ Memory Feature for Supported Platforms with Mobile Pentium and Celeron Processor	16
2.3.2	Optane™ Memory Feature for Intel® SSD 660p NVME.....	16
2.3.3	NVME APST Optimization for Power Efficiency and Performance	16
2.4	What's New in Release 17.5.....	17
2.4.1	New Supported Platforms.....	17
2.4.2	Registry to control APM Level	17
2.4.3	Pyrite Support	17
2.4.4	Pinning Shell Extension Removal from INF distribution file.....	17
2.4.5	Intel's Virtualization for Directed I/O (a.k.a IOMMU) Support in RST Pre-OS	18
2.5	What's New in Release 17.7.....	18
2.5.1	New Supported Platforms.....	18
2.5.2	Command Line Tool (CLI) Support for Non-OEMs	18
2.6	What's New in Release 17.8.....	19
2.6.1	New Supported Platform	19
2.6.2	Disable File Cache for Intel® Optane™ Memory H10.....	19
2.6.3	Bandwidth Aggregation Support for Intel® Optane™ Memory H10 (Teton Glacier) in DC mode	20
2.6.4	Improving Idle Cleanup for Intel® Optane™ Hybrid device.....	20
2.6.5	NVME IOCTL Pass-Through support in WinPE	21
2.6.6	Using Unique RAID Alternate ID per Platform Generation	21
2.6.7	Intel® Optane™ Memory and Storage Management UI Enhancements	21
2.6.8	Changes between RST 17.8 Beta and RST 17.8 PV features.....	22
3	Intel® Rapid Storage Technology	23
3.1	Overview.....	23
3.1.1	Product Release Numbering Scheme.....	23
3.1.2	RAID Levels.....	24
3.1.3	Supported Platforms for This Release.....	25
3.1.4	Supported Optane™ Memory for This Release.....	28
3.1.5	Supported Intel NVME as Slow drive for Optane™ Memory Volume. 28	
3.1.6	Intel® RST Key Feature/Functionality Matrix	29
3.1.7	Supported Operating Systems for This Release	32
3.1.8	Supported MSFT* Performance Debug Tools.....	32
4	Intel® Rapid Storage Technology Suite.....	33
4.1	Intel® Rapid Storage Technology Software.....	34



4.2	Intel® Rapid Storage Technology Option ROM	34
4.3	Intel Pre-OS RAID Configuration Utilities	34
4.3.1	RCfgSata Utility for MS-DOS* and UEFI	35
4.4	RSTCLI (32/64 bit) Windows Utilities	36
4.5	UEFI System BIOS and Intel® RST UEFI/RAID Package	44
4.5.1	Specification References	44
4.5.2	What Intel® RST Provides to OEMs/BIOS Vendors	45
4.5.3	UEFI System BIOS Requirements for Platform Compatibility with Intel® RST UEFI	47
4.5.4	How-to-Enable the Platform with Intel® RST UEFI Driver/HII_GUI .	49
4.5.5	Known Compatibility Issues with UEFI Self Certification Test (UEFI SCT) Tool	50
4.6	Pre-OS	51
4.6.1	BIOS PCH SATA Controller Modes	51
4.6.2	Platform BIOS Settings	52
5	Intel® Optane™ Memory and Storage Management UI	55
5.1	Introduction	55
5.2	Getting Started	55
5.2.1	Understanding the Application	55
5.3	Storage System Status	57
5.3.1	Storage System View	57
5.4	Installation/Configuration of the Intel® Optane™ Memory and Storage Management UI (RST_HSA UI)	57
5.5	Manage	61
5.6	Create Volume	63
5.6.1	RAID 0	63
5.6.2	RAID 1	66
5.6.3	RAID 5	68
5.6.4	RAID 10	70
5.7	Intel® Optane™ Memory	72
5.7.1	Enable Intel® Optane™ Memory Volume	72
5.7.2	Disable Intel® Optane™ Memory Volume	76
5.7.3	Pin Files and Folders	78
5.7.4	Pin Applications	80
5.8	Performance	80
5.9	Settings	81
5.10	About	82
5.11	Additional operations in Intel® Optane™ Memory and Storage Management UI	82
5.11.1	User Pinning of Files/Folders/Applications	82
5.11.2	Adding a disk to an Array	85
5.11.3	Creating a Matrix Array	88
5.11.4	Deleting a RAID Volume	90
5.11.5	Using Optane with Cached data from another system	91
5.11.6	Marking a Disk as a Spare	95
5.11.7	Clear Metadata	97
5.12	HSA 16.7 - Optane™ Memory and Storage Management UI Functionality Limitations	102
5.12.1	Creating a RAID Volume with a disk containing user data	102
5.12.2	Deleting a RAID Volume	104
5.12.3	Marking a Disk as a Spare	108
5.12.4	Adding a disk to an Array	110



5.12.5	Using Optane disk which has user data	113
5.12.6	Using Optane with Cached data from another system	114
5.12.7	Un-initialize disk such that it can be used with the HSA App.	118
5.12.8	Clear Metadata for RAID disks	120
5.12.9	Intel® Optane™ Memory and Storage Management App Reboot..	125
5.13	Compatibility Matrix - Optane™ Memory and Storage Management UI and RST Driver	127
5.13.1	Troubleshooting when using Middleware/Driver and UI mismatch (HSA UI 16.7 and 17.x RST Middleware/Driver)	127
5.13.2	Troubleshooting when using Middleware/Driver and UI mismatch (HSA UI 17.x and 16.7 RST Middleware/Driver)	128
6	System Acceleration with Intel® Optane™ Memory	130
6.1	Limitations	130
6.1.1	Hardware limits	130
6.1.2	Functional limits.....	131
6.2	Minimum Requirements:	132
6.2.1	Intel® Optane Memory	132
6.2.2	Intel® Optane Memory H10 w/ Solid State Storage (Teton Glacier).....	133
6.2.3	Operating System	133
6.2.4	“Optane™ Memory Ready” Logo: Intel® RST 5MB Metadata Requirement	133
6.3	User Pinning of Files/Folders/Applications	134
6.3.1	Overview	134
6.3.2	Minimum Requirements	134
6.3.3	Pinning using the Intel® Optane™ Memory and Storage Management UI	135
6.3.4	Pinning using the Intel® Optane™ Memory UI.....	137
6.3.5	Pinning using the Intel® RST UI	139
6.3.6	User Pinning using Windows File Explorer application.....	141
6.4	Configuring Intel® Optane™ Memory (Post-Factory Build Environment ¹).....	148
6.4.1	Enable Optane™ Volume on a Brand New System	148
6.4.2	System Upgrade (Windows*10 OS Already Installed)	162
6.4.3	System Upgrade (Windows* 10 OS Already Installed with BIOS in AHCI mode)	169
6.5	Intel® Optane™ Memory Member Disk Upgrades	172
6.5.1	Slow Disk (SATA HDD, SSD, SSHD) Upgrade/Replacement.....	173
6.5.2	Intel® Optane™ Memory Module Upgrade/Replacement	175
6.6	Managing Intel® Optane™ Memory	177
6.6.1	During the Pre-OS (Pre-Boot)	177
6.6.2	During the OS Runtime	178
6.6.3	Roaming Optane™ Volumes.....	180
6.7	I/O Error Handling	181
6.7.1	Host I/O Failures.....	181
6.7.2	RST I/O Failures:	181
6.7.3	Missing Media Failures:	182
6.7.4	S.M.A.R.T. Events	185
6.7.5	Fast Media: Block Cache Errors	186
6.8	Intel® Optane™ Memory Member Disk Failures Requiring Replacement of Disk	187
6.8.1	Slow Disk (SATA HDD, SSD, SSHD) Replacement.....	187
6.8.2	Intel® Optane™ Memory Module Replacement	188
6.9	Windows Recovery Environment Support.....	190
6.9.1	Setting Up the Windows Recovery Environment (WinRE)	190
6.9.2	WinRE Menu Items	192
7	OEM HVM Factory Support for Intel® Optane™ System Acceleration	194
7.1	Intel® Optane™ Pre-Factory Recommendations for the ‘ReferencePC’	194



7.1.1	Optane™ Recommendations for the 'ReferencePC'	195
7.2	Intel® Optane™ Factory-Enabled System Build	197
7.2.1	Requirements/Considerations	198
7.2.2	PHASE 1: OEM Pre-Optane™-Config Factory Processes	198
7.2.3	PHASE 2: Optane™ Storage Sub-System Configuration.....	198
7.2.4	PHASE 3: OS and SW Download and Installation and OOBE Preparation	199
7.3	Intel® Optane™ Post-Factory-Enabled Builds	200
7.3.1	Requirements/Considerations	200
7.3.2	Example Build Flow	200
7.4	OEM Application Pinning in the Factory Flow	200
7.4.1	Manufacturing Considerations for Pinning	201
7.4.2	Using the JSON files in the Factory Flow.....	202
7.4.3	OEM Pinning Methods	202
8	CPU Attached Storage: PCIe NVMe	206
8.1	Overview.....	206
8.2	New Intel® RST Driver Architecture	206
8.3	Limitations and Minimum Requirements:	207
8.3.1	HW.....	207
8.3.2	SW/FW	208
8.3.3	WHQL Certification Testing Limitations.....	208
8.4	Usage models	208
9	Intel Rapid Storage Technology for PCIe NVMe Storage Devices	210
9.1	OEM System BIOS Requirements.....	210
9.2	General Requirements.....	210
9.3	Feature Limitations.....	210
9.4	PCIe NVMe Device Usage Model	211
9.5	Intel® RST for PCIe NVMe Storage Use cases	211
9.6	Intel® Rapid Storage Technology UEFI Compliance Utility for PCIe Storage	213
10	Intel Rapid Storage Technology for PCIe AHCI Storage Devices	215
10.1	OEM System BIOS Requirements.....	215
10.2	General Requirements.....	215
10.3	Warnings.....	215
10.3.1	Features Limitations	215
10.3.2	PCIe Device Usage Model	216
10.4	Intel Rapid Storage Technology for PCIe Storage Use cases	216
10.5	Intel® Customer Reference Board BIOS Settings	216
10.6	Intel® Rapid Storage Technology UEFI Compliance Utility for PCIe Storage	217
11	How to Enable the Platform for Intel® RST Support of BIOS Fast Boot.....	219
11.1.1	OEM System BIOS Vendors' Requirements	219
11.1.2	Supported System Configurations	219
12	Creating a RAID Volume.....	221
12.1	Minimum Requirements.....	221
12.2	Feature Limitations.....	221
12.3	Using Intel® Intel® Optane™ Memory and Storage Management UI	221
12.4	Using Intel® Rapid Storage Technology UI	222



12.5	Using Intel® Rapid Storage Technology Legacy Option ROM User Interface .	223
12.6	Using Intel® Rapid Storage Technology UEFI User Interface.....	223
12.7	Using the RAID Configuration Utilities (DOS, UEFI Shell, and Windows*)	228
13	Deleting a RAID Volume	230
13.1	Using the Intel® Optane™ Memory and Storage Management UI	230
13.2	Using the Intel® Rapid Storage Technology User Interface Utility.....	230
13.3	Using the Option ROM User Interface	230
13.4	Using the Intel® Rapid Storage Technology UEFI User Interface	231
13.5	Using the RAID Configuration Utilities (DOS, UEFI Shell, and Windows*)	231
14	Common RAID Setup Procedures.....	232
14.1	Build a SATA RAID 0, 1, 5 or 10 System.....	232
14.1.1	Using the Legacy OROM User Interface	232
14.1.2	Using the UEFI HII User Interface	233
14.2	Build a “RAID Ready” System	234
14.3	Migrate to RAID 0 or RAID 1 on an Existing “RAID Ready” System	234
14.4	Migrate an Existing Data Hard Drive to a RAID 0 or RAID 1 Volume	235
14.5	Migrating From one RAID Level to Another	235
14.6	Create a RAID Volume on Intel® SATA Controller While Booting to Different Controller	236
14.7	Build a RAID 0 or RAID 1 System in an Automated Factory Environment	237
14.7.1	Part 1: Create Master Image	237
14.7.2	Part 2: Apply Master Image.....	237
15	RAID Volume Data Verification and Repair Feature	239
15.1	Verify and Repair Volume Feature	239
15.2	Verify and Repair Scheduler.....	239
16	Intel® Rapid Recover Technology.....	241
16.1	Creating a Recovery Volume Through the RAID Option ROM	241
16.2	Creating a Recovery Volume Using Intel® Rapid Storage Technology UEFI User Interface	242
16.3	Creating a Recovery Volume Through Intel® RST UI	242
16.4	Changing Recovery Volume Modes.....	243
16.5	Update Recovery Volume in On Request Update Policy	243
16.6	Access Recovery Drive Files	243
16.7	Hide Recovery Drive Files	244
16.8	Scenarios of Recovering Data.....	244
16.9	System Running from Recovery Drive	246
16.10	Drive Offline or Missing	246
17	Pre-OS Installation of Intel® Rapid Storage Technology Driver	248
17.1	Pre-OS Driver Installation Using the “Load Driver” Method.....	248
18	Determining the Version of the RAID Driver.....	249
18.1	Using Intel® Rapid Storage Technology User Interface (UI).....	249
18.2	Using Intel® Rapid Storage Technology User Interface (UI).....	249
18.3	Using Intel® RST File Properties (Alternate)	249
18.4	Determining the Version of the Option ROM	250
18.4.1	Using Intel® Rapid Storage Technology UI.....	250
18.4.2	Using Intel® RST Option ROM User Interface	250
18.4.3	Using the EFI Shell.....	250
19	Un-Installation	251



19.1	Un-Installing Intel® RST Software (except the RAID Driver).....	251
19.2	Un-Installing Intel® Optane™ Memory and Storage Management UI (except the RAID Driver)	251
19.3	Disabling the RAID Driver by Disabling the RAID Controller	252
20	Registry Customizations	253
20.1	Zero Power ODD Settings	253
20.2	E-mail Notification UI Visible Enable/Disable	254
20.3	Disabling Maximized Mode Option for Intel® SRT	255
20.4	Rebuild On Hot Insert	255
20.5	SATA Asynchronous Notification	256
20.6	Runtime D3 (RTD3)	256
20.7	Hybrid Hinting.....	257
20.7.1	Instructions to Disable Hybrid Hinting	257
20.7.2	Hybrid Hint Reset	257
20.7.3	Disable Hybrid Hinting During Hibernation	258
20.8	APM Value Registry Setting.....	258
21	Power Savings with Intel® Rapid Storage Technology.....	260
21.1	Modern Standby Support.....	260
21.2	Link Power Management (LPM)	260
21.2.1	Instructions to Disable/Enable LPM.....	261
21.2.2	LPM Updates in 14.0 (APS, SIPM).....	262
21.3	Runtime D3 (RTD3)	263
21.3.1	Adapter RTD3 Support	263
21.3.2	RTD3 Support - RAID HDD/SSD/SSHDs Unit Support.....	263
21.3.3	RTD3 Support - RAID w Mixed RTD3 Capable/Non-Capable Ports .	264
21.3.4	RTD3 Support - RRT	264
21.3.5	RTD3 Support - SRT	264
21.3.6	RTD3 Support - Hot Spares	264
21.3.7	RTD3 Support – Migrations and Rebuilds.....	264
21.4	DEVSLP.....	264
21.4.1	DEVSLP Registry Key Setting	266
21.5	DevSleep Tool.....	266
21.5.1	CsDeviceSleepIdleTimeoutInMS	267
21.5.2	DeviceSleepIdleTimeoutInMS.....	267
21.5.3	DeviceSleepExitTimeoutInMS.....	267
21.5.4	MinimumDeviceSleepAssertionTimeInMS.....	267
21.5.5	DevSleep Tool Usage	268
21.6	L1.2 Support.....	269
21.7	InstantGo* Device Notification Support	269
21.7.1	Requirements	269
21.7.2	Detail Description.....	270
21.7.3	Registry Settings.....	270
21.8	New in 14.5 Release	271
21.8.1	Connected Standby Power State Support for SSHD	271
21.8.2	CONNECTED STANDBY Power Model	272
21.8.3	Adaptive D3 Idle Timeout.....	272
21.8.4	Connected Standby Power Model Support for SRT	273
21.8.5	SATA Link Power Management Support.....	275



22	Legacy RAID Option ROM and Utilities.....	276
23	HDD Password Support with RAID Volumes	277
23.1	HDD Password Use Cases	277
23.2	Unlocking Password Protected Disks	278
24	Intel® Rapid Storage Technology User Interface	279
24.1	Introduction.....	279
24.1.1	Getting Started	280
24.1.2	Understanding the Application	281
24.1.3	Notification Area	283
24.2	Storage System Status	284
24.2.1	Understanding the Status.....	284
24.2.2	Storage System View.....	285
24.3	Creating a Volume.....	287
24.3.1	Volume Requirements.....	287
24.3.2	Creation Process	289
24.3.3	Creating Additional Volumes.....	293
24.4	Managing the Storage System	294
24.4.1	Managing Arrays	294
24.4.2	Managing Volumes	298
24.4.3	Managing Disks.....	311
24.4.4	Managing Ports.....	316
24.4.5	Managing ATAPI Devices	317
24.4.6	Managing Solid-State Hybrid Drives (SSHD)	317
24.5	Accelerating the Storage System.....	318
24.5.1	Cache Device Properties.....	318
24.5.2	Enabling Acceleration.....	320
24.5.3	Disabling Acceleration.....	322
24.5.4	Changing Acceleration Mode	322
24.5.5	Accelerating a Disk or Volume	323
24.5.6	Resetting a Cache Device to Available.....	324
24.5.7	Disassociating the Cache Memory	324
24.6	Preferences	325
25	Opal Drive Support.....	327
25.1	Opal ATA Commands Supported.....	327
25.2	Intel® Rapid Storage Technology UI Support.....	327
25.3	Opal SCSI Commands Supported	327
25.4	Opal UEFI Protocol Supported	327
25.5	Intel® RST PCIe NVMe Support for Opal	327
25.6	NVMe Device Requirements for Intel® RST Opal Support	328
26	eDrive Support.....	329
26.1	What is an eDrive?	329
26.2	SCSI Standard Inquiry Command Response.....	329
26.3	Configurations Supported	329
27	Using the BCFS to Differentiate Platform SKUs	330
27.1	Configuring the Platform’s RAID Related Features.....	330
27.1.1	Configuring the Standard Supported RAID Levels	330
27.1.2	Configuring Intel® RRT Related RAID Features	331
27.1.3	Configuring the Behavior of the OROM UI and Banner	331
27.1.4	Configuring Intel® RST UI Capabilities	332



27.1.5	Configuring the Platform to Support Intel® SRT.....	333
27.1.6	Configuring the Platform to Support Intel® Optane™ Memory System Acceleration	333
27.1.7	Configuring the Platform to Support CPU Attached Storage.....	333
27.2	BIOS Control Feature Set	334
28	Testing, Certification Notes.....	336
29	Glossary.....	337
30	Troubleshooting	344
30.1	Failed Volumes.....	344
30.2	Degraded Volumes	346
30.3	Other Volume States.....	349
30.4	Disk Events	353
30.5	Caching Issues.....	355
30.6	Software Errors.....	358
30.7	UI Error Handling	359
Appendix A	RST SATA Port Bitmap Implementation	360
A.1	Legacy OROM	360
A.2	UEFI Driver.....	361
A.2.1	EFI_DEVICE_PATH_PROTOCOL	361
Appendix B	Common Storage Management Interface Support (CSMI).....	362
Appendix C	Drive and Volume Encryption Support.....	363
C.1	ATA Security Commands and HDD Password Support.....	363
C.2	Self-Encrypting Drives (SED)	363
C.3	Solid State Hybrid Drives (SSHD's) with Encryption	363
C.4	RAID Volume and Drive Partition Encryption	363





Revision History

Revision Number	Description	RST Release Version	Revision Date
1.0	<ul style="list-style-type: none">▪ InitialCreation started on RST_OEM TechGuide 16.7-rev.1.0▪ Updated Chapter 4 (New in Release) and merge the features from all 16.x releases into in respective section.▪ Initial release for TG Alpha▪ Added changes to TG BIOS information regarding Dynamic configuration and removing static configuration.▪ Updated screenshot for TG Bios seletion▪ Section 5 updated for HSA 17.0▪ Change "\\CurrentControlSet\Services\iaStorA" to "\\CurrentControlSet\Services\iaStorAC" to reflect windows registry changes.▪ Add overview description of TRIM support for Optane Volume.▪ Added Section 21.1 Modern Standby Support.▪ Modified Supported Platform Table▪ Added section 5.12 for handling scenarios with a mismatch between HSA UI and Driver/Middleware▪ Added section 30.7 UI Error handling▪ Changed Page 1 – Changed description from "17.xx.xx" to "17.0" on Page 1 description and updated revision number to 1.0	17.0	January 2019
1.0.1	<ul style="list-style-type: none">▪ Add new features for RST 17.2 release. (section 2.2)▪ Change "iaStorA.sys" to "iaStorAC.sys"	17.0, 17.2	January 2019
1.0.2	<ul style="list-style-type: none">▪ Added Disabling Adaptive D3 to What's new for 17.2.▪ Added section 6.4.1.3 about Pagefile Optimization.	17.0, 17.2	January 2019.
1.0.3	<ul style="list-style-type: none">▪ Updated documents at various locations based on rev 1.0.2 feedback of internal teams.▪ Generalised driver version from 17.x to 17.0 in Section 5	17.0, 17.2	February 2019



1.0.4	<ul style="list-style-type: none"> ▪ Added section 2.2.2 for Pentium/Celeron support in 17.2 release. ▪ Added note about the type of CPU sku that will support Optane Memory in section 3.1.3 	17.2	February 2019
1.1.0	<ul style="list-style-type: none"> ▪ Added RST 17.3 released features into What New for 17.3 section ▪ Added Optane Memory support for Mobile Pentium and Celeron into What's New section for 17.3 ▪ Updated Supported Platform in 3.1.3 ▪ Updated Features in 3.1.4 	17.3	March 2019
1.2.0	<ul style="list-style-type: none"> ▪ Added RST 17.5 released features into What's New for 17.5 section. ▪ Update Support Table with new supported platforms. (section 3.1.3) ▪ Update Feature Table with new supported platforms. (section 3.1.4) ▪ Added APM Level setting to What's New. ▪ Added Section 20.8 for APM Level Registry Key. 	17.5	April 2019
1.2.1	<ul style="list-style-type: none"> ▪ TG Optane Roaming Limitation to section 6.1.2.3 ▪ Modify Disk Defrag/Optimization of an Optane Volume in section 6.1.2.2 	17.x	April 2019
1.2.2	<ul style="list-style-type: none"> ▪ Modified Section 8.4 table to add CPUa + PCHa configuration RAID. 	17.x	April 2019
1.2.3	<ul style="list-style-type: none"> ▪ Updated Platform Supported Table (3.1.3) and Key Feature/Functionality Matrix Table (3.1.6) 	17.x	April 24 th 2019
1.2.4	<ul style="list-style-type: none"> ▪ Updated 5.1 – Added message displayed in AHCI mode ▪ Updated 5.1 – Added note about supported resolution ▪ Updated 5.7 – Added IOM Module usage 	17.x	April 24 th 2019
1.2.5	<ul style="list-style-type: none"> ▪ Remove GCF from Supported platform List in section 3.1.3 and 3.1.6 	17.x	May 17 th 2019
1.2.6	<ul style="list-style-type: none"> ▪ Added notes regarding enabling Optane in AC mode for section 6.1.1.2, 6.4.1.2.4, 6.4.2.4 ▪ Added section 2.4.3 and 2.4.4 	17.x	June 2019



1.2.7	▪ Added section 2.5 What's new in 17.7 release.	17.x, 17.7	June 2019
1.2.8	▪ Modify section 6.1.1.2, item#3, to support only one TG per platform.	17.x	July 2019
1.3.1	▪ Modified for RST 17.8 PV release.	17.8	September 2019
1.3.2	▪ Modified for RST 18.0 Alpha release	18.0	September 2019
1.3.4	▪ Added note about a downgrade scenario in 2.6.7 for RST 17.8 beta.	17.8	October 2019
1.3.7	▪ Moving section 2.6.7 (VTIO support) to 2.6.8.1 ▪ Added known issues to 4.5.5.4 ▪ Update platform and feature supported. ▪ Restructure section 4.5.5	17.8	November 2019
1.3.8	▪ Removing RST 18.0 release information. ▪ Added RRT warning in section 24.3.2.2	17.8	December 2019
1.3.9	▪ Remove incorrect information on unpinning multiple files/folders	17.8	December 2019

§ §



1 About This Document

1.1 Purpose and Scope of this Document

This document will assist customers in evaluating, testing, configuring, and enabling CPU Attached Storage, Intel® Optane™ Memory, RAID 0/1/5/10, and AHCI functionality on Intel-based platforms using the *Intel® Rapid Storage Technology* (Intel® RST) software for the chipset components as listed in the product's Readme.txt file.

This document also describes installation procedures, caching acceleration techniques, other RST features, RAID volume management such as creating, deleting, and modifying volumes, common usage models, and any special notes necessary to enable customers to develop their RST-compatible computer systems.

1.2 Intended Audience

This document is targeted for the following audience under proper Intel NDA guidelines and thus can be shared amongst the following provided they have proper NDA in place (e.g. an OEM can share with an ODM that has Intel NDA in place) (e.g. an OEM can share with an ODM that has Intel NDA in place):

- OEMs (Original Equipment Manufacturers)
- ODMs (Original Design Manufacturers)
- IHVs (Independent Hardware Vendors)
- ISVs (Independent Software Vendors)
- IBVs (Independent BIOS Vendors)
- SIs (System Integrators)

§ §



2 New in Release Version 17.x

This section is for keeping track of new features introduced in Intel Rapid Storage Technology (RST) version 17.x releases.

2.1 What's New in Release 17.0

This section covers new features added in the initial release of Intel® RST version 17.0.

2.1.1 Intel® Optane™ Memory H10 (Teton Glacier) Support

The Intel® Optane™ Memory H10 with Solid State Storage (Teton Glacier) combines 3D-XPoint and traditional NAND flash-based media into a single M.2 socket 3 device. The M.2 PCIe Gen 3 x4 device is split into two Gen 3x2 devices where each ASIC will utilize 2 lanes of PCIe and share PERST#, REFCLK, and CLKREQ# signals. Architecturally Teton Glacier will be enumerated as two separate devices in the system. The host system will see each device individually and separately. Intel RST will combine them into a single Intel Optane Memory volume (bootable or data volume).

Due to the dual drives nature of the product, platform BIOS must support detection and reconfiguring the M.2 port to support two PCIe gen3 x2 devices at the same time. Refer to [section 4.6.2](#) for TG's BIOS information.

For a list of known hardware limitations for Teton Glacier, refer to [section 6.1.1.2](#).

For a list of minimum requirements for Teton Glacier, refer to [section 6.2.2](#).

For procedure on how to setup Teton Glacier Optane Memory Boot Volume, refer to [section 6.5.1.2.4](#).

For procedure on how to setup Teton Glacier Optane Memory Data Volume, refer to [section 6.5.2.4](#).

2.1.2 TRIM Support For NAND SSD in Optane™ Volume

Starting with version 17.0, the RST driver supports TRIM for Optane™ Volume if a slow drive (SSD/NAND) reports support for TRIM and reported to the OS. When the RST driver receives a TRIM command from the OS to Optane™ Volume, it will forward that command to Optane™ Volume's slow drive. In the case of Intel® Optane™ Memory H10 (Teton Glacier) Optane™ Volume, TRIM commands will be forwarded to TG's NAND device.

2.1.3 Bandwidth Aggregation Support for Intel® Optane™ Memory H10 (Teton Glacier) in AC mode

Starting with RST version 17.0.0.1072 PV, there is a new featured named Bandwidth Aggregation (BA) enabled only for Optane™ Memory volumes created in an Intel® Optane™ Memory H10 (Teton Glacier) device. This feature improves I/O performance by allowing redirections of I/O to the backing storage when the storage workload demand of the cache starts to queue up.



2.1.3.1 Limitations

Bandwidth Aggregation feature is enabled only when the system is in AC mode.

2.2 What's New in Release 17.2

This section covers few features added in Intel RST version 17.2

2.2.1 Disable Adaptive D3 for Optane™ Configuration

Starting with RST version 17.2, Adaptive D3 is disabled for Optane Volume because Adaptive D3 is designed for HDD disks. For Optane configuration during Modern Standby, the RST driver controls the power of slow disk, and OS controls Dx state of the fast disk. The fast disk is SSD, and the whole volume is exposed to the OS as SSD disk, therefore, Adaptive D3 should be disabled for Optane Volume.

2.2.2 Optane™ Memory Support for Desktop Pentium and Celeron Sku.

Starting with RST version 17.2, Optane™ Memory feature is added to Optane capable platforms that use desktop Pentium/Celeron Sku. Optane Memory feature is not yet available for Optane capable platforms that use mobile Pentium/Celeron Sku.

2.3 What's New in Release 17.3

This section covers few features added in Intel RST version 17.3

2.3.1 Optane™ Memory Feature for Supported Platforms with Mobile Pentium and Celeron Processor

Starting with RST version 17.3, Optane™ Memory feature is added to Optane capable platforms that use mobile Pentium/Celeron Sku. Please refer to section 3.1.3 for a list of supported platforms.

2.3.2 Optane™ Memory Feature for Intel® SSD 660p NVME

With previous versions of Intel® Rapid Storage Technology (RST) driver, only SATA HDD/SDD can be accelerated by Optane™ Memory module. Starting with RST 17.3, Intel® SSD 660p NVME (Neptune Barbour QLC NVME) drive can also be accelerated by Optane™ Memory module.

2.3.3 NVME APST Optimization for Power Efficiency and Performance

The Autonomous Power State Transitions (APST) feature is a part of the NVME specification (version 1.1 and above) to allow NVME storage devices to support multiple power states for client power-focused implementation. APST feature allows the NVME controller to transition to a lower power state after a certain idle period without software intervention. The idle period to transition is



typically programmed by the system software driver. Intel Rapid Storage Driver (Intel RST) NVME driver implements the APST feature so that NVME devices that support the APST feature can reduce power consumption by transitioning to lower power state or temporary go to sleep state and wake up on system activities. Microsoft Windows OS uses APM (Advanced Power Management) to manage the power states of NVME drives for different Power Profile. When using RST driver, APM cannot be disabled for NVME drives because RST support NVME drives via remapping, which does not expose the NVME drives to Windows OS. Because of this, regardless of power profile, APST is always enabled for NVME drives when using RST driver. Starting 17.3, the RST driver will enable or disable the APST feature for remapped NVME PCIe storage device based on current Windows OS Power Profile to optimize power efficiency and performance.

2.4 What's New in Release 17.5

2.4.1 New Supported Platforms

Refer to [section 3.1.3](#) for new supported platforms added in this release.

2.4.2 Registry to control APM Level

For a system that uses HDD drive, Intel® Optane™ Memory delivers world-class responsiveness of SSD performance at a fraction of a cost by caching frequently accessed data from HDD to Optane™ memory module. In Optane + HDD configuration, an HDD with a self-managed, aggressive power policy setting may spin down to save power while Optane™ is servicing I/O operations. However, if Optane™ module does not contain the data requested from the HDD (cache miss), the spin-up latency will cause a negative performance impact (e.g., lagging in a game). To avoid data lagging in Optane configuration with HDD, starting with RST 17.5, the user can disable disk spin down by setting a new RST windows registry setting. Refer to [section 20.8](#) for more information.

2.4.3 Pyrite Support

Starting with RST 17.5, RST supports TCG's Pyrite feature for Pyrite-capable NVME devices in pass-through, Optane, and RAID configuration. Pyrite support also requires both the platform BIOS and the RST PreOS to be updated. For detailed information on how to add Pyrite feature to supported platforms as well RST related information (PreOS version, OS version, etc...), refer to section 3.1 of Intel Client Storage SIG document ([CDI#612209](#)).

2.4.4 Pinning Shell Extension Removal from INF distribution file.

To meet Microsoft's DCH compliance and improve the Intel® RST driver installation process, Pinning Shell Extension has been removed from the INF distribution method. Before RST 17.5, Pinning shell extension was distributed as part of the Extension INF/Component INF (iaStorSW.cat, iaStorSW.inf, iaStorSWExt.cat, iaStorSwExt.inf) along with the Pinning Shell MSI package so that it can be installed by either PnPUtil/DeviceManager/INF Default Install or RST/Optane Installer. For RST 17.5 and beyond, Extension INF/Component INF for Pinning Shell extension (iaStorSW.cat, iaStorSW.inf, iaStorSWExt.cat, iaStorSwExt.inf) are removed. As a result, these are improvements to the Intel® RST installation process:

1. Avoids issues related to asynchronous MSI installation through AddSoftware and overlapped installation when OEM/ODM installs/injects INFs and then uses RST installer (SetupRST.exe/SetupOptaneMemory.exe) to install the RST driver that triggers Shell Extension MSI at the end of the installer and potentially affect other MSI installations.



2. Simplifies and provides more control over the installation process with almost transparent change for customers. However, keep in mind the following potential impacts due to the changes:
 - a. The customer deployment process must be aligned with this change.
 - i. If the customer deployment process uses iaStorSW.inf and iaStorSWExt.inf to install the Pinning Shell MSI package, the process must be modified to use MSI exec to install Pinning Shell MSI.
 - ii. If the customer uses the RST installer (SetupRST.exe) or Optane installer (SetupOptaneMemory.exe), then by default, these installers will install the Shell extension.
 - b. Pinning Shell extension component device entry will not show up in Device Manager.

2.4.5 Intel’s Virtualization for Directed I/O (a.k.a IOMMU) Support in RST Pre-OS

Starting with RST 17.5, The Intel® RST Pre-OS adds support for IOMMU technology. The support is added in these PreOS’ UEFI drivers:

1. RaidDriver.eif.
2. RstPeim.efi and RstSecPeim.efi
3. RaidDriverSmm.efi

2.5 What’s New in Release 17.7

2.5.1 New Supported Platforms

Refer to [section 3.1.3](#) for new supported platforms added in this release.

2.5.2 Command Line Tool (CLI) Support for Non-OEMs

Starting with RST 17.7, a separate and scaled-down CLI version is available for corporate users. This CLI version (CLIPro) has a limited subset of functionality to allow corporate IT administrators to deploy and manage Optane volume on IT-image client computers in a corporate environment.

Below is a list of available commands in CLI for Corporate.

Available Commands	Description
rstclipro.exe --OptaneMemory --enable	Create Optane Memory
rstclipro.exe --OptaneMemory --enable --fast-drive <driveId> --drive-to-accel <driveId>	Specifies a fast drive that will be used as a cache/accelerator. If another fast drive is being used as a cache, then that volume needs to be deleted to use a new fast drive.
rstclipro.exe --OptaneMemory --disable	Separate Optane Memory into Optane drive and capacity drive.
rstclipro.exe --OptaneMemory --progress	Displays the progress of file cache migration.
rstclipro.exe --OptaneMemory --info	Lists information about Optane Memory settings.



rstclipro.exe --information	Displays disk, volume, array, and controller information.
rstclipro.exe --manage --delete-all-metadata	Delete Optane Volume metadata information.
rstclipro.exe --version	Displays version information.
rstclipro.exe --help	Displays help documentation for command-line utility modes, options, usage, examples, and return codes.

2.6 What's New in Release 17.8

2.6.1 New Supported Platform


Refer to [section 3.1.3](#) for new supported platforms added in this release.

2.6.2 Disable File Cache for Intel® Optane™ Memory H10

Intel® Optane™ File Cache feature accelerates access to a given file by moving the file to Intel® Optane™ memory module. By default, for Intel® Optane™ Memory H10, File Cache feature move files from Intel® Optane™ Memory H10 QLC to Optane™ part to accelerate access to given files. However, Intel® Optane™ Memory H10 requires Bandwidth Aggregation to improve I/O performance. Bandwidth Aggregation feature does not work with File Cache in certain usage scenarios. Starting with RST 17.8, when Optane™ volume is enabled for Intel® Optane™ Memory H10, File Cache will be disabled by default. As a result, Optane™ pinning feature will also not be available by default because this feature relies on File Cache.

2.6.2.1 Intel® Optane™ Memory and Storage Management UI Status

The Intel® Optane™ Memory and Storage Management UI Status Screen will display a message to inform the end-user that pinning files/folders/applications is not available and how to re-enable Optane™ Pinning feature using the UI.



2.6.2.2 Re-Enable Pinning Feature by End-Users

The end-user can enable the Pinning feature in Intel® Optane™ Memory and Storage Management UI for a system with Intel® Optane™ Memory H10 32GB/512GB SKU and 32GB/1TB SKU by first [disabling Optane Volume](#), then [enabling Optane Volume](#) w/ Responsiveness Mode.

Note: Enabling the Pinning feature will also enable File Cache.

2.6.2.3 RST Driver Upgrade Impact to File Cache

For Optane™ volume on systems with Intel® Optane™ Memory H10, upgrading RST driver from previous versions (e.g., RST 17.0.0.1024 to 17.5.2.1024) to RST 17.8 will NOT impact Optane™ Pinning or File Cache. Upgrading the Intel® RST driver will not automatically disable File Cache.

2.6.3 Bandwidth Aggregation Support for Intel® Optane™ Memory H10 (Teton Glacier) in DC mode

Bandwidth Aggregation Support for Intel® Optane™ Memory H10 (Teton Glacier) was introduced in RST 17.0.0.1072 PV to improve I/O performance for Optane™ volumes created in a TG device when the system is in AC mode ([link](#)). Starting with RST 17.8, Bandwidth Aggregation feature for Intel® Optane™ Memory H10 is also enabled when the system is in DC mode.

2.6.4 Improving Idle Cleanup for Intel® Optane™ Hybrid device

To improve Intel® Optane™ Hybrid SSD (e.g., Intel® Optane™ Memory H10 with Solid State Storage) performance, Intel® RST software will monitor SLC Cache utilization of Intel® Optane™



Hybrid device and trigger SLC Cache Cleanup when the utilization threshold reaches a pre-defined value.

2.6.5 NVME IOCTL Pass-Through support in WinPE

Starting with RST 17.8, Intel® RST driver will allow all NVME IOCTL Admin commands to be sent to HW/SW Remapped NVME SSD that is not part of a RAID/Optane Volume in WinPE environment. For more information on Intel® RST API support, please refer to Intel® RST API and IOCTL Reference Guide ([Doc#563914](#)).

2.6.6 Using Unique RAID Alternate ID per Platform Generation

Intel® RST software has been using two static device IDs (one for mobile and one for desktop) in its INF file for RST driver installation when the platform's SATA mode is set to RAID/Intel Premium. A single device ID prohibits us from targeting driver updates to certain platform generations and also recognize platforms which are not supported by the latest RST driver. Starting with Intel® RST 17.8, we will have a unique RAID device ID for every new platform support added (i.e. CML-S/H/U-V2 with 17.8). Refer to the table below as an example

Intel® RST ver.	New Platform
17.8	CML-S/H CML-U V2
18.0	TGL U/Y with VMD

Because of this change, please do the following:

- Customers need to update their scripts/tools if they refer the device ID in them to include the new Device ID's. For the unique device ID, please refer to the respected platform EDS.
- RST inbox driver support will be limited to certain OS versions as the device ID's in the inbox inf will be updated aligning with the OS release.

2.6.7 Intel® Optane™ Memory and Storage Management UI Enhancements

Intel® Optane™ Memory and Storage Management application released on Windows App Store for RST 17.8 will contain the following enhancements:

- Intel® Optane™ Memory and Storage Management application will support displaying limited system and storage related information when SATA Mode is set to AHCI.
- Intel® Optane™ Memory and Storage Management application will display both Serial Number and Controller Serial Number for NVME SSD. This feature required both the latest Intel® RST driver and Intel® Optane™ Memory and Storage Management UI.



2.6.8 Changes between RST 17.8 Beta and RST 17.8 PV features

2.6.8.1 Moving Secure Biometrics Support for Windows* 10 19H1 to a later release

Windows*10 19H1 Secure Biometrics/PCI Protection Support is moved to a later Windows* release. Therefore, RST 17.8's Secure Biometrics Support, previously communicated as "VTIO Mode Support for Windows 10 19H1", is also moved to a later RST release to align with Windows* feature availability.

§ §



3 Intel® Rapid Storage Technology

Intel® Rapid Storage Technology (Intel® RST) provides added performance and reliability for supported systems equipped with serial ATA (SATA) hard drives (HDDs) and solid-state drives (SSD's) and PCIe AHCI/NVMe SSD's to enable an optimal PC storage solution. It offers value-add features such as RAID and advanced Serial ATA* capabilities for the Microsoft* Windows* operating systems (for detailed OS support, review the Release Notes for each software release). Also, overall system responsiveness is boosted by the Intel® Optane™ Memory system acceleration caching feature.

The RAID feature supports RAID level 0 (striping), RAID level 1 (mirroring), RAID level 5 (striping with parity) and RAID level 10 (striping and mirroring). A configuration supporting two RAID levels can also be achieved by having two volumes in a single RAID array that use Intel® RST. This configuration is known as a Matrix array. The RAID capability addresses the demand for high-performance or data-redundant desktop and mobile platforms.

The product also includes premium-RST features as well as support for other premium-platform technologies.

3.1 Overview

3.1.1 Product Release Numbering Scheme

The product release **version** is divided into 4 sections or numbers (**AA.B.CC.DDDD**, e.g. **12.0.0.1001**).

Number / Section	Description
AA: Major Release Number	This section represents the major release version of the product. It usually is usually associated with a major change in features or new platform/chipset launch.
B: Minor (Maintenance) Release Number	This section represents the minor release version of the product. If this number is non-zero , then the release is a minor release of the AA major release version. This can represent a maintenance release with several bug fixes or it can align with a platform refresh as an example.
CC: Hot Fix Release Number	This section represents customer-specific hotfixes. If this number is non-zero , then the release is a customer-specific hotfix release to resolve a customer-specific issue.
DDDD: Release Build Number	This section represents the build number of release AA.B.CC , Note: for production releases, the build number always begins with the number '1' (e.g. AA.B.CC.1001)



3.1.2 RAID Levels

RAID 0 (striping)

RAID level 0 combines two to six drives so that all data is divided into manageable blocks called strips. The strips are distributed across the array members on which the RAID 0 volume resides. This improves read/write performance, especially for sequential access, by allowing adjacent data to be accessed from more than one hard drive simultaneously. However, data stored in a RAID 0 volume is not redundant. Therefore, if one hard drive fails, all data on the volume is lost.

The RAID 0 volume appears as a single physical hard drive with a capacity equal to twice the size of the smaller hard drive.

The Intel® SATA AHCI/RAID controllers with Intel Rapid Storage Technology allows up to six** drives to be combined into a single RAID 0 array, providing additional scaling of storage performance.

**Note: the number of drives supported in a RAID 0 array is dependent upon the chipset model. Consult the specification for your chipset to determine the maximum number of drives supported in a RAID array.

RAID 1 (mirroring)

RAID level 1 combines two hard drives so that all data is copied concurrently across the array members that the RAID 1 volume resides on. In other words, the data is mirrored across the hard drives of the RAID 1 volume. This creates real-time redundancy of all data on the first drive, also called a mirror. RAID 1 is usually used in workstations and servers where data protection is important.

The RAID 1 volume appears as a single physical hard drive with a capacity equal to that of the smaller hard drive.

RAID 5 (striping with parity)

RAID level 5 combines three to six drives so that all data is divided into manageable blocks called strips. RAID 5 also stores parity, a mathematical method for recreating lost data on a single drive, which increases fault tolerance. The data and parity are striped across the array members. The parity is striped in a rotating sequence across the members.

Because of the parity striping, it is possible to rebuild the data after replacing a failed hard drive with a new drive. However, the extra work of calculating the missing data will degrade the write performance to the volumes. RAID 5 performs better for smaller I/O functions than larger sequential files.

RAID 5, when enabled with volume write-back cache with Coalescer, will enhance write performance. This combines multiple write requests from the host into larger more efficient requests, resulting in full stripe writes from the cache to the RAID5 volume. RAID 5 volume provides the capacity of $(N-1) * \text{smallest size of the hard drives}$, where $N \geq 3$ and ≤ 4 .

For example, a 3-drive RAID 5 will provide capacity twice the size of the smallest drive. The remaining space will be used for parity information.



RAID 10 (striping and mirroring) RAID level 10 uses four hard drives to create a combination of RAID levels 0 and 1. The data is striped across a two-disk array forming a RAID 0 component. Each of the drives in the RAID 0 array is mirrored to form a RAID 1 component. This provides the performance benefits of RAID 0 and the redundancy of RAID 1. The RAID 10 volume appears as a single physical hard drive with a capacity equal to two drives of the four drive configuration (the minimum RAID 10 configuration). The space on the remaining two drives will be used for mirroring.

*RAID 10 is currently NOT supported on RST PCIe Storage member disks.

3.1.2.1 Typical Usage Model for RAID Levels

- | | |
|----------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| RAID 0 | RAID0 provides end-users the performance necessary for any disk-intensive applications; these include video production and editing, image editing, and gaming applications. |
| RAID 1 | RAID1 provides end-users with data redundancy by mirroring data between the hard drives. |
| RAID 5 | RAID5 provides end-users with good performance and data redundancy by striping data and parity across all the hard drives. The write performance is enhanced with volume write-back cache. |
| RAID 10 | RAID10 provides end-users with the benefits of RAID 0 (performance) and RAID 1 (data mirroring). |

3.1.3 Supported Platforms for This Release

Note:

- All platform/chipset SKUs listed in this section support AHCI mode.
- Premium chipsets also support RST Premium/Optane™ mode.
- Certain non-Premium SKUs (see the following table) support AHCI along with RST/Optane™ mode.
- Optane Memory is available for Optane-capable platform/chipset SKUs that uses Core processor, Desktop Pentium/Celeron Sku processor, or Mobile Pentium/Celeron processor.
- **The highlighted** platforms are the newly added platforms for this release.



Table 3-1: Platform/Chipset SKUs Supported in this Release

PCH SKU	Chipset Name	CPU	PCH Family	Segment	AHCI Mode	Premium Mode	Optane Mode	RST 15.5	RST 15.7	RST 15.8	RST 15.9	RST 16.0	RST 16.5	RST 17.0	RST 17.2	RST 17.3	RST 17.5	RST 17.7	RST 17.8
X299 (Basin Falls)	Intel® 200 Series Chipset Family	SKL-X	KBP-H	HEDT	X	X			x	x	x						x	x	x
X299 (Basin Falls)	Intel® 200 Series Chipset Family	KBL-X	KBP-H	HEDT	X	X			x	x	x						x	x	x
KBL-R Base U	Intel® 200 Series Chipset Family	KBL-R	SPT-LP	Mobile	X			x	x	x	x	x	x	x	x	x	x	x	x
KBL-R Premium-U	Intel® 200 Series Chipset Family	KBL-R	SPT-LP	Mobile	X	X		x	x	x	x	x	x	x	x	x	x	x	x
CNL-Y Premium	Intel® 300/240 Series Chipset Family	CNL	CNP-LP	Mobile	X	X							x	x	x	x	x	x	x
CNL-U Premium	Intel® 300/240 Series Chipset Family	CNL	CNP-LP	Mobile	X	X						x	x	x	x	x	x	x	x
CNL-U Base/Mainstream	Intel® 300/240 Series Chipset Family	CNL	CNP-LP	Mobile	X							x	x	x	x	X	x	x	x
WHL-U Premium	Intel® 300/240 Series Chipset Family	WHL	CNP-LP	Mobile	X	X								x	x	x	x	x	x
H310/H310C	Intel® 300/240 Series Chipset Family	CNL/CFL	CNP-H	Desktop	X							x	x	x	x	x	x	x	x
H310D	Intel® 300/240 Series Chipset Family	CNL/CFL	CNP-H	Desktop	X											x	x	x	x
H370	Intel® 300/240 Series Chipset Family	CNL/CFL	CNP-H	Desktop	X	X								x	x	x	x	x	x
Z390	Intel® 300/240 Series Chipset Family	CNL/CFL	CNP-H	Desktop	X	X						x	x	x	x	x	x	x	x
Q370	Intel® 300/240 Series Chipset Family	CNL/CFL	CNP-H		X	X						x	x	x	x	x	x	x	x
B360	Intel® 300/240 Series Chipset Family	CNL/CFL	CNP-H		X		X					x	x	x	x	x	x	x	x
C246	Intel® 300/240 Series Chipset Family	CNL/CFL	CNP-H		X	X						x	x	x	x	x	x	x	x
QM370	Intel® 300/240 Series Chipset Family	CNL/CFL	CNP-H	Mob/Desk	X	X						x	x	x	x	x	x	x	x
HM370	Intel® 300/240 Series Chipset Family	CNL/CFL	CNP-H	Mob/Desk	X	X						x	x	x	x	x	x	x	x
CM246	Intel® 300/240 Series Chipset Family	CNL/CFL	CNP-H	Desktop	X	X						x	x	x	x	x	x	x	x
Z370	Intel® 200 Series Chipset Family	CNL/CFL	KBP-H	Desktop	X	X				x	x	x	x	x	x	x	x	x	x
B365	Intel® 300/240 Series Chipset Family	CFL	KBP-H	Mobile	X	X								x	x	X	x	x	x
ICL Y Premium		ICL	ICP-LP	Mobile	x	x										x	x	x	x
ICL U Premium		ICL	ICP-LP	Mobile	x	x										x	x	x	x
ICL U Base/Mainstream		ICL	ICP-LP	Mobile	x											x	x	x	x
CML-U V1 Premium		CML	CML-LP	Mobile	X	X											x	x	x
CML-U V1 Base/Mainstream		CML	CML-LP	Mobile	X												x	x	x
X299 (Glacier Fall HEDT)	Intel® 200 Series Chipset Family	CLX-N1	KBP-H	HEDT	X													x	x
CML-U V2 Premium		CML	CML-LP	Mobile	x														x
CML-U V2 Base/Mainstream		CML	CML-LP	Mobile	x														x
Z490		CML-S	CMP-H	Desktop	X	X													x
Q470		CML-S	CMP-H	Desktop	X	X													X
W480		CML-S	CMP-H	WorkStation	X	X													X
H470		CML-S	CMP-H	Desktop	X	X													X
HM470		CML-H	CMP-H	Mobile	X	X													X
QM480		CML-H	CMP-H	Mobile	X	X													X



3.1.4 Supported Optane™ Memory for This Release

Optane Memory Model	Initial Intel® RST Release Version	Initial PreOS Version
Optane Memory H10 (Teton Glacier)	17.0.0.1072	17.0.0.3679
Optane Memory M10 (Stoney Beach 2)	15.9	15.9
Optane Memory (Stoney Beach 1)	15.5.0.1051	15.5.0.2875

3.1.5 Supported Intel NVME as Slow drive for Optane™ Memory Volume

Intel NVME Drive Model	Initial Intel® RST Release Version	Initial PreOS Version
Intel SSD 660p NVME (Neptune Harbor QLC NVME)	17.3.0.1011	17.3.0.4057



3.1.6 Intel® RST Key Feature/Functionality Matrix

PCH SKU	Chipset Name	RST Features Released In															
		N/A	N/A	N/A	RST 11.0	RST 12.5	RST 12.5	RST 12.5	RST 13.0	RST 15.0	RST 15.0	RST 15.5	RST 15.9	RST 16.0	RST 16.0	RST 16.5	RST 17.0
		BFB	ZPODD	RAID 0/1/5/10	TRIM on RAID0	SATA DevSleep (DEVSLP)	SATA Runtime D3	Basic Hybrid Drive Hinting	PCIe Storage Device Remapping (PCIe-PCH)	PCIe NVME Runtime D3	PCIe NVME in Modern Standby (2)	Optane (1)	HMB	Data Drive Acceleration (DDA)(4,5)	CPU Attached (CPU-A)	Optane Pinning (OPT-PIN) (3)	Hybrid Drive Support (TG)
X299 (Basin Falls)	Intel® 200 Series Chipset Family	X	X	X	X	X	X	X	X	X	X	X	X			X	
X299 (Basin Falls)	Intel® 200 Series Chipset Family	X	X	X	X	X	X	X	X	X	X	X	X			X	
KBL-R Base U	Intel® 200 Series Chipset Family		X			X	X	X					X				
KBL-R Premium-U	Intel® 200 Series Chipset Family	X	X	X	X	X	X	X	X	X	X	X	X			X	
CNL-Y Premium	Intel® 300/240 Series Chipset Family	X	X	X	X	X	X	X	X	X	X	X	X			X	
CNL-U Premium	Intel® 300/240 Series Chipset Family	X	X	X	X	X	X	X	X	X	X	X	X			X	
CNL-U Base/Mainstream	Intel® 300/240 Series Chipset Family		X			X	X	X									
WHL-U Premium	Intel® 300/240 Series Chipset Family	X	X	X	X	X	X	X	X	X	X	X	X			X	X



H310/H310C	Intel® 300/240 Series Chipset Family	X	X			X	X	X					X				
H310D	Intel® 300/240 Series Chipset Family	X	X			X	X	X					X				
H370	Intel® 300/240 Series Chipset Family	X	X	X	X	X	X	X	X	X	X	X	X	X		X	
Z390	Intel® 300/240 Series Chipset Family	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	
Q370	Intel® 300/240 Series Chipset Family	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	
Q360	Intel® 300/240 Series Chipset Family	X	X			X	X	X	X	X	X	X	X	X		X	
B360	Intel® 300/240 Series Chipset Family	X	X			X	X	X	X	X	X	X	X	X		X	
C246	Intel® 300/240 Series Chipset Family	X	X			X	X	X	X	X	X	X	X	X	X	X	
QM370	Intel® 300/240 Series Chipset Family	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X
HM370	Intel® 300/240 Series Chipset Family	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X
CM246	Intel® 300/240 Series Chipset Family	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X
Z370	Intel® 200 Series Chipset Family	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	
B365	Intel® 300/240 Series Chipset Family	X	X	X	X	X	X	X	X	X	X	X	X	X		X	
ICL Y Premium		X	X	X	X	X	X	X	X	X	X	X	X			X	17.5
ICL U Premium		X	X	X	X	X	X	X	X	X	X	X	X			X	17.5
ICL U Base/Mainstream			X			X	X	X									
CML-U V1/V2 Premium		X	X	X	X	X	X	X	X	X	X	X	X			X	17.5
CML-U V1/V2 Base/Mainstream			X			X	X	X					X				
X299 (Glacier Falls HEDT)	Intel® 200 Series Chipset Family	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	
Z490		X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	17.8
Q470		X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	17.8
W480		X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	17.8
H470		X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	17.8



HM470		X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	17.8
QM480		X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	17.8
WM490		X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	17.8
H420E		X	X			X	X	X					X					17.8
B460		X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	17.8
H410		X	X			X	X	X					X					17.8

Notes:

1. Feature not available for Windows Server and 32-bit Windows Client
2. Modern Standby only available for Windows 10 and beyond.
3. This feature requires an Intel Optane Memory module with a capacity of 32GB or larger. Optane Memory module with a capacity of 16GB is NOT SUPPORTED
4. Required Pre-OS: 16.0.2.3402 or later
5. Pinning is NOT SUPPORTED with DDA.



3.1.7 Supported Operating Systems for This Release

Table 3-2: Supported OS Matrix

Operating System	Supported Editions	RST Release Supported
Windows*	Windows RS4	17.0,
	Windows RS5	17.0, 17.2, 17.5, 17.7, 17.8
	Windows 19H1	17.5, 17.7, 17.8
	Windows 19H2	17.8
Windows* Server 2016	All editions with latest available service release	17.0, 17.2, 17.5, 17.7, 17.8
Windows PE~	All editions	17.0, 17.2, 17.5, 17.7, 17.8

Notes:

1. All the supported OS are 64-bit.
2. OEM manufacturing support only for WinPE.

3.1.8 Supported MSFT* Performance Debug Tools

Beginning with Intel® Rapid Storage Technology 13.0, Intel® RST Driver supports the MSFT* “Crimson” Event Tracing for Windows*(ETW) performance measurements for responsiveness. Refer to MSFT* for information on this ETW.

§ §



4 Intel® Rapid Storage Technology Suite

The Intel® Rapid Storage Technology Suite contains these core components:

1. Intel® Rapid Storage Technology (Intel® RST) OS runtime software package:
 - a. AHCI/RAID driver (and filter driver for backward compatibility)
 - b. Graphical User Interface (Intel® RST UI), optional
 - c. Event Monitor service (IAStorDataMgrSvc) optional; interfaces with:
 - i. Intel® RST UI (graphical user interface)
 - ii. Event Notification Tray Icon (IAStorIcon)
 - iii. Windows system NT Event log
 - d. Intel® Optane™ Memory Service¹ (iastorAfsService)
 - e. Intel® Optane™ Memory Minifilter¹ driver (iastorAfs)
 - f. Intel® Optane™ Memory Native App¹ (iastorAfsNative)

For Intel® Optane™ Memory Storage and Management UI:

- a. AHCI/RAID driver (and filter driver for backward compatibility)
 - b. Graphical User Interface (Intel® Optane™ Memory Storage and Management UI)
 - c. Event Monitor service (IAStorDataMgrSvc) optional; interfaces with:
 - i. Intel® Intel® Optane™ Memory Storage and Management UI (GUI)
 - ii. Event Notification Tray Icon (IAStorIcon)
 - iii. Windows system NT Event log
 - d. Intel® Optane™ Memory Service¹ (iastorAfsService)
 - e. Intel® Optane™ Memory Minifilter¹ driver (iastorAfs)
 - f. Intel® Optane™ Memory Native App¹ (iastorAfsNative)
 - g. (RSTMwService)
2. Intel® Rapid Storage Technology BIOS components:
 - a. Intel® Rapid Storage Technology RAID Option ROM (legacy support)
 - b. UEFI driver (with HII-compliant UI)

Note¹: Although installed in all cases, only runs when 32GB or larger SKUs of the Intel® Optane™ module are being used to enable System Acceleration.

The following components are available for OEM manufacturing use only; NOT to be distributed to end-users!

3. Intel® Rapid Storage Technology RAID mode utilities
 - a. Intel® RSTCLI 64-bit Windows/WinPE command line interface utilities
 - b. DEVSLP Tool - command-line utility for configuring DEVSLP register values
 - c. RcfgSata
 - i. DOS-based command-line interface utility (legacy support)
 - ii. UEFI Shell-based command-line interface utility
 - d. RcmpSata compliance utility
 - i. DOS-based Intel® RST RAID mode compliance check utility (legacy support)



ii. UEFI Shell-based Intel® RST RAID mode compliance check utility

4.1 Intel® Rapid Storage Technology Software

The Intel® RST software is the major component of the Intel® Rapid Storage Technology Suite. The software includes the Intel® RST AHCI and RAID 64 bit drivers for supported Windows* operating systems. The driver supports several Intel® Serial ATA AHCI/RAID controllers and will recognize each unique device ID and sub-class code. Because of this, the driver must be installed before the Windows operating system is installed onto a RAID volume or a single SATA hard drive connected to the RAID controller. The OS runtime driver, in conjunction with the Intel Rapid Storage Technology option ROM or the RST pre-OS UEFI driver, will provide boot capability for all supported RAID levels. The driver, in conjunction with the Intel® RST UI, provides RAID volume management (create, delete, migrate, etc.) within the Windows operating system. It also displays SATA* device and RAID volume information. Included with the software package is the RAID monitor service that monitors and reports various events of the storage subsystem. Other advanced features supported include System Acceleration with Intel® Optane technology.

4.2 Intel® Rapid Storage Technology Option ROM

The Intel® Rapid Storage Technology Option ROM is a standard Plug and Play option ROM that adds the Int13h services and provides a pre-OS user interface for the Intel® Rapid Storage Technology solution. The Int13h services allow a RAID volume to be used as a boot hard drive. They also detect any faults in the RAID volume being managed by the RAID controller. The Int13h services are active until the RAID driver takes over after the operating system is loaded.

The Intel Rapid Storage Technology option ROM expects a BIOS Boot Specification (BBS) compliant BIOS. It exports multiple Plug and Play headers for each non-RAID hard drive or RAID volume, which allows the boot order to be selected from the system BIOS's setup utility. When the system BIOS detects the RAID controller, the *RAID option ROM* code should be executed.

The Intel Rapid Storage Technology option ROM is delivered as a single uncompressed binary image compiled for the 16-bit real mode environment. To conserve system flash space, the integrator may compress the image for inclusion into the BIOS. System memory is taken from conventional DOS memory and is not returned.

4.3 Intel Pre-OS RAID Configuration Utilities

The Intel RAID Configuration utility is an executable with capabilities similar to the Intel Rapid Storage Technology option ROM. Both Legacy OROM and UEFI configuration utilities can operate in 16-bit MS-DOS* mode. It provides customers with the ability to create, delete, and manage RAID volumes on a system within a DOS environment. For ease of use, the utility has command line parameters that make it possible to perform these functions by using DOS scripts or shell commands.

The RAID Configuration utilities use command line parameters. Below is a snapshot of the help text displayed when using the `-?` flag. It shows the usage of all supported command line flags necessary for creating, deleting, and managing RAID volumes.



4.3.1 RCfgSata Utility for MS-DOS* and UEFI

- Rcfgsata.exe = DOS application
- Rcfgsata.efi = UEFI application (UEFI shell required)

The command syntax for the Intel RAID Configuration utility is shown below:

=====

```
rcfgsata.efi (or rcfgsata.exe) [/?] [/Y] [/Q] [/C:vol_name] [/SS:strip_size] [/L:raid_level]
  [/S:vol_size] [/DS:disk_id] [/D:vol_name] [/X] [/I] [/P] [/U] [/ST] [/SP] [/V] [/RRT] [/Sync:
  <Auto | Manual>] [/M:disk_port] [/EM] [/ER] [/ACCEL:vol_name1 cache_vol mode] [/RA]
  [/SD] [CONCAT Device_ID_fast-drive Device_ID_slow-drive Concatenation_boundary_in_MB]
  [DECONCAT]
```

- /? Displays Help Screen. Other options ignored.
- /Y Suppress any user input. Used with options /C, /D, /SP and /X.
- /Q Quiet mode / No output. Should not be used with status commands.

COMMANDS - Only one command at a time unless otherwise specified.

- /C Create a volume with the specified name. /S, /DS, /SS, and /L can be specified along with /C.
- /SS Specify strip size in KB. Only valid with /C.
- /L Specify RAID Level (0, 1, 10, or 5). Only valid with /C.
- /S Specify volume size in GB or percentage if a '%' is appended. Percentage must be between 1-100. Only valid with /C.
- /DS Selects the disks to be used in the creation of volume. List should be delimited by spaces.
- /D Delete Volume with specified name.
- /X Remove all metadata from all disks. Use with /DS to delete metadata from selected disks.
- /I Display All Drive/Volume/Array Information. /P can be specified.
- /P Pause display between sections. Only valid with /I or /ST.
- /U Do not delete the partition table. Only valid with /C on RAID 1 volumes.
- /SP Marks the selected drive(s) as spare(s). Use with /DS
- /ST Display Volume/RAID/Disk Status.
- /V Display version information
- /RRT Create a recovery volume. Only valid with /C. Requires /M.
- /Sync Set sync type for 'Recovery' volume. Only valid with /RRT.



- /M Specify the port number of the Master disk for 'Recovery' volume. Only valid with /RRT.
 - /EM Enable only master disk for recovery volume
 - /ER Enable only recovery disk for recovery volume; /EM and /ER actions will result in change from Continuous Update mode to On-Request.
 - /ACCEL Intel® SRT: Specify the volume to accelerate and acceleration mode
 - vol_name1 - volume to accelerate
 - cache_vol - the volume to use as cache
 - mode - "enh" for enhanced, "max" - maximized
 - /RA Intel® SRT: Removes the Intel® SRT Disk/Volume Acceleration.
 - /SD Intel® SRT: Synchronizes the data from the cache device to the Accelerated Disk/Volume.
 - /CONCAT Concatenates drives into Optane™ Memory Volume in postfix mode with specified migrations size in megabytes.
 - device_id_of_fast_drive - DeviceId of fast drive (e.g. 1.0)
 - device_id_of_slow_drive - DeviceId of slow drive (e.g. 0.0)
 - concatenation_boundary_in_MB - concatenation boundary in MB which is the offset the C: partition (e.g. 615 : *where 615 is MB*)
- Example:** rfcgsata.exe /concat 1.0 0.0 615
- /DECONCAT Disables the Optane™ Memory Volume Acceleration.
 - deconcat_mode "safe" or "unsafe"
- Example:** rfcgsata.exe /deconcat safe
- =====

4.4 RSTCLI (32/64 bit) Windows Utilities

Note: : RSTCLI Commands are Case SenSiTiVe

The Intel RSTCLI 32/64 utility is an executable. It provides OEMs with the ability to create, delete, and manage RAID volumes on a system within a windows environment using command line parameters that make it possible to perform these functions by using scripts or shell commands. For use in all supported Windows OS including WinPE 32/64.

The command syntax for the Intel RSTCLI utilities is shown below. Please also refer to the clireadme.txt file included with each release for the information below.

USAGE: rstcli.exe (or rstcli64.exe)



Create Commands:

Flag	Name
-C	--create
-E	--create-from-existing
-l	--level
-n	--name
-s	--stripe-size
-z	--size
	--rrt
	--rrtMaster
	--rrtUpdate

Create Usage:

Creates a new volume and array or creates a new volume on an existing array.

```
--create --level x [--size y] [--stripe-size z] --name string [--create-from-existing diskId] diskId  
  {[diskId]}
```

Create Examples:

-C -l 1 -n Volume 0-0-1-0 0-0-2-0 (format of the disk ID is "0-0-**SATA_Port**-0" where the second digit from the left represents the SATA port on the platform where the disk is located; thus 0-0-1-0 represents SATA port # 1)

```
--create -l 0 -z 5 --name RAID0Volume 0-0-3-0 0-0-4-0 0-0-5-0
```

```
-C -l 1 -E 0-0-1-0 -n VolumeWithData 0-0-2-0
```

```
-C --rrt -n RRTVolume 0-0-1-0 0-0-2-0 --rrtMaster 0-0-1-0
```

```
-C --rrt -n RRTVolume 0-1-0-0 0-2-0-0 --rrtUpdate Continuous
```

```
--create --help
```

Information Commands:

Flag	Name
-I	--information
-a	--array
-c	--controller
-d	--disk
-v	--volume
	--comma

Information Usage:

Displays disk, volume, array, and controller information.

```
--information --controller|--array|--disk|--volume {[device]}
```

Information Examples:

```
-I -v Volume
```

```
-I -d 0-0-5-0
```

```
-I --comma
```

```
-I -v --comma
```

```
-I -d 0-2-0-0 --comma
```

```
--information --array Array_0000
```

```
--information --help
```

Manage Commands:

Flag	Name
-M	--manage
-x	--cancel-verify



- D --delete
- p --verify-repair
- f --normal-volume
- F --normal
- i --initialize
- L --locate
- T --delete-metadata
- Z --delete-all-metadata**
- N --not-spare
- P --volume-cache-policy
- R --rebuild
- S --spare
- t --target
- U --verify
- w --write-cache

****WARNING: Using this command deletes the metadata on ALL disks in the system. There is no option to select individual disks with this command and there is no warning prior to the command initiating and completing. To delete metadata on individual disks use the -D (--delete) command with either "volume_name" or "diskID".**

Manage Usage:

Manages arrays, volumes and disks present in the storage system.

- manage --cancel-verify volumeName
- manage --delete volumeName
- manage --verify-repair volumeName
- manage --normal-volume volumeName
- manage --normal diskId
- manage --initialize volumeName
- manage --locate diskId
- manage --delete-metadata diskId (deletes the metadata only on disks that are in a non-Normal state e.g. offline or unknown)
- manage --delete-all-metadata
- manage --not-spare diskId
- manage --volume-cache-policy off|wb --volume volumeName
- manage --rebuild volumeName --target diskId
- manage --spare diskId
- manage --verify volumeName
- manage --write-cache true|false --array arrayName

Manage Examples:

- manage --spare 0-0-3-0
- M -D VolumeDelete
- M --normal 0-0-2-0
- manage -w true -array Array_0000
- M -U VolumeVerify
- M -Z
- manage --help

Modify Commands:

Flag	Name
-m	--modify
-A	--Add



-X --expand
-l --level
-n --name
-s --stripe-size
-v --volume

Modify Usage:

Modifies an existing volume or array.

--modify --volume VolumeName --add diskId {[diskId]}
--modify --volume VolumeName --expand
--modify --volume VolumeName --level L [--add diskId {[diskId]} [--stripe-size s] [--name N]
--modify --volume VolumeName --name n

Modify Examples:

-m -v Volume_0000 -A 0-0-3-0 0-0-4-0
-m --volume ModifyVolume --level 5
--modify -v Volume -n RenameVolume
--modify --help

Intel® SRT Accelerate Commands:

****NOTE: SRT is not supported in this version of the RST Driver. Booting from previously existing SRT volumes is allowed.**

Flag	Name
	--accelerate
	--createCache
	--setAccelConfig
	--disassociate
	--reset-to-available
	--accel-info
	--loadCache
	--stats

Accelerate Usage:

Accelerates a given disk or volume with the specified SSD disk.

--accelerate --createCache|--setAccelConfig|--disassociate|--reset-to-available|--accel-info
--accelerate --createCache --SSD <diskId> --cache-size X [where $16 \leq X \leq 64$]
--accelerate --setAccelConfig --disk-to-accel <diskId> | --volume-to-accel <volume name> --
mode [enhanced | maximized | off]
--accelerate --disassociate --cache-volume <volume name>
--accelerate --reset-to-available --cache-volume <volume name>
--accelerate --accel-info
--accelerate --loadCache <files or directory> --recurse
--accelerate --stats

Accelerate Examples:

--accelerate --createCache --SSD 0-0-3-0 --cache-size X [where $16 \leq X \leq 64$]
--accelerate --setAccelConfig --disk-to-accel 0-0-5-0 --mode enhanced
--accelerate --setAccelConfig --volume-to-accel MyVolume --mode maximized
--accelerate --disassociate --cache-volume Cache_Volume
--accelerate --reset-to-available --cache-volume Cache_Volume
--accelerate --accel-info
--accelerate --loadCache C:\Windows*. * --recurse
--accelerate --stats
--accelerate --help



Intel® Optane™ Memory Commands:

Flag	Name
	--enable
	--disable
	--progress
	--info
	--clear-cache
	--file-cache-offset
	--file-cache-size
	--block-cache-size

Optane Memory Usage:

Options to manage Optane Memory drive:

```
--OptaneMemory --enable  
    [--file-cache-offset <starting LBA>]  
--OptaneMemory --enable --fast-drive <driveId> --drive-to-accel <driveId>  
    [--file-cache-offset <starting LBA>]  
--OptaneMemory --disable  
--OptaneMemory --progress  
--OptaneMemory --info <--verbose>  
--OptaneMemory --clear-cache
```

Optane Memory Examples:

```
--OptaneMemory --enable  
--OptaneMemory --enable --fast-drive 0-3-0-0 --drive-to-accel 0-0-5-0 --file-cache-offset <LBA>  
--OptaneMemory --disable  
--OptaneMemory --info --verbose  
--OptaneMemory --help
```

OPTIONS:

```
--clear-cache  
    Clear Optane™ block cache; only recommended to use when running benchmarks.  
--disable  
    Separate Optane™ Memory Volume into Optane device and slow capacity drive.  
--enable  
    Create Optane™ Memory volume. No other parameters are required if the only 2 attached  
    drives controlled by RST are the fast-drive and the drive-to-accel. The RSTCLI/driver will  
    automatically select those two drives to enable Optane™.  
-h, --help  
    Displays help documentation for command line utility modes, options,  
    usage, examples, and return codes. When used with a mode switch  
    (create, information, manage, modify, or accelerate), instructions for  
    that mode display. For example, --create --help displays Create option  
    help.  
--file-cache-offset  
    This option is important and should be used with the --enable command to specify the start  
    point on the slow drive, from which data will be transferred to fast drive. In Practice, --file-  
    cache-offset must be equal to the beginning of Windows (C:\) partition on the slow drive,  
    specified in LBA. If --file-cache-offset parameter is set to 0, or not defined properly, during  
    the next boot (e.g. OOBE) the Optane™ Memory volume rebuilds. The rebuilds process  
    consist of disable Optane™ Memory volume, and enable Optane™ Memory with proper --file-  
    cache-offset value (set automatically to the beginning of C: partition).  
--info
```



Lists information about Optane Memory settings.

--progress
Displays the progress of file cache migration.

RSTCLI OPTIONS:

- A <<host>-<bus>-<target>-<lun>>, --add <<host>-<bus>-<target>-<lun>>
Adds new disks to an existing volume.
- a, --array
Lists information about the arrays in the storage system.
- accel-info
Lists information about Accelerate settings.
- accelerate
Accelerates a given disk or volume with the specified SSD disk.
- C, --create
Creates a new volume and array or creates a new volume on an existing array.
- c, --controller
Lists information about the controllers in the storage system.
- cache-size <MIN or MAX>
Sets a size in gigabytes for the cache memory. This is an optional switch. If the size is not specified, the complete size of the SSD will be used for acceleration.
- cache-volume <Volume name>
Specifies a name for the volume used as cache.
- clear-cache
Clear Optane block cache.
- createCache
Creates the cache.
- D <Volume name>, --delete <Volume name>
Deletes the specified volume.
- d, --disk
Lists information about the disks in the storage system.
- disable
Separate Optane Memory Volume into Optane device and capacity drive.
- disassociate
Disassociates the Cache volume from acceleration
- disk-to-accel <<host>-<bus>-<target>-<lun>>
Specifies a disk if accelerating a pass-through disk.
- drive-to-accel <<host>-<bus>-<target>-<lun>>
Specifies a disk if enabling an Optane volume on a pass-through disk.
- dynamic-storage-accelerator <true or false>
Enables/disables dynamic storage accelerator; using 'true' enables, 'false' disables.
- E <<host>-<bus>-<target>-<lun>>, --create-from-existing <<host>-<bus>-<target>-<lun>>
Identifies the disk if data is to be migrated from one of the disks. Disk identifier is SCSI address.
- enable
Create Optane Memory Volume
- F <<host>-<bus>-<target>-<lun>>, --normal <<host>-<bus>-<target>-<lun>>
Resets failed or SMART event disk to normal.
- f <Volume name>, --normal-volume <Volume name>
Resets failed RAID 0 volume to normal and recovers data.
- fast-drive <<host>-<bus>-<target>-<lun>>
Specifies the location of the Optane device that will be used to enable Optane Memory volume
- file-cache-offset



This option is important and should be used with the --enable command to specify the start point on the slow drive, from which data will be transferred to fast drive. In Practice, --file-cache-offset must be equal to the beginning of Windows (C:\) partition on the slow drive, specified in LBA. If --file-cache-offset parameter is set to 0, or not defined properly, during the next boot (e.g. OOBE) the Optane™ Memory volume rebuilds. The rebuilds process consist of disable Optane™ Memory volume, and enable Optane™ Memory with proper --file-cache-offset value (set automatically to the beginning of C: partition).

- h, --help
Displays help documentation for command line utility modes, options, usage, examples, and return codes. When used with a mode switch (create, information, manage, modify, or accelerate), instructions for that mode display. For example, --create --help displays Create option help.
- I, --information
Displays disk, volume, array, and controller information.
- i <Volume name>, --initialize <Volume name>
Initializes the redundant data on a RAID 1, 5 or 10 volume.
- info
Lists information about Optane Memory settings.
- L <<host>-<bus>-<target>-<lun>>, --locate <<host>-<bus>-<target>-<lun>>
Locates device and blinks the LED.
- l <0, 1, 5, 10>, --level <0, 1, 5, 10>
Changes the RAID type of an existing volume. Options are migrations from RAID 1 to RAID 0 or 5, RAID 0 to RAID 5, and RAID 10 to RAID 5.
- loadCache C:\Windows*. * --recurse
Used to pre-load files into the cache
- M, --manage
Manages arrays, volumes and disks present in the storage system.
- m, --modify
Modifies an existing volume or array.
- mode <Enhanced or Maximized mode>
Specifies Accelerate mode as Enhanced or Maximized.
- N <<host>-<bus>-<target>-<lun>>, --not-spare <<host>-<bus>-<target>-<lun>>
Resets a spare disk to available.
- n <Volume name>, --name <Volume name>
Specifies a name for the volume created. Renames an existing volume in Modify mode.
- P <Volume name>, --volume-cache-policy <Volume name>
Sets volume cache policy to either off or wb.
- p <Volume name>, --verify-repair <Volume name>
Verifies and repairs the volume.
- progress
Displays the progress of file cache migration.
- q, --quiet
Suppresses output for create, modify, and manage modes. Not valid on info mode.
- R <Volume name>, --rebuild <Volume name>
Rebuilds the degraded volume.
- r, --rescan
Forces the system to rescan for hardware changes.
- reset-to-available
Resets the cache volume to available.
- rrt
Creates a recovery volume using Intel(R) Rapid Recovery Technology (RRT).
- rrtMaster <<host>-<bus>-<target>-<lun>>
Optionally creates a recovery volume that allows you to select a specific disk as the master disk. Default is the first disk in the disk list.



- rrtUpdate <Continuous or OnRequest Update>
Specifies a data update setting when creating a recovery volume as Continuous or OnRequest. Default is Continuous.
- S <<host>-<bus>-<target>-<lun>>, --spare <<host>-<bus>-<target>-<lun>>
Marks a disk as a spare.
- SSD <<host>-<bus>-<target>-<lun>>
Specifies SSD disk that will be used as cache. If another SSD is being used as cache, then that volume needs to be deleted to use a new SSD disk.
- s <size in KB>, --stripe-size <size in KB>
Sets a stripe size in kilobytes (2^10 bytes) for a volume. Valid when creating or changing the type of a volume and for RAID 0, RAID 5 and RAID 10. Options are 4, 8, 16, 32, 64 and 128 KB.
- setAccelConfig
Sets the config for accelerating a volume or disk.
- stats
Indicates percentage of cache usage.
- T <<host>-<bus>-<target>-<lun>>, --delete-metadata <<host>-<bus>-<target>-<lun>>
Deletes the metadata from the specified disk. (deletes the metadata only on disks that are in a non-Normal state e.g. offline or unknown)
- t <<host>-<bus>-<target>-<lun>>, --target <<host>-<bus>-<target>-<lun>>
Indicates the pass-through disk to be used for rebuilding a degraded volume.
- U <Volume name>, --verify <Volume name>
Verifies data on the volume.
- u <password>, --unlock <password>
Unlocks a disk.
- V, --version
Displays version information.
- v, --volume
Lists information about the volumes on the system. Stipulates the volume to act on when used in Modify or Manage mode.
- volume-to-accel <Volume name>
Specifies a name of the volume to be accelerated.
- w <true or false>, --write-cache <true or false>
Enables or disables write cache for all disks that are part of an array.
- X, --expand
Expands a volume to consume all available space in an array.
- x <Volume name>, --cancel-verify <Volume name>
Cancels a verify operation in progress.
- z <size in GB>, --size <size in GB>
Sets a size in gigabytes. This is an optional switch. If the size is not specified or specified to 0, then the maximum size available will be used.
- Z --delete-all-metadata
Deletes the metadata on **all disks** in the system without any warning prior to initiating and completing the action.
- file-cache-size <size in GB>
Specify the size of Optane Memory that will be used for file caching. The user can disable file caching and file pinning by specify the file cache size used to be 0 (--file-cache-size 0)
- block-cache-size <size in GB>
Specify the size of Optane Memory that will be used for block caching. This flag is typically used in conjunction with --file-cache-size. If the user want to disable file cache, it is suggested to use with block cache size set to max. (eg. --file-cache-size 0 --block-cache-size 27)



RETURN CODES:

- 0, Success
Request completed successfully.
 - 1, Request Failed
Request is formatted correctly but failed to execute.
 - 2, Invalid Request
Unrecognized command, request was formatted incorrectly.
 - 3, Invalid Device
Request not formatted correctly, device passed in does not exist.
 - 4, Request Unsupported
Request is not supported with the current configuration.
 - 5, Device State Invalid
Request is not supported with the current device state.
 - 20, Invalid Stripe Size
Stripe size is not supported.
 - 21, Invalid Name
Volume name is too long, has invalid characters, or already exists.
Volume name cannot exceed 16 English characters.
 - 22, Invalid Size
Size requested is invalid.
 - 23, Invalid Number Disks
Number of disks requested is invalid.
 - 24, Invalid RAID Level
RAID level requested is invalid.
-

4.5 UEFI System BIOS and Intel® RST UEFI/RAID Package

Beginning with the Intel® RST 11.5 Release version, the product provides a native UEFI driver for OEMs and their BIOS vendors to integrate into their RAID-enabled platforms (Not required for AHCI mode platforms).

4.5.1 Specification References

This document is not intended to be a go-to document for the UEFI specification. The specification is owned by the UEFI working group and detailed information regarding UEFI can be found in documents published by that organization. The Intel® RST UEFI driver implementation conforms to the UEFI specification and is in compliance with version 2.3.1.

Table 3-1: UEFI Specifications and Location

Specification	Location
UEFI Specification version 2.3.1	(http://www.uefi.org/specsandtesttools)
UEFI Platform Initialization Specification version 1.2	(http://www.uefi.org/specsandtesttools)
UEFI Shell Specification version 2.0	(http://www.uefi.org/specsandtesttools)



4.5.2 What Intel® RST Provides to OEMs/BIOS Vendors

4.5.2.1 Intel® Rapid Storage Technology UEFI Driver

This is the main component of the Intel® RST pre-OS EFI solution. It is provided in three different formats:

RaidDriver.efi (filename):

- UEFI driver that requires integration into the UEFI System BIOS by the OEM's BIOS vendor. This file can be placed into the OEMs' UEFI BIOS source build where their tools can integrate it.

RaidDriver.ffs (filename):

- The Intel® RST UEFI driver (RaidDriver.efi) is wrapped in the Firmware File System (.ffs)
- Useful for an external tool to integrate the binary into a compiled BIOS image. Firmware File System Details:
 - Firmware File Type - EFI_FV_FILETYPE_DRIVER (0x07)
 - File GUID - 90C8D394-4E04-439C-BA55-2D8CFCB414ED
 - 2 Firmware File Sections
 - EFI_SECTION_PE32 (0x10)
 - EFI_SECTION_USER_INTERFACE (0x15)
Name "SataDriver"

RaidDriver.bin (filename):

- This is an optional format that is provided to OEMs that might want it delivered as a PCI 3.0 UEFI OROM
- Disadvantage of the UEFI OROM format is that it likely will require the BIOS to have a Compatibility Support Module (CSM) in order to function

4.5.2.2 Intel® RST UEFI User Interface

An **HII-compliant** user interface is provided for the pre-boot configuration of the RAID system, including management of the premium cacheing features Intel® Smart Response Technology and System Acceleration with Intel® Optane™ Technology. The same functionality provided in the legacy OROM UI is available in the HII UI.

- The UI is integrated within the UEFI driver binary (RaidDriver.efi, .ffs, and .bin files)
- Per the UEFI specification, we publish the UI as string and forms packages
- The UI is accessible from within the UEFI BIOS (How the user accesses it from within the BIOS is OEM-dependent upon implementation)
- The text string 'Intel(R) Rapid Storage Technology' will be displayed as the selection to enter the UI
- Some OEMs may want to hard assign where the Intel® RST UEFI GUI will be located within their BIOS.
- **The Intel® RST UEFI Driver FORMSET_GUID is:**
FORMSET_GUID { 0xd37bcd57, 0xaba1, 0x44e6, { 0xa9, 0x2c, 0x89, 0x8b, 0x15, 0x8f, 0x2f, 0x59 } }



{D37BCD57-ABA1-44e6-A92C-898B158F2F59}

Figure 3-1: Example location of RST UEFI UI in a System BIOS



4.5.2.3 Command Line RAID Configuration Utility

RcfgSata.efi (filename):

- A UEFI application that requires booting to the UEFI Shell environment to run
- Same functionality and commands as have been provided by the legacy DOS version (**RcfgSata.exe**) in previous releases of the Intel® RST product.
- Requires the exact same version of the RST UEFI Driver to be loaded on system in order to function.

Figure 3-2: rcfgsata command line syntax



4.5.2.4 Command Line RAID Compliance Checking Utility

RcmpSata.efi (filename):

- A UEFI application that requires booting to the UEFI Shell environment to run.
- Investigates if the list of UEFI required protocols by the RST UEFI Driver are present. Also provides a list of the protocols published by the RST UEFI Driver and the capabilities/features of the RST UEFI Driver.

Figure 3-3: rcfgsata command line syntax



```
fs2:\11.5\1141_Beta\OROM> rcfgsata /st  
  
fs2:\11.5\1141_Beta\OROM> rcmpsata > output.txt
```

4.5.3 UEFI System BIOS Requirements for Platform Compatibility with Intel® RST UEFI

This section covers what the OEM/BIOS Vendor is required to accomplish in order to ensure that the platform is compatible the Intel® RST UEFI driver.

4.5.3.1 Required Protocols/Functions to be Provided by UEFI System BIOS

The Intel® RST UEFI driver requires the following protocols/functions to be provided by the BIOS:

EFI_BOOT_SERVICES:

- LocateHandleBuffer
- OpenProtocol
- CloseProtocol
- WaitForEvent
- HandleProtocol
- FreePool
- AllocatePages
- AllocatePool
- InstallMultipleProtocolInterfaces
- UninstallMultipleProtocolInterfaces
- Stall

EFI_RUNTIME_SERVICES:



- SetVariable
- GetVariable
- GetTime

Other Protocols:

- EFI_ACPI_TABLE_PROTOCOL (or EFI_ACPI_SUPPORT_PROTOCOL (EDK117))

4.5.3.2 Optional Protocols/Functions to be Provided by UEFI System BIOS

If the OEM plans to use the Intel® RST HII-compliant UI, then **the following protocols/functions are required to be provided by the BIOS:**

- Form Browser 2 Protocol
- Config Routing Protocol
- HII String Protocol
- HII Database Protocol

4.5.3.3 Protocols Provided by Intel® RST UEFI Driver

The Intel® RST UEFI driver provides the following protocols:

- *Driver Binding Protocol*
- *Component Name Protocol (English only)*
- *Component Name 2 Protocol (English only)*
- *Driver Supported EFI Version Protocol*
- *Device Path Protocol*
- *Config Access Protocol*
- EFI_BLOCK_IO_PROTOCOL
 - For Logical Devices
- EFI_STORAGE_SECURITY_PROTOCOL
 - For Non-RAID disks that support TCG Feature Set
- EFI_EXT_SCSI_PASS_THRU_PROTOCOL:
 - All SCSI commands are supported (for ATAPI devices)
- EFI_ATA_PASS_THRU_PROTOCOL:
 - Non-RAID disks:
 - All ATA commands are supported
 - RAID disks (only the following commands are supported):
 - EXECUTE DEVICE DIAGNOSTIC (0x90)
 - IDENTIFY DEVICE (0xEC)
 - IDLE (0xE3)
 - IDLE IMMEDIATE (0xE1)
 - SECURITY DISABLE PASSWORD (0xF6)
 - SECURITY ERASE PREPARE (0xF3)
 - SECURITY ERASE UNIT (0xF4)



- SECURITY FREEZE (0xF5)
- SECURITY SET PASSWORD (0xF1)
- SECURITY UNLOCK (0xF2)
- SET FEATURES (0xEF)
- SMART READ DATA (0xB0 / 0xD0)
- SMART READ LOG (0xB0 / 0xD5)
- SMART RETURN STATUS (0xB0 / 0xDA)
- STANDBY (0xE2)
- STANDBY IMMEDIATE (0xE0)
- All disk types:
 - EFI_ATA_PASS_THRU_PROTOCOL_ATA_NON_DATA
 - EFI_ATA_PASS_THRU_PROTOCOL_PIO_DATA_IN
 - EFI_ATA_PASS_THRU_PROTOCOL_PIO_DATA_OUT
 - EFI_ATA_PASS_THRU_PROTOCOL_DEVICE_DIAGNOSTIC
 - EFI_ATA_PASS_THRU_PROTOCOL_UDMA_DATA_IN
 - EFI_ATA_PASS_THRU_PROTOCOL_UDMA_DATA_OUT
 - EFI_ATA_PASS_THRU_PROTOCOL_RETURN_RESPONSE

4.5.4 How-to-Enable the Platform with Intel® RST UEFI Driver/HII_GUI

This section covers what the OEM/BIOS Vendor is required to accomplish in order to ensure that the platform is compatible with the Intel® RST UEFI driver.

4.5.4.1 Step1: Platform UEFI BIOS

1. Ensure that the UEFI System BIOS meets UEFI Specification 2.3.1 compliance
2. The BIOS must provide the following protocols:
 - EFI_Boot_Services Protocols (see section 3.5.3.1)
 - EFI_Runtime_Services Protocols (see section 3.5.3.1)
 - EFI_HII Protocols** (see section 3.5.3.2) *** Required for the Intel® RST UEFI UI

4.5.4.2 Step2: Download and Integrate Intel® RST UEFI Package

1. Download the latest kit from the Intel VIP (Validation Internet Portal) website. From the kit select the **efi_sata.zip** file which will contain the UEFI driver binary files (*RaidDriver.efi*, *RaidDriver.ffs*, and *RaidDriver.bin*)
2. Select and extract the binary file based on the planned integration method:
 - **RaidDriver.efi**: Use this binary if planning to integrate at the time of the BIOS image build
 - **RaidDriver.ffs**: Use this binary if planning to integrate into an already built BIOS image



- **RaidDriver.bin**: Use this binary if planning to integrate as legacy type OROM (CSM may also be required)
3. Use the proper integration tools based on the binary file selected above

4.5.4.3 Step3: Verify Compliance

1. From the **efi_sata.zip** downloaded in step 2, extract the **RCmpSata.efi** file.
2. Place the file on a USB thumb drive and insert the drive into the platform
3. Boot to the UEFI Shell environment.
4. Run the RCmpSata.efi application (it's a command-line utility): at the prompt type the command:
 - To print to screen: `rcmpsata.efi`
 - To print to a file: `rcmpsata.efi > comply.txt`
5. Ensure all sections pass with no fails reported

4.5.5 Known Compatibility Issues with UEFI Self Certification Test (UEFI SCT) Tool

The following UEFI SCT tests will appear as FAIL in reports generated using the "Report Generation" tool of the SCT framework. The "Report Generation" tool is the only method that should be used to determine if tests fail. Do not determine test failing test results by viewing the raw log files. The "Report Generation" tool will discard any test results that failed due to an invalid system configuration.

Test GUID	Reason
61EE3A34-62A2-4214-B076-5073B177156C 98530F3D-8BD8-44A1-9D06-08039FD FEC63 9EFE26C2-C565-478A-A0B4-05A8FD2E7E3E	The Intel® RST UEFI driver does not support Reset – EFI_UNSUPPORTED is returned
D72E6A78-5292-4493-9040-B0445A9C1714 A42A0E01-7B80-46E4-A757-86C4EC53F4E4 322F00C1-F6BF-41ED-AEFD-AAC48F3FA9DB 230D44B6-CE53-42B6-9BA6-3D115D492B33 0F2F0849-690B-48EA-8E35-64363FAA8C5C	The Intel® RST UEFI driver does not support BuildDevicePath – EFI_UNSUPPORTED is returned



<p>1F99EBC8-0253-455F-88AC-9E2BA6DCD729</p>	<p>The Intel® RST UEFI driver does not support RouteConfig – EFI_UNSUPPORTED is returned. RouteConfig is not supported so that Intel® RST HII form values are only modified by the Intel® RST driver itself</p>
<p>495C99F3-0231-45A5-AFFA-D25C6F9A191C 1A15DF85-6CC1-43F2-9B86-218BD5FDF4A0 603E52F0-2CE3-4E7A-A72E-DF8CA3FDB20D</p>	<p>The Intel® RST UEFI does not use EFI HII Configuration Access Protocol.</p>
<p>35749ACF-EED8-4230-BC18-DE1F8B7CFAEF</p>	<p>Call is made upon remapped NVMe drive, which UEFI SCT Suite treats as ATA device, due to test criteria mismatch EFI_DEVICE_ERROR is returned</p>
<p>6A8CAA83-B9DA-46C7-98F6-D4969DABDAA0</p>	<p>Starting with RST UEFI version 17.x and later, the following changes are required in OPAL Driver to support RST UEFI PreOS driver:</p> <ul style="list-style-type: none"> Opal driver does not check if EFI_BLOCK_IO_PROTOCOL is present along with EFI_STORAGE_SECURITY_COMMAND_PROTOCOL. <p>Opal driver no longer needs EFI_BLOCK_IO_PROTOCOL to be installed on the same handle that EFI_STORAGE_SECURITY_COMMAND_PROTOCOL is installed.</p>
<p>9C88D95C-228A-48E0-BD17-D1873109F1FC 06F45FC1-A9CD-4889-881D-5E34B812FA3D 2B9446E8-EA00-49EE-972D-CF2AA49E0AD3 A11DEDE9-E13D-4096-90C8-A62E16C576AF 976D1926-0862-4F41-8442-A523F3C79E4B</p>	<p>The Intel® RST NVME PassThru protocol implementation expects NamespaceID parameter to represent a valid port number (not NamespaceID). If there is no device connected, the RST protocol will return EFI_INVALID_PARAMETER status</p>

4.6 Pre-OS

4.6.1 BIOS PCH SATA Controller Modes

The following table explains the PCH SATA controller modes available on all Kaby Lake and later platforms:



Pre-Kaby Lake BIOS code SATA modes (Old)	Kaby Lake BIOS code SATA modes (New)	Supported Platforms	Major Feature Support
AHCI	AHCI (no change)	All	AHCI basic features
RAID	Intel® RST Premium and System Acceleration with Intel® Optane Technology	Premium Intel® PCH Chipsets (e.g. Q270, Z270, Z370)	<ul style="list-style-type: none"> • RAID 0/1/5/10 • Intel® Optane™ Memory • Intel® SRT** • PCIe NVMe by remapping
None/New Mode	Intel® RST and System Acceleration with Intel® Optane Technology	Non-Premium Intel® PCH Chipsets (e.g. B250, Q360)	<ul style="list-style-type: none"> • Intel® Optane™ Memory • PCIe NVMe by remapping


Discontinued beginning on Intel® 300/240 Series Chipset Family

4.6.1.1 Enable SATA Mode for Optane/RAID Support on RVP

This settings (SATA Mode Selection) can be accessed from the main BIOS menu by go to:

Intel Advanced Menu -> PCH-IO Configuration -> SATA And RST Configuration

Change the SATA Mode Selection from "AHCI" to "Intel RST Premium With Intel Optane System Acceleration" or "RAID"



4.6.2 Platform BIOS Settings

In addition PCH SATA Controller mode to be set as "Intel® RST Premium and System Acceleration with Intel® Optane Technology" in BIOS, these are the bios settings to enable Teton Glacier in a supported systems.

Note: The information can also be found in Chapter 3 of WHL_TG_Integration_Guide (CDI/IBP#: 596835).



4.6.2.1 Dynamic PCIe Port Configuration

4.6.2.1.1 Minimum BIOS and CSME Requirements

In order to support dynamic PCIe port configuration, the following components are required:

1. BIOS reference code version 164.5 or newer.
2. CSME version 12.0.20.1301 or newer.
3. PCIe port where TG is located must be set to 1x4 mode (Default Strap Configurations).

4.6.2.2 Teton Glacier BIOS Settings

These are BIOS settings for Teton Glacier in supported platform.

Teton Glacier BIOS Settings	Value
Teton Glacier Mode	<Dynamic Configuration for Teton Glacier Enable> Enable Teton Glacier Support. <Disable> Disable Teton Glacier Support. <Static Configuration for Teton Glacier Enable> DEBUG PURPOSE ONLY.

4.6.2.2.1 Enable TG Support for RVP

Note: Make sure that SATA Mode is set to either "RAID" or "Intel RST Premium With Intel Optane System Acceleration".

The settings can be accessed from the main BIOS menu by go to:

Intel Advanced Menu -> PCH-IO configuration

1. Teton Glacier Mode <Dynamic Configuration for Teton Glacier Enable>
This BIOS option is used to disable Teton Glacier Mode on the platform or to enable Teton Glacier and select the TG PCIe Port configuration mode. Available selection:
 - a. Disable: Disable Teton Glacier mode.
 - b. Dynamic Configuration for Teton Glacier Enable: Enable Teton Glacier mode and set the PCIe Port Configuration mode to Dynamic.
 - c. Static Configuration for Teton Glacier Enable: **DO NOT USE THIS AS THIS OPTION IS ADDED ONLY FOR DEBUG PURPOSES.**

Change Teton Glacier Mode to **<Dynamic Configuration for Teton Glacier Enable>**



PCH-IO Configuration

Disable DSX ACPRESENT PullDown	<Disabled>	↑ Select Teton Glacier Mode
PXE ROM	<Disabled>	
CLKRUN# logic	<Enabled>	
Serial IRQ Mode	<Quiet>	
State After G3	<S0 State>	
Port 80h Redirection	<LPC Bus>	
Enhance Port 80h LPC Decoding	<Enabled>	
Compatible Revision		
PCH Cross Throttling	Static Configuration for Teton Glacier Enable	
PCH Energy Reporting	Dynamic Configuration for Teton Glacier Enable	
Energy Reporting Deb	Disabled	
Enable ICO Timer		
Pcie P11 SSC	<Auto>	
Flash Protection Range	<Enabled>	
Registers <FPRR>	<TRUE>	
SPD Write Disable	<Disabled>	
LGMR	<Disabled>	
Teton Glacier Mode	<Disabled>	
RST Driver Select	<Auto>	

§ §



5 Intel® Optane™ Memory and Storage Management UI

5.1 Introduction

The Intel® Optane™ Memory and Storage Management UI is a Windows* Store app that provides users with monitoring and management capabilities for the Intel® RST storage subsystem. It offers a wide range of monitoring and management activities for the Intel® RST RAID subsystem. It also provides support for all Intel® Optane™ Memory features, including File, Folder, and Application pinning.

Notes:

1. ***The minimum resolution supported by Intel® Optane™ Memory and Storage Management UI is 1024x768.***
2. ***For Windows 10 RS4, Intel® Optane™ Memory and Storage Management UI requires to be launch as Administrator manually by right click and select "Run as Administrator." This requirement does not apply for Windows 10 RS5 and above.***
3. ***The Intel® Optane™ Memory and Storage Management UI required BIOS's SATA Mode selection set to "AHCI" or "RAID/Intel RST Premium" on a non-VMD platform. The BIOS SATA Mode set to disabled is an unsupported configuration.***

5.2 Getting Started

The Intel® Optane™ Memory and Storage Management UI software package provides high-performance RAID capabilities for supported operating systems.

The Intel® Optane™ Memory and Storage Management UI requires the Microsoft .NET Native Framework 2.0 framework, Microsoft .NET Native Framework 2.0 runtime, and the Microsoft VC Libs beginning with Intel® RST 17.0 HSA release.

Refer to the System Requirements and the online user's manual to set up your system's configuration and feature support level. You can also review the Readme file installed with this software or visit Intel's online support to learn more about the full system requirements and RAID BIOS configuration.

5.2.1 Understanding the Application

The "Intel® Optane™ Memory and Storage Management" application allows you to optimize and maintain a healthy storage system by creating volumes, customizing performance settings and managing storage system elements. This section provides you with a general overview of a storage system configuration and an individual review of all the areas contained in this application.

5.2.1.1 Storage System Configuration

The storage system combines hardware capabilities with RAID technology to provide flexible data storage units on your computer. Each data storage unit, or RAID configuration, consists of three



elements that include physical SATA disks, one or two volumes, and one array. When at least one volume is present on the system, these elements are represented in the storage system view of the Status and Manage areas.

In this section, we describe each of these RAID configuration elements and explain how they relate to each other.

- **Array**

An array is a collection of two or more SATA disks in a RAID configuration and is the highest element in the hierarchy of a storage system. Once a volume is created, the disks you used to create that volume form an array. Refer to the Creating Additional Volumes topic for details on how you can create two volumes across the same disks. An array can include one or two RAID volumes if the hardware allows it.

- **Volume**

A volume is the storage area on two or more disks whose type dictates the configuration of the data stored. If you created a volume for data protection, then your storage system may include a RAID 1 volume spanning two SATA disks, which mirrors data on each disk.

- **Disks**

A disk (i.e., hard disk or hard disk drive) physically stores data and allows read/write data access. If a disk is used to create a volume, it becomes an array disk because it has been grouped with other disks to form an array.

The storage system can also include ATAPI devices, which cannot be used to create a volume. They are a mass storage device with a parallel interface, such as CD-ROM, DVD/Blu-ray disc, or tape drive.

5.2.1.2 Navigation

The application is organized into five main areas depicted by the top navigation buttons: Manage, Create Volume, Intel® Optane™ Memory, Performance, Settings and About.

Manage:



The 'Manage' tab has information on all the volume information along with all the devices attached to the system. We can initialize, verify, or delete a volume from this menu option. For more details on managing volumes, see subsection 5.5.

Create Volume:



The 'Create Volume' tab is used to create different RAID volumes. The supported volumes are RAID0, RAID1, RAID5 and RAID10. For more details on creating volumes see subsection 5.6.

Intel® Optane™ Memory:



The 'Intel® Optane™ Memory' tab allows the user to enable, disable or manage Optane memory stick attached to the system. It also provides the menu for pinning files/folders or applications. For more details on creating, deleting or managing Optane volumes see subsection 5.7.

Performance:





The 'Performance' tab provides the menu to disable or enable LPM (Link Power Management). For more details on performance see sub section 5.8

Settings:



The 'Settings' tab provides a link to enable or disable Optane notifications in windows notification settings. For more details see sub section 5.9

About:



The 'About' tab contains the version and developer information. It also provide a link to support. For more details see sub section 5.10

5.3 Storage System Status

Anytime Intel® Optane™ Memory and Storage Management is launched, the application opens to the 'Manage' area. This is where the general state of health of your storage system is reported, both in the storage system view and in details. Depending on the status, volume creation and management options may be available in order to enhance or repair your storage system.

5.3.1 Storage System View

The storage system view provides a visual representation of your storage system and displays arrays, volumes, devices, and ports. Volumes and SATA disks graphics reflect their current states, which allows you to quickly identify the element that is causing the storage system to be in a state other than normal.

Note: Hovering over a designated element in the storage system view provides a snapshot of its properties. Clicking allows you to access and manage its properties.

Overview of SATA disks attached

State	Description	Recommendation
SATA SSD	An internal SATA SSD disk is connected	None
PCIe SSD	An internal PCIe SSD (NVMe) or Optane is connected.	None
Disk unavailable	An disk has been removed from a RAID volume	Connect the removed disk or add a spare disk to start rebuilding
Internal empty port	An empty port	None

5.4 Installation/Configuration of the Intel® Optane™ Memory and Storage Management UI (RST_HSA UI)

Note: The following instructions assume that your computer meets all the requirements for supporting all the premium features of the 17.x HSA stack that you wish to test. Also,



these instructions are valid as of the 16.7 HSA and above release version. Subsequent release versions may render any part or all of these instructions invalid.

1. Before You Start:

- a) Download the latest 17.x RST release SW kit as downloaded from the Intel VIP site that supports the RST_HSA UI. You will need the following **files** from the 17.x kit:

- i) **\F6\f6flpy-64.zip**

- ii) **\HSA**

- (1) **RstHSA_17.x.x.0_x64.appxbundle**

- (2) **Dependencies\x64\Microsoft.VCLibs.appx**

- iii) **Working Internet Connection**

- b) Install the HW that you require to do the testing that you plan to do (e.g. if you plan to test RAID functionality be sure that you have the proper number of drives required for the RAID levels you wish to test, etc.)

2. OS Installation and Setup:

- i) Install Windows x64 RS4 OS; make whatever setup settings you like

- a) **Set the OS to 'Sideload mode'**

Once the OS is installed, you will need to set the OS to 'Sideload mode' mode:

- i) Go to 'Start' Menu and click on 'Settings'

- ii) In 'Settings' click on 'Update & Security'

- iii) In 'Update & Security' click on 'For developers' and set the computer to 'Sideload mode'


- b) **Install RST_HSA UI Pre-PV Dependencies**

From the RST 17.x package you will need to install the HSA dependent package for the RST_HSA UI to launch.


- i) Go to RST 17.x kit and install the following

- (1) **\HSA\Dependencies\x64\Microsoft.VCLibs.appx**

Installation of VC
Libs dependency -
Initialize



Installation of VC
Libs dependency -
Complete



3. Install the RST 17.x Driver


From the RST 17.x package you will need to install the RST 17.x driver (this will install the necessary service for the RST_HSA UI to run (**RstMwService**; this service must be running in order for the UI to launch).

- a) Go to RST 17.x kit and expand the following zip:

\F6\F6flpy-64.zip

- b) Install the RST driver using the right click method on the driver INF file:
iaStorAC.inf (right click on the file and select 'Install' from the drop-down menu)

RST Driver
Installation



- c) Restart the computer

4. If you are planning to support file pinning on the system, "Intel® Optane™ Pinning Explorer Extensions" can be installed. The purpose of the "Intel® Optane™ Pinning Explorer Extensions" is to enable pinning through file explorer.


- c) Go to RST 17.x kit and expand the following directory (obtained from obtain the zip file from step 3(a)):



\F6\6flpy-64

- d) Click on "ShellPackage.msi" to install the shell extensions.
- e) The Shell extension will appear in the "Apps & features" section in settings as a separate application.

Shell extension will appear in the "Apps & features" as "Intel® Optane™ Pinning Explorer Extensions"



- a) The Shell extension will appear in the "Apps & features" section in settings as a separate application.


Note:

1. You can only see the extension in explorer menu only when Optane is enabled.

5. Install the RST HSA UI (Intel® Optane™ Memory and Storage Management UI)


Note: The RST_HSA UI package does not contain the necessary RST driver so be sure to follow the instructions in section 3 above to install the 17.x RST driver before proceeding to step 4.a below:

- a) Go to RST 17.x kit and install the following





- b) Connect to the Internet and launch the app.
HSA GUI



Note: The internet connection is required for first launch only. However, you might need internet connection for support and online help.

This completes the RST 17.x installation and setup instructions. Any releases of the RST 17.x.x SW will likely change from these instructions. For any issues please contact the RST Customer Engineering team.

The Intel® Optane™ Memory and Storage Management UI (RST_HSA UI) combines the management of all the Intel® RST premium features into a single UWP compliant UI. The two major premium features that can be managed from this UI are the Intel® Optane™ Memory feature and the Intel® RST RAID feature.

The UI is laid out in the following functional sections and accessed through the following tabs:

5.5 Manage

This tab gives a graphical overview of the current status of the storage subsystem of the computer. It will display only those items that are controlled by the RST driver. The following are displayed

- Pass-through SATA and PCIe disks
- Empty SATA ports
- RAID volumes
- Optane volumes

You can click on each of the objects listed above to display more detail information and actions associated with each item. Available actions are dependent upon the type of object and its current usage:

- Rename volume
- Delete volume (with exception of the boot volume)
- Data verification



Manage Main View

Intel Optane™ Memory and Storage Management

Manage

- Manage
- Create Volume
- Intel Optane™ Memory
- Performance
- Settings
- About

Status

✔ Your storage system is functioning normally.

Storage System View

Click on any component below to manage its properties.

- SATA SSD (224 GB) (System)
- Internal empty port 1
- Internal empty port 2
- Internal empty port 3
- Internal empty port 4
- Internal empty port 5

Rescan

Manage Detailed Object View

Intel Optane™ Memory and Storage Management

Manage

- Manage
- Create Volume
- Intel Optane™ Memory
- Pin Files and Folders
- Pin Applications
- Performance
- Settings
- About

Status

✔ Your storage system is functioning normally.

Storage System View

Click on any component below to manage its properties.

- SATA SSD (224 GB) (System)
- Internal empty port 1
- Internal empty port 2
- Internal empty port 3
- Internal empty port 4
- Internal empty port 5

Rescan

SATA (224 GB) (System)

Controller 0, Port 0
Port Location: Internal
Status: Normal
Type: SATA SSD
Usage: Available
Size: 224 GB
Serial number: CVCV31360AM1240CGN
Model: INTEL SSD5C2CW240A3
Firmware: 400i

System disk: Yes
Password protected: No
Data disk cache: On
Native command queuing: 32
SATA transfer rate: 6Gb/s
Physical sector size: 512 Bytes
Logical sector size: 512 Bytes



5.6 Create Volume


This tab allows for the management of RAID volumes. User has the capability to do the following tasks:

- Create volume (depending on RAID level the following actions are available)
 - Disk selection
 - Selection to reserve data on one disk
 - Volume size (select a percentage to create a matrix array; 2 volumes)
 - Data strip size
 - Enable write back cache on the volume
 - Name the volume

5.6.1 RAID 0

1. Select type of volume to be created

Create Volume Main View – Select volume type





2. Select drives to be included in the volume
Create Volume Main View – Select disks

The screenshot shows the 'Create Volume' window in the Intel Optane Memory and Storage Management application. The left sidebar contains navigation options: Manage, Create Volume (selected), Intel Optane Memory, Pin Files and Folders, Pin Applications, Performance, Settings, and About. The main area is titled 'Create Volume' and includes the following options:

- Select array disks:** A list of four SATA disks. The first is 'SATA disk on Controller 0, Port 0 (224 GB) (System)' and is unchecked. The second is 'SATA disk on Controller 0, Port 2 (56 GB)' and is checked. The third is 'SATA disk on Controller 0, Port 3 (932 GB)' and is unchecked. The fourth is 'SATA disk on Controller 0, Port 5 (56 GB)' and is checked.
- Keep the data from one of selected disks?:** A radio button selection with 'No' selected.
- Volume Size:** A slider set to 112 GB.
- Data stripe size:** A dropdown menu set to 64kB.
- Enable volume write-back cache:** An unchecked checkbox.

At the bottom right, there are 'Back' and 'Next' buttons. A 'Proposed Configuration' window is open on the right, showing two 56 GB disks and a volume named 'volume_0000' with a RAID 0 type and a total size of 112 GB.

3. Create the volume
Create Volume Main View – Create volume

The screenshot shows the 'Create Volume' window in the Intel Optane Memory and Storage Management application, now at the 'Create volume' step. The left sidebar is the same as in the previous screenshot. The main area is titled 'Create Volume' and includes the following options:

- Review the selected configuration:** A text block stating: 'Review the selected configuration. This process could take a while depending on the number and size of the disks. You can continue using other applications during this time.'
- WARNING:** A yellow warning icon followed by the text: 'Completing this action will permanently delete existing data on the following disks. Back up data before continuing.'
- Delete data on:** A list of two disks with checkboxes: 'SATA disk on Controller 0, Port 2 (56 GB)' and 'SATA disk on Controller 0, Port 5 (56 GB)'. Both are checked.

At the bottom right, there are 'Back' and 'Create Volume' buttons. The 'Proposed Configuration' window on the right is the same as in the previous screenshot.



4. Volume is created and can be seen under manage tab
Create Volume Main
View – volume
created

The screenshot displays the Intel Optane Memory and Storage Management application interface. The top navigation bar includes the Intel logo and the title "Intel® Optane™ Memory and Storage Management". A left-hand sidebar contains several menu items: "Manage" (highlighted with a mouse cursor), "Create Volume", "Intel® Optane™ Memory", "Pin Files and Folders", "Pin Applications", "Performance", "Settings", and "About". The main content area is divided into two sections. The "Status" section shows a green checkmark and the message "Your storage system is functioning normally." Below this is the "Storage System View" section, which includes the instruction "Click on any component below to manage its properties." and a list of storage components: "SATA_Array_0001" (containing two 56 GB SATA drives in RAID 0, with a tooltip showing "volume_0000 Type: RAID 0 112 GB"), "SATA SSD (224 GB) (System)", "SATA hard disk (932 GB)", "PCIe Intel® Optane™ Memory (27 GB)", "Internal empty port 1", and "Internal empty port 4". A "Rescan" button is located at the bottom right of the storage system view.



5.6.2 RAID 1

1. Select type of volume to be created

Create Volume Main View – Select volume type

Intel® Optane™ Memory and Storage Management

Manage

Create Volume

Intel® Optane™ Memory

Pin Files and Folders

Pin Applications

Performance

Settings

About

Create Volume

Name:

Select controller:

PCIe

SATA

Select volume type:

Optimized disk performance (RAID 0)

Real-time data protection (RAID 1)

Efficient data hosting and protection (RAID 5)

Balanced performance and data protection (RAID 10)

Next

Proposed Configuration

Protection

Performance

Capacity

Combine two disks to create a volume where each disk stores an exact copy of the data and provides real-time redundancy.

2. Select drives to be included in the volume

Create Volume Main View – Select disks

Intel® Optane™ Memory and Storage Management

Manage

Create Volume

Intel® Optane™ Memory

Pin Files and Folders

Pin Applications

Performance

Settings

About

Create Volume

Select array disks :

SATA disk on Controller 0, Port 0 (224 GB) (System)

SATA disk on Controller 0, Port 2 (56 GB)

SATA disk on Controller 0, Port 3 (932 GB)

SATA disk on Controller 0, Port 5 (56 GB)

Keep the data from one of selected disks?

Yes: SATA disk on Controller 0, Port 2 (56 GB)

No

Volume Size: 56 GB

Enable volume write-back cache

Initialize volume

Back Next

Proposed Configuration

56 GB

932 GB

volume_0000

Type: RAID 1

56 GB



3. Create the volume
Create Volume Main
View – Create
volume

The screenshot shows the 'Create Volume' interface in the Intel Optane Memory and Storage Management application. On the left is a navigation sidebar with options: Manage, Create Volume (selected), Intel Optane Memory, Pin Files and Folders, Pin Applications, Performance, Settings, and About. The main area is titled 'Create Volume' and contains a warning: 'WARNING: Completing this action will permanently delete existing data on the following disks. Back up data before continuing.' Below the warning, a checkbox labeled 'Delete data on:' is checked, with a dropdown menu showing 'SATA disk on Controller 0, Port 3 (932 GB)'. To the right, a 'Proposed Configuration' box shows a RAID 1 setup with two 56 GB drives. At the bottom are 'Back' and 'Create Volume' buttons.

4. Volume is created and can be seen under manage tab
Create Volume Main
View – volume
created

The screenshot shows the 'Status' screen in the Intel Optane Memory and Storage Management application. The navigation sidebar is the same as in the previous screenshot, with 'Manage' selected. The main area is titled 'Status' and shows a green checkmark with the text 'Your storage system is functioning normally.' Below this is the 'Storage System View' section, which lists various storage components: SATA Array_0000 (containing two SATA drives: 56 GB and 932 GB), SATA SSD (224 GB) (System), SATA SSD (56 GB), PCIe Intel Optane Memory (27 GB), and two internal empty ports. A 'Rescan' button is located at the bottom right.



5.6.3 RAID 5

1. Select type of volume to be created
Create Volume Main View - Select volume type

The screenshot displays the 'Create Volume' window in the Intel Optane Memory and Storage Management application. The window title is 'Intel® Optane™ Memory and Storage Management'. On the left, a navigation pane includes 'Manage', 'Create Volume' (highlighted), 'Intel® Optane™ Memory', 'Performance', 'Settings', and 'About'. The main area is titled 'Create Volume' and contains the following elements:

- Name:** A text input field containing 'volume_0000'.
- Select controller:** Radio buttons for 'PCIe' and 'SATA' (selected).
- Select volume type:** Radio buttons for 'Optimized disk performance (RAID 0)', 'Real-time data protection (RAID 1)', 'Efficient data hosting and protection (RAID 5)' (selected), and 'Balanced performance and data protection (RAID 10)'.
- Next:** A blue button with a mouse cursor over it.

On the right side, a 'Proposed Configuration' panel shows three horizontal bars: 'Protection' (full blue), 'Performance' (partial blue), and 'Capacity' (partial blue). Below these bars, a text box explains: 'Combine three or more disks to create a volume that uses striping with parity to maintain data redundancy. This allows you to replace a disk without interruption.'



2. Select drives to be included in the volume
Create Volume Main View – Select disks

Intel Optane™ Memory and Storage Management

Manage

Create Volume

Intel Optane™ Memory

Performance

Settings

About

Create Volume

Select array disks:

- SATA disk on Controller 0, Port 0 (224 GB) (System)
- SATA disk on Controller 0, Port 2 (56 GB)
- SATA disk on Controller 0, Port 3 (932 GB)
- SATA disk on Controller 0, Port 5 (56 GB)

Keep the data from one of selected disks?

No

Volume Size: 112 GB

Data stripe size: 128kB

Enable volume write-back cache

Initialize volume

Proposed Configuration

56 GB	volume_0000 Type: RAID 5 112 GB
932 GB	
56 GB	

Back Next

3. Create the volume
Create Volume Main View – Create volume

Intel Optane™ Memory and Storage Management

Manage

Create Volume

Intel Optane™ Memory

Performance

Settings

About

Create Volume

Review the selected configuration. This process could take a while depending on the number and size of the disks. You can continue using other applications during this time.

WARNING: Completing this action will permanently delete existing data on the following disks. Back up data before continuing.

Delete data on:

- SATA disk on Controller 0, Port 2 (56 GB)
- SATA disk on Controller 0, Port 3 (932 GB)
- SATA disk on Controller 0, Port 5 (56 GB)


Proposed Configuration

56 GB	volume_0000 Type: RAID5 112 GB
932 GB	
56 GB	

Back Create Volume




4. Volume is created and can be seen under manage tab
Create Volume Main View – volume created




5.6.4 RAID 10

1. Select type of volume to be created
Create Volume Main View – Select volume type






2. Select drives to be included in the volume
Create Volume Main View – Select disks




3. Volume is created and can be seen under manage tab
Create Volume Main View – Create volume





4. Volume is created and can be seen under manage tab
Create Volume Main
View – volume
created



5.7 Intel® Optane™ Memory

This tab allows for the management of Accelerated Optane™ volume. There is a graphical view of the Optane™ volume and its member disks. User can click on either object in the volume and the UI will display detailed information associated with the object.

Actions available to the user are:

- Enable Optane
- Disable Optane

5.7.1 Enable Intel® Optane™ Memory Volume



Intel® Optane™ Memory Main View

The screenshot shows the 'Intel® Optane™ Memory and Storage Management' application. On the left is a navigation menu with options: Manage, Create volume, Intel® Optane™ Memory (selected), Performance, Settings, and About. The main content area shows the status as 'Disabled'. Below this, there are two dropdown menus: 'Select fast Intel® Optane™ memory drive:' (set to '32 GB Intel® Optane™ Memory (Controller 13, Port 0)') and 'Select a compatible drive to be accelerated:' (set to 'INTEL HBRPEKNX0203A (Controller 14, Port 0) (SYSTEM)'). At the bottom right, a blue button labeled 'Enable Intel® Optane™ Memory' is highlighted with a red box and a red arrow pointing to it.

Starting with RST driver version 17.8.0.1034 and UI version 17.8.1001.0 or later, for Hybrid Intel® Optane™ drive (e.g. Intel® Optane™ Memory H10), Intel® Optane™ Memory and Storage Management UI will present a Mode selection screen.

Intel® Optane™ Memory Mode Selection for Intel® Optane™ Memory H10 Only

The screenshot shows the 'Intel® Optane™ Memory and Storage Management' application in the mode selection screen. The navigation menu is the same as in the previous screenshot. The main content area is titled 'Choose mode for Intel Optane Memory'. It asks the user to select a mode for the Intel Optane Memory Volume. There are two radio button options: 'Performance Mode' (selected) and 'Responsiveness Mode'. Below each option is a brief description and a note. At the bottom, there is a link for more information: <http://www.intel.com/support/optane-memory>. At the very bottom, there are two buttons: 'Back' and 'Next'.



Intel® Optane™
Memory Enable
Verify View

The screenshot shows the 'Intel® Optane™ Memory and Storage Management' window. On the left is a navigation pane with options: Manage, Create Volume, Intel® Optane™ Memory (selected), Pin Files and Folders, Pin Applications, Performance, Settings, and About. The main content area is titled 'Intel® Optane™ Memory Status'. It contains a warning icon and text: 'WARNING: This process will erase all data on Intel® Optane™ memory module. Please back-up any data on this module before continuing.' Below this is a note: 'NOTE: This process WILL NOT erase data on any other drives in your system.' A checkbox labeled 'Erase all data on Intel® Optane™ memory module.' is checked. At the bottom right are two buttons: 'Cancel' and 'Enable'.

Intel® Optane™
Memory Restart
after Enable

The screenshot shows the 'Intel® Optane™ Memory and Storage Management' window. The navigation pane is the same as in the previous screenshot. The main content area is titled 'Restart Is Required'. It contains the text: 'To work with Intel® Optane™ memory, restart is required.' Below this text is a single button labeled 'Restart'.



Intel® Optane™
Memory Status
View

Intel® Optane™ Memory Module Usage info in Intel® Optane™ Memory tab shall present 3 categories of items:

Category	Metric	Tool tip text	How statistics is calculated
Auto-managed/system files	GB (% of total)	- Auto-managed/system files – This portion is not available for end user pinning, it is automatically controlled and managed by the driver	Block cache + system files
User-pinned content	GB (% of total)	- User-Pinned Content – This portion is available for end user pinning, it represents content currently pinned by the end user or enabled applications.	Hard pinned files + Soft pinned (user pinned Apps, pinned by SDK via API, space used by NGSA
Unused Space	GB (% of total)	- Unused Space – This portion is available for end user pinning. It is auto-managed by the driver and may not represent all space available for end user pinning.	Unused space + space used by NGSA

Starting with RST driver version 17.8.0.1034 and UI version 17.8.1001.0 or later, for Hybrid Intel® Optane™ drive (e.g. Intel® Optane™ Memory H10), Below is the status screen when the end user select "Performance Mode".



Intel® Optane™
Memory Status
View for Intel®
Optane™ Memory
H10 with [File Cache
disabled](#).

The screenshot shows the 'Intel® Optane™ Memory and Storage Management' window. The left sidebar contains navigation options: Manage, Create volume, Intel® Optane™ Memory (selected), Pin Files and Folders, Pin Applications, Performance, Settings, and About. The main content area is titled 'Intel® Optane™ Memory Status' and shows a green checkmark indicating that Intel® Optane™ memory is enabled and accelerating the system. A 'Disable' button is visible. Below this, the 'Total Installed System Memory' is shown as 48 GB, which is the sum of 32 GB Intel® Optane™ Memory and 16 GB RAM. The 'Intel® Optane™ Memory Volume Configuration' section lists 'PCIe Intel® Optane™ Memory (27 GB)' with firmware K5110440 and 'PCIe SSD (954 GB)' with firmware TGF050K, with a total usable drive capacity of 954 GB. An 'Info' section at the bottom states: 'Pinning is not available in Performance mode. In order to utilize Pinning, please enable Intel® Optane™ memory in Custom Responsiveness mode.' A red box highlights this information. A green arrow points from the 'Pin Files and Folders' option in the sidebar to the 'Total Installed System Memory' section. Another green arrow points from the 'Info' section to the 'Pin Files and Folders' option. A red text box on the right side of the screenshot reads: 'When File Cache is disabled for Intel Optane Memory H10: - Optane Pinning for Files/Folders/Applications is not available. - Message informing end-user in UI'.

5.7.2 Disable Intel® Optane™ Memory Volume



Intel® Optane™ Memory Main View

Intel® Optane™ Memory and Storage Management

Manage
Create volume
Intel® Optane™ Memory
Pin Files and Folders
Pin Applications
Performance
Settings
About

Intel® Optane™ Memory Status
✓ Intel® Optane™ memory is enabled and accelerating your system. **Disable**

Total Installed System Memory
126 GB = 110 GB Intel® Optane™ Memory + 16 GB RAM

Intel® Optane™ Memory Volume Configuration

- PCIe Intel® Optane™ Memory (110 GB)
Firmware: K4110411
- SATA hard disk (932 GB)
Firmware: SDM1

Usable Drive Capacity: 932 GB

Module Usage

Category	Amount	Percentage
Auto-managed/system files	48.6 GB	(44.1%)
User-pinned content	0 GB	(0.0%)
Unused Space	61.4 GB	(55.9%)

Optimization Schedule

Last Optimization	8/29/2019 3:46 AM
Next Optimization	8/30/2019 2:00 AM

Intel® Optane™ Memory Disabling status View


Intel® Optane™ Memory and Storage Management

Manage
Create Volume
Intel® Optane™ Memory
Performance
Settings
About

Preparing system ...



Intel® Optane™ Memory Restart View




Also, under this tab are two subtabs:

5.7.3 Pin Files and Folders


Note: Pinning is not available for 16GB memory module SKUs and for data drive acceleration (DDA). This tab allows the user to select files or folders to pin into the file cache



Intel® Optane™ Memory Pin Files and Folders View



Intel® Optane™ Memory Currently Pinned Files and Folders View





5.7.4 Pin Applications

This tab allows the user to select applications to pin into the file cache.

Intel® Optane™
Memory Currently
Pinned Applications
View

The screenshot shows the Intel Optane Memory and Storage Management application window. The title bar reads "Intel® Optane™ Memory and Storage Management". On the left is a navigation pane with the following items: "Manage" (wrench icon), "Create Volume" (plus icon), "Intel® Optane™ Memory" (circular arrow icon, currently selected), "Pin Files and Folders" (pin icon), "Pin Applications" (pin icon, highlighted in blue), "Performance" (checkmark icon), "Settings" (gear icon), and "About" (info icon). The main content area is titled "Pinned Applications". It contains the text: "Pinning applications ensures they will always benefit from the speed and responsiveness of Intel® Optane™ memory." and "Applications can be pinned or unpinned using the buttons below." Below this text is a list of pinned applications, currently showing "SetupOptaneMemory". At the bottom of the list are two buttons: "Unpin" and "+ Application" (with a refresh icon).

5.8 Performance

This tab allows for the enablement/disablement of Link Power Management (LPM) of SATA devices


Performance

The screenshot shows the Intel Optane Memory and Storage Management application window. The title bar reads "Intel® Optane™ Memory and Storage Management". On the left is a navigation pane with the following items: "Manage" (wrench icon), "Create Volume" (plus icon), "Intel® Optane™ Memory" (circular arrow icon), "Performance" (checkmark icon, highlighted in blue), "Settings" (gear icon), and "About" (info icon). The main content area is titled "Configure power and performance settings". It contains the text: "Link Power Management" and "Link Power Management helps the SATA device save power during idle time when there is no I/O activity or when devices are absent or unused." Below this text is a toggle switch labeled "Disabled".


5.9 Settings

We can use this tab to change notification settings. The link in these settings will open the windows notification center to change Notification settings for Intel® Optane™ Memory Storage and Management UI.

Settings tab –
Notification Settings
and Automatic
rebuild



Notification settings
in Windows





5.10 About

This tab allows you to get version information about the App and contact Intel® help and support.

About the Application

The screenshot shows the Intel Optane Memory and Storage Management application interface. The left sidebar contains the following menu items: Manage, Create Volume, Intel Optane Memory, Performance, Settings, and About (which is highlighted). The main content area displays the following information:

- Intel® Optane™ Memory and Storage Management**
- Product Version : 17.0.9231.0
- Driver Version : 17.0.0.1051
- Copyright © 2018
- For help and support visit: <http://intel.com/support/optane-memory>.
- Additional components**
- NLog for .NET Platform Standard 1.3 5.0.0-beta11
- Copyright (c) 2004-2016 Jaroslaw Kowalski, Kim Christensen, Julian Verdurmen
- BSD 3-clause "New" or "Revised" License [view full text](#)
- Autofac 4.6.2
- Copyright © 2015 Autofac Contributors
- MIT License [view full text](#)
- Json.NET .NET Standard 2.0 11.0.2
- Copyright © James Newton-King 2008
- MIT License [view full text](#)

5.11 Additional operations in Intel® Optane™ Memory and Storage Management UI

Note: These features are apply to all combinations of HSA UI 17.x and 17.x RST driver version and above. If either of 16.7 HSA UI or 16.7 Driver is installed on the system then it will have some limitations. For more details on the behavior, refer to section 5.12.

5.11.1 User Pinning of Files/Folders/Applications

5.11.1.1 Limitations

Limitations The following objects as seen on the Windows desktop cannot be pinned:

1. Quick Access
2. This PC
3. Any disk's Root directory (e.g. Local Disk (C:))
4. Control Panel
5. Libraries folder
6. Network objects
7. Recycle Bin

Minimum Requirements

The minimum requirements to support the User Pinning feature are as follows:



1. Optane™ capable motherboard
2. Intel® 8th generation core i-processor
3. Intel® 300/240 Series Chipset Family (see table 2-3 for supported SKUs)
4. 32GB or larger Intel® Optane™ memory module installed in a PCH HW remapped port or in a PEG port supporting Intel® RST CPU attached Storage
5. Windows 10 64bit (RS3 or later) installed
6. Intel® RST 16.x PV or later release installed
7. System Acceleration with Intel® Optane™ Memory enabled


5.11.1.2 Pinning using the Intel® Optane™ Memory and Storage Management UI

Pinning Tab: The following instructions assume that the computer supports Intel® Optane™ Memory and is already properly configured and enabled to support the User Pinning feature (see the minimum requirements for the pinning feature in the preceding section).

1. Launch the Intel® Optane™ Memory and Storage Management UI
2. In the left navigation pane, click on the Intel® Optane™ Memory tab to expand it.

The page displays information on Optane™ Memory status and a graphic of the current Optane™ Volume configuration.

Intel® Optane™
Memory Main Page




Pin Files and Folders tab:

Click on the 'Files' tab to launch the 'Currently Pinned Files and Folders' page



Currently Pinned
Files and Folders
Page



How-to pin files:

1. Click [+Files] button; this launches file explorer
2. Browse to the file you wish to pin and do one of the following:
 - a. double click on the file to pin it
 - b. click on the file to highlight it, then click the [Open] button to pin it
3. To pin multiple files in the same folder, click on one file then use either the <Shift> key to highlight the multiple sequential files or use the <Ctrl> key to select multiple files

How-to pin folders:

1. Click [+Folder] button; this launches the 'Browse for Folder' window.
2. Browse to the folder you wish to pin and click to highlight it

Note: Only the files directly in the folder will be pinned. Subfolders will not be pinned. If there are only subfolders and no individual files in the folder, then pinning the folder will only pin an empty folder.

3. Click [Select Folder] to pin the folder

How-to Unpin files/folders:

1. While in the 'Currently Pinned Files and Folders' window, use the left click button of the mouse to click through the file structure


until you find the file/folder that you wish to unpin. Click on the file/folder to highlight it (multiple files/folders cannot be selected for unpinning operation)

2. Click the [Unpin] button to unpin the file/folder

Applications Sub-Tab:

Click on the 'Applications' tab to launch the 'Currently Pinned Applications' page

Currently Pinned Applications Page



How-to pin applications:

1. Click [+Application] button; this launches the Windows file Explorer window.
2. Browse to the application that you wish to pin and do one of the following:
 - a. double click on the file to pin it
 - b. click on the file to highlight it, then click the [Open] button to pin it

How-to Unpin applications:

1. While in the 'Currently Pinned Applications' window, use the left click button of the mouse to highlight the application you wish to unpin
2. Click the [Unpin] button to unpin the application

5.11.2 Adding a disk to an Array

You can add one or more SATA disks to an existing array to increase the system storage capacity.

This feature can be useful if you want to change to a volume type that requires additional disks.

This option is only available if:

- A RAID 0 and/or RAID 5 volume is present,
- One or more SATA disks are connected to the computer and available,
- The available disk matches the internal or external connection type of the existing array disks.




You cannot add an external disk to an array that includes internal disks, and vice versa.

This action can also be performed from Manage Volume.

1. Under 'Status' or 'Manage', in the storage system view, click the array to which you want to add a disk. The element properties are now displayed on the left.
2. Click 'Add disk'.


Select the option to add disk to a volume.



3. Select the disk you want to use to increase the array capacity.




Add disk to the volume



3. Click 'Add Disk'.

Disk added to the volume



Caution: Once the data migration starts, the operation cannot be canceled.

4. Once the migration has completed, restart your computer for changes to take effect. Then use Windows Disk Management* to increase the partition size on the volumes for which a disk was added, or add another partition.




5.11.3 Creating a Matrix Array

You can create a Matrix array as well. This feature can be useful if you want to have multiple RAID configurations in a single array.

This action can also be performed from Manage Volume.


1. Under 'Status' or 'Manage', in the storage system view, click the array to which you want to add another RAID configuration. The element properties are now displayed on the left.
2. Click 'Create additional volume'.

Select the option to 'Create additional volume' to a RAID volume.




3. Select the disks you want to type of volume (RAID0 or RAID) to be added to the existing array and click 'Create Volume'.

Select the second RAID configuration of the Matrix Volume. Click 'Create Volume'



4. Matrix Volume created.

Matrix Volume created



Caution: Once the data migration starts, the operation cannot be canceled.

- Once the migration has completed, restart your computer for changes to take effect. Then use Windows Disk Management* to increase the partition size on the volumes for which a disk was added, or add another partition.



5.11.4 Deleting a RAID Volume

RAID volumes can be deleted in three different ways. The method most widely used by end-users is the Windows user interface utility. The second method is to use the Intel Rapid Storage Technology Option ROM user interface. The third way, used by OEMs only, uses the RAID Configuration utility.


1. Run the Intel® Optane™ Memory and Storage Management UI from the following Start menu

link:

Start -> All Programs -> Intel® Optane™ Memory and Storage Management -> Intel® Optane™ Memory and Storage Management UI

2. Under 'Status' or 'Manage' Click on the volume you want to delete. The user will be presented with the volume properties on the left.


Selected Volume to be deleted



3. Click on 'Delete volume'.



Delete the Volume




4. Review the warning message, and click 'Yes' to delete the volume.
5. The 'Status' page refreshes and displays the resulting available space in the storage system view. You can now use it to create a new volume.

5.11.5 Using Optane with Cached data from another system

We cannot use the Optane module from another system without resetting the Metadata. If we try to use an Optane memory which has already been used by another system for caching and not been disabled before being added to this system. We get a prompt as given below:



Optane memory not detected as it has Optane volume from another system (OS)



Note:

- 1. We can clear metadata in BIOS. Please note that different mother boards will have different interfaces, they have similar steps for clear metadata.**
- 2. In BIOS, it could also be referred as "Reset Metadata", "Reset to Non-Optane", convert to "Non-RAID", "remove/delete RAID data" instead of "Clear Metadata". This metadata has information.**
- 3. The steps to locate the RST Menu in BIOS may vary depending upon the manufacturer. Please refer to your manufacturer support or documentation to locate the RST menu.**

The Steps for clearing the metadata from BIOS are given below:

1. Open BIOS Settings. Enter the EFI Device Manager.


Open BIOS menu



2. Open Intel ® Rapid Storage Technology Settings




Open EFI Device manager



- Here we have all the RST Volumes listed here. Optane is also listed among the non-RAID volumes as although it has RAID metadata, it has information on whether the Optane disk is currently enable with acceleration and has cache data rather than the RAID information as Optane is not used to create RAID volumes. Select Optane disk among the Non-RAID physical disks mentioned in the list.


Select Optane



- Select the Volume and delete the RST metadata on the Optane disk and convert it back into "non-Optane" which means it does not have any cached data.




Remove Optane volume (Cached data) from Optane



5. Confirm deletion of the Optane structure on disk.

Confirm deletion



6. Disk is now Non-Optane which means that the RST Metadata has been cleared or reset.


Select Optane to check status





7. Select the Optane disk and you will notice that the properties are displayed for the Optane disk instead of a prompt "Reset to Non Optane" which confirms that RST metadata has been reset for Optane.

Selected Optane with no Optane volume shows disk attributes instead of deletion option



5.11.6 Marking a Disk as a Spare

This action is only available for non-system disks in a normal state. Also, unless your mobile computer is equipped with the Intel® 5 Series Chipset or later, which provides support for up to six SATA ports, you will not be able to mark a disk as a spare. Most mobile computers are limited to one internal and one external disk, which are used to create the volume.

Marking a disk as a spare allows you to designate an available SATA disk as the default destination for automatic volume rebuilds in the event of a failed, missing or at risk array disk. However, for RAID 0 volumes, automatic rebuilds will only occur if one of its members is reported at risk.

1. Under 'Status' or 'Manage', in the storage system view, click the disk that you want to mark as a spare. The volume properties are now displayed on the left.
2. Click 'Mark as spare'.
3. Click 'OK'.

Note: RAID 1, 5, 10, and recovery volumes can use one or more spares.

If your system is running a version of the RST OROM that does not support disks that are 2TB or larger, you can reset such a disk to available, but disallow the marking of it as a spare.



Selecting the disk to be marked as spare

The screenshot shows the Intel Optane Memory and Storage Management application window. The left sidebar contains a 'Manage' menu with options: 'Create Volume', 'Intel Optane Memory', 'Performance', 'Settings', and 'About'. The main area is titled 'Status' and shows 'Your storage system is functioning normally.' Below this is the 'Storage System View' section, which lists various storage components: 'SATA Array_0000' (containing two 932 GB SATA drives and a RAID 1 volume of 457 GB), 'SATA SSD (224 GB) (System)', 'SATA SSD (112 GB)', 'SATA hard disk (932 GB)' (highlighted in blue), 'SATA SSD (224 GB)', and 'PCIe SSD (27 GB)'. A 'Rescan' button is located at the bottom right. A tooltip for the selected 'SATA (932 GB)' drive is visible on the right, showing details such as 'Controller 0, Port 2', 'Status: Normal', 'Type: SATA hard disk', 'Usage: Available', 'Size: 932 GB', 'Serial number: WD-WXK1A37FYK9Y', 'Model: WDC WD10SPZX-21Z10T0', 'Firmware: 02.01A02', and 'Logical sector size: 512 Bytes'.


4.

Marking a disk as spare

The screenshot shows the 'Mark as spare' dialog box in the Intel Optane Memory and Storage Management application. The left sidebar is the same as in the previous screenshot. The main area is titled 'Mark as spare' and contains a warning message: 'WARNING: Completing this action will permanently delete existing data on the disk. Back up data before continuing.' Below the warning is a 'More help' link and two buttons: 'Cancel' and 'Mark as spare'.



Marking a disk as available




5.11.7 Clear Metadata


All the Volumes maintained by RST driver has a metadata maintained by RST driver. This metadata is used by RST only for managing RAID Volumes as well as Optane volumes. This metadata is written every time a volume (RAID/Optane) is created and is destroyed by deleting the volume (or disabling acceleration). If any device is a part of a volume and is moved to another system then the drive has metadata but does not have related volume making it unusable to be used for RAID configuration. In this case the metadata is of no use and we can reset it such that the drive can be used for another RAID configuration.



We get "Clear Metadata" Option for disk with



select "Clear Metadata" Option to clear the RST Metadata



- 1. We can clear metadata in BIOS. Please note that different motherboards will have different interfaces; they have similar steps for clear metadata.**



- 2. In BIOS, it could also be referred to as "Reset Metadata" or convert to "Non-RAID", "remove/delete RAID data" instead of "Clear Metadata". This metadata has information.**
- 3. The steps to locate the RST Menu in BIOS may vary depending upon the manufacturer. Please refer to your manufacturer's support or documentation to locate the RST menu.**

The Steps for clearing the metadata from BIOS are given below:


1. Open BIOS Settings. Enter the EFI Device Manager.

BIOS main page



2. Open Intel ® Rapid Storage Technology Settings


Device manager
Menu



3. Here we have all the RST Volumes listed here. If some of the volumes will have storage drives associated with them missing then it is shows as a degraded volume. In case any drive used here contains any RST metadata, then the drive will show the volume it was a part of and is marked as failed or degraded.




Select RST BIO
(PreOS)
management.



4. Select the disk in the volume and it will list the RAID information for all attached disks for that volume.


Select the disk in
the degraded/failed
"RAID" volume



5. Delete the RAID information for that disk and convert it to non-RAID




Delete the RAID information on the disk



Note: The option shows the RAID volume information of the degraded volume and this disk was a part of that volume and has such data in its metadata having information about the volume.

6. Confirm deletion of the RAID data.


Confirm deletion of Metadata



7. Disk is now Non-RAID which means that the RST Metadata has been cleared or reset.



RAID information deleted. The disk is now non-RAID



5.12 HSA 16.7 - Optane™ Memory and Storage Management UI Functionality Limitations

5.12.1 Creating a RAID Volume with a disk containing user data

RAID volumes can be created in three different ways. The method most widely used by end-users is the Windows user interface utility. The second method is to use the Intel Rapid Storage Technology Option ROM user interface. The third way, used by OEMs only, uses the RAID Configuration utility.


While the RAID can be created in many ways a recent change does not allow a volume to be created if any of the disk used by it has user data on it.

To verify the behavior we can follow these steps:


1. Run the Intel® Optane™ Memory and Storage Management UI from the following Start menu link:
Start -> All Programs -> Intel® Optane™ Memory and Storage Management -> Intel® Optane™ Memory and Storage Management UI.
2. Under 'Status' or 'Manage' Click on the volume you want to delete. The user will be presented with the volume properties on the left.



Select a RAID volume to create




Select disks to be included in RAID volume including a disk with user data



3. Click on 'Create Volume'. It is disabled as one of the disk has user data



“Create Volume”
button is disabled
as disk contains
user data



Note: A disk is considered to have user data if the drive has a valid partition table.

- To use the disk with create volume you need to use the 'diskpart' utility as shown in Sub Section 7 Un-initialize disk such that it can be used with the HSA App.
- We need to click on the "rescan" button in "Manage" menu if changes are not reflected after cleaning disk with diskpart.

5.12.2 Deleting a RAID Volume

RAID volumes can be deleted in three different ways. The method most widely used by end-users is the Windows user interface utility. The second method is to use the Intel Rapid Storage Technology Option ROM user interface. The third way, used by OEMs only, uses the RAID Configuration utility.

5.12.2.1 Using the Intel® Optane™ Memory and Storage Management UI

- Run the Intel® Optane™ Memory and Storage Management UI from the following Start menu link:
Start -> All Programs -> Intel® Optane™ Memory and Storage Management -> Intel® Optane™ Memory and Storage Management UI
- Under 'Status' or 'Manage' Click on the volume you want to delete. The user will be presented with the volume properties on the left.



Selected Volume to be deleted

The screenshot shows the Intel Optane Memory and Storage Management application. The left sidebar contains navigation options: Manage, Create Volume, Intel® Optane™ Memory, Pin Files and Folders, Pin Applications, Performance, Settings, and About. The main area displays the 'Storage System View' with a status message: 'Your storage system is functioning normally.' Below this, a list of storage components is shown: SATA_Array_0000 (containing two 56 GB SATA drives), SATA SSD(224 GB) (System), PCIe SSD(27 GB), and three internal empty ports. A blue callout box highlights 'volume_0002' (Type: RAID 0, 112 GB) in the SATA_Array_0000 section. A right-hand panel shows the details for 'volume_0002': Status: Normal, System volume: False, Initialized: Yes, and links for Rename volume, Delete volume, and Verify. A 'Rescan' button is located at the bottom right of the storage system view.

8. Click on 'Delete volume'.

Delete the Volume

The screenshot shows the 'Delete volume' dialog box for 'volume_0002'. The title bar reads 'volume_0002: Delete volume'. The dialog contains a 'Cancel' button and a 'Delete' button with a mouse cursor over it. A 'More help' link is visible below the buttons. The left sidebar is identical to the previous screenshot.

9. Review the warning message, and click 'Yes' to delete the volume.

10. The 'Status' page refreshes and displays the resulting available space in the storage system view. You can now use it to create a new volume.




5.12.2.2 Delete a RAID volume with a disk containing user data

1. Run the Intel® Optane™ Memory and Storage Management UI from the following Start menu link:

Start -> All Programs -> Intel® Optane™ Memory and Storage Management -> Intel® Optane™ Memory and Storage Management UI.

2. Under 'Status' or 'Manage' Click on the volume you want to delete. The user will be presented with the volume properties on the left.
3. Click on 'Delete Volume'.

Delete button is disabled as disk contains user data



Note: A disk is considered to have user data if the drive has a valid partition table.

4. To delete the disk you need to use the diskpart utility as shown in

Sub Section 7 Un-initialize disk such that it can be used with the HSA App.

Note: We need to click on the "rescan" button in "Manage" menu if changes are not reflected after cleaning disk with diskpart.

5. Run the Intel® Optane™ Memory and Storage Management UI from the following Start menu link:

Start -> All Programs -> Intel® Optane™ Memory and Storage Management -> Intel® Optane™ Memory and Storage Management UI.

6. Under 'Status' or 'Manage' Click on the volume you want to delete. The user will be presented with the volume properties on the left.



Again select the volume to be deleted

Intel Optane™ Memory and Storage Management

Manage

- Create Volume
- Intel® Optane™ Memory
- Performance
- Settings
- About

Status

Your storage system is functioning normally.

Storage System View

Click on any component below to manage its properties.

SATA_Array_0000

- SATA (56 GB) **volume_0007**
Type: RAID 0
112 GB
- SATA (56 GB)

SATA SSD(224 GB) (System)

PCIe SSD(27 GB)

Internal empty port 1

Internal empty port 2

Internal empty port 3

Rescan

7. Click on 'Delete Volume'.

Delete button enabled as it does not contain user data anymore

Intel Optane™ Memory and Storage Management

Manage

- Create Volume
- Intel® Optane™ Memory
- Performance
- Settings
- About


volume_0007: Delete volume

Cancel Delete

[More help](#)



The volume successfully deleted



5.12.3 Marking a Disk as a Spare

5.12.3.1 Using the Intel® Optane™ Memory and Storage Management UI

This action is only available for non-system disks in a normal state. Also, unless your mobile computer is equipped with the Intel® 5 Series Chipset or later, which provides support for up to six SATA ports, you will not be able to mark a disk as a spare. Most mobile computers are limited to one internal and one external disk, which are used to create the volume.

Marking a disk as a spare allows you to designate an available SATA disk as the default destination for automatic volume rebuilds in the event of a failed, missing or at risk array disk. However, for RAID 0 volumes, automatic rebuilds will only occur if one of its members is reported at risk.

5. Under 'Status' or 'Manage', in the storage system view, click the disk that you want to mark as a spare. The volume properties are now displayed on the left.
6. Click 'Mark as spare'.
7. Click 'OK'.

Note: RAID 1, 5, 10, and recovery volumes can use one or more spares.

If you system is running a version of the RST OROM that does not support disks that are 2TB or larger, you can reset such a disk to available, but disallow the marking of it as a spare.



Marking a disk as spare

The screenshot shows the Intel Optane Memory and Storage Management application. The left sidebar contains navigation options: Manage, Create Volume, Intel® Optane™ Memory (selected), Performance, Settings, and About. The main window displays the 'Storage System View' with a status message: 'Your storage system is functioning normally.' Below this, a list of storage components is shown: SATA SSD(224 GB) (System), SATA SSD(56 GB) (selected), PCIe SSD(27 GB), and five Internal empty ports. A tooltip for the selected SATA SSD(56 GB) provides detailed information: Controller 0, Port 2; Port Location: Internal; Status: Normal; Type: SATA SSD; Mark as Spare (highlighted); Usage: Available; Size: 56 GB; Serial number: CVMF21600357060AGN; Model: INTEL.SSD5CZCT060A3; Firmware: 300i. Additional details include System disk: No, Password protected: No, Data disk cache: On, Native command queuing: 32, SATA transfer rate: 66Gb/s, Physical sector size: 512 Bytes, and Logical sector size: 512 Bytes. A Rescan button is located at the bottom right of the storage list.

5.12.3.2 Mark a disk as spare with user data:

"Mark as spare" disabled as disk contains user data

The screenshot shows the Intel Optane Memory and Storage Management application with the 'Mark as spare' dialog box open. The left sidebar is the same as in the previous screenshot. The main window displays the 'Mark as spare' title and a warning message: 'The operation cannot be performed because one or more of the selected disk(s) contains data. To continue, please back up all data and erase data on the select disk(s). Click Help for detailed instructions'. Below the message are two buttons: 'Cancel' and 'Mark as spare' (disabled). A 'Help' link is also present at the bottom left of the dialog.

Note: To use the disk with create volume you need to use the diskpart utility as shown in

Sub Section 7 Un-initialize disk such that it can be used with the HSA App.



We need to click on the "rescan" button in "Manage" menu if changes are not reflected after cleaning disk with diskpart.

5.12.4 Adding a disk to an Array

5.12.4.1 Using the Intel® Optane™ Memory and Storage Management UI

You can add one or more SATA disks to an existing array to increase the system storage capacity. This feature can be useful if you want to change to a volume type that requires additional disks. This option is only available if:

- A RAID 0 and/or RAID 5 volume is present,
- One or more SATA disks are connected to the computer and available,
- The available disk matches the internal or external connection type of the existing array disks.


You cannot add an external disk to an array that includes internal disks, and vice versa.

Refer to Connecting a Disk under Managing Disks for more information on installing SATA disks on your computer.

This action can also be performed from Manage Volume. Refer to the Adding a Disk to a Volume section for more information.

1. Under 'Status' or 'Manage', in the storage system view, click the array to which you want to add a disk. The element properties are now displayed on the left.
2. Click 'Add disk'.

Select the option to add disk to a volume.





3. Select the disk you want to use to increase the array capacity.

Add disk to the volume

Intel® Optane™ Memory and Storage Management

Add Disk

Select array disks :

- SATA disk on Controller 0, Port 3 (56 GB)
- SATA disk on Controller 0, Port 4 (56 GB)
- SATA disk on Controller 0, Port 5 (56 GB)
- SATA disk on Controller 0, Port 1 (56 GB)

Once the migration is complete, you will need to restart your computer for the operating system to recognize the new volume size. Also, you will need to extend the existing partition or create a new partition to utilize any new volume space, using Windows Disk Management*

You can continue using other applications during this time.

Cancel **Add disk**

[More help](#)

6. Click 'Add Disk'.

Disk added to the volume

Intel® Optane™ Memory and Storage Management

Status

Your storage system is functioning normally.

Storage System View

Click on any component below to manage its properties.

SATA_Array_0000

- SATA (56 GB)
- SATA (56 GB)
- SATA (56 GB)
- SATA (56 GB)
- SATA SSD(224 GB) (System)
- PCIe SSD(27 GB)
- Internal empty port 2

Rescan

volume_0000
Type: RAID 5
112 GB

volume_0000

Status: **Migrating**
System volume: **False**
Initialized: **Yes**
[Rename volume](#)
[Delete volume](#)
[Verify](#)

Type: **RAID 5**
Size: **112 GB**
[Increase size](#)
Data stripe size: **32kB**
Physical sector size: **512**
Logical sector size: **512**

Caution: Once the data migration starts, the operation cannot be canceled.

7. Once the migration has completed, restart your computer for changes to take effect. Then use Windows Disk Management* to increase the partition size on the volumes for which a disk was added, or add another partition.



5.12.4.2 Add to a RAID volume a disk containing user data:

The user cannot add a disk to an array if the disk has user data. The HSA App would not any RAID operation on a drive that has user data. Any drive with a valid partition table is considered as a drive with user data.

Select the add disk option for a volume

The screenshot shows the 'Intel® Optane™ Memory and Storage Management' application. The left sidebar has 'Manage' selected. The main area shows 'Storage System View' for 'SATA_Array_0000'. It lists two 'SATA (56 GB)' disks. A tooltip for 'volume_0000' is displayed over the disks, showing 'Type: RAID 0' and '112 GB'. Below the disks are other storage components: 'SATA SSD(224 GB) (System)', 'SATA SSD(56 GB)', 'PCIe SSD(27 GB)', and two 'Internal empty port' entries. A 'Rescan' button is located at the bottom right.

Select the disk to be added

Add disk is disabled as the added disk contains user data

The screenshot shows the 'Add Disk' dialog in the 'Intel® Optane™ Memory and Storage Management' application. Under 'Select array disks:', three SATA disks are checked: 'SATA disk on Controller 0, Port 1 (56 GB)', 'SATA disk on Controller 0, Port 3 (56 GB)', and 'SATA disk on Controller 0, Port 5 (56 GB)'. A warning icon and message state: 'The operation cannot be performed because one or more of the selected disk(s) contains data. To continue, please back up all data and erase data on the select disk(s). Click Help for detailed instructions'. Below this, two information icons provide further details: 'Once the migration is complete, you will need to restart your computer for the operating system to recognize the new volume size. Also, you will need to extend the existing partition or create a new partition to utilize any new volume space, using Windows Disk Management*' and 'You can continue using other applications during this time.' At the bottom, there are 'Cancel' and 'Add disk' buttons. A 'Help' link is also present.



Note: To use the disk with create volume you need to use the diskpart utility as shown in


Sub Section 7 Un-initialize disk such that it can be used with the HSA App.

We need to click on the "rescan" button in "Manage" menu if changes are not reflected after cleaning disk with diskpart.

5.12.5 Using Optane disk which has user data


An Optane memory stick with user data is an Optane stick with at least a valid GPT (if not partitions). In the HSA App you cannot use any disks with user data on it. So, when we try to use such an Optane for acceleration we get a prompt restricting us to use that disk.

Select Optane with user data (valid partition table)





"Enable" button is disabled as Optane has user data.



Note: To use the disk with create volume you need to use the diskpart utility as shown in

Sub Section 7 Un-initialize disk such that it can be used with the HSA App.


We need to click on the "rescan" button in "Manage" menu if changes are not reflected after cleaning disk with diskpart.

5.12.6 Using Optane with Cached data from another system

We cannot use the Optane module from another system without resetting the Metadata. If we try to use an Optane memory which has already been used by another system for caching and not been disabled before being added to this system. We get a prompt as given below:




Optane memory not detected as it has Optane volume from another system (OS)



For this Optane memory stick you also get a "Clear Metadata" in attribute

getting "Clear Metadata" for Optane memory



Note:

- 4. We can clear metadata in BIOS. Please note that different mother boards will have different interfaces, they have similar steps for clear metadata.**
- 5. In BIOS, it could also be referred as "Reset Metadata" or convert to "Non-RAID", "remove/delete RAID data" instead of "Clear Metadata". This metadata has information.**



6. **The steps to locate the RST Menu in BIOS may vary depending upon the manufacturer. Please refer to your manufacturer support or documentation to locate the RST menu.**

The Steps for clearing the metadata from BIOS are given below:


8. Open BIOS Settings. Enter the EFI Device Manager.

Open BIOS menu



9. Open Intel ® Rapid Storage Technology Settings

Open EFI Device manager



10. Here we have all the RST Volumes listed here. Optane is also listed among the non-RAID volumes as although it has RAID metadata, it has information on whether the Optane disk is currently enable with acceleration and has cache data rather than the RAID information as Optane is not used to create RAID volumes. Select Optane disk among the Non-RAID physical disks mentioned in the list.




Select Optane




11. Select the Volume and delete the RST metadata on the Optane disk and convert it back into "non-Optane" which means it does not have any cached data.

Remove Optane volume (Cached data) from Optane



12. Confirm deletion of the Optane structure on disk.


Confirm deletion



13. Disk is now Non-Optane which means that the RST Metadata has been cleared or reset.




Select Optane to check status



14. Select the Optane disk and you will notice that the properties are displayed for the Optane disk instead of a prompt "Reset to Non Optane" which confirms that RST metadata has been reset for Optane.

Selected Optane with no Optane volume shows disk attributes instead of deletion option




5.12.7 Un-initialize disk such that it can be used with the HSA App.

We can use the "diskpart" utility inside windows to un-initialize user data in order to use the disks with HSA App. The un-initialization means that we can remove the GPT partition. It can done in steps given below:


1. Open *diskpart* utility
 - a. Open Run by pressing "Win+r" keys on the keyboard, enter diskpart and press "OK".

Open windows
"Run" utility



- b. Press "Yes" on the User Account Control prompt to run diskpart with elevated privileges. This will Open Diskpart Utility

Open "diskpart"
utility



2. Select disk to clean or uninitialized
 - a. List all the disk by using the command.

```
> list disk
```

You will note that we have an asterisk sign next to the uninitialized drive under the GPT column
 - b. Select disk to be uninitialized by using the command

```
> select disk <number>
```



Where <number> is the disk number as shown in the *list disk* command from step a.

- c. Un-initialize disk by using the command
 > *clean*

Steps to un-initialize disk such that it can be used with HSA App

```
C:\Windows\system32\diskpart.exe
Microsoft DiskPart version 10.0.17134.1
Copyright (C) Microsoft Corporation.
On computer: DESKTOP-KEIM1P4

DISKPART> list disk

   Disk ###  Status         Size      Free      Dyn  Gpt
   -----  -
   Disk 0    Online         223 GB   1024 KB
   Disk 1    Online         55 GB    55 GB
   Disk 2    Online         55 GB    55 GB

DISKPART> select disk 1

Disk 1 is now the selected disk.

DISKPART> clean

DiskPart succeeded in cleaning the disk.

DISKPART> list disk

   Disk ###  Status         Size      Free      Dyn  Gpt
   -----  -
   Disk 0    Online         223 GB   1024 KB
   * Disk 1    Online         55 GB    55 GB
   Disk 2    Online         55 GB    55 GB

DISKPART> _
```


- d. Note that the asterisk (*) sign is not anymore under to the Gpt column for the disk. Diskpart is a standard MS Disk Utility and help is available at Microsoft website. Reference: [https://docs.microsoft.com/en-us/previous-versions/windows/it-pro/windows-xp/bb490893\(v%3dtechnet.10\)](https://docs.microsoft.com/en-us/previous-versions/windows/it-pro/windows-xp/bb490893(v%3dtechnet.10))

5.12.8 Clear Metadata for RAID disks


All the Volumes maintained by RST driver has a metadata maintained by RST driver. This metadata is used by RST only for managing RAID Volumes as well as Optane volumes. This metadata is written every time a volume (RAID/Optane) is created and is destroyed by deleting the volume (or disabling acceleration). If any device is a part of a volume and is moved to another system then the drive has metadata but does not have related volume making it unusable to be used for RAID configuration. In this case the metadata is of no use and we can reset it such that the drive can be used for RAID configuration.



We get "Clear Metadata" Option for disk with RAID Metadata



When we click on "Clear Metadata" Option



- 4. We can clear metadata in BIOS. Please note that different mother boards will have different interfaces, they have similar steps for clear metadata.**
- 5. In BIOS, it could also be referred as "Reset Metadata" or convert to "Non-RAID", "remove/delete RAID data" instead of "Clear Metadata". This metadata has information.**



6. **The steps to locate the RST Menu in BIOS may vary depending upon the manufacturer. Please refer to your manufacturer's support or documentation to locate the RST menu.**

The Steps for clearing the metadata from BIOS are given below:


8. Open BIOS Settings. Enter the EFI Device Manager.

BIOS main page



9. Open Intel ® Rapid Storage Technology Settings


Device manager Menu



10. Here we have all the RST Volumes listed here. If some of the volumes will have storage drives associated with them missing then it is shown as a degraded volume. In case any drive used here contains any RST metadata, then the drive will show the volume it was a part of and is marked as failed or degraded.




Select RST BIO
(PreOS)
management.



11. Select the disk in the volume and it will list the RAID information for all attached disks for that volume.


Select the disk in
the degraded/failed
"RAID" volume



12. Delete the RAID information for that disk and convert it to non-RAID




Delete the RAID information on the disk



Note: The option shows the RAID volume information of the degraded volume and this disk was a part of that volume and has such data in its metadata having information about the volume.

13. Confirm deletion of the RAID data.


Confirm deletion of Metadata



14. Disk is now Non-RAID which means that the RST Metadata has been cleared or reset.




RAID information deleted. The disk is now non-RAID



5.12.9 Intel® Optane™ Memory and Storage Management App Reboot

Intel® Optane™ Memory and Storage Management UI shall notify User to restart system manually when such operation is needed.

Disable Optane Memory





HSA App notified user to “restart manually” instead of giving a button to restart and therefore not allowing restart from within the app.

The screenshot shows the Intel Optane Memory and Storage Management application interface. The top header is blue with the Intel logo on the left and the text "Intel® Optane™ Memory and Storage Management" on the right. Below the header is a vertical sidebar menu with the following items: "Manage" (wrench icon), "Create Volume" (plus icon), "Intel® Optane™ Memory" (circular arrow icon, highlighted in blue with a dropdown arrow), "Performance" (checkbox icon), "Settings" (gear icon), and "About" (info icon). The main content area on the right displays a "Restart Is Required" message in bold, followed by the text "To stop working with Intel® Optane™ memory, restart is required."



5.13 Compatibility Matrix - Optane™ Memory and Storage Management UI and RST Driver

There were some limitations in 16.7 HSA UI and Middleware which required HSA to have some constraints for some of the operation. All the limitation has been mentioned in

Section 5.12: HSA 16.7 - Optane™ Memory and Storage Management UI Functionality Limitations

These limitations were removed from 17.x HSA UI.

I have included a table below which would help us determine the behavior of the HSA for different combinations of HSA UI and RST Middleware/Driver

Optane™ Memory and Storage Management UI	HSA 16.7.x.x	HSA 17.x.x.x
RST Driver and Middleware 16.7.x.x	Limited Functionality	Limited Functionality
RST Driver and Middleware 17.x.x.x	Limited Functionality	No limitations

5.13.1 Troubleshooting when using Middleware/Driver and UI mismatch (HSA UI 16.7 and 17.x RST Middleware/Driver)

This scenario will have limited functionality as we are using the 16.7 UI. The behavior in this scenario will be similar to using 16.7 HSA UI and 16.7 RST/Middleware. For more information you can refer the following section:


Section 5.12: HSA 16.7 - Optane™ Memory and Storage Management UI Functionality Limitations

Note: We can remove all limitation by upgrading to the 17.x HSA UI and Drivers/Middleware.



5.13.2 Troubleshooting when using Middleware/Driver and UI mismatch (HSA UI 17.x and 16.7 RST Middleware/Driver)

Mismatch between the RST Middleware and HSA UI



This scenario will have limited functionality as we are still using the 16.7 Driver/Middleware which has the limitation. Since the limitation was not included in 17.x UI, so the operations are enabled in UI but not allowed by Driver/Middleware which would generate an error. We must note that the error notification received in this case will be generated by RST Middleware service and will pop up under "Windows Notification".

For more information please refer the table below:
Scenario and Error Code

Scenario: Create volume using a disk containing user data

Error Code:0xA0010063

Error Handling
Refer to section 5.12.7

Scenario: Delete volume using a disk containing user data

Error Code:0xA0010063

Refer to section 5.12.7

Scenario: Add disk to a volume using a disk containing user data

Error Code:0xA0010063

Refer to section 5.12.7

Scenario: Mark as spare a disk containing user data

Error Code:0xA0010063

Refer to section 5.12.7

Scenario: Clear Metadata from a disk containing user data

Error Code:0xA0010066

Refer to section 5.12.8



Scenario: Restart a system after enabling/disabling Optane Memory acceleration

Perform a manual restart from the Start Menu

Error Code:0xA0010064

Note: We can remove all limitation by upgrading to the 17.x HSA UI and Drivers/Middleware.



6 System Acceleration with Intel® Optane™ Memory

6.1 Limitations

6.1.1 Hardware limits

6.1.1.1 Intel Optane Memory HW Limits

1. **Fast disk** (the term "fast disk" refers to the Optane™ memory module or the Optane™ SSD being used as the cache device)

Attention: the following terms are used interchangeably throughout this document:

- Fast disk
 - Optane™ memory module
 - Optane™ SSD
 - Optane™ device
-
- Only a single HW or SW remapped Intel® Optane™ memory module
2. **Slow¹ disk** (disk to be accelerated must be larger capacity than the fast disk) only in the following configurations and drive interfaces:
 - **Boot Drive (System)** (Active boot volume):
 - SATA HDD – single pass-through²
 - SATA SSD - single pass-through
 - SSHD³ - single pass-through
 - Intel brand NVME drive⁴.
 - **Data Drive** (No active boot volume):
 - SATA HDD – single pass-through²
 - SATA SSD - single pass-through
 - SSHD³ - single pass-through
 - Intel brand NVME drive⁴.
 3. Optane™ Memory volume
 - Only one Optane™ Memory volume allowed per boot instance. If more than one volume detected during boot, the second volume detected will be placed offline and not accessible to the system.

NOTES:

Note¹: The slow disk (targeted disk to be accelerated) can be data drives as well as boot drives with the active boot volume beginning with release version 16.0.2.



Note²: Only single pass-through disks can be accelerated. The acceleration of RAID volumes or other multiple disk configurations is not supported.

Note³: Self-pinning SSHDs only, SSHDs that use the Hybrid Information Feature Set is not supported.

Note⁴: Intel brand NVME drive only. See [section 3.1.5](#) for a complete list of supported NVME drive.

6.1.1.2 Teton Glacier HW Limits

These are the known limitations for Teton Glacier.

1. Only one Optane™ Memory volume allowed per boot instance.
2. Only ONE(1) Teton Glacier device can be configured as Intel Optane Memory Volume by Intel RST as a boot or data volume.
 - a. Intel Optane Memory Volume is created from concatenating slow disk (NAND main storage) and fast disk (Optane) of the SAME TG device.
 - b. Intel Optane Memory Volume CANNOT be created by concatenating TG's fast disk with other SATA/NVME slow disks (HDD, SSD, SSHD) or another TG's slow disk (NAND main storage).
3. Only ONE TG device can be plugged into the supported platform.
 - a. Only the M.2 slot that supports TG will show both disk members of the same TG device. The devices plugged into other slots might not be detected or displayed at all in Windows.
 - b. If two or more TG device is plugged into the system, the system might not boot on certain platforms.
4. Teton Glacier device must be connected to M.2 ports locally connected to PCH. TG connected via Thunderbolt or PCIe bridge is not supported.
5. Teton Glacier's Optane Memory Volume cannot be moved (Roaming) to another platform that does not meet TETON GLACIER requirements listed in [section 6.2.2](#).

6.1.2 Functional limits

6.1.2.1 SATA controller mode switching to AHCI mode

Once the system is set up with Intel® Optane™ Memory enabled, the user cannot switch the PCH SATA controller mode from one of the Intel RST modes to the AHCI mode. If the mode is switched and the user attempts to boot the system, the Intel® RST configuration metadata can be corrupted making the system unbootable when PCH SATA mode is switched backed to the available Intel RST mode. To avoid this error condition the following precautions should be taken:

1. All users: If you require switching the PCH SATA controller mode to AHCI for some reason, then before switching, disable Intel® Optane™ Memory prior to switching the mode. You can re-enable Intel® Optane™ Memory once the controller is switched back to the supported Optane mode.
2. BIOS vendors: Upgrading BIOS should maintain pre-upgrade BIOS settings (specifically, the PCH SATA mode should remain in the 'Intel RST...' mode and not switch to AHCI mode)



6.1.2.2 Disk Defragmentation and Optimization for Optane™ Volume

The 'Defragment and Optimization' feature in Windows will only be available for Optane™ Volume if **both** members (fast drive and slow drive) have trim support.

6.1.2.3 Hybrid Drive (TG) Optane™ Roaming Functionality Limitation

For Hybrid drive (TG) family, Intel® Rapid Storage Technology (RST) creates Optane™ Memory Volume by combining QLC NAND and Optane™ Memory media on the same single M.2 board. The goal of this pairing is to combine the large capacity of the QLC NAND and fast random access performance of the Optane disk into a single easy-to-use volume exposed to the customer. This volume is primarily intended to serve as the boot media for the platform. **This volume will only work on with RST drivers and supported platforms. If the user attempts to move this drive/volume to non-supported platform (AHCI mode) or use non-RST storage drivers to access the disk, the volume and data will be lost permanently.**

6.1.2.4 OS Limitation on Volume Member Removal at Hibernation Resume.

When a system with OS installed on Optane™ or RAID volume enters Hibernation (S4) power state, the user must not perform the following operations:

- Disable Optane™ or de-concatenate RAID volume in Intel® UEFI HII Menu.
- Disable Optane™ or de-concatenate RAID volume using Rcfgsata.efi or RstVmdConfig.efi in EFI shell.
- Disable Optane™ or de-concatenate RAID volume using RST CLI tool in WinPE environment.
- Removing or replacing Optane™ or RAID volume disk members or moving disk member to another port.

These operations will change boot drive BIOS path and result in BSOD or system hang.

6.2 Minimum Requirements:

6.2.1 Intel® Optane Memory

CPU	Intel® Kaby Lake or later CPU family of platforms
PCH	PCH: Intel® 100/C230 Series, 200 Series, C240 Series, or 300 Series family of chipsets
Motherboard	Supporting Intel® RST PCH HW remapping technology or a x2 or x4 PEG port for CPU attached Intel-branded SSDs or Optane™ memory modules
M.2 Connector	An M.2 connector is required for the Optane™ memory module; it can be down on the motherboard or on a PCIe adapter card plugged into a PCH remapped PCIe x2 or x4 slot or CPU PEG port.



BIOS	<ul style="list-style-type: none">• UEFI-compliant system BIOS based on Intel® Kaby Lake BIOS reference code version 1.5.0 or later.• BIOS Intel PCH SATA controller mode set to “Intel® RST...” with remapping enabled on the HSIO lanes connecting the Intel® Optane™ technology NVMe SSD/memory module.
RST Pre-OS and Windows Driver	Refer to section 3.1.4 for the correct version of Pre-OS and Windows RST version.

6.2.2 Intel® Optane Memory H10 w/ Solid State Storage (Teton Glacier)

Platform	Platform (Chipset & Motherboard) that supports software remapping at M.2 connector: <ul style="list-style-type: none">• WHL – U42• CFL-H82 (CPU:CFL-H 8+2, PCH:CNP-H)
M.2 Connector	A single M.2 that supports PCIe 2x2 configuration and PCIe dynamic port reconfiguration from BIOS. <ul style="list-style-type: none">• Bios version 164.5 or newer.• CSME version 12.0.20.1301 or newer• PCIe port where TG is located must be set to 1x4 mode (Default Strap Configurations)
BIOS/CSME	
Pre-OS	Intel® RST uEFI driver with support for TG version 17.0.0.3679 or later must be integrated into the system BIOS image.
Windows RST driver	Intel® RST SW and driver package with support for TG version 17.0.0.1072 or later must be installed.

6.2.3 Operating System

- Microsoft Windows 10 x64 bit Editions (latest RTM e.g. Redstone X)
- GPT disks only (MBR not supported)

6.2.4 “Optane™ Memory Ready” Logo: Intel® RST 5MB Metadata Requirement

This notice is for System Manufacturers and System Integrators who will ship “Optane™ Memory Ready” systems in the following configurations (or any system that they wish an end-user to be able to enable Optane™ Memory):

- Complete systems with the OS already installed **AND**
- PCH SATA controller mode set to (AHCI) **OR** (Intel RST) **OR** (Intel RST Premium) **AND**
- The system does not have Optane™ Memory enabled

When all these conditions exist, especially if the manufacturer or integrator partitions the system drive with a hidden partition as the final partition (the end of the disk) or if the OS installation places the WinRE partition at the end of the disk, there must be unallocated space of 5MB reserved or left



at the end of the disk (at the max LBA after the final partition). This space will be required for RST metadata when updating those systems at a later date to Optane™ Memory enabled accelerated systems.

6.3 User Pinning of Files/Folders/Applications

6.3.1 Overview

User pinning functionality is available in Intel® Optane™ Memory UI, Intel® RST™ UI, and Windows File Explorer. Pinning utilizes the file cache portion of the Intel® Optane™ memory module. Pinning allows the user to select files, folders, and applications that they wish to pin to the file cache which is the highest performance level of the Intel® Optane™ Memory caching solution. All items pinned by the user are considered to be “hard” pinned which means they can only be removed/unpinned from the file cache by the user. The Intel® Optane™ Memory caching policies cannot evict ‘hard pinned’ items

IMPORTANT NOTES:

- *The pinning feature is not available when accelerating data drives (DDA). This feature is only supported when Intel® Optane™ Memory is accelerating the **system drive** (which is GPT partitioned (no MBR)), and the Intel® Optane™ memory module is **32GB** or larger. This also applies to Teton Glacier Optane Memory device.*
- *The following objects as on Windows desktop CANNOT be pinned:*
 - *Quick Access*
 - *This PC*
 - *Any disk’s Root directory (e.g. Local Disk (C:))*
 - *Control Panel*
 - *Libraries folder*
 - *Network objects*
 - *Recycle Bin*

6.3.2 Minimum Requirements

The minimum requirements to support the User Pinning feature are as follows:

1. Optane™ capable motherboard
2. Intel® 8th generation core i-processor
3. Intel® 300/240 Series Chipset Family (see table 2-3 for supported SKUs)
4. 32GB or larger Intel® Optane™ memory module installed in a PCH HW remapped port or in a PEG port supporting Intel® RST CPU attached Storage
5. Windows 10 64bit (RS3 or later) installed
6. Intel® RST 16.5 PV or later release installed
7. System Acceleration with Intel® Optane™ Memory enabled




6.3.3 Pinning using the Intel® Optane™ Memory and Storage Management UI

Pinning Tab: The following instructions assume that the computer supports Intel® Optane™ Memory and is already properly configured and enabled to support the User Pinning feature (see the minimum requirements for the pinning feature in the preceding section).

3. Launch the Intel® Optane™ Memory and Storage Management UI
4. In the left navigation pane, click on the Intel® Optane™ Memory tab to expand it.

The page displays information on Optane™ Memory status and a graphic of the current Optane™ Volume configuration.

Intel® Optane™ Memory Main Page




Pin Files and Folders tab:

Click on the 'Files' tab to launch the 'Currently Pinned Files and Folders' page



Currently Pinned
Files and Folders
Page



How-to pin files:

4. Click [+Files] button; this launches file explorer
5. Browse to the file you wish to pin and do one of the following:
 - a. double click on the file to pin it
 - b. click on the file to highlight it, then click the [Open] button to pin it
6. To pin multiple files in the same folder, click on one file then use either the <Shift> key to highlight the multiple sequential files or use the <Ctrl> key to select multiple files

How-to pin folders:

4. Click [+Folder] button; this launches the 'Browse for Folder' window.
 5. Browse to the folder you wish to pin and click to highlight it
- Note: Only the files directly in the folder will be pinned. Subfolders will not be pinned. If there are only subfolders and no individual files in the folder, then pinning the folder will only pin an empty folder.**
6. Click [Select Folder] to pin the folder

How-to Unpin files/folders:

3. While in the 'Currently Pinned Files and Folders' window, use the left click button of the mouse to click through the file


structure
 until you find the file/folder that you wish to unpin. Click on the file/folder to highlight it (multiple files/folders cannot be selected for unpinning operation)

4. Click the [Unpin] button to unpin the file/folder

Applications Sub-Tab:

Click on the 'Applications' tab to launch the 'Currently Pinned Applications' page

Currently Pinned Applications Page



How-to pin applications:

8. Click [+Application] button; this launches the Windows file Explorer window.
9. Browse to the application that you wish to pin and do one of the following:
 - a. double click on the file to pin it
 - b. click on the file to highlight it, then click the [Open] button to pin it

How-to Unpin applications:

3. While in the 'Currently Pinned Applications' window, use the left click button of the mouse to highlight the application you wish to unpin
4. Click the [Unpin] button to unpin the application

6.3.4 Pinning using the Intel® Optane™ Memory UI


Pinning Tab:

1. Launch the Intel® Optane™ Memory UI
2. Click on the 'Pinning' tab in the left navigation pane. This will bring up the 'Intel Optane Memory Pinning' page of the UI



The page displays information on pinning and unpinning of files/folders and applications. Also there is a graphical display of the current usage of the Optane™ memory module in terms of the capacity of files/content that is in the module and any un-used space remaining in the module.

Intel® Optane™ Memory UI Pinning Main Page



Files Sub-Tab: Click on the 'Files' tab to launch the 'Currently Pinned Files and Folders' page

- How-to pin files:**
1. Click [+Document] button; this launches file explorer
 2. Browse to the file you wish to pin and do one of the following:
 - a) double click on the file to pin it
 - b) click on the file to highlight it, then click the [Open] button to pin it
 3. To pin multiple files in the same folder, click on one file then use either the <Shift> key to highlight the multiple sequential files or use the <Ctrl> key to select multiple files

- How-to pin folders:**
1. Click [+Folder] button; this launches the 'Browse for Folder' window.
 2. Browse to the folder you wish to pin and click to highlight it

Note: Only the files directly in the folder will be pinned. Subfolders will not be pinned. If there are only subfolders and no individual files in the folder, then pinning the folder will only pin an empty folder.



3. Click [OK] to pin the folder

How-to Unpin files/folders:	<ol style="list-style-type: none">1. While in the 'Currently Pinned Files and Folders' window, use the left click button of the mouse to click through the file structure until you find the file/folder that you wish to unpin. Click on the file/folder to highlight it (multiple files/folders cannot be selected)2. Click the [Unpin] button to unpin the file/folder
Applications Sub-Tab:	Click on the 'Applications' tab to launch the 'Currently Pinned Applications' page
How-to pin applications:	<ol style="list-style-type: none">1. Click [+Application] button; this launches the Windows file Explorer window.2. Browse to the application that you wish to pin and do one of the following:<ol style="list-style-type: none">a) double click on the file to pin itb) click on the file to highlight it, then click the [Open] button to pin it
How-to Unpin applications:	<ol style="list-style-type: none">1. While in the 'Currently Pinned Applications' window, use the left click button of the mouse to highlight the application you wish to unpin2. Click the [Unpin] button to unpin the application


6.3.5 Pinning using the Intel® RST UI

-
- | | |
|---------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Pinning Tab: | <ol style="list-style-type: none">1. Launch the Intel® RST UI2. Click on the Intel® Optane™ Memory tab at the top of the application. This will bring up the 'Intel Optane Memory' main page of the UI |
|---------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|

The left pane of this page displays information on pinning and unpinning of files/folders and applications.



Intel® RST UI Pinning Main Page



Files Display Box:

Scroll down to the display box that displays Files (it also displays Folders)

How-to pin files:

1. Directly underneath the display box locate and click [+File](#) link; this launches file explorer
2. Browse to the file you wish to pin and do one of the following:
 - a) double click on the file to pin it
 - b) click on the file to highlight it, then click the [Open] button to pin it
3. To pin multiple files in the same folder, click on one file then use either the <Shift> key to highlight the multiple sequential files or use the <Ctrl> key to select multiple files



- How-to pin folders:**
4. Click the [+Folder](#) link; this launches the 'Browse for Folder' window.
 5. Browse to the folder you wish to pin and click to highlight it
- Note:** Only the files directly in the folder will be pinned. Subfolders will not be pinned. If there are only subfolders and no individual files in the folder, then pinning the folder will only pin an empty folder.
6. Click [OK] to pin the folder

-
- How-to Unpin files/folders:**
1. While in the Files' display box, use the left click button of the mouse to click through the file structure until you find the file/folder that you wish to unpin. Click on the file/folder to highlight it (multiple files/folders cannot be selected)
 2. Click the [Unpin] button to unpin the file/folder

-
- Applications Display Box:**
- Scroll down to the 'Applications' display box
- How-to pin applications:**
1. Directly underneath the display box, locate and click the [+Application](#) link; this launches the Windows file Explorer window.
 2. Browse to the application that you wish to pin and do one of the following:
 - a) double click on the file to pin it
 - b) click on the file to highlight it, then click the [Open] button to pin it

-
- How-to Unpin applications:**
1. While in the 'Applications' display box, use the left click button of the mouse to highlight the application you wish to unpin
 2. Click the [Unpin] button to unpin the application
-

6.3.6 User Pinning using Windows File Explorer application

-
- Pinning Files (non-application):**
1. Launch the Windows File Explorer
 2. Navigate to the file that you wish to pin to Intel® Optane™ memory
 3. Use the mouse to right click on the file that you wish to pin to Intel® Optane™ memory
 4. In the pop-up menu, left click the 'Pin to Intel® Optane™ Memory' option to pin the file into the file cache. The file will be **hard pinned:**
 - a) To pin multiple files in the same folder, left click on one file then use either the <Shift> key to highlight the multiple sequential files or use the <Ctrl> key to select multiple files that are not listed sequentially
 - b) Now use the mouse to right click on one of the highlighted files
 - c) In the pop-up menu, left click the 'Pin to Intel® Optane™ Memory' option to pin the files into the file cache
-




File Types:

All file types highlighted will be pinned, including applications.


Pinning Types:

All files pinned will be **hard pinned**, except application executables which will be **soft pinned**.

File Pinned via Windows File Explorer (Right Click)




Multiple Files Pinned via Windows File Explorer (Right Click)



Unpinning Files:

1. Launch Windows File Explorer
2. Navigate to the file that you wish to unpin from Intel® Optane™ memory
3. Use the mouse to right click on the file that you wish to unpin
4. In the pop-up menu, left click the 'Unpin from Intel® Optane™ Memory' option to unpin the file

File Unpinned via Windows File Explorer (Right Click)





Pinning Folders:

1. Launch Windows File Explorer
2. Navigate to the folder that you wish to pin to Intel® Optane™ memory
3. Use the mouse to right click on the folder that you wish to pin to Intel® Optane™ memory
4. In the pop-up menu, left click the 'Pin to Intel® Optane™ Memory' option to pin the folder

Note: Only the files directly in the folder will be pinned. Subfolders will not be pinned. If there are only subfolders and no individual files in the folder, then pinning the folder will only pin an empty folder. In the example below, only the files in the red box will be pinned

5. To pin multiple folders in the same folder, click on one folder then use either the <Shift> key to highlight the multiple sequential folders or use the <Ctrl> key to select multiple folders


File Types:

All file types directly in the folder will be pinned, including applications.

Pinning Types:


All files pinned will be **hard pinned**, including application.

Folder Pinned via Windows File Explorer (Right Click)





Folder Unpinned via Windows File Explorer (Right Click)



Pinning applications:

1. Launch the Windows File Explorer
2. Navigate to the application that you wish to pin to Intel® Optane™ memory
3. Use the mouse to right click on the application executable file that you wish to pin to Intel® Optane™ memory
4. In the pop-up menu, left click the 'Pin to Intel® Optane™ Memory' option to pin the application into the file cache. The application will be **soft pinned**:
 - a) To pin multiple applications in the same folder, left click on one application then use either the <Shift> key to highlight the multiple sequential apps or use the <Ctrl> key to select multiple apps that are not listed sequentially
 - b) Now use the mouse to right click on one of the highlighted apps
 - c) In the pop-up menu, left click the 'Pin to Intel® Optane™ Memory' option to pin the apps into the file cache


File Types:

All applications highlighted will be pinned.


Pinning Types:

All applications pinned will be **soft pinned**.

Application Pinned via Windows File Explorer (Right Click)



Multiple Apps Pinned via Windows File Explorer (Right Click)



a)


How-to Unpin applications:

1. Launch Windows File Explorer
2. Navigate to the folder that you wish to unpin from Intel® Optane™ memory
3. Use the mouse to right click on the folder that you wish to unpin to Intel® Optane™ memory
4. In the pop-up menu, left click the 'Pin to Intel® Optane™ Memory' option to pin the folder



- To unpin multiple folders in the same folder, click on one folder then use either the <Shift> key to highlight the multiple sequential folders or use the <Ctrl> key to select multiple folders

Application Unpinned via Windows File Explorer (Right Click)



6.4 Configuring Intel® Optane™ Memory (Post-Factory Build Environment¹)

This section documents how to enable System Acceleration with Intel® Optane™ Memory on systems that are not shipped with the feature enabled. It focuses on systems being installed/configured by end-users/system integrators/others outside of the factory environment.

Note: : For configuring Intel® Optane™ Memory in the factory, review the next [chapter](#).

WARNING: *In all Intel® Optane Memory enabling scenarios, all data that is on the fast disk prior to enabling will be deleted during the Optane™ Memory enabling process*

6.4.1 Enable Optane™ Volume on a Brand New System

6.4.1.1 BIOS

There are no pre-OS configuration tools for Optane™ available to the end-user.



6.4.1.2 OS runtime

This section instructs how to enable the System Acceleration with Optane™ memory after the installation of the OS. Users who want to have a completely automated Intel® Optane™ Memory configuration process after the OS installation are recommended to use this method.

NOTE: For enabling Optane Boot Volume with Teton Glacier, use the procedure in [section 6.4.1.2.4](#).

6.4.1.2.1 Intel® Optane™ Memory and Storage Management UI/Installer (All User Levels)

This configuration method can be used by experienced and inexperienced users. Users who want to have a completely automated Intel® Optane™ Memory configuration process after the OS installation are recommended to use this method. It automates all of the BIOS configuration tasks involved in setting up the entire system to support System Acceleration with Intel® Optane™ Memory.

System prep:

Boot Drive Acceleration (requires 2 drives):

- Ensure that you have installed:
 - A. A SATA HDD/SSD/SSHD (the slow media to install OS)
 - B. An Intel® Optane™ NVMe SSD or memory module (fast media to be the cache) in a PCH remappable port or a CPU PEG port

Data Drive Acceleration (requires 3 drives):

- Ensure that you have installed:
 - A. A drive to install the OS to (no specific requirement)
 - B. A SATA HDD/SSD/SSHD (the slow media data drive); must be larger than the fast media drive
 - C. A PCIe Intel® Optane™ NVMe SSD or memory module (fast media to be the cache) in a PCH remappable port or a CPU PEG port.

BIOS Setup:

Enter the BIOS and configure the following:

1. Locate the menu to configure the SATA PCH controller
2. Set the SATA mode to one of the non-AHCI modes:
 - a. Intel RST with System Acceleration with Optane Memory..., or
 - b. Intel RST Premium with System Acceleration with Optane Memory...



-
3. Locate the setting for enabling/disabling remapping for the PCIe port where the fast media drive is located
 4. Set the port to remapped enabled (controlled by RST)
-

OS installation:

Obtain your copy of the supported Windows 10 installation media and install the OS using the default installation or any customizations desired.

Verify OS detects Optane™ module:

1. Complete the OS installation and boot to the Windows desktop.
 2. Launch Windows Device Manager
 3. Expand 'Disk drives' and confirm that all drives are detected
 - A. Intel® Optane™ model disk (fast media)
 - B. HDD/SSD (slow media)
 - C. If accelerating a data drive, then there should be a 3rd drive for the OS
 4. Exit Device Manager
-

Optane™ volume creation:

The following steps in this process will automatically accomplish all or some of the following tasks depending on the state of your system:

- *Install the required SW needed for Optane™ Memory*
- *Select the proper mode for the PCH SATA controller*
- *Enable remapping required for the Optane™ PCIe NVMe device to be detected by Intel® RST*
- *Installs the Intel® Optane™ Memory UI*
- *And finally, with user input, enables System Acceleration with Intel® Optane™ Memory*

If any of the above steps are already in the required state the installer will automatically skip those steps that are not required and complete the installation and configuration process

Note: In Optane™ Memory and Storage Management UI, for all Intel® Optane Memory enabling scenarios, all data that is on the fast disk prior to enabling should be deleted before the Optane™ Memory enabling process otherwise the App would not allow the Optane memory to be used. The Optane memory disk should not be



initialized (does not have a valid partition table) or have RST Metadata.

1. Obtain the Intel® Optane™ Memory Storage Management from Windows store or follow the steps given in Section 6.4
2. To complete the Optane™ enabling process (*to combine the Optane™ memory device and the OS system drive into a single accelerated Optane™ volume*), go to the 'Intel® Optane™ Memory' page,
 - A. Select an Optane drive from the "Compatible drive" drop down box (if only a single Optane module is present in the system then skip this step, there will be no drop down box)
 - B. If multiple compatible drives are in the system select the drive to be accelerated:
 1. For OS drive acceleration select the disk labeled "SYSTEM"
 2. For data drive acceleration select any disk not labeled "SYSTEM"
 - C. Click the [Enable Intel® Optane™ Memory] button
 - D. Click [Enable]
3. Once any necessary file migration completes, reboot to Windows to complete the configuration process.
4. For Optane Memory module that support file caching (32GB and greater), a native application will be run at the boot up to move the Windows OS pagefile. Please refer to [section 6.4.1.3](#) for more information. **DO NOT interrupt this process.**

Verify the system is Optane™ Memory accelerated:

From Windows desktop, launch the Windows Device Manager

1. Go to 'Disk Drives' and click to expand
 - You should see a single drive labeled "Intel Optane+slow media" (e.g. "Intel Optane+1.0TBHDD")
 - If you are accelerating a data drive then you will see the OS drive listed as well
2. Go to Disk Manager
 - The Intel® Optane™ memory module should not be listed. It will be combined with either the OS drive or a data drive.
3. Another method is to launch the Intel® Optane™ Memory and Storage Management UI and see the 'Intel® Optane™ Memory' page.

These three items confirm that the Intel® Optane™ NVMe SSD/memory module and the large capacity HDD/SSD



have been combined to form the accelerated Intel® Optane™ volume.

6.4.1.2.2 Intel® Optane™ Memory UI/Installer (All User Levels)

This configuration method can be used by experienced and inexperienced users. Users who want to have a completely automated Intel® Optane™ Memory configuration process after the OS installation are recommended to use this method. It automates all of the BIOS configuration tasks involved in setting up the entire system to support System Acceleration with Intel® Optane™ Memory.

System prep:

Boot Drive Acceleration (requires 2 drives):

- Ensure that you have installed:
 - A. A SATA HDD/SSD/SSHD (the slow media to install OS)
 - B. An Intel® Optane™ NVMe SSD or memory module (fast media to be the cache) in a PCH remappable port or a CPU PEG port
-

Data Drive Acceleration (requires 3 drives):

- Ensure that you have installed:
 - A. A drive to install the OS to (no specific requirement)
 - B. A SATA HDD/SSD/SSHD (the slow media data drive); must be larger than the fast media drive
 - C. A PCIe Intel® Optane™ NVMe SSD or memory module (fast media to be the cache) in a PCH remappable port or a CPU PEG port.
-

BIOS Setup:

Enter the BIOS and configure the following:

1. Locate the menu to configure the SATA PCH controller
 2. Set the SATA mode to one of the non-AHCI modes:
 - a. Intel RST with System Acceleration with Optane Memory..., or
 - b. Intel RST Premium with System Acceleration with Optane Memory...
 3. Locate the setting for enabling/disabling remapping for the PCIe port where the fast media drive is located
 4. Set the port to remapped enabled (controlled by RST)
-



OS installation: Obtain your copy of the supported Windows 10 installation media and install the OS using the default installation or any customizations desired.

Verify OS detects Optane™ module:

1. Complete the OS installation and boot to the Windows desktop
2. Launch Windows Device Manager
3. Expand 'Disk drives' and confirm that all drives are detected
 - A. Intel® Optane™ model disk (fast media)
 - B. HDD/SSD (slow media)
 - C. If accelerating a data drive, then there should be a 3rd drive for the OS
4. Exit Device Manager

Optane™ volume creation: *The following steps in this process will automatically accomplish all or some of the following tasks depending on the state of your system:*

- *Install the required SW needed for Optane™ Memory*
- *Select the proper mode for the PCH SATA controller*
- *Enable remapping required for the Optane™ PCIe NVMe device to be detected by Intel® RST*
- *Installs the Intel® Optane™ Memory UI*
- *And finally, with user input, enables System Acceleration with Intel® Optane™ Memory*

If any of the above steps are already in the required state the installer will automatically skip those steps that are not required and complete the installation and configuration process

WARNING: In all Intel® Optane Memory enabling scenarios, all data that is on the fast disk prior to enabling will be deleted during the Optane™ Memory enabling process

1. Obtain the Intel® Optane™ Memory SW/driver installation package and run the executable (**SetupOptaneMemory.exe**)
 2. Install the defaults
 3. When this part of the installation process completes the installer will prompt you to 'Restart', click [Finish] to restart the system:
-



-
- A. During this reboot the system will accomplish any required system configuration tasks (BIOS settings) and may reboot more than once
 - B. When complete, the system will reboot back to the Windows desktop
 4. There will be a few seconds delay; the installation process continues and completes driver installation
 5. A pop-up ("You're Almost There ...") will prompt you to continue to enable Optane™; click [Next] then [Yes] and the Intel® Optane™ UI will launch
 6. To complete the Optane™ enabling process (*to combine the Optane™ memory device and the OS system drive into a single accelerated Optane™ volume*), go to the 'Setup' page,
 - A. Select an Optane drive from the "Compatible drive" drop down box (if only a single Optane module is present in the system then skip this step, there will be no drop down box)
 - B. If multiple compatible drives are in the system select the drive to be accelerated:
 1. For OS drive acceleration select the disk labeled "SYSTEM"
 2. For data drive acceleration select any disk not labeled "SYSTEM"
 - C. Click the [Enable] button
 - D. Click the "Erase all data on the Intel® Optane™ memory module" box to place a check in the box
 - E. Click [Continue]
 7. Once any necessary file migration completes, click the [Restart] button to reboot
 8. Reboot to Windows to complete the configuration process.
 9. For Optane Memory module that support file caching (32GB and greater), a native application will be run at the boot up to move the Windows OS pagefile. Please refer to [section 6.4.1.3](#) for more information. **DO NOT interrupt this process**

Verify the system is Optane™ Memory accelerated:

- From Windows desktop, launch the Windows Device Manager
1. Go to 'Disk Drives' and click to expand
 - You should see a single drive labeled "Intel Optane+slow media" (e.g. "Intel Optane+1.0TBHDD")
 - If you are accelerating a data drive then you will see the OS drive listed as well
-



-
2. Go to Disk Manager
 - The Intel® Optane™ memory module should not be listed. It will be combined with either the OS drive or a data drive.
 3. Another method is to launch the Intel® Optane™ Memory UI and see the 'Status' page.

These three items confirm that the Intel® Optane™ NVMe SSD/memory module and the large capacity HDD/SSD have been combined to form the accelerated Intel® Optane™ volume.
-

6.4.1.2.3 Intel® RST UI/Installer (Experienced Users)

This section instructs how to enable the System Acceleration with Optane™ technology as part of the OS installation. Experienced users who want to have full control of the configuration process are recommended to use this method.

System prep:

1. Ensure the computer HW meets the minimum requirements for this feature (see the [Minimum Requirements](#) section above). This includes installing the Intel® Optane™ memory module or Intel® Optane™ NVMe SSD in the proper remappable M.2 connector or PCIe slot.
2. Confirm that the system BIOS has a supported Intel® RST pre-OS UEFI driver integrated:
 - a) Enter your system BIOS and locate the Intel® Rapid Storage Technology HII UI
 - b) At the top of the UI page confirm that the Intel RST UEFI Driver version is 15.9.3.xxxx or later
3. Set SATA PCH I/O controller to proper mode:
 - a) While still in the BIOS find the page that allows you to configure the PCH and SATA mode to "Intel RST Premium..." (**AHCI mode is not supported**)
 - b) Enable remapping so that Intel® RST can control the Intel® Optane™ memory module or Intel® Optane™ NVMe SSD

Note: The location of the above functions/settings in the system BIOS on your computer will vary based on the manufacturer of your computer system. If you have trouble locating these settings contact your system manufacturer. Alternately you can follow the instructions for all users in the previous section.



OS installation: Obtain your copy of the Windows 10 installation media and install the OS using the default installation or any customizations desired.

Verify that OS detects Optane™ module:

1. Complete the OS installation and boot to the Windows desktop
2. Launch Windows* Device Manager
3. Expand 'Disk drives' and confirm that all drives are detected
 - A. Intel® Optane™ model disk (fast media)
 - B. HDD/SSD (slow media)
 - C. If accelerating a data drive, then there should be a 3rd drive for the OS
 - D. Exit Device Manager

Optane™ volume creation:

WARNING: In all Intel® Optane Memory enabling scenarios, all data that is on the fast disk prior to enabling will be deleted during the Optane™ Memory enabling process

1. Obtain the Intel® RST SW/driver installation package and run the executable (SetupRST.exe)
 2. Install the defaults and reboot the computer
 3. From Windows* desktop, find and launch the Intel® RST UI application.
 4. The application will open to the 'Status' page
 5. Click the 'Intel® Optane™ Memory' tab
 6. Click the "Enable" link to start the enabling process.
 7. A pop-up will prompt you to select:
 - A. From drop down, select the NVMe fast media Optane™ device
 - B. From drop down, select the SATA disk to be accelerated (for OS drive acceleration, select the drive labeled 'SYSTEM'; for data drive acceleration select a drive not labeled "SYSTEM")
 8. Click OK to start the enable process
 9. Depending on the size of your Optane™ module, the following may be seen:
 - A. Progress indicator: Let progress indicator complete to 100%
 - B. Text: Finalizing operation...
 10. Click the [Reboot] button to complete the process
 11. System reboots into Windows to complete the enabling process.
-



-
12. For Optane Memory module that support file caching (32GB and greater), a native application will be run at the boot up to move the Windows OS pagefile. Please refer to [section 6.4.1.3](#) for more information. **DO NOT interrupt this process.**
-

Verify system is Optane™ Memory accelerated:

From Windows desktop, launch the Windows Device Manager

1. Go to 'Disk Drives' and click to expand
 - You should see a single drive labeled "Intel Optane+slow media" (e.g. "Intel Optane+1.0TBHDD")
 - If you are accelerating a data drive you will see at least one other drive that is the OS drive
2. Go to Disk Manager
 - The Intel® Optane™ module should not be listed.
3. Another method is to launch the Intel® RST UI or Intel® Optane™ UI, depending on your install, and see the Status page.

These three items confirm that the Intel® Optane™ NVMe SSD/memory module and the large capacity HDD/SSD have been combined to form the accelerated Intel® Optane™ volume.

6.4.1.2.4 Intel RST UI/Installer for Teton Glacier (Experienced Users)

System prep:

- Ensure that the TG device is plugged into M.2 slot that support TG configuration. Refer to previous sections for minimum requirement and bios requirements.
 - Make sure that RST F6 drivers are available on a thumb drive.
-

BIOS Setup


These steps are applicable to TG Boot Drive Acceleration only.

Enter the BIOS and configure the following:

1. Locate the menu to configure the SATA PCH Controller.
 2. Set the SATA Mode to non-AHCI modes:
 - a. Intel RST with System Acceleration with Optane Memory..., or
 - b. Intel RST Premium with System Acceleration with Optane Memory...
 3. Locate the menu to configure Teton Glacier Mode and set the value to "Dynamic Configuration for Teton Glacier Enable".
-



Check point: Make sure TG's devices are visible in Intel RST UEFI User Interface.




OS Installation


Obtain your copy of the supported Windows 10 installation media and install the OS using the default installation or any customizations desired.

These steps will walk you through basic installation of a default Windows 10 OS onto TG's NAND storage area:


1. Start Windows installation process from USB thumb drive and follow the instructions of Windows installer.
2. At the screen "Where do you want to install Windows?", press F6 or select "Load Driver".




3. Browse to the directory where the RST F6 drivers are. When prompted, Select "Intel® Chipset SATA/PCIe RST Premium Controller". Then Select "Next" to install the RST driver.



4. After the driver installation completes, Select the drive that has **higher capacity** at the screen "Where do you want to install Windows?". Then Select "Next" to continue Windows installation process.



Check point: After Windows installation process completes, use "Device Manager" to verify that correct devices appeared under Disk Drives and Storage Controllers. Refer to the screen shot below.




Install Intel RST

Execute SetupRST.exe installer version that supports Teton Glacier and follow the instructions provided by the installer

Check point: After the installation completes and reboots the system, verify that:


- Teton Glacier's two devices appears in Intel RST UI.
- Intel Optane Memory can be enabled.




Enable Intel Optane Memory Volume

Enable Intel® Optane™ Memory and follow the instructions provided by Intel RST UI.

IMPORTANT: Make sure that the system is in AC mode before enabling Optane Volume.



Check point: After the enablement completes and reboots the system, verify that Intel Optane Memory Volume is visible in Intel RST UI. For TG module that support file caching (SB2 is 32GB and greater), a native application will be run at the boot up to move the Windows OS pagefile. Please refer to [section 6.4.1.3](#) for more information. **DO NOT interrupt this process.**



6.4.1.3 Optane Service Pagefile Boot Optimization

For 32GB and greater Optane Memory module with file caching enabled, RST optimizes Windows boot process by placing page file into Optane Memory. During the enabling process, the page file may not be accessible due to exclusive use by Windows and is not placed into Optane Memory. In order to move the pagefile to Optane Memory, an optimization is done on next reboot before the Windows is loaded. The end user will see a similar screen as figure 6.1 during the boot process after Optane was initially enabled:



```
Intel(R) Optane(TM) Memory

Enabling Intel(R) Optane(TM) Memory...

Press any key to stop enablement process.

Enablement phase 1 of 2 progress: 100.0 %
Enablement phase 2 of 2 progress: 5 %
```

Figure 6.4.1.3 – Optane Optimization Process

There are 2 phases to this pagefile boot optimization:

- Phase 1: The space is made in Optane Memory module for Windows OS pagefile.
- Phase 2: The pagefile is moved into the destination area in Optane Memory module.

***IMPORTANT*:** *If the end user stop this process, the performance will be impacted and reduced because the pagefile is not cached in Optane Memory module.*

6.4.2 System Upgrade (Windows*10 OS Already Installed)

This section covers upgrading those systems that have Windows* 10 already install by installing a new Intel® Optane™ memory module then enabling System Acceleration with Intel® Optane™ Memory.

NOTE: *Teton Glacier module does not support creation of Optane Memory Volume with existing system drive or data drive. See Teton Glacier Hardware Limitation for more information. For procedure to configure Teton Glacier module as Optane Data Volume, refer to [section 6.5.2.4](#).*

6.4.2.1 Intel® Optane™ Memory and Storage Management UI/Installer

System starting configuration:	<ul style="list-style-type: none">• Windows 10* x64 OS installed on SATA HDD/SSD• Intel® RST driver installed• System BIOS has Intel® RST pre-OS version 15.5.0.2875 or later integrated
Optane™ module installation:	<ol style="list-style-type: none">1. Power down the system and install the Intel® Optane™ memory device into an M.2 connector located either on the motherboard or PCIe adapter card plugged into a remappable PCIe slot or module connected to CPU PEG port



2. Reboot system to Windows

Verify OS detects Optane™ module:

Note: Unless the following conditions are met, the Optane™ memory module will not be detectable:

- a) Intel® RST 16.7 PV or later driver installed (if not installed then the Optane™ module will not be detectable yet; skip to the next section and proceed to install the 16.7 or later SW package with driver)
 - b) The BIOS has the Intel RST 15.9.3 or later UEFI preOS driver installed
 - c) The PCIe port with the Optane™ module is remapped
1. Boot to the Windows desktop
 2. Launch Windows Device Manager
 3. Expand 'Disk drives' and confirm that all drives are detected:
 - A. Intel® Optane™ Memory module/Disk
 - B. SATA HDD/SSD/SSHD (to be accelerated)
 - C. Additional disk for OS if accelerating a data drive

Optane™ volume creation:

The following steps in this process will automatically accomplish all or some of the following tasks depending on the state of your system:

1. *Install the required SW needed for Optane™*
2. *If in AHCI mode, switch the PCH SATA controller to the proper 'Intel RST...' mode*
3. *Enable remapping required for the Optane™ PCIe NVMe device*
4. *Installs the Optane™ Memory UI*
5. *And finally, with user input, enable System Acceleration with Intel® Optane™ Memory*

If any of the steps above are already in the required state the installer will automatically skip those steps that are not required and complete the installation and configuration process.

Note: In Optane™ Memory and Storage Management UI, for all Intel® Optane Memory enabling scenarios, all data that is on the fast disk prior to enabling should be deleted before the Optane™ Memory enabling process otherwise the App would not allow the Optane memory to be used. The Optane memory disk should not be



initialized (does not have a valid partition table) or have RST Metadata.

6. Obtain the Intel® Optane™ Memory Storage Management from Windows store or follow the steps given in Section 6.4
7. To complete the Optane™ enabling process (to combine the Optane™ device and the OS system drive into a single accelerated Optane™ volume), on the 'Intel® Optane™ Memory' page, click the [Enable] button and click the [Yes] button to proceed
8. Once any necessary file migration completes, reboot to Windows and this completes the configuration process.
9. For Optane Memory module that support file caching (32GB and greater), a native application will be run at the boot up to move the Windows OS pagefile. Please refer to [section 6.4.1.3](#) for more information. **DO NOT interrupt this process.**

Verify the system is Optane™ Memory accelerated:

From Windows desktop, launch the Windows Device Manager

1. Go to 'Disk Drives' and click to expand
 - You should see a single drive labeled "Intel Optane+slow media" (e.g. "Intel Optane+1.0TBHDD")
2. Go to Disk Manager
 - If you see the Optane™ volume displayed in 'Disk drives', then you should see a single Windows OS disk. The Optane™ module should not be listed.
3. Another method is to launch the Intel® RST UI, Intel® Optane™ UI or Intel® Optane™ and Storage management UI, depending on your install, and see the Status page. These three items confirm that the Intel® Optane™ NVMe SSD/memory module and the large capacity HDD/SSD have been combined to form the accelerated Intel® Optane™ volume.

6.4.2.2 Intel® Optane™ Memory UI/Installer

System starting configuration:

- Windows 10* x64 OS installed on SATA HDD/SSD
- Intel® RST driver installed
- System BIOS has Intel® RST pre-OS version 15.5.0.2875 or later integrated



Optane™ module installation:

1. Power down the system and install the Intel® Optane™ memory device into an M.2 connector located either on the motherboard or PCIe adapter card plugged into a remappable PCIe slot or module connected to CPU PEG port
2. Reboot system to Windows

Verify OS detects Optane™ module:

Note: Unless the following conditions are met, the Optane™ memory module will not be detectable:

- a) Intel® RST 15.5 PV or later driver installed (if not installed then the Optane™ module will not be detectable yet; skip to the next section and proceed to install the 15.5 or later SW package with driver)
 - b) The BIOS has the Intel RST 15.9.3 or later UEFI preOS driver installed
 - c) The PCIe port with the Optane™ module is remapped
1. Boot to the Windows desktop
 2. Launch Windows Device Manager
 3. Expand 'Disk drives' and confirm that all drives are detected:
 - A. Intel® Optane™ Memory module/Disk
 - B. SATA HDD/SSD/SSHD (to be accelerated)
 - C. Additional disk for OS if accelerating a data drive

Optane™ volume creation:

The following steps in this process will automatically accomplish all or some of the following tasks depending on the state of your system:

- *Install the required SW needed for Optane™*
- *If in AHCI mode, switch the PCH SATA controller to the proper 'Intel RST...' mode*
- *Enable remapping required for the Optane™ PCIe NVMe device*
- *Installs the Optane™ Memory UI*
- *And finally, with user input, enable System Acceleration with Intel® Optane™ Memory*

If any of the steps above are already in the required state the installer will automatically skip those steps that are not required and complete the installation and configuration process.

WARNING: In all Intel® Optane Memory enabling scenarios, all data that is on the fast disk prior to enabling will be deleted during the Optane™ Memory enabling process



-
1. Obtain the Intel® Optane™ SW/driver installation package and run the executable (**SetupOptaneMemory.exe**)
 2. Install the defaults
 3. When this part of the installation process completes the installer will prompt you to 'Restart', click [Finish] to restart the system:
 - A. During this reboot the system will accomplish any required system configuration tasks (e.g. BIOS settings like switching from AHCI mode) and may reboot more than once
 - B. When complete, the system will reboot back to the Windows desktop
 4. There will be a few seconds delay; the installation process continues and completes driver installation
 5. A pop-up ("Thank you for installing...") will prompt you to continue to enable Optane™; click [Yes] and the Optane™ UI will launch
 6. To complete the Optane™ enabling process (to combine the Optane™ device and the OS system drive into a single accelerated Optane™ volume), on the 'Setup' page, click the [Enable] button and click the [Yes] button to proceed
 7. Once any necessary file migration completes, click the [Restart] button to reboot
 8. Reboot to Windows and this completes the configuration process.
 9. For Optane Memory module that support file caching (32GB and greater), a native application will be run at the boot up to move the Windows OS pagefile. Please refer to [section 6.4.1.3](#) for more information. **DO NOT interrupt this process.**

Verify the system is Optane™ Memory accelerated:

From Windows desktop, launch the Windows Device Manager

1. Go to 'Disk Drives' and click to expand
 - You should see a single drive labeled "Intel Optane+slow media" (e.g. "Intel Optane+1.0TBHDD")
 2. Go to Disk Manager
 - If you see the Optane™ volume displayed in 'Disk drives', then you should see a single Windows OS disk. The Optane™ module should not be listed.
 3. Another method is to launch the Intel® RST UI or Intel® Optane™ UI, depending on your install, and see the Status page.
-



These three items confirm that the Intel® Optane™ NVMe SSD/memory module and the large capacity HDD/SSD have been combined to form the accelerated Intel® Optane™ volume.

6.4.2.3 Intel® RST UI/Installer

This method is for upgrading a system that is in one of the Intel RST Optane™ modes and running the Intel RST driver

System starting configuration:

- Windows 10 OS installed on SATA HDD/SSD
- RST driver installed
- System BIOS SATA controller set to one of the Intel RST Optane™ modes

Note: : *The system must meet minimum requirements to support System Acceleration with Intel® Optane™ technology. See the 'Minimum Requirements' section above*

Optane™ module installation:

1. Power down the system and install the Optane™ device into an M.2 connector located either on the motherboard or PCIe adapter card plugged into a remappable PCIe slot or a CPU PEG port
 2. Enter BIOS and enable remapping on the port where the Optane™ device is plugged into
 3. Reboot to Windows
-

Verify OS detects the Optane™ device:

1. Boot to the Windows desktop
 2. Launch Windows Device Manager
 3. Expand 'Disk drives' and confirm that newly installed Intel Optane™ device is detected as a drive
 - A. Intel Optane™ Model Disk (fast media)
 - B. HDD/SSD (slow media)
-

Optane™ volume creation:

WARNING: In all Intel® Optane Memory enabling scenarios, all data that is on the fast disk prior to enabling will be deleted during the Optane™ Memory enabling process

1. Obtain the Intel RST SW/driver installation package and run the executable (SetupRST.exe)
 2. Install the defaults and reboot the computer
 3. From Windows desktop, find and launch the Intel® RST UI application.
 4. The application will open to the 'Status' page
 5. Click the 'Optane™ Memory' tab
-



-
6. Click the "Enable" link to start the enabling process.
 7. A pop-up will prompt you to 'Select a compatible fast drive:' (the Optane™ NVMe device)
 8. Click [Yes] button to start the enable process
 9. Depending on the size of your Optane™ module, a progress indicator may be displayed; let it complete to 100%
 10. Click the [Reboot] button to complete the process
 11. System reboots into Windows to complete the enabling process.
-

**Verify the system is
Optane™ Memory
accelerated:**

From Windows desktop, launch the Windows Device Manager

1. Go to 'Disk Drives' and click to expand
 - You should see a single drive labeled "Intel Optane+slow media" (e.g. "Intel Optane+1.0TBHDD")
2. Go to Disk Manager
 - If you see the Optane™ volume displayed in 'Disk drives', then you should see a single Windows OS disk. The Optane™ module should not be listed.
3. Another method is to launch the Intel® RST UI or Intel® Optane™ UI, depending on your install, and see the Status page.

These three items confirm that the Intel® Optane™ NVMe SSD/memory module and the large capacity HDD/SSD have been combined to form the accelerated Intel® Optane™ volume.

6.4.2.4 Intel® RST UI/Installer for Teton Glacier as Optane Data Volume

This method is for upgrading a system that meets Teton Glacier [minimum system requirements](#) and already has Windows 10 installed on a SATA HDD/SSD. In this configuration, Teton Glacier can only be configured as Optane Data Volume (DDA).

**System starting
configuration**

- Windows 10* x64 OS installed on SATA HDD/SSD.
- Intel Rst driver and software version 17.0.0.1072 or later installed.
- System BIOS has Intel® RST pre-OS version 17.0.0.3679 or later integrated.



Module installation and BIOS configuration

- Power down the system and install the TG Optane™ device into an M.2 slot that supports 2x2 configuration and PCIe port reconfiguration from BIOS.
- Refer to [section 6.5.1.2.4](#) BIOS Setup for BIOS configuration and checkpoint.

Enable Optane™ Memory Data Volume

- Enable Intel® Optane™ Memory and follow the instructions provided by Intel RST UI.
- **IMPORTANT: Make sure that the system is in AC mode before enabling Optane Volume.**

6.4.3 System Upgrade (Windows* 10 OS Already Installed with BIOS in AHCI mode)

This section covers upgrading those systems that have Windows* 10 already install by installing a new Intel® Optane™ memory module then enabling System Acceleration with Intel® Optane™ Memory.

Note: This upgrade path is only possible via the Intel® Optane™ Memory UI installer program.

Note: Teton Glacier device can only be configured as Data Drive Volum.

6.4.3.1 Intel® Optane™ Memory and Storage Management UI/Installer

Refer to Section 6.4

6.4.3.2 Intel® Optane™ UI/Installer

System starting configuration:

- Windows* 10 OS installed on SATA HDD/SSD
- Intel® RST AHCI driver or default inbox AHCI driver installed
- System BIOS SATA controller in AHCI mode

Intel® Optane™ memory module installation:

1. Power down the system and install the Intel® Optane™ memory module or NVMe SSD into an M.2 connector located either on the motherboard or a PCIe adapter card plugged into a remappable PCIe slot or a CPU PEG port
 2. Reboot system to Windows
-



Verify OS detects Intel® Optane™ module:

Note: Skip this section if the Intel® RST AHCI driver is installed

1. Boot to the Windows desktop
2. Launch Windows Device Manager
3. Expand 'Disk drives' and confirm that both drives are detected:
 - A. Intel® Optane™ memory module/disk
 - B. HDD/SSD

Intel® Optane™ volume creation:

The following steps in this process will automatically accomplish some or all of the following tasks depending on the state of your system:

- *Install the required SW needed for Optane™*
- *Switch the PCH SATA controller from AHCI mode to the proper 'Intel RST...' mode*
- *Enable remapping required for PCIe NVMe devices*
- *Installs the Intel® Optane™ Memory UI*
- *And finally prompt to enable System Acceleration with Intel® Optane™ Memory*

If any of the steps above are already in the required state the installer will automatically skip those steps that are not required and complete the installation and configuration process

Note: In Optane™ Memory and Storage Management UI, for all Intel® Optane Memory enabling scenarios, all data that is on the fast disk prior to enabling should be deleted before the Optane™ Memory enabling process otherwise the App would not allow the Optane memory to be used. The Optane memory disk should not be initialized (does not have a valid partition table) or have RST Metadata.

WARNING: In Intel® Optane Memory enabling scenarios for RST and In Optane™ Memory UI, all data that is on the fast disk prior to enabling will be deleted during the Optane™ Memory enabling process



-
1. Obtain the Intel® RST and Optane™ SW/driver installation package and run the executable (SetupOptaneMemory.exe)
 2. Install the defaults
 3. When this part of the installation process completes the RST installer program will prompt for you to restart your system to continue the process (click default [Finish] to restart the computer).
 4. Depending upon the initial configuration of your system:
 - A. During this reboot the system will accomplish any required system configuration (BIOS settings) and may reboot more than once
 - B. When all necessary configuration processes complete, the system will reboot back to the Windows desktop
 5. The installation continues and a pop-up box will prompt you to continue to enable Intel® Optane™ volume; click [Yes] to continue
 6. Click [Yes] for User Account Control pop-up
 7. The Intel® Optane™ Memory UI will launch, click 'Enable' then click 'Yes' to continue to combine your OS system drive or a data drive and your Intel® Optane™ memory module (or SSD) into a single accelerated Optane™ volume
 8. Once the migration process successfully completes you will be prompted to reboot to complete the process; Click 'Restart'
 9. Your computer will reboot to Windows* completing the Intel® Optane™ Memory enabling process.
 10. For Optane Memory module that support file caching (32GB and greater), a native application will be run at the boot up to move the Windows OS pagefile. Please refer to [section 6.4.1.3](#) for more information. **DO NOT interrupt this process.**

Verify the system is Optane™ Memory accelerated:

- From Windows desktop, launch the Windows Device Manager
1. Go to 'Disk Drives' and click to expand
 - You should see a drive labeled "Intel Optane+slow media" (e.g. "Intel Optane+1.0TBHDD")
 2. Go to Disk Manager
 - The Optane™ module should not be listed.
 3. Another method is to launch the Intel® RST UI or Intel® Optane™ UI, depending on your install, and see the Status page.
-



These three items confirm that the Intel® Optane™ NVMe SSD/memory module and the large capacity HDD/SSD have been combined to form the accelerated Intel® Optane™ volume.

6.5 Intel® Optane™ Memory Member Disk Upgrades

This section covers upgrading an Optane-enabled system with a new system disk or a new Intel® Optane™ memory module. This section does not apply to Teton Glacier Memory device.



6.5.1 Slow Disk (SATA HDD, SSD, SSHD) Upgrade/Replacement



Disable Optane™:

Before replacing any component of your Optane™ Memory storage solution, you must always disable Optane™ Memory to ensure all data has been migrated from the Optane™ module and synced with the slow disk.

NOTE: You should backup any important data prior to starting this process!

Intel® Optane™ Memory and Storage Management UI installed:

1. From Windows Start Menu, launch the Intel® Optane™ Memory and Storage Management UI
2. Click on the 'Intel® Optane™ Memory' tab
3. Click Disable to start the disabling process
4. Confirm the action
5. Once the UI has completed all tasks for disabling Optane™ and any necessary file migration has completed (progress indicator reaches 100%)
6. Restart the windows manually using the restart button from Start Menu to reboot the system and complete the disablement process

Intel® Optane™ Memory UI installed:

1. From Windows desktop, launch the Intel® Optane™ Memory UI
2. Click on the 'Setup' tab
3. Click Disable to start the disabling process
4. Confirm the action
5. Once the UI has completed all tasks for disabling Optane™ and any necessary file migration has completed (progress indicator reaches 100%), the [Restart] button will be displayed
6. Click the [Restart] button to reboot the system and complete the disablement process

Intel® RST UI installed:

1. From Windows desktop, launch the RST UI
 2. Click the 'Optane™ Memory' tab at the top
 3. Click Disable to start the disabling process
 4. Confirm the action
 5. Once the UI has completed all tasks for disabling Optane™ and any necessary file migration has completed (progress indicator reaches 100%), the [Reboot] button will be displayed
-



-
6. Click the [Reboot] button to reboot the system and complete the disablement process
-

Reinstall your OS or copy over your current to the new slow disk

WARNING: In all Intel® Optane Memory enabling scenarios, all data that is on the fast disk prior to enabling will be deleted during the Optane™ Memory enabling process

At this point you can reinstall the operating system and rebuild your system or you can use whatever process you wish to use to clone/copy your current system and apply it to the new slow disk:

Replacing an accelerated OS drive:

1. Install the new slow media (SATA HDD, SSD, or SSHD)
 - a. If the slow media is the OS disk, then continue with step 2
 - b. If the slow media is a data drive
2. Install the Windows 10 OS or apply clone/copy
3. Once the OS has been installed or transferred to the new slow media, re-enable the Intel® Optane™ Memory
4. Complete any customizations or application installs
5. Replacing an accelerated data drive
6. If possible backup all data from original data drive
7. Remove the old data drive and insert the new data drive
8. Re-enable data drive acceleration with Optane™ Memory
9. Copy all required data to the new data drive
10. EOT

6.5.2 Intel® Optane™ Memory Module Upgrade/Replacement

Disable Optane™ Memory:

1. From Windows desktop, launch the Intel® Optane™ Memory UI
 - or launch the Intel® RST UI
 - or launch Intel® Optane™ Memory and Storage Management UI
 2. Click the 'Setup' tab at the left
 - or for the Intel® RST UI, click the Intel Optane™ Memory tab at the top
 - or the Intel® Optane™ Memory and Storage Management UI, click the 'Intel® Optane™ Memory' tab
 3. Click Disable to start the disabling process
 4. Confirm the action
 5. Once the UI has completed all tasks for disabling Optane™ and any necessary file migration has completed
-



(after the progress indicator reaches 100%), the [Restart] or [Reboot] button will be displayed

- For Intel® Optane™ Memory and Storage Management UI, you have to restart manually.
6. Click the [Restart] or [Reboot] button to reboot the system and complete the disablement process
-

Replace the Intel® Optane™ memory module:

1. Power down the computer
 2. Open the computer and locate the old Optane™ memory module that you wish to replace (**Note: consult your computer manufacturer for the location of the slot for the Optane™ memory module and instructions to remove and insert an M.2 module**)
 3. Remove the old module and insert the new module.
 4. Close the computer and power it on and boot into the Windows OS.
-

Re-enable Intel® Optane™ Memory:

WARNING: In all Intel® Optane™ Memory enabling scenarios, all data that is on the fast disk prior to enabling will be deleted during the Optane™ Memory enabling process

1. From Windows desktop, launch the Intel® Optane™ Memory UI
 - or launch the Intel® RST UI
 - or launch Intel® Optane™ Memory and Storage Management UI
 2. Click on the 'Setup' tab
 - or for the Intel® RST UI, click the Intel Optane™ Memory tab at the top
 - or the Intel® Optane™ Memory and Storage Management UI, click the Intel® Optane™ Memory tab
 3. Click Enable to start the enabling process
 4. Select the fast media to use for enabling and continue
 5. Once the UI has completed all tasks for enabling Optane™ and any necessary file migration has completed (after the progress indicator reaches 100%), the [Restart] or [Reboot] button will be displayed
 - For Intel® Optane™ Memory and Storage Management UI, you have to restart manually.
 6. Click the [Restart] or [Reboot] button to reboot the system and complete the enablement process
-



6.6 Managing Intel® Optane™ Memory

This section describe the management functions available in the various user interfaces that are available to the end-user

6.6.1 During the Pre-OS (Pre-Boot)

6.6.1.1 BIOS HII User Interface for Intel® RST

The BIOS HII UI only allows the user to view storage sub-system configuration and the ability to disable the Optane™ configuration

Disable Optane™ configuration:

1. Enter your system BIOS and locate the Intel® Rapid Storage Technology HII UI
2. You will see listed the Optane™ volume and the physical disks that are used in the Optane™ volume. Starting with version 16.7, Optane volume will also display “Incomplete Optane Volume” if incomplete Optan volume member disk is present in the system.
3. Highlight the Optane™ volume or “Incomplete Optane™ Volume” and hit <Enter>
 - A. Deconcatenate : Use this option to disable Optane™ and return the system to a non-accelerated state.
 - i. [X] Checkbox to preserve user data upon deconcatenation; checked is the default.
 - When checked this action will take time to migrate data from the cache device to the HDD/SSD.
 - **WARNING!!** When unchecked there is no time taken to preserve the user data (any data on the drive will be **DELETED**). RST removes the RST metadata from the disk and does not migrate any user or system data to the HDD/SSD
 - ii. <No> Decision box to confirm deconcatenation action; Yes or No (No is default)

Note: The location of the above functions in the system BIOS on your computer will vary based on the manufacturer of your computer system. If you have trouble locating these settings contact your system manufacturer.



6.6.2 During the OS Runtime

6.6.2.1 Intel® Optane™ Memory and Storage Management UI

This section describes management capabilities of the Intel® Optane™ Memory and Storage Management UI

6.6.2.1.1 Enabling/Disabling Intel® Optane™ Memory Acceleration

**Intel® Optane™
Memory and Storage
Management UI Tab:**

**Enable Optane™
configuration:**

1. From Windows desktop, launch the Intel® Optane™ Memory and Storage Management UI
 2. Click on the 'Intel® Optane™ Memory' tab
 3. Click **Enable** to start the enabling process
 4. Select the fast media to use for enabling and continue
 5. Once the UI has completed all tasks for enabling Optane™ and any necessary file migration has completed, reboot the system manually and complete the enablement process
-

**Intel® Optane™
Memory and Storage
Management UI:**

**Disable Optane™
configuration:**

1. From Windows desktop, launch the Intel® Optane™ Memory and Storage Management UI
 2. Click on the 'Intel® Optane™ Memory' tab
 3. Click **Disable** to start the disabling process
 4. Confirm the action
 5. Once the UI has completed all tasks for disabling Optane™ and any necessary file migration has completed (progress indicator reaches 100%), reboot the system manually and complete the disablement process
-

About Tab:

There are no user actions available other than to view the following information:

- A. The version number of the Intel® Optane™ UI
 - B. A link to Intel support website
 - C. And some application licensing information
-

6.6.2.2 Intel® Optane™ Memory UI

This section describes management capabilities of the Intel® Optane™ Memory UI

6.6.2.2.1 Enabling/Disabling Intel® Optane™ Memory Acceleration

Setup Tab:

**Enable Optane™
configuration:**

1. From Windows desktop, launch the Intel® Optane™ Memory UI
 2. Click on the 'Setup' tab
-



-
3. Click Enable to start the enabling process
 4. Select the fast media to use for enabling and continue
 5. Once the UI has completed all tasks for enabling Optane™ and any necessary file migration has completed, the [Restart] button will be displayed
 6. Click the [Restart] button to reboot the system and complete the enablement process
-

Setup:

Disable Optane™ configuration:

1. From Windows desktop, launch the Intel® Optane™ Memory UI
 2. Click on the 'Setup' tab
 3. Click Disable to start the disabling process
 4. Confirm the action
 5. Once the UI has completed all tasks for disabling Optane™ and any necessary file migration has completed (progress indicator reaches 100%), the [Restart] button will be displayed
 6. Click the [Restart] button to reboot the system and complete the disablement process
-

Statistics Tab:

Note! This feature only supports Intel® Optane™ devices that have a capacity of 32GB or more.

There is no user interactions available other than to view the status of "Intel® Optane™ Memory Optimization Schedule". The indicators are:

- A. Last Optimization
 - B. Next Scheduled Optimization
-

About Tab:

There are no user actions available other than to view the following information:

- A. The version number of the Intel® Optane™ UI
 - B. A link to Intel support website
 - C. And some application licensing information
-

6.6.2.3 Intel® RST UI

This section describes Optane™ management capabilities of the Intel® RST UI.



Enable Optane™ configuration:

1. From Windows desktop, launch the RST UI
2. Click the 'Optane™ Memory' tab at the top
3. Click Enable to start the enabling process
4. Select the fast media to use for enabling and continue
5. Once the UI has completed all tasks for enabling Optane™ and any necessary file migration has completed, the [Reboot] button will be displayed
6. Click the [Reboot] button to reboot the system and complete the enablement process

Disable Optane™ configuration:

1. From Windows desktop, launch the RST UI
 2. Click the 'Optane™ Memory' tab at the top
 3. Click Disable to start the disabling process
 4. Confirm the action
 5. Once the UI has completed all tasks for disabling Optane™ and any necessary file migration has completed (progress indicator reaches 100%), the [Reboot] button will be displayed
 6. Click the [Reboot] button to reboot the system and complete the disablement process
-

6.6.3 Roaming Optane™ Volumes

Roaming Optane™ volumes intact between computers can be done safely if certain conditions are met (both member disks must remain paired; do not physically separate):

1. The target computer (where you are moving the volume to) is the same or similar Optane™ capable system as the source computer (where you are moving the volume from)
2. The target computer BIOS meets the minimum requirements to support Optane™
3. The BIOS must have the following properly set prior to booting to the roamed volume:
 - a. The SATA PCH must be set to the proper mode to support Optane™ (Intel RST ... or Intel RST Premium...) **WARNING! If the computer is in AHCI mode and you boot with the Optane volume installed, the Optane™ volume will become corrupted and all data on the Optane™ volume will be inaccessible and have to be reset to non-Optane which will delete all data on the volume. You MUST ensure that the SATA PCH mode is in the proper mode as indicated above!**
 - b. The PCIe slot where the Optane™ module will be inserted must be set to remapping enabled
 - c. The SATA port for the slow disk must be an internal SATA port
4. Once these prerequisites have been met it is safe to insert the Optane™ volume member disks into the target computer and boot to the Optane™ volume. **It is recommended to always backup important data prior to roaming as a precaution.**
5. **Teton Glacier does not support**



6.7 I/O Error Handling

6.7.1 Host I/O Failures

Fast Media- I/O failure:

1. Action taken by the RST SW:
 - A. The RST driver returns the I/O error to Windows.
 2. System Ending State:
 - A. No change: Optane acceleration remains enabled.
-

Slow Media- I/O failure:

1. Action taken by the RST SW:
 - A. RST driver returns the I/O error to the Windows
 2. System Ending State:
 - A. No change: Optane acceleration remains enabled.
-

6.7.2 RST I/O Failures:

6.7.2.1 During Optane Enabling

READ failure to slow drive:

1. Action taken by the RST SW:
 - A. Write bad ECC to fast drive
 - B. Enabling is halted and rollback to disabling
 - C. Notify user of significant amount of errors and recommend disabling the Optane™ Memory
 2. System ending state:
 - A. System Acceleration enabled.
 3. Recommended corrective action:
 1. Disable Optane™ Memory
 2. Replicate system disk to new drive
 3. Replace faulty slow drive with new drive
 4. Re-enable Optane™ Memory
-

WRITE failure to fast disk:

1. Action taken by the RST SW:
 - A. Continue in WT cache mode during Optane™ Memory enabling.
 - B. Enabling is halted and rollback to disabling
 - C. Display failure in UI.
 2. System ending state:
 - A. Optane™ Memory disabled.
 3. Recommended corrective action:
 - A. Power down system
 - B. Replace faulty fast media with new fast media
 - C. Enable Optane™ Memory
-



6.7.2.2 During Optane™ Memory Disabling

WRITE failure to slow media:

1. Action taken
 - A. Continue disabling Optane™ Memory
 2. System ending state:
 - A. Optane™ Memory successfully disabled
 3. Recommended corrective action:
 - A. Reboot the system normally
 - B. Let the Intel® RST driver handle any RST specific recovery tasks.
-

READ failure to fast media:

1. Action taken by the RST SW:
 - A. Write bad ECC to slow drive for LBAs that cannot be read from fast drive
 - B. Continue the Optane™ Memory volume disabling
 2. System ending state:
 - A. Optane™ Memory disabled
 - B. System Normal state
 3. Recommended corrective action:
 - A. None
-

6.7.3 Missing Media Failures:

6.7.3.1 Drive Missing at Boot

Fast disk missing:

1. Action taken by the RST SW:
 - A. If system boots and the Optane™ module is not detected by the RST UEFI driver, the RST UEFI driver will protect the current data on the slow media by disabling it and not exposing it to the boot manager. This allows the user the opportunity to locate and reinsert the missing fast media (or try additional reboots) to allow the UEFI driver additional opportunity to detect and pair the slow media and fast media and return the Optane™ volume to a normal state.
 2. System ending state:
 - A. System is unbootable.
 - B. Slow media set to 'Disabled' state
 3. Recommended corrective action:
 - A. Power down and confirm the location of the missing Optane™ memory module.
 1. Reattach if missing
 2. If not missing:
-



-
- a) Check the connector
 - b) Disconnect the slow media and boot to BIOS menu
 - c) Enter the RST HII UI
 - d) Confirm that the Optane™ memory module is displayed (its Status should be 'Offline' in this scenario)
 - e) If the Optane™ memory module is not present, then exit the RST HII UI and enter your BIOS menu where the SATA controller remapping function is located and confirm that the port location of the Optane™ memory module has remapping enabled
 - f) If remapping not enabled, enable it. Save the configuration and power down the computer.
3. Reattach the slow media and power up the computer
-



Slow disk missing:

1. Action taken by the RST SW:
 - A. If system boots and the slow media device is not detected by the RST UEFI driver, the RST UEFI driver will protect the current data on the Optane™ Memory module by disabling it and not exposing it to the boot manager. This allows the user the opportunity to locate and reinsert the missing slow media (or try additional reboots) to allow the UEFI driver additional opportunity to detect and pair the slow media and fast media and return the Optane™ volume to a normal state.
2. System ending state:
 - A. System is unbootable.
 - B. Fast media set to status Disabled¹

Note¹: a current errata on file has the status of the Disabled fast media displayed as 'Cache' when viewed in the RST preOS UEFI HII UI. The correct status should be displayed as 'Disabled' and will be fixed in a future release.

3. Recommended corrective action:
 - A. Power down and confirm the location of the missing slow media drive.
 1. Reattach if drive is physically missing
 2. If not missing:
 - a) check the connection
 - b) Boot into the BIOS and go to the Intel® Rapid Storage UI
 - c) In the UI see if either the slow or fast disk is listed on the main page
 - d) It appears the slow disk has experienced an uncorrectable failure and may need to be replaced. Go to the [Disk Failure](#) section in this chapter for instructions to replace the failed slow disk.

6.7.3.2 Drive Hot Unplugged

Hot unplug fast media disk:

1. Action taken
 - A. No RST action taken; System is expected to experience a Windows* bug check (blue screen)
 2. System ending state:
 - A. Windows* blue screen bug check
-



-
- B. Upon next boot, the Intel® RST driver will evaluate the storage subsystem
3. Recommended corrective action:
 - A. Reinsert the fast media back into the remapped PCIe slot
 - B. Reboot the system normally
 - C. Let the Intel® RST driver handle any RST specific recovery tasks.
-

Hot unplug slow media disk:

1. Action taken by the RST SW:
 - A. No RST action taken; System is expected to experience a bug check (blue screen)
 2. System ending state:
 - A. Blue screen bug check
 - B. Upon next boot, the Intel® RST driver will evaluate the storage subsystem
 3. Recommended corrective action:
 - A. Reinsert the slow media to its SATA port
 - B. Reboot the system normally
 - C. Let the Intel® RST driver handle any RST specific recovery tasks.
-

6.7.4 S.M.A.R.T. Events

S.M.A.R.T. event (event count threshold reached) on fast media:

1. Action taken (once the SMART event count threshold is reached):
 - A. The fast media's block cache (BC) is placed in Write-Through mode (reduced performance)
 - B. Pop-up message with notification of media errors with recommendation to disable Optane™ Memory and correct the problem (e.g. replace the fast media)
 2. System ending state:
 - A. Optane™ Memory remains enabled.
 - B. Optane™ Memory placed in reduced performance mode (WT cache mode)
 3. Recommended corrective action:
 - A. Disable Intel® Optane™ Memory
 - B. Power down the system
 - C. Replace the Intel® Optane™ memory module
 - D. Reboot and enable Intel® Optane™ Memory
-

S.M.A.R.T. event (event count threshold

1. Action taken (once the SMART event count threshold is reached):
-



reached) on slow media:

- A. The fast media's block cache (BC) is placed in Write-Through mode (reduced performance)
 - B. Pop-up tray icon notification of media errors with recommendation to disable Optane™ Memory and correct the problem (e.g. replace the fast media)
2. System ending state:
 - A. Intel® Optane™ Memory remains enabled.
 - B. Intel® Optane™ Memory placed in reduced performance mode (WT cache mode)
 3. Recommended corrective action:
 - A. Disable Optane™ Memory
 - B. Power down the system
 - C. Recover (or whatever duplication method you choose) your faulty system drive to a new drive and replace the faulty drive
 4. Reboot and enable Intel® Optane™ Memory
-

6.7.5 Fast Media: Block Cache Errors

RST Metadata Read failure during boot:

1. Action taken by the RST SW:
 - A. Optane™ volume is placed 'offline'.
 2. System ending state:
 - A. Optane™ volume offline.
 - B. System unbootable
 3. Recommended corrective action:
 - A. Retry boot
 - B. If system unbootable after several tries then the metadata is corrupted and unrecoverable
-

RST Metadata Write failure during shutdown

1. Action taken by the RST SW:
 - A. Treat the same as a dirty shutdown
 - B. RST evaluate storage subsystem at next boot
 2. System ending state:
 - A. System is bootable.
 - B. System in normal state
 3. Recommended corrective action:
 - A. Continue power down/restart as normal
-



Read failure of cache frame with dirty data exceeds the preset threshold value (fast media failure could be imminent)

1. Action taken by the RST SW:
 - A. The fast media's block cache (BC) is placed in Write Through mode (reduced performance)
 - B. Tray icon notification of media Read errors with recommendation to disable Optane™ Memory and correct the problem (e.g. replace the fast media).
 - C. RST evaluate storage subsystem at next boot
 2. System ending state:
 - A. BC in WT cache mode in reduced performance state.
 - B. Optane™ Memory remains enabled
 3. Recommended corrective action:
 - A. Disable Optane™ Memory
 - B. Power down the system
 - C. Replace the Optane™ memory module
 - D. Reboot and enable Optane™ Memory
-

6.8 Intel® Optane™ Memory Member Disk Failures Requiring Replacement of Disk

6.8.1 Slow Disk (SATA HDD, SSD, SSHD) Replacement

If your system encounters an unrecoverable catastrophic failure of the slow media (the OS system disk becomes inoperable), there is no recovery/repair available. Use the following recommended steps to get the system back up and running:

Data recovery:

No Intel® RST data recovery tools are available for a drive that has experienced mechanical or electrical failure and is considered 'inoperable'. There may be third party tools available for recovering data in this situation. Intel has no recommendations regarding third party data recovery tools.



Disassociate the Optane™ memory module.

Disassociation of the Optane™ module is required in order to be able to reuse it to enable Optane™ with the replacement slow media.

Note: Disassociation removes the Optane™ configuration information from the Optane™ module and deletes all data (data which is unusable cached data from the inoperable OS disk that is being replaced). Once this disassociation is completed the module can again be used to enable Optane™.

1. Boot into your system BIOS
2. Enter the Intel® Rapid Storage Technology pre-OS UI
(Note: consult your computer manufacturer for the location of this UI in your system BIOS)
3. The slow media (Intel® Optane™ memory module) should be displayed on the main page,
 - A. Highlight it and hit <Enter> to take you to the "Reset to non-Optane" page
 - B. Under 'Disk Actions' highlight the action 'Reset to non-Optane' and hit <Enter>
 - C. Highlight 'Yes' and hit <Enter>
4. The disk is now available to be used to enable System Acceleration with Intel® Optane™ Memory

Reinstall your OS or recover it from a previous backup

At this point you can reinstall the operating system and rebuild your system:

1. Install the new slow media (SATA HDD, SSD, or SSHD)
2. Install the Windows 10 OS
3. Re-enable Intel® Optane™ Memory
4. Complete any customizations or application installs

6.8.2 Intel® Optane™ Memory Module Replacement

This section documents support for Intel® Optane™ memory module upgrades or replacements for systems that already have Intel® Optane™ Memory enabled.

Whether you are upgrading the memory module or replacing a faulty memory module, the following steps will apply:

Disable Optane™ Memory:

1. From Windows desktop, launch the Intel® Optane™ Memory UI
 - or launch the Intel® RST UI
-



-
- or launch Intel® Optane™ Memory and Storage Management UI
2. Click the 'Setup' tab at the left
 - or for the Intel® RST UI, click the Intel Optane™ Memory tab at the top
 - or the Intel® Optane™ Memory and Storage Management UI, click the 'Intel® Optane™ Memory' tab
 -
 3. Click Disable to start the disabling process
 4. Confirm the action
 5. Once the UI has completed all tasks for disabling Optane™ and any necessary file migration has completed (after the progress indicator reaches 100%), the [Restart] or [Reboot] button will be displayed
 - For Intel® Optane™ Memory and Storage Management UI, you have to restart manually.
 6. Click the [Restart] or [Reboot] button to reboot the system and complete the disablement process
-

Replace the Intel® Optane™ memory module:

1. Power down the computer
2. Open the computer and locate the old or faulty Optane™ memory module that you wish to replace

Note: Consult your computer manufacturer for the location of the slot for the Optane™ memory module and instructions to remove and insert an M.2 storage module

3. Remove the old or faulty module and insert the new module.
 4. Close the computer and power it on and boot into the Windows OS.
-



**Re-enable Intel®
Optane™ Memory:**

1. From Windows desktop, launch the Intel® Optane™ Memory UI
 - *or launch the Intel® RST UI*
 - *or launch Intel® Optane™ Memory and Storage Management UI*
 2. Click on the 'Setup' tab
 - *or for the Intel® RST UI, click the Intel Optane™ Memory tab at the top*
 - *or the Intel® Optane™ Memory and Storage Management UI, click the 'Intel® Optane™ Memory' tab*
 3. Click Enable to start the enabling process
 4. Select the fast media to use for enabling and continue
 5. Once the UI has completed all tasks for enabling Optane™ and any necessary file migration has completed (after the progress indicator reaches 100%), the [Restart] *or* [Reboot] button will be displayed
 - *For Intel® Optane™ Memory and Storage Management UI, you have to restart manually.*
 6. Click the [Restart] *or* [Reboot] button to reboot the system and complete the enablement process
-

6.9 Windows Recovery Environment Support

This section documents support for system recovery when Intel® Optane™ Memory is enabled on the system.

6.9.1 Setting Up the Windows Recovery Environment (WinRE)

All WinRE recovery methods are supported provided the following steps are taken prior to installing the Operating system:

6.9.1.1 OEM Factory Built Systems

Prior to building the system that the reference PC image will be used for imaging systems as they are built on the factory assembly line, update the .wim files located in the Windows OS distribution media or ISO by injecting the RST 15.5.0.1051 or later driver files. Using the built-in Windows DISM tool, mount and add the RST 15.5.0.1051 driver into the following image files:

1. Boot.wim
2. Install.wim
3. WinRE.wim (note that the WinRE image file is located within the Install.wim image and will have to be mounted while the Install.wim image is mounted)



Systems built with these file having the RST driver injected into them will be setup to support Intel® Optane™ Memory enabled systems in the event of a recovery condition that causes to system to boot to the WinRE menu.

6.9.1.2 Post-Factory Built Systems

For systems built outside of the factory using the default Windows setup, the in-box storage driver is used when the Windows Recovery Environment is configured during the Windows setup. The in-box driver does not support Intel® Optane™ Memory volumes. Thus when the system boots to the WinRE environment with the in-box storage driver, the Optane™ Memory volume will not be detectable. None of the recovery methods will be successful.

However, prior to experience a recovery condition, the WinRE.wim file can be updated with the RST 15.5 driver. Then if a recovery condition happens, the WinRE will be able to detect the Optane™ Memory volume. Use the following procedure to update the WinRE on a live system (while the Windows* OS is running):

Note: *Not all recovery conditions will be successful 100% of the time, not even on non-Optane™ Memory enabled systems.*

Open a command prompt on your desktop, and run the command:

```
>\reagentc.exe /info (the output printed to screen will tell you where to find the WinRE.wim image file; the output is as follows):
```

- Windows RE Location: \\?\GLOBALROOT\device\harddisk0\partition2\Recovery\WindowsRE
- **disk0** : this indicates that the Winre.wim image file is on disk 0 (use diskpart list disk)
 - **partition2** : this indicates that WinRE.wim is on partition 2 of disk 0 (diskpart select disk 0, select partition 2)
 - **Recovery\WindowsRE** : indicates the directory where the image file is located

So, on the second partition of the harddisk0 (also known as the "C:" drive, according to "Diskpart"), you will find a hidden "recovery" directory, with subdirectory "WindowsRE". Within here is the "winre.wim" file.

Now to inject the drivers into the image file, first, place all the drivers you wish to inject into an easily accessible directory (such as c:\temp\drivers, in our example), and then run the following commands:

```
>\diskpart
>\select disk 0
>\select partition 2
>\assign letter=R
>\exit
>\md c:\temp\mount\winre
>\md c:\temp\drivers
    "copy RST 15.5 driver files to the c:\temp\drivers directory"
>\dism /mount-wim /WimFile:R:\recovery\WindowsRE\winre.wim /index:1
    /mountdir:c:\temp\mount\winre
>\dism /image:c:\temp\mount\winre /add-driver /driver:C:\temp\drivers /recurse
>\dism /unmount-wim /mountdir:c:\temp\mount\winre /commit
```



6.9.2 WinRE Menu Items

6.9.2.1 Troubleshoot → Advanced Options

Invoke the Windows Recovery Environment menu. Main page “Choose an option:”, select ‘Troubleshoot’, then select ‘Advanced options’:

System Restore:

Before you can use this option, you must have created a ‘restore point’ while in Windows Control Panel. From Control Panel, select ‘Recovery’ and follow defaults to ‘Configure System Restore’. Once ‘restore point’ is created you can use this option:

1. Click on the option; your system will reboot
2. Click on the account you wish to use
3. Enter the password and click [Continue]
4. Follow the default prompts
5. Select a backup and follow the prompts to complete the **restore**

System Image Recovery:

Before you can use this option, you must have created a ‘backup’ while in Windows Control Panel. From Control Panel, select ‘Backup and Restore (Windows 7)’, then select ‘Setup backup’, and in the left navigation click on ‘Create a system image’ and follow defaults. Once an image is created you can use this option:

1. Click on the option; your system will reboot
2. Click on the account you wish to use
3. Enter the password and click [Continue]
4. Follow the default prompts
5. Select a backup and follow the prompts to complete the **recovery**

6.9.2.2 Troubleshoot → Recover from a Drive

Invoke the Windows Recovery Environment from the bootable ‘Recovery Drive’:

Recovery Disk:

Warning! Use this method as a last resort. The ‘Fully clean the drive’ option of this process will reformat your entire HDD and reinstall a fresh OS. Personal data is not reserved with this method of Window Recovery.



Before you can use this option, you must have created a 'Recovery Disk' while in Windows Control Panel. Connect a USB thumb drive, minimum 32GB (you may need larger based on your system). From Control Panel, select 'Recovery' and follow defaults to 'Create a recovery disk'. Once the bootable 'Recovery disk' is created you can use this option:

1. Insert the USB Recovery disk and boot your system.
2. Select the USB drive as the boot device and boot to the USB key
3. Click on your Keyboard Layout
4. Click on 'Troubleshoot'
5. Click on 'Recover from a drive'
6. Click on the option you wish to use
 - a. Option 1: Just remove my files
 - b. Option 2: Fully clean the drive
7. Follow the default prompts to complete the recovery process



7 OEM HVM Factory Support for Intel® Optane™ System Acceleration


As there are many possible OEM factory processes, it is beyond the scope of this document to cover all possible OEM factory flows. There are two objectives for this chapter. One is to provide OEMs with an example of a possible flow based on what RST believes will provide the factory the fastest build process that is based upon the Microsoft provided manufacturing tools and processes. The other objective is to provide OEMs with all the requirements and considerations they need to take into account when building systems configured with Intel® Optane™ Memory.

Important Note: For OEM/ODM manufacturing process flow with Teton Glacier, RST 17.0 does not inject RST driver into recovery image. OEM/ODM must inject RST 17.0 driver into recovery image because Windows RS4/RS5 RST inbox driver does not support TG configuration. Otherwise, the system will not be able to recover once Optane is enabled on TG.

7.1 Intel® Optane™ Pre-Factory Recommendations for the 'ReferencePC'

This section is meant to provide guidance on building the reference PC ('ReferencePC') in the pre-factory-assembly environment. This is where the OEM does their normal build process of installing the Windows OS and any applications required on a PC (ReferencePC) with the HW that represents the ordered PC that will be going through the factory assembly process (the CustomerPC). The OEM/ completes the build of the ReferencePC, extracts and stores the "gold" image of the install to a server ('Image Server') where the image can be accessed by the factory floor. At the proper point during the factory assembly/build process, the image is downloaded from the 'Image Server' onto the 'CustomerPC' and applied to the storage media (HDD, SSD, Optane™ drive, etc.). Below are recommended tasks to ensure that the final customer OS image will properly support System Acceleration with Optane™ Memory. This process can be used for BTO (Build-to-Order) or BTP (Build-to-Plan) HVM.

Figure 7.1: Reference PC Build Flow





7.1.1 Optane™ Recommendations for the 'ReferencePC'

7.1.1.1 Windows installation media update

1. Download the latest Intel® RST SW/driver package that supports Intel® Optane™ Memory
2. Obtain the desired Windows 10 OS distribution media from Microsoft
3. Follow the Microsoft process to add drivers to an image file (.wim). Add the Intel® RST driver to the following image files in the Windows 10 distribution media:
 - Boot.wim
 - Install.wim
 - WinRE.wim
4. (Optional if you already have a WinPE bootable disk with the Intel® RST 15.5 or later driver installed). Create bootable WinPE USB with the Intel® RST 15.5 or later driver installed and copy the RSTCLI64.exe command line utility to a folder on the disk.

7.1.1.2 Windows OS Installation

1. Boot to the WinPE thumb drive and create the Optane™ volume that the OS will be installed to using the following command:

```
rstcli64 --OptaneMemory --enable --fast-drive [fastdrive_id] --drive-to-accel [slowdrive_id] --file-cache-offset
```

Example: `rstcli64 --OptaneMemory --enable --fast-drive 0-3-0-0 --drive-to-accel 0-0-1-0 --file-cache-offset [LBA]1`

[LBA]¹ (see important note at the end of this section)

Note: If the fast PCIe NVMe Optane™ drive and the slow media to be accelerated are the only RST controlled drives in the system, then you can use the following simplified command:

```
rstcli64 --OptaneMemory --enable
```

The **fast-drive** and the **drive-to-accel** will be auto-detected if they are the only two drives in the system (the USB thumb drive is not controlled by RST so it will not be detected as a third drive)

2. Reboot and insert the updated Windows OS distribution media
3. Run the Windows installation setup program and complete the OS installation.
4. Complete installation and configuration of all apps and settings that are to be included in the 'Reference PC Image' (ReferencePC.wim)



Figure 7.2: Example of Partition Offset LBA in Windows Diskpart

```
Administrator: Command Prompt - diskpart

DISKPART> list partition

Partition ### Type          Size      Offset
-----
Partition 1   Recovery    300 MB    1024 KB
Partition 2   System      499 MB    301 MB
Partition 3   Reserved    128 MB    800 MB
Partition 4   Primary     148 GB    928 MB
Partition 5   OEM         70 MB     148 GB

DISKPART> select partition 4

Partition 4 is now the selected partition.

DISKPART> detail partition

Partition 4
Type       : ebd0a0a2-b9e5-4433-87c0-68b6b72699c7
Hidden     : No
Required   : No
Attrib     : 0000000000000000
Offset in Bytes: 973078528

Volume ### Ltr Label      Fs   Type          Size      Status      Info
-----
* Volume 0  C  OSDisk     NTFS Partition    148 GB    Healthy     Boot

DISKPART>
```

Note: This parameter is very important when enabling Optane™ Memory using Optane™ devices that are 32GB or larger when you using the RSTCLI64.exe tool (or RcfgSata.efi tool). 32GB or larger SKUs have a file cache region in addition to the block cache. This parameter designates the LBA of the slow disk that aligns with the beginning of the file cache to begin. This LBA is at the beginning of the Windows* primary (C:\) partition. You must determine the offset of the Windows primary partition. This number is usually given in Bytes if you use the 'Detail' command in 'Diskpart' (or MB if you use the 'list partition' command). In Diskpart select the disk (or Optane™ volume) containing the OS. Then select the Windows* partition, then type the following command: 'detail partition'. The partition's offset will be given in 'Bytes'. Divide that number by 512 (an LBA is 512B) to determine the LBA of the offset. Example: (using info in Figure 6.2) if the offset is given as 973078528 bytes, then the offset LBA would be calculated as follows:

$973078528 \div 512 = 1900544$ LBA. Thus the command to enable Optane™ Memory would be:

`rstcli64 --OptaneMemory --enable --fast-drive 0-3-0-0 --drive-to-accel 0-0-1-0 --file-cache-offset 1900544`

Or alternately using the 'list partition' command it can be calculated as follows:

$(928 \times 1024 \times 1024) \div 512 = 1900544$ LBA.

If this parameter is incorrect, the first time the system is booted into Windows after the install (e.g. during OOBE), in the background the RST driver will rebuild the Optane™ volume to place the file cache at the proper offset. This will have a slight negative impact to the system performance during the volume rebuild period.



Note: : Manufacturers that boot the customer computer that is being built into the Windows 10 OS during their factory build process after enabling Optane™ on the build system, can omit the file-cache-offset parameter. This is because when you boot the customer computer that is being built into the Windows 10 OS the first time, the Intel® RST SW automatically repairs the file cache offset in the background if it is not specified or if it is specified incorrectly during the Optane™ enabling step. Although it is recommended that the offset parameter be specified correctly, it can be omitted with little impact to the Optane™ configuration in this manufacturing scenario.


7.1.1.3 Extract 'Reference PC' "Gold" Image and Store for Later Use in the Factory Build of 'Customer PC'

1. Run Microsoft 'DISM' Imaging tool to capture gold 'Reference PC Image' (ReferencePC.wim)
2. Store the gold image on a source that will be available to the 'Customer PC' during the factory assembly build process (e.g. on a server, "Image Server", that is accessible via the network in the factory environment)
3. This completes the pre-factory 'Reference PC'/'ReferencePC image' build process

7.2 Intel® Optane™ Factory-Enabled System Build

This build process allows the OEM to ship the system to end-user fully configured and optimally accelerated at the time of the end-user OOBE. This allows for the best OOBE as the cache regions have already been populated with data when shipped from the factory.

Figure 7.3: Factory Build Flow





7.2.1 Requirements/Considerations

1. Ensure that there are no Windows system partitions on the Optane™ memory device. The Optane™ enabling process will delete all non-Windows OS partitions but will fail to enable if a Windows OS partition is detected. **(Note: all data on the Optane™ memory module will be deleted during the enable process)**
2. System must be in either Intel® RST, or Intel® RST Premium mode with the Intel® RST 15.5 OS driver installed and the Intel® RST 15.5 UEFI driver integrated in the system BIOS

7.2.2 PHASE 1: OEM Pre-Optane™-Config Factory Processes

This is the initial part of the OEM factory build process for the 'CustomerPC' build. There are no Optane™ requirements for this portion of the build process. These are processes specific to the OEM that the OEM would perform on all system configurations, not just Optane™. Any processes in this phase that require testing the final storage configuration would require that the system be in UEFI BIOS configuration, with the SATA controller in one of the Intel RST modes and the Optane™ device remapped.

7.2.3 PHASE 2: Optane™ Storage Sub-System Configuration

During this phase of the 'CustomerPC' build process, there are some Optane™-specific considerations:

1. Boot 'CustomerPC' to WinPE environment (ensure RST 15.5 driver is loaded and RSTCLI64 tool is on the WinPE boot environment or connected thumb drive).
2. Use the Microsoft 'Diskpart' tool to 'clean' the slow media prior to enabling Optane™. **(This ensures fastest Optane™ volume creation with no data to migrate. This is more important with any Optane™ module that is larger than the 16GB SKU)**
3. As there is only the Optane™ device and the slow media attached to the system, use the following simplified command to enable Optane™:

```
rstcli64 --OptaneMemory --enable --file-cache-offset xx
```

For Optane™ devices larger than the 16GB SKU, ensure that this value for 'xx' is correctly calculated. See section [Windows OS installation](#) above for details on calculating this value.

(The fast-drive and the drive-to-accel will be auto-detected if they are the only two drives in the system controlled by RST)

Note: Optional process (although not recommended) is to skip this step until a later point either in this phase or Phase 3 of the build process. If this step is skipped then in the next step the factory must reserve 5MB of unallocated space at the end of the slow media (max LBA) for RST metadata.

4. Partition the Optane™ volume (or slow media disk) using the recommended Microsoft* partitioning for Windows* 10. The following figure is the default partition layout for Windows* 10 UEFI/GPT based computers. **UEFI/GPT is required for Optane™**

Recovery – Windows Recovery Environment (WinRE) partition is where the Windows recovery tools are stored. This partition has a minimum size requirement of 300MB and must be large enough to



place the WinRE.wim image and must be formatted NTFS. If the size is less than 500MB, there must be at least 50MB of free space, otherwise 320MB of free space is required for larger than 500MB partitions.

Note: Make sure the WinRE.wim image file has the RST 15.5 driver added.

- a. System – ESP (EFI System Partition) must be a minimum of 100MB (this is the partition that the system boots to) and must be FAT32 formatted
 - b. MSR – (Microsoft Reserved Partition), beginning in Win10 the size is 16MB (receives no partition ID)
 - c. Windows – this is the OS partition and must be a minimum of 20GB (64-bit OS versions) and must be formatted NTFS.
 - d. OEM Recovery Partition -OEM-specific partitions (Utility partition) - OEMs that build systems with Recovery Image partitions usually place these partitions at the end of the disk. This partition is where OEM can copy the full Install.wim, this is recommended for Optane™ system, **(must have the RST 15.5 driver added)** as the recovery image. **If step 3 above was skipped then you are partitioning the slow media disk not the Optane™ volume. Prior to assigning attributes to the partition you must shrink the Recovery partition by 5MB to allow for RST metadata at the max LBA. This will allow for Intel® Optane™ Memory to be enabled later.** If step 3 was not skipped then you are partitioning the Optane™ Volume and the metadata space has already been reserved by the RST driver.
5. This completes phase 2 of the build flow (assuming you used the recommended flow and did not skip step 3), the 'CustomerPC' state is:
- a. Optane™ volume already enabled
 - b. Optane™ volume properly partitioned for Optane™
 - c. OEM Recovery partition large enough to store the 'ReferencePC.wim' image as Install.wim.

7.2.4 PHASE 3: OS and SW Download and Installation and OOBE Preparation

In this final phase of the factory build process, the factory process downloads the ReferencePC.wim (Install.wim), the WinRE.wim to the 'CustomerPC' and install the images. Also any additional custom applications not included in the 'ReferencePC.wim gold image can be downloaded and installed during this phase. Once all installations have completed, the factory process then prepares the 'CustomerPC' for the OOBE. The Optane™ recommended process should be similar to the following:

1. While still in the WinPE environment (no reboot is required once you start Phase 2), connect to the 'ImageServer' and download the ReferencePC.wim image to the OEM Recovery partition (rename it Install.wim)
2. Download the WinRE.wim to the WinRE partition
3. Apply the image to the Windows partition using the Microsoft* DISM tool
4. Use BCDBOOT to configure the system partition (ESP)
5. Register the location of the Recovery image (Install.wim) by using the REAgentC command in Windows
6. Register the location of the WinRE tools (WinRE.wim) by Using the REAgentC command
7. This completes Optane™ setup requirements
8. Continue with any additional configuration and OOBE preparation
9. This completes phase 3; 'CustomerPC' is ready to be shipped.



7.3 Intel® Optane™ Post-Factory-Enabled Builds

This build process allows the OEM to setup and fully configure their systems with all the Optane™ components installed but without the Optane™ volume enabled. The Optane™ acceleration enabling portion is to be accomplished during the end-user initial boot of the system OOBE. Via scripting, RSTCLI64 will enable the Optane™ volume during the initial customer boot. This is not the recommended build process as the initial OOBE is not accelerated.

7.3.1 Requirements/Considerations

1. 5MB of unallocated space must be left at the end of the HDD/SSD slow disk. OEM should not place any unmovable or protected partitions within this space
2. If required to place partition at the end of the disk, OEM must leave an offset of (Max LBA – 5MB) for the RST metadata (this can be done by shrinking the partition by 5MB prior to assigning attributes/GUID type to the partition)
3. Ensure no Windows OS partitions are on the Optane™ device
4. System must be in Intel RST or Intel RST Premium mode with RST 15.5.0.1051 or later driver installed and RST 15.5.0.2875 or later UEFI driver integrated into the system BIOS

7.3.2 Example Build Flow

1. OEM/System Integrator begins their build process
2. OEM/System Integrator can run any diagnostic and test programs as required on the system
3. Partition the SATA HDD/SSD as required for the system build
 - a) Ensure no partition is located in LBA offset of Max LBA – 5MB. This space must be unallocated
4. Apply Windows image to the HDD/SSD prepared for OOBE
 - a) The Intel® RST RSTCLI64 tool must be inserted in the Windows image with script to enable Optane™
 - b) Inject RST 15.5 driver in all .wim files (boot.wim, install.wim, winre.wim)
5. Complete the build process and prepare the system for OOBE shipment
 - a) Post-factory the OOBE runs script using RSTCLI64 to enable System Acceleration with Intel® Optane™ technology

7.4 OEM Application Pinning in the Factory Flow

This section covers OEM options for enabling application pinning in the factory process. OEM Pinning process is of type 'Soft Pinning'. File/application pinning falls in one of two types, a) Hard pinned files and b) Soft pinned files:

Hard Pinned files: These files are files pinned by the end user. They are pinned into the file cache region of the Intel® Optane™ memory module and can only be removed from the cache by the end user 'Unpinning' them. They are not influenced by the Intel® RST caching policies. So even if they



are never used they will never be automatically evicted from the cache by the Intel® RST caching policies.

Soft Pinned files: These files are files pinned by OEM/ISV. They are also pinned into the file cache region of the cache. Soft pinned files are influenced by the Intel® RST caching policies. As such they can be automatically evicted from the file cache if they become stale/cold from non-use or inactivity.

7.4.1 Manufacturing Considerations for Pinning

Process to accomplish pinning:

JSON Configuration Files:

JSON configuration files (e.g. "OEM_App-A.json") will be used in the factory environment for OEMs to define what files associated with an application will be pinned into the file cache as specified by the OEM. Each JSON file will define an application to be pinned and include a list of files that are important¹ to the functionality of that application which should be pinned along with the app's executable file.

Note1: *Please contact your Application SW vendor for suggestion/guideline on which files are deemed as important enough to include in pinning to enhance the performance of that application.*

JSON File Naming:

Each JSON file must be named according to the application's executable file name. If file name is OEMApp01.exe, then the JSON file for that application must be named OEMApp01.json.

JSON File Naming Example

Application to be Pinned Name	Application Executable	JSON File Name
Chrome	Chrome.exe	chrome.json
Windows Photo Viewer	ImagingDevices.exe	ImagingDevices.JSON
Windows Media Player	WmPlayer.exe	wmplayer.JSON

JSON File Location:

JSON files must be placed in a specific location of the computer's directory structure. OEM must place the files in the following directory:

`%CommonProgramFiles%\Intel\Intel Optane Memory\SupportedApps`
E.g. most commonly `C:\Program Files\Common Files\Intel\Intel Optane Memory\SupportedApps`


Note: *Normally this directory is created by the Intel® RST installers (SetupRST.exe and SetupOptaneMemory.exe). However, depending upon specific OEM factory build flow, this directory may have to be manually created by the OEM.*

JSON File Format:

The following screenshot shows one of the formats of the JSON file. The following 'short' example is for those applications where all of the supporting files to be pinned are located in the same directory as the application's executable file.



Figure 7.4: JSON file 'short' format example for the Chrome.exe Application



7.4.2 Using the JSON files in the Factory Flow

It is recommended that the JSON files be integrated into the factory flow process post customer specific application install prior to setting the computer to the OOBE configuration.

Typical BTO flow:

1. OEM-specific pre-SW installation HW verification
2. Enable/create Optane™ volume, partition disk, and apply gold OS image (pre-built)
3. Install BTO customer-specific applications
4. Set computer to OOBE-ready

Example BTO w/pinned applications flow:

1. OEM-specific pre-SW installation HW verification
2. Enable/create Optane™ volume, partition disk, and apply gold OS image (pre-built)
3. Install BTO customer-specific applications in the following order:
 - a. Install and configure custom applications
 - b. Copy the required JSON files into the correct folder in the file system's directory tree (a JSON file for each application to be pinned is required)
 - c. Integrate the Intel® RST OEM Pinning process into the manufacturing build process at this point to setup the pre-Pinning task (this prepares the computer to
 - i. Install BTO customer-specific applications
 - ii. Pin customer-specific applications
4. Prep the computer for OOBE and power down the computer in OOBE-ready state

7.4.3 OEM Pinning Methods

There are several possible methods available to accomplish the pinning process in the factory. The method selected to be used by a specific computer manufacturer/builder is determined by their build process and their customers' requirements. More than one method might be used in build process.



7.4.3.1 Pinning via Unattend.xml file

Unattend.xml file is generated by the Windows installation process. Pinning can be accomplished during the OS installation by modifying the Unattend.xml file. Figure 7.5 below shows an example of the format required to be followed to modify the Unattend.xml to include OEM Application Pinning during the OS installation.

Note: If the factory build process does not require any generic applications to be pinned (these would be applications that would ship with every computer regardless of specific customer order that the computer manufacturer/builder would deem advantageous to pin), then modifying the Unattend.xml file may not be feasible.

Figure 7.5 Example of 'Pinning' section of the Unattend.xml

```
<SynchronousCommand wcm:action="add">
  <CommandLine>rundll32.exe C:\Windows\IAStorAfsService\Optane.dll,OptanePinOemApplication path_to_OEM_app.exe</CommandLine>
  <Order>23</Order>
  <Description>Pin OEM application</Description>
</SynchronousCommand>
```

- Ensure that this section is placed near the end of the Unattend.xml file after the customer applications are installed
- Replace OEM_app.exe with the application's executable (e.g. path_to_Chrome.exe)
- Replace <Description> text with actual application (e.g. "Pin Chrome")
- Order of each app to be pinned is irrelevant; they can be pinned in any order

Pinning via the Unattend.xml is used when OEM wishes to define and pin applications during the OS Installation/Setup. OEM may choose this pinning option when there are default applications that will be pinned on all builds regardless of any order customization.

Also can be used when final build image "Gold Image" is the image that all builds will receive. E.g. an IT build that every system will receive.

7.4.3.2 Pinning via Windows Registry modification of the Install.wim

OEM may choose to use this method similar to the reasons for choosing the Unattend.xml method. OEM will modify the Install.wim to include the JSON files and the registry modifications to pin the application on first login by end-user. The build flow is as follows:

1. Mount the Install.wim of the gold image
2. Create directory for JSON files
(%MountDir%\Program Files\Common Files\Intel\Intel Optane Memory\SupportedApps)
3. Copy JSON files to SupportedApps directory
4. Load the registry of the install.wim image
5. Modify the registry of install.wim; use .reg file or edit directly through script to add registry entry for each application to be pinned
6. Unload the install.wim registry
7. Unmount and commit the changes to the Install image

Example of using a batch file and a reg file to accomplish the above flow for Excel, Internet Explorer, Windows Photo Viewer, and Power Point:

Batch file:

```
Dism /Mount-Image /ImageFile:E:\WindowsPart2.wim /index:1 /MountDir:C:\Temp\Mount\Windows
```



```
md C:\Temp\Mount\Windows\Program Files\Common Files\Intel\Intel Optane Memory\SupportedApps
xcopy C:\Temp\JSON\*. * C:\Temp\Mount\Windows\Program Files\Common Files\Intel\Intel Optane Memory\SupportedApps
reg load HKLM\MyKey2 C:\Temp\Mount\Windows\System32\config\software
C:\Temp\Mount\OEMPinRunOncePinned.reg
reg unload HKLM\MyKey2
Dism /unmount-image /MountDir:C:\Temp\Mount\Windows /commit
```

Reg file (e.g. OEMPinRunOncePinned.reg):
Windows Registry Editor Version 5.00

```
[HKEY_LOCAL_MACHINE\MyKey2\Software\Microsoft\Windows\CurrentVersion\RunOnce]
"Excel"="C:\windows\system32\rundll32.exe C:\Windows\IAStorAfsService\Optane.dll,OptanePinOemApplication C:\Program Files\Microsoft Office\Office15\excel.exe"
"iexplore"="C:\windows\system32\rundll32.exe C:\Windows\IAStorAfsService\Optane.dll,OptanePinOemApplication C:\Program Files\Internet Explorer\iexplore.exe"
"ImagingDevices"="C:\windows\system32\rundll32.exe C:\Windows\IAStorAfsService\Optane.dll,OptanePinOemApplication C:\Program Files\Windows Photo Viewer\ImagingDevices.exe"
"PowerPnt"="C:\windows\system32\rundll32.exe C:\Windows\IAStorAfsService\Optane.dll,OptanePinOemApplication C:\Program Files\Microsoft Office\Office15\powerpnt.exe"
```

Once this has been done the OEM applications will be pinned upon first boot after the image has been applied to the build system.

7.4.3.3 Pinning via Windows Registry modification

OEM may choose to use this method when the applications to be pinned are installed after the general OS build (common for BTO factory flow).

Example build flow is as follows:

1. Complete installation of all applications that are to be pinned
2. Create the directory for JSON files
(C:\Program Files\Common Files\Intel\Intel Optane Memory\SupportedApps)
3. Create .reg file (see example below: [OEMPinRunOnce.reg](#)) or use script to add registry keys
4. Create JSON files for each of the applications to be pinned
5. Copy JSON files to the SupportedApps directory



6. Modify the registry; use .reg file or edit directly through script to add registry entry for each application to be pinned
7. Prepare the computer for OOBE
8. Shutdown the computer; *the computer is now setup to run the pinning process on first time user boots into the OS.*

Example of using a batch file and a reg file to accomplish the above flow for Excel, Internet Explorer, Windows Photo Viewer, and Power Point:

Batch file (**AppPnForOOBE.bat**):

```
Rem You must first create the directory where the App pinning requires the JSON files

Rem be located in order to pin the files associated with the applications

md C:\Program Files\Common Files\Intel\Intel Optane Memory\SupportedApps"

xcopy C:\Temp\JSON\*.* C:\Program Files\Common Files\Intel\Intel Optane Memory\SupportedApps\

C:\Temp\OEMPinRunOnce.reg
```

Reg file (e.g. **OEMPinRunOnce.reg**):

Windows Registry Editor Version 5.00

```
[HKEY_LOCAL_MACHINE\Software\Microsoft\Windows\CurrentVersion\RunOnce]

"Excel"="C:\windows\system32\rundll32.exe C:\Windows\IAStorAfsService\Optane.dll,OptanePinOemApplication C:\Program Files\Microsoft Office\Office15\excel.exe"

"iexplore"="C:\windows\system32\rundll32.exe C:\Windows\IAStorAfsService\Optane.dll,OptanePinOemApplication C:\Program Files\Internet Explorer\iexplore.exe"

"ImagingDevices"="C:\windows\system32\rundll32.exe C:\Windows\IAStorAfsService\Optane.dll,OptanePinOemApplication C:\Program Files\Windows Photo Viewer\ImagingDevices.exe"

"PowerPnt"="C:\windows\system32\rundll32.exe C:\Windows\IAStorAfsService\Optane.dll,OptanePinOemApplication C:\Program Files\Microsoft Office\Office15\powerpnt.exe"
```

Once this has been done the OEM applications to be pinned will be pinned upon first boot of the computer by the end-user.





8 CPU Attached Storage: PCIe NVMe

8.1 Overview

CPU Attached Storage (CPUaS) feature eliminates existing platform HW restrictions: no Cycle Routers are connected to the CPU PCIe port. Using Intel® RST Software (SW) remapping technology, Intel-branded PCIe NVMe storage devices can be attached to the PCI Express Graphics port (PEG-port) with full support for Intel® RST premium features such as RAID and Intel® Optane™ Memory acceleration.

8.2 New Intel® RST Driver Architecture

Beginning with the 16.0.1.x PV release of the Intel® RST product, the architecture of the driver has changed in order to support the new CPU Attached Storage (via SW remapping) feature. The Intel® RST driver now installs by default in two modes with regards to PCIe NVMe drive support:

❑ **Pre-16.x old behavior:**

- The Intel® RST driver installs only on HW/PCH **remapped** PCIe NVMe storage devices (includes all brands).

❑ **16.x new behavior:**

- The Intel® RST driver installs in two modes:

1. **Mode1- Remapped:**

- a. *Intel® RST driver installs to all PCH/HW remapped PCIe NVMe drives detected in the computer (all-brands)*
- b. *Intel® RST driver installs to all CPUaS/SW remapped PCIe NVMe drives detected in the computer (Intel-branded only)*

2. **Mode2- Stand-alone (code name Ronin):**

- a. *By default, the Intel® RST driver installs to all non-remapped PCIe NVMe drives (Intel-branded only). Regardless whether the non-remapped drive was being controlled by the inbox standard NVMe driver, the RST driver will automatically be installed over the inbox driver.*
- b. *PCIe NVMe drives using Mode2 stand-alone driver are limited as follows:*

*Pass-through mode only with **No Support** for:*

- i. ***RAID volumes (cannot be used to create RAID volumes; including IRRT volumes)***
- ii. ***Optane™ Memory volumes (cannot be used to enable Optane™ Memory)***

How the different modes of the 16.x driver are depicted in the Windows Device Manager:


❑ **Remapped mode (HW/SW):**

- **"Intel(R) Chipset SATA/PCIe Premium Controller"**: All PCH/HW remapped PCIe NVMe devices are controlled by this single instance of the driver (maximum of 3 devices hidden behind the PCH controller; not seen here in the Device Manager); see figure 5.1
- **"Intel® CPU Attached NVMe Controller"**: Each CPUaS/SW remapped PCIe NVMe device (Intel-branded) will have an instance of this driver loaded (maximum of 4 instance of this driver will be seen here in the Device Manager); see figure 5.1

❑ **Stand-alone non-remapped mode:**

- **"Intel(R) NVMe Controller"**: Each non-remapped PCIe NVMe drive will be seen here in the Device Manager; see figure 5.1

Figure 5.1: Example of Device Manager Display of 16.x Driver Implementation



8.3 Limitations and Minimum Requirements:

8.3.1 HW

- Intel-branded PCIe NVMe devices only (3rd party devices not supported)
 - A maximum of 4 Intel-branded PCIe NVMe devices
 - Requires 4 x2 or x4 PEG ports configured with either M.2 connectors or PCIe slots.
- NOTE:**
- Only support Intel-branded NVMe device up to four under the same CPU PEG slot of HEDT platform.
 - One or more Intel-branded NVMe device installed on different CPU PEG slot is not supported.



8.3.2 SW/FW

- Intel® RST SW release version 16.0.1 PV or later
- Intel® RST pre-OS version 16.0.1 PV or later

8.3.3 WHQL Certification Testing Limitations

Platforms to be certified with Intel® RST CPU attached Storage will need to use the Microsoft manual errata (id 22302) in order to override/waiver the following tests:

- Disk Stress
- Disk Verification
- Storage Query Property
- NVMe Deallocate Performance Test
- NVMe Deallocate Test
- NVMe Interrupt Modes Test
- NVMe IO test
- NVMe SCSI Compliance Test

8.4 Usage models

CPU attached Intel® Optane™ memory modules and SSDs can be used in the following configurations.

Configuration	Details
Pass-through data storage disk	An Intel-branded PCIe NVME SSDs installed into a properly configured PEG port (CPU Attached) can be used as a pass-through data storage disk.
Bootable storage disk	An Intel-branded PCIe NVME SSDs installed into a properly configured PEG port (CPU Attached) can be used as a bootable OS disk.
RAID 0/1 data volume	<p><u>Configuration #1:</u> Two Intel-branded PCIe NVME SSDs installed into properly configured PEG ports (CPU Attached) can be configured into a RAID 0 or RAID 1 volume and used as a data storage disk.</p> <p><u>Configuration #2:</u> One Intel-branded PCIe NVME SSD installed into properly configured PEG ports (CPU Attached) and One Intel-branded/3rd party-branded PCIe NVME SSD installed into PCH-attached port (Hardware Remapped) can be configured into a RAID or RAID1 volume and used as a data storage disk.</p>



RAID 0/1 bootable volume

Configuration #1: Two Intel-branded PCIe NVME SSDs installed into properly configured PEG ports (CPU Attached) can be configured into a RAID 0 or RAID 1 volume and used as a bootable OS disk.

Configuration #2: One Intel-branded PCIe NVME SSD installed into properly configured PEG ports (CPU Attached) and One Intel-branded/3rd party branded PCIe NVME SSD installed into PCH-attached port (Hardware Remapped) can be configured into a RAID or RAID1 volume and used as a bootable OS disk.

Intel® Optane™ Memory fast media disk

An Intel® Optane™ memory module or Intel® Optane™ PCIe NVME SSD installed into a properly configured PEG port (CPU Attached) can be used as a fast media disk to enable System Acceleration with Intel® Optane™ memory.

Note: The slow media (disk to be accelerated) must be a single pass through SATA disk (SSD, SSHD, or HDD). It can be the active OS GPT partition or a single disk data drive (***data drive is defined as any SATA drive with data that does not have the active OS partition on it***).



9 Intel Rapid Storage Technology for PCIe NVMe Storage Devices

9.1 OEM System BIOS Requirements

System BIOS System BIOS must enable remapping for the device to be supported by RST(consult the Intel BIOS Writers Guide/Specification for your platform)

9.2 General Requirements

Hardware Only enabled on specific SKUs of the Skylake platforms (see 1st section above in this chapter). SATA/PCIe Remapping must be enabled on the platform. (Refer to the External Design Specification for the respective platforms:

Doc #545659: Skylake Platform Controller Hub (SKL PCH) External Design Specification – Volume 1 of 2

- Tables 1-2, 1-3
- Chapter 3
- Chapter 25, Table 25-2

Doc #546717: Skylake H Platform Controller Hub (SKL PCH-H) External Design Specification – Volume 1 of 2

- Tables 1-2, 1-4, 1-5, and 1-7
- Chapter 3
- Chapter 25, Table 25-3).

Operating System All x64 bit supported Operating Systems for this release

Supported Devices NVMe PCIe Devices

SATA Mode RAID Mode Only

Specification Support Will adhere to the NVMe Specification

The driver will implement MSI-X vectors for PCH AHCI devices and remapped PCIe SSDs

9.3 Feature Limitations

Intel® Rapid Storage Technology for PCIe NVMe Storage Devices has the following feature limitations:



- No support for:
 - Legacy AHCI DEVSLP
 - RTD3
 - Hot Plug
 - InstantGo*
- Supports: maximum of 3 ports can be remapped using x2 or x4 lanes
- If used in a RAID volume, all member devices must be on the same bus type

9.4 PCIe NVMe Device Usage Model

Intel® Rapid Storage Technology NVMe PCIe Device storage is limited to the following usages:

- As a single Pass-Thru Bootable device with PCH SATA controller in RAID mode.
- As a cache device for Intel® Smart Response Technology with the PCH SATA controller in RAID mode.
- As a member disk in a RAID volume with the PCH SATA controller in RAID mode (all member devices have to be on the same bus type).
- As a spare disk for a RAID volume (has to be on the same bus type as the RAID member devices)

9.5 Intel® RST for PCIe NVMe Storage Use cases

Prerequisite:

- A remapping-enabled PCH chipset.
- The platform BIOS must implement the remapping logic and turn it on.
- The PCIe Storage device must be attached to a remappable PCIe slot or PCIe M.2 connector.
 - Only **x2** and **x4** lane support for Skylake and later platforms
 - Only **x1** and **x2** lane support for pre-Skylake platforms that support re-mapping
- The PCIe Storage device must be NVMe-controller based.
- System must be in RAID mode.
- The platform must include the Intel® Rapid Storage Technology UEFI driver*.

If any of the above conditions are not met, the PCIe NVMe SSD will not be recognized by the RST driver.

*No Legacy OROM support

Use Cases:

Use Case	Description	Boot Support
Pass-through Device: Using NVMe PCIe Storage device as a pass-through device	When all the prerequisites referred above are met, the PCIe Storage device can be used as a pass-through device. It can be a boot device or a data device. Configurations: <ul style="list-style-type: none">• Up to 3 pass-through disks PCH SKU dependent)	RAID



SRT Cache Device: Turn on SRT, using NVMe PCIe Storage device to accelerate SATA HDD, RAID volume	When all the prerequisites referred above are met and all conditions to enable SRT are met, SRT can be turned on to use the PCIe Storage device as the cache device to accelerate the SATA HDD.	RAID
	*Refer to section on SRT	
Extra Space Volume: Turn on SRT, using NVMe PCIe Storage device to accelerate SATA HDD	When all the prerequisites referred above are met and all conditions to enable SRT are met, SRT can be turned on to use the PCIe Storage device as the cache device to accelerate the SATA HDD. Any additional space on the PCIe device not being used for cache can be used disk volume.	RAID
	*Refer to section on SRT	
RAID Volume: Creation of RAID volumes using NVMe PCIe storage devices	When all the prerequisites referred above are met the PCIe devices can be used to create RAID volumes. Only supported RAID levels are 0, 1, and 5. The actual RAID level support will be dependent upon your platform's specific SKU and configuration; consult your platform documentation	RAID
	Configurations:	
	<ul style="list-style-type: none">• 3-disk RAID volume (RAID 0 or 5)• 2-disk RAID volume (RAID 0 or 1) + Spare• 2-disk RAID volume (RAID 0 or 1) + Single Disk	



9.6 Intel® Rapid Storage Technology UEFI Compliance Utility for PCIe Storage

Beginning with Intel® RST UEFI version 13.0, the RcmpSata.efi utility includes the ability to test Intel® RST PCIe conformance for OEMs and ODMs in the UEFI shell (RcmpSata.efi) or DOS environment (RcmpSata.exe).

**RcmpSata utility is also available in earlier releases for Legacy OROM and UEFI compliance testing in the Pre-OS environment (see section 3.5.2.4).*

With the RcmpSata.efi utility downloaded to a Fat32 formatted USB drive attached to the platform, the following syntax can be used in the UEFI shell to download compliance data to a text file for viewing in a text editor (where '#' is the file system number of the USB drive shown when booting to the UEFI shell):

```
Fs#:> rcmpsata.efi > rcmpsata.txt
```

You may scroll through the text file in the UEFI shell by typing the following command:

```
Fs#:>edit rcmpsata.txt
```

The final test results are displayed at the end. Test Section 16 will confirm "remap" for PCIe is enabled/disabled for debugging issues in the Pre-OS environment.

```
EFI Editor 0.99      rcmpsata.txt      UNICODE
7.19 CAP.SIS and PxCMD.ISP Agreement:      PASS
7.21 HBA Capabilities Ext. Supports DEVSLP:  DISABLED
7.22 HBA Capabilities Ext. Supports ADM:    DISABLED
7.23 HBA Capabilities Ext. Enabled DESO:    DISABLED

16.1 Remap ACPI Table:                      ENABLED
Remap ACPI table isValid:                   1
Remap dev's vendorId:                       0x144D
Remap dev's deviceId:                       0x1600
Remap dev's classCode:                      0x106
Remap dev's remapOffset:                    0x4000
Remap dev's linkSpeed:                      2
Remap dev's linkWidth:                      2
PCH AHCI Controller BAR:                    0x90430000
16.2 Cycle Router Enabled:                  ENABLED
GCR.Raw:                                    0xB0041
16.3 PCIe Memory BAR Remapped:              ENABLED

17. FFS Tests

RstCacheMpb Protocol:                       WARN
17.1 RstCacheMpbProtocol Discovery:         DISABLED

Number of successes: 32, Number of warnings: 0, Number of failures: 0
Total tests: 73
Row: 266 Col: 1
F1 Go To Line      F2 Save File      F3 Exit           F4 Search
F9 File Type ace  F6 Cut Line       F7 Paste Line     F8 Open File
```







10 Intel Rapid Storage Technology for PCIe AHCI Storage Devices

Beginning with the Intel® RST 13.0 Release version, PCIe storage devices are supported on the following SKUs:

PCH SKU	PCH Family	Segment
H97	LPT-H	Refresh Desktop
Z97	LPT-H	Refresh Desktop

10.1 OEM System BIOS Requirements

System BIOS	System BIOS must enable remapping for the device to be supported by RST(consult the Intel BIOS Writers Guide for your platform)
--------------------	---------------------------------------------------------------------------------------------------------------------------------

10.2 General Requirements

Hardware	Only enabled on specific SKUs of the Haswell Refresh platforms. Remapping must be enabled on the platform. (Refer the Product Design guide for the respective platforms).
Operating System	All x64 bit supported Operating Systems for this release
Supported Devices	AHCI PCIe Devices
SATA Mode	RAID Only

10.3 Warnings

10.3.1 Features Limitations

Intel® Rapid Storage Technology 13.1 for PCIe Storage Devices will not support the following features:

- Legacy AHCI DEVSLP
- L1.2 Support for PCIe devices is not supported until 13.5 release
- RTD3
- Hot Plug
- InstantGo*



10.3.2 PCIe Device Usage Model

Intel® Rapid Storage Technology PCIe Device storage is limited to the following usages:

- As a single Pass-Thru Bootable device with controller in RAID mode.
- As a cache device for Intel® Smart Response Technology with controller in RAID mode.

10.4 Intel Rapid Storage Technology for PCIe Storage Use cases

Prerequisite:

- The chipset must have the remapping hardware.
- The BIOS must implement the remapping logic and turn it on.
- The PCIe Storage device must be attached to remappable PCIe slot or PCIe M.2 connector.
- The PCIe Storage device must be AHCI-controller based.
- System must be in RAID mode.
- The system BIOS must include the Intel® Rapid Storage Technology UEFI driver*.

If any of the above conditions are not met, the PCIe SSD will not be recognized by the RST driver.

*No Legacy OROM support

Reference documents: For detailed use case information refer to RST13.0 Use case document ID 539242 published on CDI

Use Cases:

Use Case	Description	Boot Support
Using PCIe Storage device as a pass-through device	When all the prerequisites referred above are met, the PCIe Storage device can be used as a pass-through device. It can be a boot device or a data device.	RAID
Turn on SRT, using PCIe Storage device to accelerate SATA HDD	When all the prerequisites referred above are met and all conditions to enable SRT are met, SRT can be turned on to use the PCIe Storage device as the cache device to accelerate the SATA HDD. *Refer to section on SRT	RAID

10.5 Intel® Customer Reference Board BIOS Settings

The following settings can be used on Intel® Customer Reference Boards (CRB) that support remapping. Consult with your BIOS vendor for compatible settings for Intel® RST PCIe storage.

BIOS Settings using the EDISTO BEACH FAB 4 SKU-2 SDIO WIFI card with PCIe SSD connected



1. Enter into Bios set-up and choose the below settings:
 - a. Intel Advanced Menu->PCI Subsystem Settings->Install Ext OpRom Before BIOS = "Ext PCIe Both Storage and Other OpRom"
 - b. Intel Advanced Menu -> SA Configuration->X2APICOPTOUT = Disabled
 - c. Intel Advanced Menu -> SA Configuration-> VT-d = disabled
 - d. Intel Advanced Menu-> PCH-IO Configuration->PCI Express Configuration->PCI Express Root Port 6->PCIe Speed = Gen1
 - e. Intel Advanced Menu->PCH-IO Configuration->SATA Configuration->SATA Mode Selection = RAID
 - f. Intel Advanced Menu->PCH-IO Configuration-> SATA Configuration ->PCIe Nand Configuration = Enabled
 - g. Intel Advanced Menu->PCH-IO Configuration->PCI Express Configuration->PCIe Nand Port Selection = Port 6
 - h. Intel Advanced Menu->PCH-IO Configuration->SATA Configuration->EFI RAID = Enabled
 - i. Boot Maintenance Manger Menu->boot configuration Menu->CSM control = Always On
2. Restart the SUT to reflect the setting in BIOS
3. Enter into Bios and navigate to TVP Device manager-> Check for the PCIe NAND SSD

10.6 Intel® Rapid Storage Technology UEFI Compliance Utility for PCIe Storage

Beginning with Intel® RST UEFI version 13.0, the RcmpSata.efi utility includes the ability to test Intel® RST PCIe conformance for OEMs and ODMs in the UEFI shell (RcmpSata.efi) or DOS environment (RcmpSata.exe).

**RcmpSata utility is also available in earlier releases for Legacy OROM and UEFI compliance testing in the Pre-OS environment (see section 3.5.2.4).*

With the RcmpSata.efi utility downloaded to a Fat32 formatted USB drive attached to the platform, the following syntax can be used in the UEFI shell to download compliance data to a text file for viewing in a text editor (where '#' is the file system number of the USB drive shown when booting to the UEFI shell):

Fs#:> rcmpsata.efi > rcmpsata.txt

You may scroll through the text file in the UEFI shell by typing the following command:

Fs#:>edit rcmpsata.txt

The final test results are displayed at the end. Test Section 16 will confirm "remap" for PCIe is enabled/disabled for debugging issues in the Pre-OS environment.



```
EFI Editor 0.99      rcmpsata.txt      UNICODE
7.19 CAP.SIS and PxCMD.ISP Agreement:      PASS
7.21 HBA Capabilities Ext. Supports DEVSLP:  DISABLED
7.22 HBA Capabilities Ext. Supports ADM:    DISABLED
7.23 HBA Capabilities Ext. Enabled DESO:    DISABLED

16.1 Remap ACPI Table:                     ENABLED
    Remap ACPI table isValid:              1
    Remap dev's vendorId:                  0x144D
    Remap dev's deviceId:                  0x1600
    Remap dev's classCode:                 0x106
    Remap dev's remapOffset:               0x4000
    Remap dev's linkSpeed:                 2
    Remap dev's linkWidth:                 2
    PCH AHCI Controller BAR:               0x90430000
16.2 Cycle Router Enabled:                 ENABLED
    GCR.Raw:                               0xB0041
16.3 PCIe Memory BAR Remapped:             ENABLED

17. FFS Tests

    RstCacheMpb Protocol:                  WARN
17.1 RstCacheMpbProtocol Discovery:        DISABLED

Number of successes: 32, Number of warnings: 0, Number of failures: 0
Total tests: 73
Row: 266 Col: 1
F1 Go To Line      F2 Save File      F3 Exit          F4 Search
F9 File Type ace  F6 Cut Line      F7 Paste Line    F8 Open File
```

§ §



11 How to Enable the Platform for Intel® RST Support of BIOS Fast Boot

Beginning with the Intel® RST 12.0 Release version, Intel® RST implements pre-OS UEFI driver and Windows runtime driver support for the platform BIOS Fast Boot specification.

11.1.1 OEM System BIOS Vendors' Requirements

This section covers what the OEM's system BIOS vendor must provide in order for the Intel® RST Fast Boot BIOS implementation to be enabled on the platform.

- System BIOS** The Intel® RST UEFI driver requires the following BIOS components:
- 2KB of non-volatile UEFI variable storage with access from runtime and as a boot service
 - Access to UEFI Hand-off Block Hand-off Info Table (PHIT HOB) to determine boot mode
 - BOOT_WITH_FULL_CONFIGURATION = Fast-Boot disabled
 - BOOT_WITH_MINIMAL_CONFIGURATION = Fast-Boot enabled
 - BOOT_ON_S4_RESUME = Fast-Boot enabled

11.1.2 Supported System Configurations

This section covers the system configurations that are required for the Intel® RST BIOS Fast Boot implementation to support the platform's BIOS Fast Boot specification.

- System BIOS** SATA controller must be set to RAID mode
Any of the following configurations are supported:
- HW Configuration**
1. Platform configured with a single pass-through SSD or PCIe storage device (system boot drive)
 2. Platform configured with a single SSD/mSATA + 2 HDD's as a RAID 1 (system boot drive), Accelerated with Intel® Smart Response Technology*
 3. Platform configured with a single SSD/mSATA + single HDD (system boot drive), Accelerated with Intel® Smart Response Technology*

Note: ATAPI devices do not affect BIOS Fast Boot specification

*Fast Boot will not be supported on configurations where the PCIe Storage device is used as the cache disk.



**Operating
System**

- Windows 8.1 64
- Windows 8 64
- Windows 7 64

§ §



12 Creating a RAID Volume

RAID volumes can be created three different ways. The method most widely used by end-users is to use the Intel Rapid Storage Technology UI in Windows*. The second method to create a RAID volume is to use the Intel Rapid Storage Technology option ROM user interface (or the Intel® RST pre-OS UEFI HII UI). The third way, used by OEMs only, is using the pre-OS RCfgSata or Windows (including WinPE) RSTCLI 32/64 utilities.

12.1 Minimum Requirements

1. BIOS: Requires a BIOS with the Intel® RST preOS UEFI driver or OptionROM integrated
2. Number of disks required for the desired RAID level
 - a. RAID 0- 2 disks minimum (6 max)
 - b. RAID 1- 2 disks only
 - c. RAID 5- 3 disks minimum (6 max)
 - d. RAID 10- 4 disks only
3. 5MB unallocated space at the end (max LBA) of the disk for RST metadata

12.2 Feature Limitations

Table 10-1 Disk, volume, and array maximum limitations

Configuration	Maximum
Number of arrays per system	4
Number of volumes per system	4
Number of volumes per array	2
Number of disks per volume/array	6
Number of disks per system	8

12.3 Using Intel® Intel® Optane™ Memory and Storage Management UI

Refer to the section 6.4.2



12.4 Using Intel® Rapid Storage Technology UI

1. Run the Intel Rapid Storage Technology UI from the following Start menu link within Windows:

Pre-Windows* 8

Start→Programs→Intel Control Center (optional) ->Intel® Rapid Storage Technology→Intel Rapid Storage Technology UI

Windows* 8 and Newer

****The UI is not added to the Start Window upon installation and must be added manually***

File Explorer->Local Disk(C)->Program Files->Intel->Intel® Rapid Storage Technology->IAStorUI.exe (right click and pin to start)

2. Based on the available hardware and your computer's configuration, you may be able to create a volume by selecting the 'easy to use' options such as 'Protect data' under 'Status', or by selecting a volume type under 'Create'. Based on the number of non-RAID disks available to you and the size of the disks the user will only be able to see the possible volume creation options... (e.g. if you have only two disks ...you can only see options to create RAID 0, RAID1 and Recovery(Intel® RRT) ; if you have three disks, you can only see options for creating RAID 0, RAID 1, RAID5 and Recovery)

Note: To create a volume the user must be in admin mode and the system must be in RAID Ready mode with two or more hard disks connected to it

3. Instructions to create a volume by selecting volume type under 'Create'
 - a. After selecting the volume type to create, click on 'Next'
 - b. Now configure the volume by providing the volume name, selecting the hard disks to be part of the volume and strip size if applicable

NOTE: When configuring a volume, the application will only list the disks that meet the min requirements to be part of the volume. Based on the first disk selected or the order of selection, some disks may become grayed out if one or more requirements are not met. Changing the order of selection generally helps re-enable disks that were grayed out. For Ex: If the first selection is a system disk, only disks that are of equal or greater size will be presented for selection and other remains grayed out. For more information on disk requirements refer 'creating a volume' under help file in the UI.
 - c. Once the disks are selected for volume creation, the user will presented with option, if you want preserve data on which selected disk. Click on 'Next' and select the 'Create Volume' button.
4. After the RAID volume is created, you will be shown a dialog box stating that the RAID volume was successfully created and you will need to use Windows Disk Management or other third-party software to create a partition within the RAID volume and format the partition. Click OK to close this dialog box.
5. After formatting the partition, you may begin to copy files to, or install software on, the RAID volume.



12.5 Using Intel® Rapid Storage Technology Legacy Option ROM User Interface

1. Upon re-boot, you will see the option ROM status message on the screen – press CTRL-I to enter the Intel Rapid Storage Technology option ROM user interface.
2. In the Main Menu, select option #1 'Create RAID Volume'. Enter the name you want to use for the RAID volume, then press Enter.
3. Select the RAID level by using the arrow keys, then press Enter.
4. Press Enter to select the disks to be used by the array that the volume will be created on. Press Enter when done.
5. Select the strip size (128 KB is the default for RAID 0) by using the arrow keys, then press Enter when done.
6. Enter the size for the RAID volume in gigabytes. The default value will be the maximum size. If you specify a smaller size, you will be able to create a second volume in the remaining space using the same procedure.
7. After this is done, exit the Option ROM user interface.


12.6 Using Intel® Rapid Storage Technology UEFI User Interface

Note: This section is OEM dependent. Where/how the OEM chooses to implement the UEFI UI is based on OEM preference

1. Upon re-boot, launch the Intel® RST UEFI user interface (HII compliant)



Figure 4




The UEFI UI is divided into three main sections:

1. Section 1 is the main section.
 - a. It displays RAID configuration and status information
 - b. It displays RST UEFI driver version (see arrow #4 in figure above)
 - c. It displays physical devices enumerated by the RST UEFI driver that are not part of the RAID volume
2. Section 2 gives a brief description of current page of the UI
3. Section 3 gives information on how to navigate within the current page of the UEFI UI.

Note: *This section is not implemented by the RST UEFI driver and is specific to the BIOS that was used for documentation purposes.*


2. In the Main Menu, select 'Create RAID Volume'
 - a. Enter the name you want to use for the RAID volume, then press <Enter>.

Figure 5



b. Scroll down to 'RAID Level' and press <Enter> to select a RAID level

Figure 6



c. Scroll down to 'Select Disks' and at each disk that you wish to include in the RAID volume press <space bar>



Figure 7

```
Aptio Setup Utility - Copyright (C) 2009 American Megatrends, Inc.
Advanced
UAAAAAAAAAAAAAAAAAAAAAAAAAAAAAAAAAAAAAAAAAAAAAAAAAAAAAAAAAAAAAAAAAAAAAAAAA
Create RAID Volume                                X - to Select Disk
Name: Volume0
RAID Level: [RAID0(Stripe)]
Select Disks:
Port 0, WDC WD800BEVT [ ]
Port 1, INTEL SSDSC2M [ ]
Port 3, WDC WD800BEVT [X]
Port 4, Hitachi HTS54 [X]
Strip Size: [16kB]
Capacity (MB): 152633
Create Volume
F1: General Help
F2: Discard Changes
F3: Setup Defaults
F4: Save ESC: Exit
Version 2.00.1201.
```

- d. Next scroll down to 'Strip Size' and press <enter> to select a Strip size or continue if you wish to use the default strip size


Figure 8

```
Aptio Setup Utility - Copyright (C) 2009 American Megatrends, Inc.
Advanced
UAAAAAAAAAAAAAAAAAAAAAAAAAAAAAAAAAAAAAAAAAAAAAAAAAAAAAAAAAAAAAAAAAAAAAAAAA
Create RAID Volume                                Strip size help
Name: Volume0
RAID Level: [RAID0(Stripe)]
Select Disks:
Port 0, WDC WD800BEVT [ ]
Port 1, INTEL SSDSC2M [ ]
Port 3, WDC WD800BEVT [X]
Port 4, Hitachi HTS54 [X]
Strip Size: [16kB]
Capacity (MB): 152633
Create Volume
F1: General Help
F2: Discard Changes
F3: Setup Defaults
F4: Save ESC: Exit
Version 2.00.1201.
```



- e. Next scroll down to 'Capacity (MB)' where the maximum capacity is selected and displayed in MB. To select a smaller capacity for the RAID volume, type in the size in MB that you wish to use

Figure 9



- f. Next scroll down to 'Create Volume' and press <Enter>


3. After this is done, exit the Intel® RST UEFI UI.

Note: The "Create Volume" action will only be enabled if the RAID volume options selected will result in a valid configuration.

4. Changes in HII, Beginning with Intel® RST UEFI 13.0, for PCIe Devices include new labeling for Devices and multiple controller management ability.
 - Device Ids numbering scheme = <Device Type><Controller ID>."<Device ID>
 - Example below: "PCIe 1.0"



Figure 10



12.7 Using the RAID Configuration Utilities (DOS, UEFI Shell, and Windows*)

Note: rstcli and rstcli64 can be used interchangeably below.

Run "rcfgsata.exe in DOS environment (or rcfgsata.efi from UEFI shell) or "rstcli.exe (or rstcli64.exe)" (Windows environment) with the following command line flags to create a RAID volume.

With PCIe Storage, the command line utilities will require a controller ID to be specified when creating RAID volumes:

- SATA SSD, HDD, SSHD Controller ID = 0
- PCIe AHCI SSD Controller ID = 1
- PCIe NVMe SSD Controller ID = 2

The following command line will instruct the utility to create a RAID 0 volume named "OEMRAID0" on hard drives attached to the SATA Controller (Controller #0) on Port 0 and 1 with a strip size of 128 KB and a size of 120 GB:

```
C:\>rcfgsata.exe (or rcfgsata.efi) /C OEMRAID0 /DS 0.0 0.1 /SS 128 /L 0 /S 120
C:\>rstcli.exe -C -l 0 -n OEMRAID 0-0-0-0 0-1-0-0 -s 128 -z 120
```

The following command will create a RAID volume using all of the default values. It will create a RAID 0 volume with a strip size of 128 KB on the two hard drives in the system. The volume will be the maximum size allowable.

```
C:\>rcfgsata.exe /C OEMRAID0 (requires that only two disks can be attached to the
system)
```

The following command line will instruct the utility to create a RAID 0 volume named "PCIeRAID0" on 1 PCIe AHCI SSD (Controller #1) and 1 PCIe NVMe SSD (Controller #2) attached to the system on remapped Port 0 and Port 2 with a strip size of 128 KB and a size of 120 GB:

```
C:\>rcfgsata.exe (or rcfgsata.efi) /C OEMRAID0 /DS 1.0 2.2 /SS 128 /L 0 /S 120
C:\>rstcli.exe -C -l 0 -n OEMRAID 0-0-0-0 0-1-0-0 -s 128 -z 120
```

The following command line will display usage for all support command line parameters:

```
C:\>rcfgsata.exe (or rcfgsata.efi) /?
C:\>rstcli.exe --help
```

Note: Selecting the strip size is only applicable for RAID 0, RAID 5, RAID 10 levels. Strip size is not applicable for RAID 1.



§ §



13 Deleting a RAID Volume

RAID volumes can be deleted in three different ways. The method most widely used by end-users is the Windows user interface utility. The second method is to use the Intel Rapid Storage Technology Option ROM user interface. The third way, used by OEMs only, uses the RAID Configuration utility.

13.1 Using the Intel® Optane™ Memory and Storage Management UI

Refer to Section 27.

13.2 Using the Intel® Rapid Storage Technology User Interface Utility

1. Run the Intel Rapid Storage Technology UI from the following Start menu link:

Start→All Programs→Intel® Rapid Storage Technology →Intel Rapid Storage Technology UI
2. Under 'Status' or 'Manage' Click on the volume you want to delete. The user will be presented with the volume properties on the left.
3. Click on 'Delete volume'
4. Review the warning message, and click 'Yes' to delete the volume.
5. The 'Status' page refreshes and displays the resulting available space in the storage system view. You can now use it to create a new volume.

13.3 Using the Option ROM User Interface

1. Upon re-boot, you will see the Intel Rapid Storage Technology option ROM status message on the screen – press CTRL-I to enter the option ROM user interface.
2. Within this UI, select option #2 'Delete RAID volume'.
3. You should be presented with another screen listing the existing RAID volume.
4. Select the RAID volume you wish to delete using the up and down arrow keys.
5. Press the Delete key to delete the RAID volume
6. Press Y to confirm.

Note: Option #3 'Reset Hard Drives to Non-RAID' in the option ROM user interface may also be used to delete a RAID volume. This resets one or more drives to non-RAID status, by deleting all metadata on the hard drives. This has the effect of deleting any RAID volumes present. This function is provided for re-setting the hard drives when there is a mismatch in RAID volume information on



the hard drives. The option #2 'Delete RAID Volume' on the contrary, will allow deleting a volume at a time, while retaining the existing RAID array metadata (for instance Matrix RAID).

13.4 Using the Intel® Rapid Storage Technology UEFI User Interface

Note: This section is OEM dependent. Where/how the OEM chooses to implement the UEFI UI is based on OEM preference. Use the following example for Intel CRB.

1. Upon re-boot, enter the system BIOS and select the Intel® Rapid Storage Technology menu for the UEFI user interface
2. In the Main Menu, go to the 'RAID Volumes' section, highlight the volume to be deleted and press <Enter>
 - a. Select 'Delete', then press <Enter>.
 - b. At the dialogue box press <Enter> to confirm the deletion of the volume

Note: All data on the volume will be lost!

3. After this is done, exit the Intel® RST UEFI UI.

13.5 Using the RAID Configuration Utilities (DOS, UEFI Shell, and Windows*)

Run "rcfgsata.exe in DOS environment (or rcfgsata.efi in UEFI shell)" or "rstcli.exe/rstcli64.exe" (Windows environment) with the following command line flag to delete a RAID volume. The following command line will instruct the utility to delete a RAID 0 volume named "OEMRAID0"

```
C:\>rcfgsata.exe /D OEMRAID0
C:\>rstcli.exe --manage --delete OEMRAID0
```

The following command line will display usage for all support command line parameters:

```
C:\>rcfgsata.exe(rcfgsata.efi) /?
```

```
C:\>rstcli.exe --help
```





14 Common RAID Setup Procedures

14.1 Build a SATA RAID 0, 1, 5 or 10 System

This is the most common setup. This configuration will have the operating system striped for RAID 0, or mirrored for RAID 1, or striped with parity for RAID 5, or mirrored and striped across two or up to four drives for RAID 10. All RAID member drives must be from the same BUS PROTOCOL GROUP. To prepare for this, you must have the Intel RAID driver on a floppy drive (USB). See the procedure for creating this floppy (USB) further down in this document.

1. Assemble the system using a motherboard that supports Intel Rapid Storage Technology and attach the drives depending on the RAID level that will be built.
2. Enter System BIOS Setup and ensure that RAID mode is enabled. This setting may be different for each motherboard manufacturer. Consult the manufacturer's user manual if necessary. When done, exit Setup.

14.1.1 Using the Legacy OROM User Interface

1. Upon re-boot if your system is using a legacy OROM, you will see the Option ROM status message on the screen – press CTRL-I to enter the Intel Rapid Storage Technology Option ROM user interface.
2. Within this UI, select option '1. Create RAID Volume'. When 'Create RAID Volume' menu is displayed, fill the following items:
 - a. Name: Enter a volume name, and press Enter to proceed to next menu item,
 - b. RAID Level: select RAID level (0, 1, 5, 10), and press Enter to proceed to next menu item;
 - c. Disks: press Enter on 'Select Disks' to select the hard drives to be used for your configuration.
 - d. Within the 'SELECT DISKS' window, choose the hard drives and press Enter to return to the 'MAIN MENU'.
 - e. Strip Size: Applicable for RAID levels 0, 5, and 10 only. You may choose the default size or another supported size in the list and press Enter to proceed to the next item.
 - f. Capacity: The default size would be the maximum allowable size summation of all the drives in your configuration. You may decrease this volume size to a lower value. If you specified a lower capacity size volume, the remaining space could be utilized for creating another RAID volume. Press Enter to proceed to the next item.
 - g. Create Volume: Press Enter to create a volume.
 - h. Press 'Y' to confirm the creation of volume.



3. After this is done, exit the Intel Rapid Storage Technology option ROM user interface by pressing the Esc key or Option #4.
4. Begin OS setup by booting from the Windows OS installation CD.
5. Installation procedures as follows: Use the 'load driver' mechanism when prompted. Insert a USB key with the Intel® RST driver and browse to the directory on the USB key where the driver that you wish to install is located. Select the driver INF file. If correct the proper Intel controller for your system will be shown. Continue the driver install.
6. Finish the Windows installation and install all other necessary drivers.
7. Install the Intel Rapid Storage Technology software package obtained from the Intel VIP website. This will add the *Intel* Rapid Storage Technology UI that can be used to manage the RAID configuration.

14.1.2 Using the UEFI HII User Interface

1. Upon re-boot if your system is using the RST UEFI Driver and the HII protocol is in the system BIOS, you will see the Intel® Rapid Storage Technology option within the BIOS setup menu.
2. Select this menu. Choose the 'Create RAID Volume'. When 'Create RAID Volume' menu is displayed, fill the following items:
 - a. Name: Enter a volume name, and press Enter to proceed to next menu item,
 - b. RAID Level: select RAID level (0, 1, 5, 10), and press Enter to proceed to next menu item;
 - c. Disks: press space bar to 'Select Disks' to select the devices to be used for your configuration.
 - d. Within the 'SELECT DISKS' window, choose the devices and press Enter to return to the 'MAIN MENU'.
 - e. Strip Size: Applicable for RAID levels 0, 5, and 10 only. You may choose the default size or another supported size in the list and press Enter to proceed to the next item.
 - f. Capacity: The default size would be the maximum allowable size summation of all the drives in your configuration. You may decrease this volume size to a lower value. If you specified a lower capacity size volume, the remaining space could be utilized for creating another RAID volume. Press Enter to proceed to the next item.
 - g. Create Volume: Press Enter to create a volume.
 - h. Press 'Y' to confirm the creation of volume.
3. After this is done, exit the Intel Rapid Storage Technology menu HII user interface by pressing to save changes and the Esc key.
4. Begin OS setup by rebooting from the Windows OS installation CD.
5. Installation procedures as follows: Use the 'load driver' mechanism when prompted. Insert a USB key with the Intel® RST driver and browse to the directory on the USB key where the



driver that you wish to install is located. Select the driver INF file. If correct the proper Intel controller for your system will be shown. Continue the driver install.

6. Finish the Windows installation and install all other necessary drivers.
7. Install the Intel Rapid Storage Technology software package obtained from the Intel VIP website. This will add the *Intel* Rapid Storage Technology UI that can be used to manage the RAID configuration.

14.2 Build a “RAID Ready” System

The following steps outline how to build an Intel “RAID Ready” system with OS installed on a single SATA hard drive. A “RAID Ready” system can be upgraded to RAID 0, RAID 1, RAID5 or RAID 10 at a later time using the RAID migration feature built into Intel Rapid Storage Technology. Intel® RST enables you to install additional SATA hard drives, and then migrate to a RAID level volume without re-installing the operating system.

1. Assemble the system using a motherboard that supports Intel Rapid Storage Technology with Intel Rapid Storage Technology OROM integrated into the BIOS and attach one SATA hard drive.
2. Enter System BIOS Setup; ensure that RAID mode is enabled. This setting may be different for each motherboard manufacturer. Consult your manufacturer’s user manual if necessary. When done, exit Setup.
3. Begin Windows Setup by booting from the Windows OS installation CD.
4. Installation procedures as follows: Use the ‘load driver’ mechanism when prompted. Insert a USB key with the Intel® RST driver and browse to the directory on the USB key where the driver that you wish to install is located. Select the driver INF file. If correct the proper Intel controller for your system will be shown. Continue the driver install:
5. Finish the Windows installation and install all other necessary drivers.
6. Install the Intel Rapid Storage Technology software package obtained from the Intel VIP website. This will add the *Intel* Rapid Storage Technology UI that can be used to manage the RAID configuration.

14.3 Migrate to RAID 0 or RAID 1 on an Existing “RAID Ready” System

If you have an existing “RAID Ready” system as defined in section [Build a SATA “RAID Ready” System](#), then you can use the following steps to migrate from a single-drive non-RAID configuration to a two drive RAID 0 or RAID 1 configuration. The resulting configuration will be identical to that created by the procedure in section [Build a SATA RAID0, 1, 5 or 10 System](#). To prepare for this, you will need to install another drive with a capacity equal to or greater than the capacity of the drive being used as the source hard drive and also belong to the same BUS PROTOCOL GROUP as the source drive.

1. Note the port number of the source hard drive already in the system; you will use this to select hard drive for preserving data for the migration.



2. Install the second drive on the system.
3. Boot Windows, then install the Intel Rapid Storage Technology software, if not already installed, using the setup package obtained from a CD-ROM or from the Internet. This will install the necessary Intel Rapid Storage Technology UI and start menu links.
4. Open the Intel Rapid Storage Technology UI from the Start Menu and select the volume type under Create from the Actions menu. Click on 'Next'
5. Under the configure options provide the volume name , select disks
6. When the disks are selected, the user will be presented the option to select the disk on which to preserve the data. Here the user need to select the right disk on the which the data needs to preserved and migrated
7. After the migration is complete, reboot the system. If you migrated to a RAID 0 volume, use Disk Management from within Windows in order to partition and format the empty space created when the two hard drive capacities are combined. You may also use third-party software to extend any existing partitions within the RAID volume.

14.4 Migrate an Existing Data Hard Drive to a RAID 0 or RAID 1 Volume

If you are booting from a parallel ATA (PATA*) drive that contains the operating system, you may use the Intel Rapid Storage Technology to create a RAID 0 or RAID 1 volume on two SATA drives. Also, if you have a single SATA hard drive that contains program or personal data, you may use the migration feature to use this hard drive as the source hard drive for a migration. After the migration is completed, you will have a two hard drive RAID 0 volume where data is striped or a two hard drive RAID 1 volume where the data is mirrored across the two SATA hard drives. To do this, the PCH I/O RAID Controller must be enabled in the BIOS and you must have the Intel Rapid Storage Technology software installed.

Begin with a system where you are booting from a PATA hard drive. Make sure the PCH I/O RAID controller is enabled and the Intel Rapid Storage Technology is installed. Then do the following:

1. Note the serial number of the SATA hard drive that is already installed. You will use this to select it as the source hard drive when initiating the migration.
2. Physically attach the second SATA hard drive to the available SATA port.
3. Boot to Windows, install the Rapid Storage Technology software, if not already installed, using the setup package obtained from a CD-ROM or from the Internet. This will install the necessary Intel Rapid Storage Technology UI and start menu links.
4. Open the Intel Rapid Storage Technology UI from the Start Menu.
5. Follow steps 4 to 7 in section [Migrate to RAID 0 or RAID 1 on an Existing "RAID Ready" System](#)

14.5 Migrating From one RAID Level to Another

RAID level migration allows an existing RAID configuration to be migrated to another RAID configuration. The following migrations are possible.

NOTE: Not all migrations are supported on all chipsets. The support varies depending on the chipset



and the ports supported on the chipset (For supported migrations for each chipset Intel Rapid Storage Technology product requirements document):

Change Type from	To
2-disk recovery volume	2-disk RAID 1
2-disk RAID 1	2-disk recovery volume
2-disk RAID 1	2-disk RAID 0 3, 4, 5 or 6-disk RAID 0 3, 4, 5 or 6-disk RAID 5
2-disk RAID 0	3, 4, 5 or 6-disk RAID 5
3-disk RAID 0	4, 5 or 6-disk RAID 5
4-disk RAID 0	5 or 6-disk RAID 5
4-disk RAID 10	4, 5 or 6-disk RAID 5

Note: In order for the migration options to be accessible, the minimum required SATA hard drives for the RAID level have to be met.

Follow the procedure illustrated below:

1. Start the Intel Rapid Storage Technology UI application:

Start Menu -> All Programs -> Intel Rapid Storage Technology -> Intel Rapid Storage Technology UI

2. Under 'Status' or 'Manage', in the storage system view, click the array or volume to which you want to modify. The volume properties now display on the left.
3. Click 'Change type'.
4. In the 'Change Volume Type' dialog, type a new name if you want to change the default name.
5. Select the new volume type, and then click 'OK'.
6. The 'Manage' page refreshes and reports the new volume type.
7. After the migration starts, you can view the migration progress under status.
8. When the Status field indicates volume as 'Normal', the migration is complete.

14.6 Create a RAID Volume on Intel® SATA Controller While Booting to Different Controller

This configuration is for users who would like to use a RAID 0 volume as a high performance data hard drive or use the data redundancy properties of RAID 1. Starting with a configuration where the system is booting to a Windows, with installation on a different disk controller, the user can add two SATA hard drives and create a RAID volume on them.

1. Physically install two SATA hard drives to the system.



2. Enter System BIOS Setup; ensure that RAID mode is enabled. This setting may be different for each motherboard manufacturer. Consult your manufacturer's user manual if necessary. When done, exit Setup.
3. Boot to Windows; install the Intel Rapid Storage Technology software, if not already installed, use the setup package obtained from a CD-ROM or from the Internet. This will install the necessary Intel Rapid Storage Technology UI and Start menu links.
4. Use the Intel Rapid Storage Technology UI to create a RAID 0 volume on two SATA drives according to the procedure in section [Using Intel® Rapid Storage Technology UI](#) of this document.
5. After the RAID volume is created, you will need to use Windows Disk Management or other third-party software to create a partition within the RAID volume and format the partition. At this point, you may begin to copy files to, or install software on, the RAID volume.

14.7 Build a RAID 0 or RAID 1 System in an Automated Factory Environment

This is a two-part process. First, create the master image of the Windows installation; you will load these on the system before they are delivered to the customer. The second part is to apply this image to a system that has two SATA hard drives installed with a RAID 0 or RAID 1 volume. This procedure will apply the image to the RAID volume so that the system may boot from it and the operating system will be fully striped by the RAID 0 volume or mirrored by the RAID 1 volume. The same procedure, and master image, could be applied to a single SATA hard drive to create a "RAID Ready" system.

14.7.1 Part 1: Create Master Image

1. Build a RAID 0 or RAID 1 System as described in section [Build a SATA RAID 0, 1, 5 or 10 System](#) of this document.
2. Install the Intel Rapid Storage Technology software from the CD-ROM included with your motherboard or after downloading it from the Internet. This will add the Intel Rapid Storage Technology UI that can be used to manage the RAID configuration in Windows*.
3. Use third-party software to create an image of the RAID volume as if it were a physical hard drive or create an image of the partition within the RAID volume containing the operating system, program and data files.
4. Store it in a place where it can be accessed by systems on the assembly line.

14.7.2 Part 2: Apply Master Image

1. Assemble the system using a motherboard that supports Rapid Storage Technology and attach two SATA hard drives.
2. Enter System BIOS Setup; ensure that RAID mode is enabled. This setting may be different for each motherboard manufacturer. Consult your manufacturer's user manual if necessary. When done, exit Setup.



3. If the system has CSM on, and can boot to a DOS environment, use the Intel RAID Configuration utility (RCfgSata.exe). Else if CSM is off, or not present, boot to the UEFI shell and use the RcfgSata.efi utility to create a RAID volume. The following command line will instruct the utility to create a RAID 0 volume named "OEMRAID0" on hard drives on Port 0 and 1 with a strip size of 128 KB and a size of 120GB (rcfgsata.efi can replace rcfgsata.exe if using the UEFI shell environment):

'DS' for device selection will distinguish the different controllers for device selection:
<Controller><Port>

0.0 = SATA device on port #0

1.3 = PCIe AHCI device remapped to port #3

2.6 = PCIe NVMe device remapped to port #6

Create RAID 0 using 1 PCIe AHCI SSD on port 3, and 1 PCIe NVMe SSD on port 6:

```
C:\>rcfgsata.exe /C:OEMRAID0 /DS:1.3 2.6 /SS:128 /L:0 /S:120.
```

The following command line will display all supported command line parameters and their usage: *C:\>RCfgSata.efi /?*

4. The system does not need to be rebooted before moving on to the next step. If there are no PATA hard drives in the system, the RAID volume created will become the boot device upon reboot.
5. Use third-party software to apply the image created in Part 1 to the RAID volume you created in Part 2.





15 RAID Volume Data Verification and Repair Feature

This feature is available starting with Intel® Matrix Storage Manager 6.1.

15.1 Verify and Repair Volume Feature

The RAID volume verification feature identifies any inconsistencies or bad data on a RAID 0, RAID 1, RAID 5, or RAID 10 volume and reports the number of inconsistencies or number of blocks with media errors found during RAID volume data verification.

When the verification process is complete, a dialog will appear that displays the number of verification errors, verification errors repaired and blocks with media errors that were found.

Follow the below steps to start RAID volume data verification

1. Under 'Status' or 'Manage' click on the RAID volume you want to perform the verify operation under 'storage system view'. The volume properties now display on the left.
2. Click on 'Advanced' and then Click on 'Verify'
3. For RAID 0 the verification process starts once you click 'verify'. For RAID1, 5, 10, Recovery volumes, a dialog box with check box option to repair the errors found automatically during the verification process is present. If the user wants to perform repair you can select this box and then click 'verify'.
4. The verification progress is shown under 'status'
5. When the verification process is complete and the volume status is set to normal, now you can click on the volume under 'status' or 'manage'. Under the volume properties to the left under 'Advanced' you can view the number of verification errors, verification errors repaired and blocks with media errors that were found.

15.2 Verify and Repair Scheduler

The Verify and Repair feature includes a scheduler for the Verify and Repair (V and R) operation. To enable the scheduler take the following steps:

Pre-conditions: UI installed, at least 1 RAID volume on the system that is initialized, in normal state, and a valid RAID type (RRT, R0**, R1, R5, R10) ****RAID 0 volumes can only do a Verify; they cannot be repaired**

1. Login to Windows and launch the Intel® RST UI and click on the 'Preferences' tab at the top of the UI
2. From the 'Preferences' page, select the 'Scheduler' button on the left navigation pane to display the
3. Check mark the 'Enable scheduler' checkbox



4. Select 'Recurrence' schedule: Once (default), Daily, Weekly, or Monthly
5. Select the 'Start Date'; day for the scheduler to begin/run the V and R operation
6. Select the 'Time' of the scheduled runs on a 24 hour clock
7. Select the 'Recur every' schedule: choices will vary depending upon what is selected for 'Recurrence' (this step is not applicable for Recurrence of once)
8. Select whether or not to Automatically Repair Errors encountered during the Verify operation
9. Click 'Apply Changes' to enable





16 Intel® Rapid Recover Technology

This technology utilizes RAID 1 functionality to copy data from a designated Master drive to a designated Recovery drive with the following limitations:

- **The size of the Master drive must be less than or equal to the size of the Recovery drive.**
- **The size of the Master drive is limited to less than or equal to (<=) 1.3125TB in capacity.**

When a Recovery volume is created, complete capacity of the Master drive will be used as the Master volume. Only one Recovery Volume can exist on a system. There are 2 methods of updating the data on the Master to the Recovery drive. They are:

- Continuous Update Policy
- On Request Update Policy

When using the continuous update policy, changes made to the data on the master drive while the recovery drive is not available are automatically copied to the recovery drive becomes available. When using the Update on request policy, the master drive data can be restored to a previous state by copying the data on the recovery drive back to the master drive.

Some of the advantages of Intel® Rapid Recover Technology are:

- More control over how data is copied between 2master and recovery drives
- Fast volume updates (only changes to the master drive since the last update are copied to the recovery drive)
- Member hard drive data can be viewed in Windows* Explorer
- Better power management on mobile systems by spinning down the Recovery drive when in On Request Update Policy mode or when the Recovery drive goes offline when in Continuous Update Policy mode.

Applications: Critical data protection for mobile systems; fast restoration of the master drive to a previous or default state.

16.1 Creating a Recovery Volume Through the RAID Option ROM

A Recovery volume consists of two disks – a primary disk and a recovery disk.

A Recovery volume can be created through the RAID Option ROM or through Intel® Rapid Storage Technology UI application.

Follow the below steps to create a Recovery volume through the OROM

1. Enter the OROM by pressing the <Ctrl> and <I> keys early during system POST.
2. Under the 'Create RAID' volume option, select the option to create a Recovery volume.



3. Select the Primary disk and the Recovery disk.

Note: The Primary disk size must be less than or equal to the Recovery disk size.

OROM Recovery menu provides the following options

1. Enable Only Recovery Disk
2. Enable Only Master Disk

16.2 Creating a Recovery Volume Using Intel® Rapid Storage Technology UEFI User Interface

Follow the below steps to create a Recovery volume through the UEFI UI

- i. Enter the BIOS Setup Menu and select Intel® Rapid Storage Technology menu.
- ii. Select 'Create RAID Volume'.
- iii. Select the RAID Level [Recovery].
- iv. Select Name and type in the name of the volume.
- v. Highlight each drive and press <space> bar to select either R or M depending on which disk will be Recovery or Master.
- vi. Highlight Synchronization, press <Enter> and select Mode of 'On Request' or 'Continuous'
- vii. Highlight 'Create Volume' and press <Enter>
- viii. Volume created will be displayed on Main Page.

16.3 Creating a Recovery Volume Through Intel® RST UI

To create a Recovery volume through the Rapid Storage Technology UI, the system needs to be configured in RAID mode with 2 drives. Boot the system and open the Rapid Storage Technology UI application.

Follow the below steps to create a Recovery Volume

1. Under Create select the volume type as 'Recovery' and click 'Next'
2. Under the 'Configure Volume' you can change the default volume name if you want, then select the 'master' disk and then the 'recovery' disk. Now change the 'update' mode if needed to 'On Request'. The default selection is 'continuous'.
3. Once all the above selections are made, click 'Next'
4. Under 'Confirm' review the selected configuration. If you are not ok with the configuration click 'back' or click 'create volume' if you are fine with the configuration.



5. Now you will see a dialog box with warning message and read the warning message before clicking 'ok' to make sure you are erasing data on the right disk.
6. Once you click 'ok' the volume creation starts and progress of the volume creation can be viewed under status. Once the status is set to 'normal' the volume creation is completed.
7. The system will synchronize the Primary with the Recovery disk once after the creation of the Recovery volume.

16.4 Changing Recovery Volume Modes

When you have a recovery volume on your system in 'continuous mode' or 'on request' mode and you need to change the mode of the recovery volume, follow the below steps

1. Open Intel® Rapid Storage Technology UI.
2. Under 'Manage' or 'Status' click on the recovery volume under the storage system view on right where you need to change the update mode. The volume properties now display on the left view
3. Click 'change mode' and then click 'yes' to confirm.
4. The page refreshes and the volume properties report the new update mode. NOTE: Disabling the continuous update policy requires the end-user to request updates manually. Only changes since the last update process are copied. The recovery volume will remain in On Request Policy until the end-user enables continuous updates.

16.5 Update Recovery Volume in On Request Update Policy

When the recovery volume is 'on request' mode on your system and you need to synchronize the data between both the master and recovery disk, follow the below instructions

1. Open Intel® Rapid Storage Technology UI.
2. Under 'Status' or 'Manage', in the storage system view, click the recovery volume. The volume properties now display on the left.
3. Click 'Update data'.
4. A dialog box is shown stating that the only changes since the last update will be copied. Select the check box if you don't want this confirmation message to display each time you request an update. Click 'Yes' to confirm.
5. The progress of update process can be viewed under 'status' or 'manage'.

16.6 Access Recovery Drive Files

When data recovery to the master disk of a recovery volume is required, you can use 'access the recovery disk files' option. This action is only available if a recovery volume is present, in a normal state, and in on request update mode. Follow the below instructions to access the recovery drive file



when you have a recovery volume in 'on request' mode on your system (If the recovery drive is not in continuous mode, use the instructions in section 8.3 to change the mode)

1. Open the 'Intel Rapid Storage Technology UI'.
2. Under 'Status' or 'Manage', in the storage system view, click the recovery volume. The volume properties now display on the left.
3. Click on 'Access recovery disk files'.
4. Now you can view recovery disk files using Windows Explorer*.

Note: The recovery drive can only be accessible in read only mode and data updates are not available in that state

16.7 Hide Recovery Drive Files

This action is only present when the recovery drive is on request mode and the recovery drive files are accessible. Follow the below instructions to hide the recovery drive files

1. Open the 'Intel Rapid Storage Technology UI'.
2. Under 'Status' or 'Manage', in the storage system view, click the recovery volume. The volume properties now display on the left.
3. Click 'Hide recovery disk files'.
4. Now the recovery drive files are no longer accessible in Windows Explorer.
5. The page refreshes and data updates on the volume are now available.

16.8 Scenarios of Recovering Data

Scenario 1:

What happens if the Recovery drive that is part of the Intel® Rapid Recover Technology volume fails or gets stolen?

Solution:

When a Recovery drive that is part of an Intel® Rapid Recover Technology volume fails, follow the below steps to set up a new disk as the Recovery drive.

1. Shut down the system.
2. Remove the failed Recovery disk and insert a new hard drive. The size of the new drive must be greater than or equal to the Master drive.
3. Boot to the Master drive and open Intel Rapid Storage Technology UI.
4. Under 'Status' or 'Manage', in the storage system view, click the recovery volume to be rebuilt. The volume properties now display on the left.
5. Click on 'rebuild to another disk'
6. Now a dialog box is shown requesting you to select one of the non-RAID disks to rebuild the volume.
7. Once the disk selection is complete, click 'rebuild'
8. Now you can view the progress of the build under 'status' or 'manage'

**Scenario 2:**

What happens if the Master Drive fails and/or the user would like to do a reverse synchronization to a new Master Drive?

Solution:

If the Recovery volume was in Continuous update policy when the Master drive crashed, then the system will continue to function off of the Recovery drive.

If the Recovery volume was in Update on Request policy, then a Master drive failure may result in a BSOD.

In either case, follow the below steps to create a new Master drive using the Recovery Drive.

1. Shut down the system.
2. Remove the old Master disk and connect a new Hard Disk Drive to be designated as the new Master disk. **Note:** The size of the new Master drive should be less than or equal to the Recovery disk.
3. Power on the system. It will automatically boot from the Recovery drive. After the operating system is running, select the Intel® Rapid Storage Technology UI from the Start Menu.
4. Under 'Status' or 'Manage', in the storage system view, click the recovery volume to be rebuilt. The volume properties now display on the left.
5. Click on 'rebuild to another disk'.
6. Now a dialog box is shown requesting you to select one of the non-RAID disks to rebuild the volume.
7. Once the disk selection is complete, click 'rebuild'.
8. Now you can view the progress of the build under 'status' or 'manage'.

Scenario 3:

What is the expected behavior if a power failure occurs (and no battery supply available) in the middle of migration for each of the below?

- Creating a recovery volume (migration)
- Updating a recovery volume (Copy some files from Master drive to Recovery drive)
- Verify and Repair a recovery volume
- Recovering a recovery volume (copy from a Recovery drive to a Master Drive)

Solution:

In each case, upon the next reboot, the migration, or Verifying a Recovery Volume, or Verify and Repair a Recovery Volume or Recovering a Recovery Volume operation would continue normally starting from where it had been interrupted by the power failure.

In the case where the Recovery volume was getting updated or was being recovered, if it were a fast synchronization, then if writes had been in progress while the power was lost, then it would result in a dirty shutdown. As a result, the fast synchronization would degenerate to a slow synchronization or a complete update.

Note: If the system is running is on battery, the volume will not synchronize if it is in continuous update policy. If the volume is in Update on Request policy, then the synchronization will be successful.

Additional comments: need to call out that an on update volume should first be updated before the recovery disk is valid.



Scenario 4:

Once a system is configured with Intel Raid Recover Technology, a user would like to revert the Master Drive Data to a Previous State.

Solution:

If the recovery volume is set to the on request update policy, you can revert master drive data to the state it was in at the end of the last volume update process. This is especially useful when a virus is detected on the master drive or guests use your system.

1. Restart the system. During the system startup, press Ctrl-I to enter the user interface of the Intel® Rapid Storage Technology option ROM.
2. In the 'MAIN MENU' select 'Recovery Volume Options'.
3. In the 'Recovery Volume Options' menu, select 'Enable Only Recovery Disk' to boot from the recovery drive.
4. Exit the option ROM and start up Windows*.
5. After the operating system is running, select the Intel® Rapid Storage Technology UI from the Start Menu.
6. Under 'Status' or 'Manage', in the storage system view, click the recovery volume to be recovered. The volume properties now display on the left.
7. Click on 'recover data' and then click 'ok' on the dialog box.
8. Now you can view the progress of the recovery under 'status' or 'manage'.
9. Once the recovery of the volume is completed, you can reboot to the master drive.

16.9 System Running from Recovery Drive

The "System Running from Recovery Drive " is an existing feature in the current UI but is documented here for the sole purpose of providing Validation and Localization with the flow of expected behavior for test pass preparation.


16.10 Drive Offline or Missing

System Configuration	2 hard drives: recovery drive connected, master drive offline or missing
Product Condition	Recovery volume created with recovery drive normal and master drive offline or missing

- Access UI OROM – Note that the master drive is designated as an offline disk or master drive missing
- Select option 4 Recovery Volume Options



Figure 11



Then Select Option 2 Enable Only Recovery Disk.

§ §



17 Pre-OS Installation of Intel® Rapid Storage Technology Driver

The Intel® Rapid Storage Technology driver can be loaded before installing the Windows OS on a RAID volume or when in AHCI mode. All later Windows OS releases do not require that the Intel® RST driver be installed and loaded prior to the OS installation. On those OS versions the Intel® RST driver can be loaded post OS installation. The Intel® Rapid Storage Technology AHCI driver can be installed over Windows's native AHCI driver.

17.1 Pre-OS Driver Installation Using the “Load Driver” Method

1. During the Operating system installation, after selecting the location to install Windows click on 'Load Driver' button to install the Intel® RST storage AHCI/RAID driver.
2. When prompted, insert the media with the Intel® RST driver files and press Enter.
3. You can find the media and browse to the folder where the files are located.
4. Follow the steps to load the driver and return the installation.
5. Continue the installation.





18 Determining the Version of the RAID Driver

There are two accurate ways to do this. The first is to use the Intel Rapid Storage Technology UI. The second alternate method is to locate the driver (iaStorAC.sys) itself and view its properties.

18.1 Using Intel® Rapid Storage Technology User Interface (UI)

Use this method if the Intel® RST UI is installed on the system; if not use the alternate method.

1. Run the Intel® Optane™ Memory and Storage Management UI from the following Start Menu path:
2. Start→All Programs→Intel → Intel® Optane™ Memory and Storage Management UI
3. Click on the 'About' tab on the left.
4. Under the tab, you can view the driver version in the following format: WW.XX.YY.ZZZZ
5. This is the current version of the user interface utility installed on your system. The WW.XX.YY portion is the product release number; the ZZZZ portion is the build number. E.g. 10.5.1.1001.

18.2 Using Intel® Rapid Storage Technology User Interface (UI)

Use this method if the Intel® RST UI is installed on the system; if not use the alternate method.

1. Run the Intel Rapid Storage Technology UI from the following Start Menu path:
2. Start→All Programs→Intel® Rapid Storage Technology →Intel Rapid Storage Technology UI
3. Click on the top menu button 'help' to launch the 'Help' window. In the 'help' window click the top menu button 'System Report'
4. If not already expanded, click on 'Intel® Rapid Storage Technology' link to expand the item. Under it you can view the driver version in the following format: WW.XX.YY.ZZZZ
5. This is the current version of the user interface utility installed on your system. The WW.XX.YY portion is the product release number; the ZZZZ portion is the build number. E.g. 10.5.1.1001.

18.3 Using Intel® RST File Properties (Alternate)

1. Locate the file "iaStorAC.sys" within the following path:
`<System Root>\Windows\System32\Drivers`
2. Right Click on "iaStorAC.sys" and select Properties



3. Select the "Details" tab (for Windows 7; may vary for other OS versions)
4. At the top of this tab, there should be a parameter called "File version". Next to it is the version of the driver currently installed on your system. It should have the same format and version as the one you obtained using the Intel Rapid Storage Technology UI

18.4 Determining the Version of the Option ROM

There are two ways to determine the version of the Intel Rapid Storage Technology option ROM integrated into the system BIOS. Use the following procedure to determine the version.

18.4.1 Using Intel® Rapid Storage Technology UI

1. Follow the procedure illustrated in section 11.1
2. Look for the parameter RAID Option ROM version.

18.4.2 Using Intel® RST Option ROM User Interface

1. Early in system boot-up, during post, or when you see the "Intel® RAID for Serial ATA" status screen output, type CTRL-I. This will open the Option ROM user interface.
2. The following banner will be displayed:
3. Intel® Rapid Storage Technology option ROM w.x.y.zzzz Intel® SATA Controller
4. w.x.y.zzzz is the version of the Option ROM currently installed on your system. The w.x.y portion is the product release number; the zzzz portion is the build number.

18.4.3 Using the EFI Shell

If the UEFI Driver is enabled the following command can be issued from the EFI shell:

```
Shell:>Drivers
```

The Intel® RST UEFI driver will be shown along with version, where xx.x.x.xxxx will be replaced with the actual UEFI OROM Version i.e.:

```
"CD 000000B B - - 1 2 Intel® RST xx.x.x.xxxx SATA Driver"
```





19 Un-Installation

Uninstalling the RAID driver could potentially cause an end-user to lose access to important data within a RAID volume. This is because the driver can only provide functionality for the Intel® SATA RAID controller. Therefore, Intel does not provide a way to permanently remove the driver from the system. However, disabling the Intel® SATA RAID Controller causes the operating system to not use the RAID driver.

The uninstallation application that is included with the Intel Rapid Storage Technology software can remove all components except the RAID driver (i.e. it removes the UI application, Start Menu links, Control Panel Applet, etc.).

Use the following procedures to remove the Intel Rapid Storage Technology software or to disable the SATA RAID controller:

19.1 Un-Installing Intel® RST Software (except the RAID Driver)

1. Run the Uninstall program from the following start menu link:
2. Start→All Programs→Intel® Rapid Storage Technology →Uninstall
3. The first dialog box that appears gives you the option of un-installing all components of the Intel Rapid Storage Technology software except the RAID driver. Click 'OK' to do so.
4. The next dialog box is a confirmation that you would like to un-install all components of the software except the RAID driver. Click 'Yes' to confirm.
5. All components of the software will be un-installed except the RAID driver. You should no longer see any Start menu links to the UI application or a control panel applet for Intel Rapid Storage Technology. However, the RAID configuration should still function normally.

19.2 Un-Installing Intel® Optane™ Memory and Storage Management UI (except the RAID Driver)

1. Run the Uninstall program from the following start menu link:
2. Start→All Programs→ Intel® Optane™ Memory and Storage Management UI →Uninstall
3. The first dialog box that appears gives you the option of un-installing all components of the HSA software except the RAID driver. Click 'OK' to do so.
4. All components of the software will be un-installed except the RAID driver. You should no longer see any Start menu links to the UI application or a control panel applet for Intel® Optane™ Memory and Storage Management UI. However, the RAID configuration should still function normally.



19.3 Disabling the RAID Driver by Disabling the RAID Controller

WARNING: If you use this method and your computer's operating system is installed to a disk attached to the Intel® SATA RAID Controller, you will no longer be able to boot into that operating system!

1. Enter System BIOS Setup and disable RAID Mode. This setting may be different for each motherboard manufacturer. Consult your manufacturer's user manual if necessary. When done, exit Setup.
2. Reboot the system (The OS must have been installed on a disk not attached to the Intel® SATA RAID controller). You should no longer see the RAID Option ROM status screen during boot, and you should no longer see the Intel® SATA RAID Controller in Device Manager.
3. At this point, Windows will no longer be using the RAID driver and you will not have Intel RAID functionality. **All data contained in existing RAID volumes will no longer be accessible.** To re-enable Intel RAID functionality, re-enter System BIOS Setup and re-enable RAID mode.

Note: To Uninstall: End-users can use this same procedure to disable the Intel® SATA RAID Controller if necessary. In fact, the uninstall program used in section 12.1 of this document will display a text file with a similar procedure. Run the Uninstall Program, click 'Cancel' when presented with the first dialog box, then click 'Yes' at the second dialog box to read the text document containing the procedure.




20 Registry Customizations

Note: Windows registry changes require reboot to take effect.

After installation of the Intel Rapid Storage Technology, the registry will contain keys to allow customization of several features. Customize Support URLs in Rapid Storage Technology UI

The Rapid Storage Technology UI [Help] Menu, Submenu [Online Support] when selected will display a pop-up window with the support URLs as shown in the figure below:



Product information and support : (http://www.intel.com/p/en_US/support/highlights/chpsts/imsm)

Compatibility information : (<http://www.intel.com/support/chipsets/imsm/sb/CS-020680.htm>)

Intel's download center :

([http://downloadcenter.intel.com/SearchResult.aspx?lang=eng&ProductFamily=Chipsets&ProductLine=Chipset+Software&ProductProduct=Intel%c2%ae+Rapid+Storage+Technology+\(Intel%c2%ae+RST\)&ProdId=2101&LineId=1090&FamilyId=40](http://downloadcenter.intel.com/SearchResult.aspx?lang=eng&ProductFamily=Chipsets&ProductLine=Chipset+Software&ProductProduct=Intel%c2%ae+Rapid+Storage+Technology+(Intel%c2%ae+RST)&ProdId=2101&LineId=1090&FamilyId=40))

20.1 Zero Power ODD Settings

Beginning with the Intel® RST 10.0 release and the Intel® Mobile Express Chipset SATA AHCI and the Intel® Desktop/Workstation/Server Express Chipset SATA AHCI controllers (PCH), the product supports the zero-power ODD feature (also referred to as ZPODD). It is intended to allow an unused ODD to be powered off, and then powered on only upon receipt of demand requests or when the ODD eject button is pressed. This goal is achieved by utilizing ACPI** methods to change the power condition of the drive when several platform (HW) conditions exist.



Note: **: This feature is not supported on Windows XP and older operating systems.

Associated with this feature are two registry keys located at

[KEY_LOCAL_MACHINE\SYSTEM\CurrentControlSet\Services\iaStorAC\Parameters]

1. ZPODD enable/disable

[KEY_LOCAL_MACHINE\SYSTEM\CurrentControlSet\Services\iaStorAC\Parameters\Device]

"OddZeroPowerEnable"=dword(0, 1)

This key determines a platform’s eligibility for the feature. When the value is zero then this feature will be disabled. When the value is non-zero or not present the feature will be enabled. Default value will be enabled (**1**).

2. ODD idle timeout

[KEY_LOCAL_MACHINE\SYSTEM\CurrentControlSet\Services\iaStorAC\Parameters\Device]

"SecondsToOddZeroPower"=dword: (30, 300)

This key determines the idle timeout value. When the value is zero then this feature will be disabled. The value is the number of seconds the ODD must be idle (defined as a period of time in which no non-GESN commands are received; minimum value is 30 and maximum value is 300) before the ODD will be powered off. The default value is **60**. If the registry value is set to a value outside this range then the default value of 60 seconds will be used.

20.2 E-mail Notification UI Visible Enable/Disable

By default the e-mail notification feature is visible in the UI under the [Preferences] button. The registry can be modified to allow or disallow the end-user from being able to configure the system to allow email notification. The registry key by default is not populated in the registry. In order to remove the functionality from the UI the registry key has to be created using the following settings:

Open the registry editor and add the following key:

HKEY_LOCAL_MACHINE\SOFTWARE\Intel\IRST

Create a new DWORD (32) value as follows:

DisableEmail

Registry Value	Description
DisableEmail	DWORD(32) = 0 (default): By default or when this value is created and cleared to 0, the UI [Preferences] page displays an item in the left column of the page that allows the user to setup the desired e-mail preferences for the system.
	DWORD(32) = 1: When this value is created and set to 1, the UI will not display a menu item in the 'Preferences' page for the end-user to setup email notification on the system. The feature is disabled.



20.3 Disabling Maximized Mode Option for Intel® SRT

OEMs have the ability to disable the Accelerate Maximized mode option and limit the Intel® Smart Response Technology to Enhanced mode selection only.

The registry key by default is not populated in the registry. In order to remove the functionality from the UI the registry key has to be created using the following settings:

Open the registry editor and add the following key:

HKEY_LOCAL_MACHINE\SOFTWARE\Intel\IRST

Create a new DWORD (32) value as follows:

DisablePerformanceMode

Registry Value	Description
DisablePerformanceMode	DWORD(32) = 0 (default): By default or when this value is created and cleared to 0, the UI will allow the end-user to Accelerate disks/volumes in both Maximized and Enhanced mode.
	DWORD(32) = 1: When this value is created and set to 1, the UI will not display the option to Accelerate to Maximized mode and will not allow the user to change from Enhanced mode to Maximized mode

20.4 Rebuild On Hot Insert

When a redundant RAID volume is in the 'Degraded' state and a hot insert event of a new disk is detected by the RST driver, the driver will automatically begin a rebuild of the degraded RAID volume to the new disk. The new disk must meet all the requirements to be an array member of the degraded RAID array.

The registry key by default is not populated in the registry. In order to enable the functionality in the UI the registry key has to be created using the following settings:

Open the registry editor and add the following key:

HKEY_LOCAL_MACHINE\SYSTEM\CurrentControlSet\Services\iaStorAC\Parameters\Device

Create a new DWORD (32) value as follows:

RebuildOnHotInsert

Registry Value	Description
RebuildOnHotInsert	DWORD(32) = 0 (default): By default or when this value is created and cleared to 0, this feature is disabled.



	DWORD(32) = 1: When this value is created and set to 1, this feature is enabled and when all the system conditions are met, the driver will begin an auto-rebuild upon hot insertion of a supported disk.
--	--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------

20.5 SATA Asynchronous Notification

The location of the key to control SATA Asynchronous Notification functionality has been added.

The registry key by default is not populated in the registry, but 'AN' is enabled by default. In order to change the functionality in the driver, the registry key has to be created using the following setting:

Open the registry editor and add the following key:

HKEY_LOCAL_MACHINE\SYSTEM\CurrentControlSet\Services\iaStorAC\Parameters\Device

Create a new DWORD (32) value as follows:

Controller0PhyXANEnable

Where 'X' represents the SATA port on which 'AN' is to be disabled or enabled.

Registry Value	Description
Controller0PhyXANEnable	DWORD(32) = 0 When set to 0, this feature is disabled.
	DWORD(32) = 1 (default) When set to 1, this feature is enabled.

20.6 Runtime D3 (RTD3)

RTD3 is part of Microsoft Power Management Framework* (PMF). The following registry setting is MSFT specific. A device may be "spun down" after being in Idle a designated time while the system is running (RTD3). When a value less than 60 seconds is chosen, it will default to 20 minutes. When using "MAXULONG" value, the registry key will be ignored and devices will not "spin down", which effectively "disables" RTD3.

KEY_LOCAL_MACHINE\SYSTEM\CurrentControlSet\Enum\SCSI\<Device ID>\<instance ID>\Device Parameters\Storport

Refer MSFT on how to set this registry key: <http://support.microsoft.com/kb/241679/en-us>

The REG_DWORD value is as follows:

MinimumIdleTimeoutInMS

Registry Key: Name	Description
MinimumIdleTimeoutInMS	Type: REG_DWORD(32) = {0 to MAXULONG-1}



	This value specifies the minimum amount of time the power framework must wait to power down a logical unit once it is at idle.
	REG_DWORD(32) = <i>MAXULONG</i> : The Default: <i>MAXULONG</i> , indicating unset. If the miniport provides no timeout value, the actual default value is 5 minutes, or, 5 * 60 * 1000.

20.7 Hybrid Hinting

Hybrid Hinting is enabled automatically without the need for user intervention. In the case that Hybrid Hinting needs to be disabled, a registry key can be created for that purpose. On Windows 8.1 platforms, a registry key is automatically added without user intervention.

20.7.1 Instructions to Disable Hybrid Hinting

Enter the registry editor and navigate to the following path:

HKEY_LOCAL_MACHINE\SYSTEM\CurrentControlSet\Services\iaStorAC\Parameters\Device

Create a new DWORD (32) value as follows:

HybridHintDisabled

Registry Value	Description
HybridHintDisabled	DWORD(32) = 0 Leaves Hybrid Hinting enabled
	DWORD(32) = 1 Disables Hybrid Hinting

20.7.2 Hybrid Hint Reset

As of Win* 8.1, MSFT introduced hinting in their inbox driver. This leaves the hybrid threshold in states that causes decreased performance when the RST driver is installed AFTER Win* 8.1 OS is installed using MSFT inbox driver. To prevent this scenario, RST has provided the following registry key when an SSHD is detected on the system and Hybrid Hinting minimum requirements are met:

Name: **HybridHintReset**

Location:

KEY_LOCAL_MACHINE\SYSTEM\CurrentControlSet\Services\iaStorAC\Parameters\Device

Note: Upon the first reboot after the driver installation is complete, the registry key is written and the hybrid log reset by the driver. Once the registry key is written, it will remain throughout reboots and OS upgrades. If deleted manually, it will be rewritten automatically by the driver upon the next reboot.



20.7.3 Disable Hybrid Hinting During Hibernation

On systems using SSHDs with small NAND size and when hybrid shutdown is enabled in Microsoft OS, it is recommended to disable hybrid hinting during hibernation. This key can be added to prevent longer shutdown time in some cases. In these cases, OEMs/ODMs may use this key to base their evaluation results.

The following registry key can be added to disable hybrid hinting during hibernation.

HKEY_LOCAL_MACHINE\SYSTEM\CurrentControlSet\Services\iaStorAC\Parameters\Device

Create a new DWORD (32) value as follows:

HiberFileHintDisable

Registry Value	Description
HiberFileHintDisable	DWORD(32) = 0 Enable hybrid hinting during hibernate (Default)
	DWORD(32) = 1 Disable hybrid hinting during hibernate

20.8 APM Value Registry Setting

For a system that uses HDD drive, Intel® Optane™ Memory delivers world-class responsiveness of SSD performance at a fraction of a cost by caching frequently accessed data from HDD to Optane™ memory module. In Optane+HDD configuration, an HDD with self-managed, aggressive power policy setting may spin down to save power while Optane™ is servicing I/O operations. However, if Optane™ module does not contain the data requested from the HDD (cache miss), the spin-up latency will cause a negative performance impact (e.g. lagging in a game).

Starting with RST 17.5, the following registry keys have been added to allow OEM/Customers to configure APM settings in Optane™ configuration with HDD.

[HKEY_LOCAL_MACHINE\SYSTEM\CurrentControlSet\Services\iaStorAC\Parameters\Device]

Create new DWORD (32) value as follows:

Controller0PhyXApmOnAC

Controller0PhyXApmOnDC

Where 'X' represents the SATA port on which APM Level is to be set.



Registry Value	Description
Controller0PhyXApmOnAC	DWORD(32) = 0x80 Value range is: 0x1 - 0xFE
Controller0PhyXApmOnDC	DWORD(32) = 0x80 Value range is: 0x1 - 0xFE

Note:

1. If one of the registries is not specified for a specific port, RST driver will read the default APM value read during boot and use this value.
2. To disable disk spin-down, the APM value should be set to 0x80.

Example:

```
[HKEY_LOCAL_MACHINE\SYSTEM\CurrentControlSet\services\iaStorAC\Parameters\Device]
"Controller0Phy0ApmOnAC"=dword:00000080
"Controller0Phy0ApmOnDC"=dword:00000080
```





21 Power Savings with Intel® Rapid Storage Technology

21.1 Modern Standby Support

In order to support Modern Standby the following conditions must be met:

1. Platform BIOS settings are properly configured.
 - a. Refer to “Modern Standby Setup Guide for Intel Reference Platforms” (<https://cdrdv2.intel.com/v1/dl/getContent/602904>) and “Modern Standby and low power enabling BIOS checklist” document (<http://www.intel.com/cd/edesign/library/asm-na/eng/565350.htm>) for platform specific configuration.
 - b. For a list of reference documents and tools, refer to section 1.4 and 1.5 in “[Modern Standby Setup Guide for Intel Reference Platforms](#)” document.
2. PEP Constrain Configuration:
 - a. For Non-Optane configuration (RAID, Passthru, etc..), no PEP constrain setting in the BIOS is required.
 - b. For Optane configuration, PEP constrain in the BIOS must be set to “RaidVolume0” in order to achieve DRIPS or Software DRIPS.
 - i. In RVP platform BIOS, this setting is found under:
ACPI Settings > PEP Constraint Configuration > PEP SATA
3. For SLP_S0 (aka Hardware DRIPS), all storage devices must support lower power state.
 - a. For SATA devices: Slumber or DevSleep.
 - b. For NVME devices: L1.2

21.2 Link Power Management (LPM)

Intel® Rapid Storage Technology implements the Link power management (LPM) feature described by the Serial ATA specification to overcome the power demand of a high-speed serial interface, SATA and providing the capability of SATA at the minimum power cost. LPM, when used in conjunction with a SATA hard drive that supports this feature, enables lower power consumption. LPM was initially enabled by default on mobile platforms starting with ICH6M with Intel® Matrix Storage Manager. Starting with ICH9R this feature has also been supported on desktop platforms with Intel® Matrix Storage Manager 7.5 release but not enabled by default.

Beginning with the Intel® Rapid Storage Technology 10.0 release, LPM support is enabled by default on both mobile and desktop platforms. OEM’s who wish to modify the default settings for LPM on their platforms can follow the instructions in the section titled [Instructions to disable/enable LPM](#).



21.2.1 Instructions to Disable/Enable LPM

After the system is setup with the OS and Intel® Rapid Storage Technology is installed, follow the below instructions to modify the default LPM support.

Note: Beginning with the Intel® Rapid Storage Technology 10.0 release, the registry keys are no longer populated in the Windows registry by default. The RST driver does not require the registry keys to be present to support the default settings.

1. Go to Start->Run
2. Type in RegEdit and press the Enter Key.
3. Go to the below mentioned location to insert or configure the registry keys for LPM.

Note: OEM's need to configure the LPM settings per SATA port. Ports are numbered starting with zero (refer to the desired platform EDS for the number of ports supported on your platform).

HKEY_LOCAL_MACHINE\System\CurrentControlSet\Services\iaStorAC\Parameters\Device

4. Now add the following registry keys under the registry location mentioned in step3, if they are not available (These registry keys are not available by default, they can be added by using automated scripts, .reg files, executable utilities, etc.). If you find the below registry keys already available, you can modify the values for desired support. Values are modified on a port by port basis so modify all ports that you wish the changes to be supported on. **

Per-port Setting:

Replace the '**X**' with the SATA port number to independently control HIPM/DIPM per port.

Host Initiated Power Management:

DWORD: **Controller0PhyXHIPM**

Value: 0 = disable, **1 = enable (default)**

-- (Old key, DWORD: LPM)

Device Initiated Power Management:

DWORD: **Controller0PhyXDIPM**

Value: 0 = disable, **1 = enable (default)**

-- (Old key, DWORD: DIPM)

Configure HIPM to use partial or slumber when the drive is in a D0 ACPI device state

DWORD: **Controller0PhyXLPMState**

Value: **0 = Partial (default)**, 1 = Slumber

-- (Old key, DWORD: LPMState)

Configure HIPM to use partial or slumber when the drive is in a D3 ACPI device state (Device receives a start_stop_unit request: e.g. HDD idle spin-down).

DWORD: **Controller0PhyXLPMState**

Value: 0 = Partial, **1 = Slumber (default)**

-- (Old key, DWORD: LPMState)

Controller-wide Setting:

This allows auto partial to slumber to be enabled. Actual setting of APS is controlled by the values below:

Auto Partial to Slumber:

DWORD: **EnableAPS**

Value: 0 = disable, **1 = enable (default)**



****Warning:** If you edit the registry incorrectly, you can cause serious problems that may require you to reinstall your operating system. Intel does not guarantee that problems that are caused by editing the Registry incorrectly can be resolved.

21.2.2 LPM Updates in 14.0 (APS, SIPM)

21.2.2.1 APS

The RST driver acknowledges the APS configuration as it is exposed by the system BIOS.

21.2.2.2 Software Initiated Power Management (SIPM)

By default RST DRIVER enables SIPM for each active SATA LINK.

21.2.2.2.1 SIPM Initiated PM Enabling Rules

The RST driver enables SIPM only for SIPM capable SATA ports, and ASP will be set to PARTIAL, and host SATA storage controller will report HIPM capability.

- The **RST DRIVER** enables **SIPM** only when **ASP** is set to **PARTIAL**
- By default the **RST DRIVER** enables **SIPM** on **SIPM** capable **SATA** ports, excluding eSATA ports and hot-pluggable **SATA** ports.
- SIPM for Hot-Pluggable SATA Ports: By default the **RST DRIVER** enables **SIPM** on **SIPM** capable **SATA** ports, excluding eSATA ports and hot-pluggable **SATA** ports
- SIPM for eSATA Ports: The **RST DRIVER** keeps **SIPM** disabled on **SATA** ports which are defined by the platform BIOS as eSATA ports
- SIPM Capable SATA Ports: The RST DRIVER enables SIPM only for SATA ports which connected devices are reporting HIPM capability
- SIPM will be enabled when the host is reporting HIPM capability
- SIPM will only be enabled for SATA devices which have APS disabled

21.2.2.2.2 SIPM Timeout Configuration

The **RST DRIVER** reads the value of **SIPM** timeout from the Windows registry. In case the Windows registry key is not present the **RST DRIVER** will use default values for the timeout. The **SIPM** timeout will be configurable for each **SATA** device independently

- The **RST driver** allows configuring the **SIPM** timeout for each SATA device independently
- The **RST driver** sets the **SIPM** timeout to 0 (zero) in order to disable **SIPM** for the given SATA port
- The **RST driver** reads the **SIPM** timeout value from the Windows registry
- The **RST driver** uses default values for **SIPM** timeout when the Windows registry key is not present. The amount of time to elapse before the RST driver puts the link into SLUMBER is as follows:



Windows OS Version	SIPM Default Timeout (milliseconds)
Windows* 8 and later	25
Windows* 7 and earlier	100

21.3 Runtime D3 (RTD3)

Intel® RST now supports Microsoft® Runtime Power Management (RTPM) framework. RTPM allows Windows® to manage the ACTIVE/IDLE power states for discrete target devices, such as hard disks, in an effort to reduce power consumption for mobile platforms.

RTD3 refers to the ability to completely remove power from devices (D3cold) during long idle periods, while the system remains in S0.

RTD3 adheres to the following requirements:

1. OS is Windows* 8 or newer.
2. The SATA AHCI controller must be in AHCI mode.
3. Only HDD's, SSD's, and SSHD's attached to the AHCI controller on ports that are RTD3 capable are managed by RTPM.
4. Devices connected to hot-pluggable ports cannot be managed under RTPM.
5. Devices connected to external ports cannot be managed under RTPM.
6. Devices connected to ports with a mechanical presence switch cannot be managed under RTPM.
7. Devices connected to a Remapped PCIe port cannot be managed under RTPM.

Note: For system's that support RTD3, but are shipped with RST in 'RAID Ready' mode, it is suggested that RTD3 be disabled in the BIOS. This is to prevent end users from creating RAID volumes while RTD3 is enabled.

21.3.1 Adapter RTD3 Support

Current releases of Intel® Rapid Storage Technology do not support Adapter RTD3. This means that only the RTD3 supported devices will be placed into D3hot/D3cold. The Intel® RST driver does not support placing the SATA controller into a D3hot / D3cold state.

For additional information on configuration and usage of this feature, refer to its documentation [CDI/IBP document # 516865](#).

21.3.2 RTD3 Support - RAID HDD/SSD/SSHDs Unit Support

The [RST DRIVER](#) will register SATA RAID ARRAY to Windows Runtime Power Management framework as a single FUNCTIONAL HARDWARE UNIT.



21.3.3 RTD3 Support - RAID w Mixed RTD3 Capable/Non-Capable Ports

RST Driver allows the creation of RAID volumes that utilize both RTD3 capable ports and non-RTD3 capable ports in the same volume. When the RST Driver receives RTD3 events for the RAID Volume, it will RTD3 the ports that are capable of RTD3.

21.3.4 RTD3 Support - RRT

The [RST DRIVER](#) shall NOT support RTD3 of SATA ports that are part of an [RRT](#) RAID Volume. Ports utilized in an [RRT](#) Volume will NOT have power removed or restored by RTD3.

21.3.5 RTD3 Support - SRT

The [RST DRIVER](#) will opt-out from RTD3 requests for [SRT CACHE DEVICES](#).

21.3.6 RTD3 Support - Hot Spares

The RST Driver does NOT support RTD3 of RST RAID Global Hot Spares.

21.3.7 RTD3 Support – Migrations and Rebuilds

The RST Driver will prevent the Windows OS from entering RTD3 for RAID Volumes that are currently under-going internal RAID rebuild or migration operations. Once the operation is complete, the RST Driver will allow RTD3 activity for the RAID Volume to continue.

21.4 DEVSLP

Beginning with Intel® Rapid Storage Technology 12.5 release, support for a new SATA link power state was introduced, device sleep (DEVSLP). DEVSLP is a fourth and lowest link power state, coming after Slumber. The link will enter DEVSLP when all current IO have completed, the link is in the Slumber state and the DEVSLP idle timer has expired granting permission for the SATA controller to assert the DEVSLP signal. BIOS is responsible for configuring and enabling DEVSLP. The driver configurable settings for DEVSLP may be found in the section titled [SATA Device Sleep \(DEVSLP\) Settings](#). For additional information on configuration and usage of this feature, refer to the document [CDI/IBP document # 516865](#).

Intel® RST supports DEVSLP for reduced power during long idle periods such as when the system is in InstantGo*. When DEVSLP is enabled, the Intel® RST driver will support InstantGo* when requested by the OS on pass through devices on the SATA ports that support DEVSLP. InstantGo* is only supported on Windows* 8.1 and newer.

The following recommendation for Intel® Rapid Storage Technology DEVSLP Idle Timeout is taken from Section 4.6 of the Intel "Ultrabook™ Storage Power Management Recommendations White Papers" CDI/IBL #528428

When the system is in InstantGo*, the DEVSLP idle timeout should be set to maximize power savings. Because the I/O pattern while in InstantGo* is not deterministic, the DEVSLP idle time



cannot be set to an arbitrarily low value, or else the power consumed by entering and exiting DEVLSP may be (on the average) greater than the power consumed by remaining in the next higher power state (Slumber). Instead, the idle timeout must be set to a value that delivers the best average power consumption. To achieve the best average power across a variety of configurations, the DEVLSP idle timeout should be set to equal the DEVLSP transition energy recoup time. The DEVLSP recoup time is the time in the next higher power state (Slumber) that consumes that same amount of power as entering and exiting DEVLSP. Using the recoup time ensures that (on the average) the device is not placed in DEVLSP before the energy consumed by the transition can be recouped.

Recoup time for a device to enter and then exit the next lowest power state relative to the device remaining in and then exiting from its current power state is calculated as follows:

$$\text{recoup time} = \frac{(\text{next state entry energy} + \text{next state exit energy} - \text{current state exit energy})}{(\text{current instate power} - \text{next state instate power})}$$

...where entry and exit transition energy is calculated as follows:

$$\text{state transition energy} = \text{transition time} * \text{average power during transition}$$

In the following example, DEVLSP recoup time is calculated for a hypothetical device with the following characteristics:

Table 21-1. DEVLSP Recoup Time

State/State Transition	In-State or Transition Time (S)	In-State or Transition Average Power (W)	In-State or Transition Energy (J)
Slumber	(1)	0.05	
Slumber resume transition	0.001	1.3	0.0013
DEVSLP entry transition	0.000	0	0.0000
DEVSLP	(2)	0.005	
DEVSLP resume transition	0.100	1.3	0.1300

1. Maximum time in Slumber is determined by the DEVLSP recoup time
2. Maximum time in DEVLSP is determined by the RTD3 recoup time (see next section)

Following the general case above, DEVLSP recoup time is calculated as follows:

$$\text{DEVSLP recoup tim} = \frac{\text{DEVSLP entry energy} + \text{DEVSLP resume energy} - \text{Slumber resume energy}}{\text{Slumber instate power} - \text{DEVSLP instate power}}$$

Substituting values from the table above:

$$\text{DEVSLP recoup time} = \frac{0 \text{ J} + .13 \text{ J} - .0013 \text{ J}}{.05 \text{ W} - .005 \text{ W}} = 2.86 \text{ seconds}$$

A device with these characteristics may stay in Slumber for 2.86 seconds and use the same power as would be consumed by transitioning to DEVLSP. Therefore, the recoup time is defined as 2.86 seconds, and the DEVLSP idle time-out when in InstantGo* should be set to 2.86 seconds.

For additional information on configuration and usage of these parameters, refer to the document [CDI/IBP document # 516865](#)



21.4.1 DEVSLP Registry Key Setting

Per-port Settings:

This allows the OEM to customize the DEVSLP Idle Time Out value for InstantGo* enabled systems. When the OS enters InstantGo*, the driver configures the SATA controller to enter DEVSLP sooner to save power. This setting will temporarily override the BIOS configured value for the duration of the InstantGo* period. Upon exiting InstantGo*, the driver will restore the value the BIOS originally programmed:

Replace the 'X' with the SATA port number to independently control the DEVSLP timeout value while in InstantGo*.

DEVSLP Device Idle Time Out Small in milliseconds:

DWORD: *Controller0PhyXDevSlpDITOsml*

Value: 0x1- 0x3FF0, default **0x0BB8** (values need to be entered as hex, equivalent decimal values are 1 to 16368 ms, default 3000 ms)

21.5 DevSleep Tool

Beginning with Intel® RST versions 13.5 and newer, OEMs can pre-configure their platforms with the DevSleep tool. This tool is a Windows/WinPE or Dos-based command line interface utility for configuring DEVSLP registry keys for fine tuning Low Power DEVSLP enabled devices.

At boot time, the RST DRIVER shall read the configured registry key values and use them as overrides on a per-device basis.

Each of the following registry keys have the characteristic:

String Value: "<product id> <timeout>"

Example: "xx740ADFD?00NLR1* 3000"

<product id>: The First part is the device product id to match

Special characters can be used in product id:

'?' matches any single character

'*' matches any length of characters

"* 3000": applies a 3000ms value to all disks.

< timeout >: The value of the DEVSLP time variable.

- CsDeviceSleepIdleTimeoutInMS
- DeviceSleepIdleTimeoutInMS
- DeviceSleepExitTimeoutInMS
- MinimumDeviceSleepAssertionTimeInMS

Multiple "product id timeout" pairs can be placed in the registry key. Each pair is separated by a null delimiter.

The RST DRIVER will first look for the per-device registry key and if a device match is found it shall use the value indicated. If per-device registry key does not contain a match for any attached device, then the driver shall use the per-port specific registry key if present. This requirement shall not modify the behavior of any per port registry key.

Per-Device Key	Per-Device String Match	Port Key	Results
Present	Found	Present	Use Per-Device
Present	Found	Missing	Use Per-Device



Present	Missing	Present	Use Port
Present	Missing	Missing	Use Default
Missing	Missing	Present	Use Port
Missing	Missing	Missing	Use Default

21.5.1 CsDeviceSleepIdleTimeoutInMS

Path: HKLM\System\CurrentControlSet\Services\iaStorAC\Parameters\Device

Key:

CsDeviceSleepIdleTimeoutInMS

This registry key is the Device Sleep idle timeout (DITOAActual) to use when the system is in connected standby. $DITOAActual = (DITO * (DM+1))$

Total DevSlp Idle Timeout is the total amount of time in ms that the host bus adapter will wait after the port is idle before raising the DevSlp signal, max=16368.

If this registry key is not present, the RST DRIVER shall check for the per-port specific registry key "DevSlpDITOsml". This registry key will not take precedence over the registry setting of "DevSlpDITOsml" if already present.

21.5.2 DeviceSleepIdleTimeoutInMS

Path: HKLM\System\CurrentControlSet\Services\iaStorAC\Parameters\Device

Key:

DeviceSleepIdleTimeoutInMS

This registry key is the Device Sleep idle timeout (DITOAActual) to use when the system is **not** in Connected Standby (CS). Note: this registry shall apply to both CS and non-CS platforms. The < timeout > is the value of the DEVSLP idle timeout to use when the system is **not** in Connected Standby, in milliseconds (decimal value).

21.5.3 DeviceSleepExitTimeoutInMS

Path: HKLM\System\CurrentControlSet\Services\iaStorAC\Parameters\Device

Key:

DeviceSleepExitTimeoutInMS

This registry key is the Device Sleep Exit timeout (PxDEVSLP.DETO). The < timeout > value is the DEVSLP exit timeout in milliseconds (decimal value).

21.5.4 MinimumDeviceSleepAssertionTimeInMS

Path: HKLM\System\CurrentControlSet\Services\iaStorAC\Parameters\Device

Key:

MinimumDeviceSleepAssertionTimeInMS

This registry key is the minimum amount of time, in ms, that the HBA must assert the DEVSLP signal before it may be de-asserted; Minimum Device Sleep Assertion time



(PxDEVSLP.MDAT). The nominal value is 10ms and the minimum is 1ms depending on device identification information.

The < timeout > value is the minimum DEVSLP assertion time in milliseconds (decimal value).

21.5.5 DevSleep Tool Usage

USAGE:

Create Options:

Create Usage:

Creates the new registry keys and populates them with default values

create [--key x] [--inline]

Create Examples:

```
-C
--create
--create --inline
--create --key CsDeviceSleepIdleTimeoutInMS
--create --key DeviceSleepExitTimeoutInMS --inline
--create --help
```

Export Options:

Export Usage:

Exports the Dev Sleep registry keys to a distributable .reg file

-export

Export Examples:

```
E
-export
--export --help
```

List Options:

List Usage:

Lists all devices and values in the registry

--list [--key x]

List Examples:

```
-L
--list
--list --key MinimumDeviceSleepAssertionTimeInMS
--list --help
```

Modify Options:

Modify Usage:

Modifies the reg key

--modify --index z --value y [--key x] [Product ID]

Modify Examples:

```
-M --index 3 --value 10
--modify --index 0 --value 3 --key DeviceSleepIdleTimeoutInMS
-M --index 1 --value 7 --key CsDeviceSleepIdleTimeoutInMS newproductid
--modify --index 1 --value 7 productid with spaces for all reg keys
--modify --help
```

Add Options:

Add Usage:

Adds a new registry key

--add --value y Product ID

Add Examples:

```
-A --value 10 newproductid
--add --value 3 --key DeviceSleepIdleTimeoutInMS newproductid
-A --value 7 productid with spaces for all reg keys
```



--add --help

Import Options:

Import Usage:

Imports the Dev Sleep registry key to a specified OS image

--import --driveLetter c

Import Examples:

-I --driveLetter C

--import --driveLetter C

--import --help

Delete Options:

Delete Usage:

Deletes an existing registry key

--delete --index z [--key x]

Delete Examples:

-D

--delete --index 3

--delete --index 1 --key MinimumDeviceSleepAssertionTimeInMS

--delete -help

21.6 L1.2 Support

Starting with RST version 13.5, L1.2 will be supported for PCIe SSD devices. L1.2 is the lowest, non-zero power state that uses a 2 step resume process for better responsiveness and power savings. RST will support L1.2 when it is enabled on the platform and when L1.2 is enabled on the PCIe Storage device. Because this feature is controlled primarily by the system BIOS, refer to your BIOS reference guide to for correct system setup.

21.7 InstantGo* Device Notification Support

Note: *Intel® Rapid Storage Technology support for InstantGo* is limited to platforms that support this feature. InstantGo* is a Microsoft feature and for more details, consult Microsoft.*

Beginning with Intel® Rapid Storage Technology 13.0, the Intel® RST driver also supports InstantGo* Notification on all InstantGo* Notification capable devices connected to the AHCI controller. The Intel® RST driver will notify devices when the system is entering/exiting InstantGo*. This allows supported devices to change policy and be more aggressive in internal power management and power savings.

21.7.1 Requirements

- Devices must support the Advanced Power Management feature (APM) defined in the ATA* standard (ACS-3) and report support for APM levels.*
 - IDENTIFY DEVICE data Word 159 set to 0xA5A5 in the Vendor Specific area.**
- Platform Hardware and Devices must support the DEVSLP Feature.



- Device supports the Device Sleep feature (per ATA IDENTIFY DEVICE command) IDENTIFY DEVICE data word 78 bit 8 is set to '1'.(i.e., resume from Device Sleep using COMWAKE).

- Devices must support DevSleep_to_ReducedPwrState (as indicated in Identify Device data).
- Supported on pass-thru devices (non-RAID member).

Intel recommendations for IHVs to support devices' INSTANTGO Notification requirements and APM levels can be found in "Ultrabook Storage Power Management Recommendations White Paper" on CDI/IBL #528428.

**InstantGo* Notification feature is currently supported on Intel Dalecrest (530) devices.

21.7.2 Detail Description

Intel® Rapid Storage Technology driver customizes InstantGo* Device Notification on a per device basis when the system is entering / exiting InstantGo*.

Once the Intel® RST driver receives notification from the OS that the system is going to enter or exit InstantGo*, Intel® RST driver will notify the device by using the APM (Advanced Power Management) mechanism defined in the ACS (ATA Command Set).

The Intel® RST driver will use a SET FEATURE command to send a hint of power/performance balance to the device. The hint value is 01 – FEh.

Values:

- FEh - max performance at the expense of power
- 01h - max power savings at the expense of performance
- 80h – defined for HDDs as max power savings, but cannot spin down, lower than 80h and the device is allowed to self spin down
- All other values are vendor specific

Intel® RST uses 10h as the default value for entering InstantGo*, and 80h is the default value Intel® RST uses for exiting InstantGo*. Values are customizable by using registry keys.

Intel® RST starting 16.7 restores APM to its original value that was read from drive, upon exiting CONNECTED STANDBY power state. The RST DRIVER uses the APM value stored in disk configuration/capabilities. OEMs may leave vendors default settings or modify it.

Note: Additionally, a device should be prepared for a power loss after any completed STANDBY IMMEDIATE command (see ACS-3) regardless of the link power state entered between the completion of a STANDBY IMMEDIATE command and the loss of power. This includes Active, Partial, Slumber and DevSleep link power states.

21.7.3 Registry Settings

InstantGo* Device Notification is enabled by default. The following registry keys can be used to disable InstantGo* Device Notification and/or to change default values on a per device basis.

Open the registry editor and navigate to this path:

HKEY_LOCAL_MACHINE\SYSTEM\CurrentControlSet\Services\iaStorAC\Parameters\Device

Add the following key to disable InstantGo* Notification for device on port 'X':

DWORD: Controller0PhyXCsDeviceNotification

Value: 0x0– 0x01, default **0x01** (1= enabled / 0=disabled)

The following Registry key will allow customizable APM levels to set the device to when the system enters and/or exits InstantGo*. This will only be done if InstantGo* Notification is enabled.



Open the registry editor and navigate to this path:

HKEY_LOCAL_MACHINE\SYSTEM\CurrentControlSet\Services\iaStorAC\Parameters\Device

Add the following registry key to customize Entry into InstantGo* notification :

DWORD: **Controller0PhyXEnterCSApmLevel**

Values: **As below (default is 10h)**

Add the following registry key to customize Exit from InstantGo* notification:

DWORD: **Controller0PhyXExitCSApmLevel**

Values: **As below (default is 80h)**

VALUES: APM levels interpreted as follows:

- FEh – Maximum performance mode
- 80h – Minimum power management without standby (e.g. balance between power savings and performance)
- 10h – High performance bursts, quick to low power (e.g. Windows* 8.1 InstantGo*)
- 01h – Minimum power consumption with standby

The requested APM levels persist across resets, but not power cycles. Intel® RST 13.0, and newer, supports this capability and will set the appropriate APM levels after power is applied to the devices (either power on or after resume from RTD3).

InstantGo is a MSFT feature and was formerly referred to as “Connected Standby”.

21.8 New in 14.5 Release

21.8.1 Connected Standby Power State Support for SSHD

The [RST DRIVER](#) allows [CONNECTED STANDBY](#) power state for [SSHD](#) under following conditions:

- Platform supports [CONNECTED STANDBY](#) power state,
- [SSHD](#) is used as [BOOT VOLUME](#),
- [SSHD](#) is used in pass-through mode.

21.8.1.1 Hybrid Type Device Criteria

The [RST DRIVER](#) classifies a drive as [HYBRID TYPE](#) when the drive reports HYBRID HINTING, [PUIS](#) and [APM](#) capabilities.

21.8.1.2 Spin-Down on Entering Connected Standby

The [RST DRIVER](#) uses [APM](#) to spin down of the [SSHD](#) rotational media when entering [CONNECTED STANDBY](#) power state.

21.8.1.3 Use Hybrid Hinting when in Connected Standby

The [RST DRIVER](#) uses HYBRID HINTING to redirect I/O requests to [SSHD_NVCACHE](#) when in [CONNECTED STANDBY](#) power state.



21.8.1.4 Use APM to Control Spindle

The [RST DRIVER](#) uses [APM](#) to control the spindle. The [APM](#) will automatically spin-up the rotational media part of the drive for time of a “read cache miss” event.

21.8.1.5 Restore APM on Exiting from Connected Standby

The [RST DRIVER](#) restores [APM](#) to its original value, read from drive, upon exiting [CONNECTED STANDBY](#) power state.

21.8.1.6 PUIS Capabilities for Connected Standby Power State

The [RST DRIVER](#) enables [PUIS](#) prior entering [CONNECTED STANDBY](#) to prevent spin-up of the rotational media part after [RTD3](#) transition requests from the operating system.

21.8.2 CONNECTED STANDBY Power Model

The [RST DRIVER](#) utilizes the [CONNECTED STANDBY](#) power model for low-power capable platforms.

21.8.3 Adaptive D3 Idle Timeout

The [RST DRIVER](#) enables the adaptive D3 idle timeout feature for SATA rotating media.

21.8.3.1 Adaptive D3 Idle Timeout for Hard Disk Drives

The [RST DRIVER](#) enables the adaptive D3 idle timeout feature for SATA HDDs.

21.8.3.2 Adaptive D3 Idle Timeout for RAID

The [RST DRIVER](#) enables the adaptive D3 idle timeout feature for homogeneous RAID volumes comprise SATA rotating media.

Adaptive D3 Idle Timeout for Matrix RAID

The [RST DRIVER](#) disables the adaptive D3 idle timeout feature for MATRIX RAID volumes.

Adaptive D3 Idle Timeout for mixed RAID

The [RST DRIVER](#) always disables the adaptive D3 idle timeout feature for MIXED RAID volumes.

21.8.3.3 Adaptive D3 Idle Timeout for Hybrid Hard Drives

The [RST DRIVER](#) always enables the adaptive D3 idle timeout feature for SSHDs (HHD).

21.8.3.4 Adaptive D3 Idle Timeout for Non-Rotating Media

The [RST DRIVER](#) always disables the adaptive D3 idle timeout feature for all types of non-rotating media.



Adaptive D3 Idle Timeout for PCIe Remapped SSDs

The [RST DRIVER](#) always disables the adaptive D3 idle timeout feature for PCIe Remapped SSDs.

Adaptive D3 Idle Timeout for SATA SSDs

The [RST DRIVER](#) always disables the adaptive D3 idle timeout feature for SATA SSDs.

21.8.3.5 Adaptive D3 Idle Timeout for ATAPI Devices

The [RST DRIVER](#) always disables the adaptive D3 idle timeout for ATAPI devices.

Adaptive D3 Idle Timeout for Tape Devices

The [RST DRIVER](#) always disables the adaptive D3 idle timeout feature for tape drives.

Adaptive D3 Idle Timeout for ODDs

The [RST DRIVER](#) always disables the adaptive D3 idle timeout feature for ODDs.

Adaptive D3 Idle Timeout for ZPODDs

The [RST DRIVER](#) always disables the adaptive D3 idle timeout feature for ZPODDs.

21.8.4 Connected Standby Power Model Support for SRT

The [RST DRIVER](#) enables entering into [CONNECTED STANDBY](#) power state when a [CACHE VOLUME](#) is configured.

21.8.4.1 Allowed Configuration

Minimum 16GB of cache and [SRT](#) must be configured in [MAXIMIZED MODE](#).

21.8.4.2 Storage Device Criteria

The [CACHE DEVICE](#) and the [BACKING STORAGE](#) both must be SATA storage devices.

21.8.4.3 Entering Connected Standby Power State

The [RST DRIVER](#) enters into [CONNECTED STANDBY](#) power state on explicit notification received from Windows operating system.

Allow Entering Connected Standby for Cache Device

The [RST DRIVER](#) allows entering into [CONNECTED STANDBY](#) power state under following conditions:

- Platform is supporting [CONNECTED STANDBY](#) power state,
- [CACHE DEVICE](#) is used to accelerate a BOOT VOLUME.



SRT Enhanced Mode Constraint on MODERN STANDBY Platforms

The [RST DRIVER](#) will not [D3](#) the [BACKING STORAGE](#) when the [CACHE VOLUME](#) is configured in [ENHANCED MODE](#).

21.8.4.4 Exiting Connected Standby for Backing Storage

The [RST DRIVER](#) will [D0](#) the [BACKING STORAGE](#) upon exiting the [CONNECTED STANDBY](#) power state.

21.8.4.5 Waking up Backing Storage

The [RST DRIVER](#) prevents the [BACKING STORAGE](#) from entering [D0](#) by directing I/O requests to [CACHE DEVICE](#).

Waking up Backing Storage on Cache Miss or Cache Clean

The [RST DRIVER](#) may [D0](#) the [BACKING STORAGE](#) while in [CONNECTED STANDBY](#) power state, regardless of power source, for time of occurred events:

- Cache miss during I/O READ request,
- Cache cleaning due to cache volume full.

21.8.4.6 Aggressive D3 and Semi-Aggressive D3 for Backing Storage

[AGGRESSIVE D3](#) and [SEMI-AGGRESSIVE D3](#) of [BACKING STORAGE](#) will only be available when [SRT](#) is configured in [MAXIMIZED MODE](#).

Registry Support for Aggressive D3 and Semi-aggressive D3 Inactivity Timeouts

The [RST DRIVER](#) reads configuration of I/O inactivity timeouts for [AGGRESSIVE D3](#) and [SEMI-AGGRESSIVE D3](#) from Windows Registry.

Default Inactivity Timeout for AGGRESSIVE D3

The [RST DRIVER](#) waits not less than 2 seconds for completion of an I/O request to [BACKING STORAGE](#) before attempting to [D3](#) the [BACKING STORAGE](#).

Default Inactivity Timeout for SEMI-AGGRESSIVE D3

The [RST DRIVER](#) waits not less than 30 seconds for completion of an I/O request to [BACKING STORAGE](#) before attempting to [D3](#) the [BACKING STORAGE](#).

21.8.4.7 Entering Resiliency Phase on AC Power

The [RST DRIVER](#) will [SEMI-AGGRESSIVELY D3](#) the [BACKINGS TORAGE](#) when entering the [RESILIENCY PHASE](#) of [CONNECTED STANDBY](#) when the system is on AC power.



21.8.4.8 Entering Resilience Phase on Battery Power

The [RST DRIVER](#) will [AGRESIVELY D3](#) the [BACKING STORAGE](#) when entering the [RESILIENCY PHASE](#) of [CONNECTED STANDBY](#) when system is on battery power.

21.8.5 SATA Link Power Management Support

The [RST DRIVER](#) implements [SATA](#) Link Power Management as specified in the Power State Transition section of the [SATA AHCI Specification](#).

21.8.5.1 SIPM Support for MODERN STANDBY Power Model

The [RST DRIVER](#) disables [SIPM](#) and sets [ASP](#) to [SLUMBER](#) upon entering into [MODERN STANDBY](#), and re-enables [SIPM](#) and sets [ASP](#) to [PARTIAL](#) upon existing from [MODERN STANDBY](#)

SIPM Disabled when in MODERN STANDBY

The RST DRIVER disables SIPM on entering to MODERN STANDBY.

SIPM Re-enabled Upon Exiting MODERN STANDBY

The SIPM is re-enabled upon exiting from MODERN STANDBY.

ASP Configuration when in MODERN STANDBY

The RST DRIVER keeps ASP set to SLUMBER when the platform is in MODERN STANDBY.

ASP Configuration when not in MODERN STANDBY

The RST DRIVER keeps ASP set to PARTIAL when the platform is not in MODERN STANDBY.





22 Legacy RAID Option ROM and Utilities

There is a unified RAID Option ROM (.ffs or .bin) and RAID Utilities (RCfgSata.exe and RCmpSata.exe) beginning with the Intel® Rapid Storage Technology 9.6 and later release versions. This unified OROM package is supported on the platforms identified below and all later platform releases when enabled for RAID. With this RAID Option ROM, these platforms now support all RAID functionality based on the hardware capability.

General Requirements

Hardware	<p>Only enabled on specific SKUs of the Intel® 8 / 9 Series chipset platforms:</p> <ul style="list-style-type: none">• H87, H97, HM87, HM97• Q87, QM87,• Z87, Z97• C226• LPT-LP Premium• Broadwell U/Y Premium <p>With one of the following Intel® Processors installed:</p> <ul style="list-style-type: none">- Intel® Core™ Branded (i3, i5, and i7 processor families)- Intel® Xeon® Processor family
Operating System	<p>All supported Operating Systems for this release 131</p>





23 HDD Password Support with RAID Volumes

Intel® Rapid Storage Technology supports password protected HDDs to be RAID array member disks and pass-thru disks. The product will rely on the BIOS implementing for most of the ATA Security support. There is a whitepaper available called "Implementing Intel® Matrix Storage Manager Compatible Support for ATA Security in BIOS" available on CDI that describes the necessary BIOS design for compatibility with the Intel Rapid Storage Technology. Rapid Storage Technology product will handle the RAID and hot-plug related behavior with regards to password protected disks.

23.1 HDD Password Use Cases

If at least one unlocked member disk and one locked member disk (with relevant data for the RAID array) are connected, then the RST Driver will reset the "offline disk member" status prior to a boot-time enumeration in the case that a member disk is unlocked by entering the correct password. The Intel® RST UI will display the locked disk as locked, and any member disks as offline.

Accelerated volumes containing a locked member disk will return to a normal online state upon transitioning from S4 to S1 and entering the correct password to unlock the volume/disk.

Scenario	Action	Result	Comments
RAID1 Volume Disk 1 - Locked Disk 2 - Unlocked Volume - Locked (Both disks have relevant data)	Remove Disk 1 (locked disk)	Volume becomes unlocked and Degraded. User can rebuild volume onto a new unlocked disk.	The user had authority to access Disk 2 which has the same data as Disk 1, by removing the locked drive the user can access Disk 2.
RAID1 Volume Disk 1 - Locked Disk 2 - Unlocked Volume - Degraded Disk 1 has old data and caused the volume to go Degraded.	None	N/A	The user has access to Disk 2 because the data on Disk 1 is old and irrelevant.
RAID5 Volume Disk 1 - Locked Disk 2 - Unlocked Disk 3 - Unlocked Volume - Locked (All disks have relevant data to Volume)	Remove Disk 1 (locked disk)	Volume becomes unlocked and Degraded. User can rebuild volume onto a new unlocked disk.	The user had authority to access Disk 2 and Disk 3 which has all the data needed to rebuild the volume, by removing the locked drive the user can access Disk 2 and Disk 3 as a Degraded Volume.



Intel® RRT Volume
Master Disk – Locked
Recovery Disk - Locked
(external port docking
station)
Volume – Locked
(Both disks have relevant
data)

User connects
laptop to docking
station and
unlocks Recovery
disk and Master
Disk and boots.
Then user takes
the laptop from
the docking
station and
leaves the
external drive
connected to
power

The recovery drive can
be connected to a new
laptop and the
information can be
used to rebuild an
Intel® RRT volume if
the power was
maintained, because
the drive is still in an
unlocked state.

Similar situation to a user
leaving a laptop unlocked
and unattended.

23.2 Unlocking Password Protected Disks


The ability to unlock password protected drives from within the Intel® RST GUI during OS runtime has been removed beginning with **RST production release version 11.6.0.1030**. Users will only be able to unlock password protected drives from within the system BIOS. Consult the system manufacturer for instructions on BIOS use for this feature.





24 Intel® Rapid Storage Technology User Interface

Note: The Intel® Rapid Storage Technology UI is not required to be installed when the storage subsystem is operating in AHCI mode. The main benefit of the Intel® RST UI is in its management and monitoring of the Intel® RST RAID storage subsystem and the management and configuration of cache accelerated volumes.



24.1 Introduction

The Intel® Rapid Storage Technology UI is a Windows*-based application that provides users monitoring and management capabilities for the Intel® RST storage subsystem. It offers a wide range of monitoring and management activities for the Intel® RST RAID subsystem (***In AHCI mode there are no management or monitoring capabilities offered by the UI application.***)



24.1.1 Getting Started

The Intel® Rapid Storage Technology software package provides high-performance SATA AHCI and SATA RAID capabilities for supported operating systems.

The Intel® Rapid Storage Technology (RST) UI requires the Microsoft .NET 4.5 framework beginning with Intel® RST 13.0 release. For prior releases, the RST UI connects and interoperates with the Microsoft .NET 3.0, 3.5, and 4.0 framework.

Refer to the System Requirements and the online user's manual to set up your system's configuration and feature support level. You can also review the Readme file installed with this software or visit Intel's online support to learn more about the full system requirements and RAID BIOS configuration.

RAID enabled systems

Redundant Array of Independent Disks (RAID) refers to multiple independent disks combined to form one logical drive. The main objective of this technology is to improve storage system performance, data protection, and increase fault-tolerance.

This technology provides support for the following features:

- **Intel® Rapid Recover Technology**
This technology provides full data redundancy by copying data from a designated source drive (i.e., master disk) to a designated destination drive (i.e., recovery disk). Data updates of recovery volumes can be continuous or on request.
- **Intel® Rapid Storage Technology RAID**
This technology provides the ability to create RAID 0, RAID 1, RAID 5, and RAID 10 volumes on desktop and mobile platforms. Data is distributed across two or more disks to provide data redundancy (exception of RAID0) or to enhance data storage performance.
- **Intel® Matrix RAID Technology**
This technology allows two independent RAID volumes to be created on a single array. The first volume occupies part of the array, leaving space for the second volume. The array may consist of two to six SATA disks depending on the volume types.
- **Hot plug**
Also referred to as hot swap, this feature allows SATA disks to be removed or inserted while the computer is turned on and the operating system is running. As an example, hot plugging may be used to replace a failed external disk.
- **Intel® Smart Response Technology caching**
This feature allows you to use a non-system solid state disk and configure it as a non-volatile intelligent cache device in order to accelerate a disk or volume that is part of the storage system. This configuration helps improve the overall system performance.
- **Volume migration**
This feature provides support for converting system data into a high-performance or protection RAID configuration.
- **Volume size increase**
This feature allows you to increase the data storage capacity of a volume by using 100% of the available array space or by adding one or more SATA disk to an existing volume.
- **Password-protected disks**
This feature provides high-level security and protection for the data on your disks with a password, denying access from any unauthorized user.
Additional features and technology supported by the driver although not directly accessible via the Intel® RST UI:
- **TRIM**
This feature provides support for all solid state disks (SSDs) in your storage system that meet the ATA-8 protocol requirements and are not part of an array. This feature optimizes write operations, helps devices reduce wear, and maintains unused storage area on devices as large as possible.



Beginning with the Intel® 7 Series chipset the driver supports TRIM on SSDs in a RAID 0 configuration.

- **ODD power optimization**

This feature allows an unused optical disk drive (ODD) to be automatically powered off when media such as a compact disk, a DVD, or Blu-ray disk are not present in the drive and the tray** is closed. The ODD is powered back on by the operating system or user interaction with the device, including when the eject button is pressed. ODD power optimization is particularly valuable for mobile computers as battery life is negatively affected when the ODD is powered on and in an idle state. This feature is only supported on the following system configurations: Intel® 6 Series Chipset or later, compatible motherboards, and compatible ODDs. For more information about compatibility requirements, refer to the SATA specifications available at www.sata-io.org

**For slot-loadable drives, the tray condition does not apply.

- **Native command queuing**

A feature that allows SATA disks to accept more than one command at a time. When used in conjunction with one or more disks that support NCQ, storage performance is increased on random workloads by allowing the disk to internally optimize the order of commands.

- **Hybrid Hinting**

This feature supports the use of Solid-State Hybrid Drives (SSHD). SSHD's are hard disks that contain Flash memory for use as a cache to store frequently accessed data. The driver provides hints to the SSHD to notify the drive which data would be best to store in the data cache.

Disks of more than two terabytes

This feature provides support for hard disks and solid state disks with a capacity greater than 2 TB that are reported as pass-through devices (available) or used in a RAID configuration. In addition, booting from a system disk greater than 2 TB is allowed as long as the version of the option ROM in your system supports this feature.

Note: : If a source disk is greater than 2TB and using the MBR partitioning scheme, the application will not allow data preservation in order to create a volume. Instead, a new volume will be created with no partition on it. Also, if the operating system is Windows* XP, capacity expansion operations will not be allowed for volume sizes equal or greater than 2TB.

AHCI-enabled systems

Advanced Host Controller Interface (AHCI) is an interface specification that automatically allows the storage driver to enable advanced SATA features, such as Native Command Queuing and Native Hot Plug, on the SATA disks connected to your computer. The following features are supported on AHCI-enabled systems:

- **Native command queuing**
- **Hot plug**
- **Disks of more than two terabytes (if that size is supported by the RST UEFI pre-OS driver or legacy OptionROM)**
- **Password-protected disks**
- **ODD power optimization (Microsoft Windows Vista* and higher)**
- **Dynamic Storage Acceleration**
- **Hybrid Hinting**

24.1.2 Understanding the Application

The Intel® Rapid Storage Technology application allows you to optimize and maintain a healthy storage system by creating volumes, customizing performance settings and managing storage system elements. This section provides you with a general overview of a storage system configuration and an individual review of all the areas contained in this application.



24.1.2.1 Storage System Configuration

The storage system combines hardware capabilities with RAID technology to provide flexible data storage units on your computer. Each data storage unit, or RAID configuration, consists of three elements that include physical SATA disks, one or two volumes, and one array. When at least one volume is present on the system, these elements are represented in the storage system view of the Status and Manage areas.

In this section, we describe each of these RAID configuration elements and explain how they relate to each other.

- **Array**

An array is a collection of two or more SATA disks in a RAID configuration and is the highest element in the hierarchy of a storage system. Once a volume is created, the disks you used to create that volume form an array. Refer to the Creating Additional Volumes topic for details on how you can create two volumes across the same disks. An array can include one or two RAID volumes if the hardware allows it.

- **Volume**

A volume is the storage area on two or more disks whose type dictates the configuration of the data stored. If you created a volume for data protection, then your storage system may include a RAID 1 volume spanning two SATA disks, which mirrors data on each disk.

- **Disks**

A disk (i.e., hard disk or hard disk drive) physically stores data and allows read/write data access. If a disk is used to create a volume, it becomes an array disk because it has been grouped with other disks to form an array.

The storage system can also include ATAPI devices, which cannot be used to create a volume. They are a mass storage device with a parallel interface, such as CD-ROM, DVD/Blu-ray disc, or tape drive.

24.1.2.2 Navigation

The application is organized into five main areas depicted by the top navigation buttons: Status, Create, Manage, Accelerate, and Preferences. Depending on your computer's configuration and available hardware, Create and Accelerate may not be available.



Status

The 'Status' area provides a general state of health of your storage system. If a status other than normal is reported, the Manage sub-section will be available to provide you with basic information and actions links necessary to return the status to normal.



Create

The 'Create' area allows you to create different types of volumes to protect data, enhance disk performance, optimize disk capacity, or create a custom volume to combine benefits.



Note

The 'Create' area is only available if your computer supports RAID technology, and if the volume requirements are met. Refer to the Volume Requirements topic for an exhaustive list of storage system conditions to create a volume.



Manage

The 'Manage' area combines the logical and physical view of your storage system. The area displays detailed information about each element that is part of the storage system, such as volumes and disks; the storage system view shows how the selected element relates to others. Each element has its own 'Manage' area which is accessible by clicking any element displayed in the storage system view under 'Status' or 'Manage'.

The 'Manage' area also provides the actions available for the selected element, such as renaming a volume or changing the volume type.



Accelerate

The 'Accelerate' area allows you to manage the cache memory configuration using a non-system solid state disk as a cache device. If the cache is reported in an abnormal state, detailed information and troubleshooting actions will display. The Acceleration View is specific to the 'Accelerate' area and only displays in this location.



Preferences

The 'Preferences' area allows you to customize system settings by enabling the display of the notification area icon, and by selecting the type of notifications that you want the application to display.



Storage System View

The storage system view has two functions:

- It is a simplified representation of your storage system and displays graphic elements, such as arrays, volumes, devices, and ports. Each element provides general attribute information, such as status, name and size. Hovering over each element provides additional attribute details.
- You can also use the graphical view to access 'Manage' by clicking the storage system element you want to work with. For example, if an array is present, clicking the volume opens Manage Volume and clicking one of the array disks will open Manage Disk for the selected disk.



Acceleration View

The Acceleration View is a graphical representation of the acceleration configuration, and only displays the devices (disks and volumes) included in this particular configuration. You can use this view to access the 'Manage' page specific to each represented device by clicking the storage system element for which you want more detailed information.

24.1.3 Notification Area

The notification area (also called the system tray) is located on your desktop. The taskbar contains the notification area icon for Intel® Rapid Storage Technology. The icon provides storage system status and notifications such as volume and disk events based on a change of state. The notification area icon will automatically display in the notification area once Intel Rapid Storage Technology is installed. Both administrators and standard users can change the notification area settings using the application or directly from the notification area. Settings changes are applied on a per user basis, and do not affect other users' settings.

Opening the application from the notification area

1. Right-click the icon.
2. Click 'Open Application'.

The notification area icon can be in the following states:

Icon	Description
	The storage system is reported in a normal state and your data is protected from a disk failure.
	The storage system is reported in a warning state and data may be at risk. We recommend that you open the application to review and resolve the reported issues.
	The storage system is reported in an error state and data may be lost. We recommend that you open the application to review and resolve the reported issues as soon as possible.
	The storage system is reported in a busy state while an operation is in progress. Once the operation is complete, all actions will be available again, allowing you to manage the storage system as long as it is reported in a normal state. You can follow the progress of the operation by hovering over the icon.



	This icon is displayed while you are attempting to open the application, but the Intel® Rapid Storage Technology service has not started running yet. The service is expected to start automatically with a delay when you launch Windows. This icon appears if you attempt to launch the application before the delay period ends. If the application fails to open, try starting the service manually using Microsoft Windows* Services.
-----------------------------------------------------------------------------------	--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------

Selecting system notifications

1. Right-click the icon.
2. Select the types of notifications you want to receive. The notification area menu allows you to select or deselect one option at a time. Repeat this procedure until you are finished with your selection. The same operation can also be completed using the application, from the 'Preferences' area.

Note: To hide the notification area icon, deselect 'Show the notification area icon' under 'System Preferences'.

Reviewing notifications

- Hover over the icon at any time to view the storage system status or the progression of an operation.
- Small pop-up windows will display for a short time to notify you of specific events, such as a missing disk or the completion of an operation.
- Open the application to view more details about storage system events in the 'Status' or 'Manage' areas.

24.2 Storage System Status

Anytime Intel® Rapid Storage Technology is launched, the application opens to the 'Status' area. This is where the general state of health of your storage system is reported, both in the storage system view and in details. Depending on the status, volume creation and management options may be available in order to enhance or repair your storage system.

24.2.1 Understanding the Status

To get the full benefits of what Intel® Rapid Storage Technology has to offer, it is critical to maintain a healthy storage system. The application helps you track and reports any disk or volume related problems that could put the safekeeping of your data at risk.

The storage system can be in the following states:

	Normal Reports that the system is functioning as expected, SATA disks are present and connected to the computer. If an array is present, volume data is fully accessible.
	The Create subsection is only available if the storage system meets the minimum requirements to create a volume. Depending on the available hardware, you may be given the option to create a volume to protect data, optimize the disk performance, or create a custom volume.
	The Manage subsection is only available if the storage system reports atypical conditions in a normal state. Typically, details or a recommended action are provided to help you rectify any storage system conditions. For example, if a recovery volume was reported as read-only, we would inform you that disk files must be hidden prior to requesting updates.

The Accelerate subsection is only available if a solid state disk can be used as a cache device and an eligible disk or volume can be accelerated. This area typically provides the option to enable acceleration and reports the cache and accelerated device health state, as well as the current acceleration mode.

Warning
Reports that storage system data may be at risk due to a problem detected on one or more SATA disks.

The Manage subsection displays any SATA disk or volume states reported by the storage system that may require your attention in order to keep data fully protected and accessible. Details or a recommended action are provided to help you fix any storage system problems. For example, if the master disk in a recovery volume is reported as failed, we would recommend that you rebuild the volume to another disk.

Note
In this state, we recommend that you backup any accessible data before taking action

In this state, the Accelerate subsection typically reports that the cache volume is failing possibly because the solid state disk is reported at risk of failing (smart event). Details and a recommended action are provided to help you fix the problem reported on the solid state disk.

Error
Reports that storage system data may be lost due to a problem detected on one or more SATA disks.

The Manage subsection displays any SATA disk or volume states reported by the storage system that require your immediate attention in order to keep data fully protected and accessible. Details or a recommended action are provided to help you fix any storage system problems. For example, if the data on a RAID 1 volume appears inaccessible due to a failed array disk, we would recommend that you rebuild the volume to another disk.

Note
In this state, we recommend that you backup any accessible data before taking action

In this state, the Accelerate subsection typically reports that the cache volume has failed possibly because the solid state disk has also failed and there is data loss. Details and a recommended action are provided to help you fix the problem reported on the solid state disk.

24.2.2 Storage System View

The storage system view provides a visual representation of your storage system and displays arrays, volumes, devices, and ports. Volumes and SATA disks graphics reflect their current states, which allows you to quickly identify the element that is causing the storage system to be in a state other than normal.

Note: Hovering over a designated element in the storage system view provides a snapshot of its properties. Clicking allows you to access and manage its properties.

Overview of SATA disks states

State	Description	Recommendation
	An internal hard disk is reported normal.	None
	An external hard disk is reported normal.	None
	An internal solid state disk is reported as normal.	None
	An external solid state disk is reported as normal.	None



	An internal solid-state hybrid disk reported as normal.	None
	An internal disk is reported missing.	Ensure that the disk is securely connected to the SATA port and that the SATA cable is functioning properly. Refer to the Troubleshooting section for more information.
	An internal disk is reported at risk or Incompatible.	Back up your data and replace the disks as soon as possible. Refer to the Troubleshooting section for more information.
	An external hard disk is reported at risk or incompatible.	Back up your data and refer to the Troubleshooting section for more information.
	An internal solid state disk is reported as being at risk or incompatible.	Back up your data and refer to the Troubleshooting section for more information.
	An external solid state disk is reported at risk or incompatible.	Back up your data and refer to the Troubleshooting section for more information.
	An internal disk is reported offline.	Unlock all array disks to unlock the volume. Refer to the Troubleshooting section for more information.
	An internal recovery disk is reported offline.	<ul style="list-style-type: none"> The recovery volume is in on request update mode. Change the volume update mode to continuous, if desired. Or, Your computer is running on battery and data updates to the recovery disk are not available. Reconnect your computer to the power supply.
	An external disk is reported offline.	Unlock all array disks to unlock the volume. Refer to the Troubleshooting section for more information.
	An external recovery disk is reported offline.	<ul style="list-style-type: none"> The recovery volume is in on request update mode. Change the volume update mode to continuous, if desired. Or, Your computer is running on battery and data updates to the recovery disk are not available. Reconnect your computer to the power supply.
	An internal disk is reported normal and locked.	Unlock the disk to access more options.
	An external disk is reported normal and locked.	Unlock the disk to access more options.
	An internal hard disk is reported failed.	Refer to the Troubleshooting section for more information.
	An external hard disk is reported failed.	Refer to the Troubleshooting section for more information.
	An internal solid state disk is reported as failed.	Refer to the Troubleshooting section for more information.

	An external solid state disk is reported as failed.	Refer to the Troubleshooting section for more information.
--	-----------------------------------------------------	------------------------------------------------------------

Volume states

Volume type	Normal	Degraded	Failed
		Refer to Troubleshooting Degraded Volumes and Caching Issues for more information.	Refer to Troubleshooting Failed Volumes and Caching Issues for more information.
RAID 0		Not applicable	
Single-disk (cache)			
Single-disk (data)		Not applicable	
RAID 1/Recovery			
RAID 5			
RAID 10			

Other storage system elements

Element	Description	Recommendation
	A port that has no devices connected to it.	None
	An ATAPI device is present, such as CD-ROM, DVD/Blu-ray disc, or tape drive.	

24.3 Creating a Volume

You can combine SATA disks to create a volume in order to enhance your storage system. Based on the available hardware and your computer's configuration, you may be able to create a volume by selecting an enhancement goal, such as 'Protect data' under 'Status', or by selecting a volume type under 'Create'. We recommend you get familiar with the minimum requirements in this section before starting the volume creation process.

Warning

Performing this action will permanently delete any existing data on the disks used to create a volume, unless you choose to keep the data when selecting array disks. Backup all valuable data before starting this process.

24.3.1 Volume Requirements

Creating a volume is only available as an option if the following requirements are met:

- You are logged on as an administrator.
- The computer is RAID ready (refer to the user's manual available on Intel's online support web site, for assistance on setting up a RAID ready system).
- Two or more SATA disks, including the operating system disk are connected, in a normal state, and unlocked (only applies to password-protected disks).
- Each of the SATA disks that are to be part of the RAID volume may not have any SMART events.

Enabling more disks

When configuring a volume, the application will only list the SATA disks that meet the requirements listed below. For example, a locked disk connected to your computer will not be listed as an option until it is unlocked.

Based on the first disk selected, some disks may become grayed out if one or more requirements are not met. Selecting a different disk generally helps re-enable disks that were previously grayed out.



- If the first selection is a system disk, any additional SATA disks selected must be of equal or greater size to ensure that all the system files are migrated to the new volume.
- If the first selection is a non-system disk, and a system disk is then selected, the latter must be of equal or smaller size to ensure that all the system files are migrated to the new volume.
- A system volume cannot be greater than 2 TB. If your first selection is a system disk, the total size of the other disks shall not allow the volume size to exceed 2 TB. Exception: If you are creating a volume using disks that have no existing data, and your operating system is a 64-bit Edition, the application will allow a volume to be greater than 2TB.
- The SATA disks used to create a volume must have the same type of connection, internal or external. An internal disk shall not be paired with an external disk to create a volume. Some systems will support mixed connection types.

Enabling more volume types

Depending on the input/output (I/O) controller hub that your computer is using and the hardware connected to the system, some volume types may not be enabled in the selection list. Refer to the Readme file located in the Program Files directory for this application or to the Device Manager to determine which controller is installed on your computer. Review the controller support table below to determine which volume types you can create.

Note: Intel® 5 Series Chipset applies to both desktop and mobile platforms as well as all later chipsets.

Volume Type	Number of Disks	Controller Support
Recovery volume	2	ICH9R, ICH9DH, ICH9DO, ICH9M, ICH9M-E, ICH10R, ICH10D, ICH10DO, 5 Series/3400 Series. Note No other volumes can be present on the system. The master disk must include 100% of the available disk space and must be less than 1.3125 TB
RAID 0	2	ICH7R, ICH7DH, ICH7MDH, ICH7M, ICH9R, ICH9DH, ICH9DO, ICH9M, ICH9M-E, ICH10R, ICH10D, ICH10DO, 5 Series/3400 Series.
RAID 0	3 or 4	ICH7R, ICH7DH, ICH9R, ICH9DH, ICH9DO, ICH10R, ICH10D, ICH10DO, 5 Series/3400 Series
RAID 0	5 or 6	ICH9R, ICH9DH, ICH9DO, ICH10R, ICH10D, ICH10DO, 5 Series/3400 Series.
RAID 1	2	ICH7R, ICH7DH, ICH7MDH, ICH7M, ICH9R, ICH9DH, ICH9DO, ICH9M, ICH9M-E, ICH10R, ICH10D, ICH10DO, 5 Series/3400 Series.
RAID 5	3 or 4	ICH7R, ICH7DH, ICH9R, ICH9DH, ICH9DO, ICH10R, ICH10D, ICH10DO, 5 Series/3400 Series.
RAID 5	5 or 6	ICH9R, ICH9DH, ICH9DO, ICH10R, ICH10D, ICH10DO, 5 Series/3400 Series.
RAID 10	4	ICH7R, ICH7DH, ICH9R, ICH9DH, ICH9DO, ICH10R, ICH10D, ICH10DO, 5 Series/3400 Series.

24.3.2 Creation Process

Now that you have reviewed the volume requirements, this section will guide you through the three easy steps necessary to create a volume.

24.3.2.1 Selecting a Volume Type

Before you can create a volume, you need to decide how you want to enhance your storage system based on your needs. Depending on the available hardware, you may have the option to combine volume types by creating more than one volume on a single array. Refer to 'Creating Additional Volumes' for more information on this type of configuration. Below is an overview of the five volume types that you can create.

Creating a two-disk volume from 'Status'

This option displays if only two disks are available, one has data such as system files, the second one doesn't, and the latter has a size that is equal or greater than the other. Based on this simple configuration, you can create a volume to protect data or optimize disk performance by clicking one of the two options listed in the Create subsection. When choosing this option, the application automatically configures the volume using the only two disks available and assigns default settings. Refer to the applicable procedure described in Completing the Process for details.

Creating a Custom Volume

1. Click 'Create' or 'Create a custom volume' under 'Status'.
2. Select the volume type. Selecting a volume type in the list updates the graphical representation to provide a detailed description of that type.
3. Click 'Next'.

Recovery volume: Flexible data protection Combines two SATA disks and utilizes RAID 1 functionality to copy data from a designated master disk to a designated recovery disk. Data updates on the volume can be continuous or on request. In 'on request' mode, you can request data updates that copy changes from the master disk to the recovery disk since the last update. No other volumes can be present on the system. The master disk must include 100% of the available disk space and must be less than 1.3125 TB.		
Disks required	2	
Advantage	Full data redundancy; more control over how data is copied between master and recovery disks; fast volume updates in on request mode; master and recovery disk files can be viewed in Windows Explorer*.	
Disadvantage	Storage capacity is only as large as the smallest disk.	
Application	Critical data protection for mobile systems; fast restoration of the master disk to a previous or default state. Available in specific mobile configurations.	

RAID 1: Real-time data protection Combines two SATA disks where each stores an exact copy of the data to appear as a mirror of each other.		
Disks required	2	
Advantage	Full data redundancy and excellent fault-tolerance; increased read transfer rate.	
Disadvantage	Storage capacity is only as large as the smallest disk; slight decrease in write transfer rate.	
Application	Typically used in workstations and servers to store critical data. Available in specific mobile configurations.	



RAID 0: Optimized disk performance Combines two to six SATA disks and breaks down data into units that are spread across the array disks.		
Disks required	2 to 6	
Advantage	Increased data access and storage performance; no loss in data capacity	
Disadvantage	No data redundancy (if one disk fails, all data on the volume is lost).	
Application	Typically used in desktops and workstations to store high performance, temporary data and software. Various RAID 0 volume configurations available in specific mobile configurations.	

RAID 5: Efficient data hosting and protection Combines three to six SATA disks where data and parity are striped across the array disks in a rotating sequence. Parity is a mathematical method for recreating lost data to a single disk.		
Disks required	3 to 6	
Advantage	Data redundancy; improved storage performance and capacity; high fault-tolerance and read performance.	
Disadvantage	Time-consuming to rebuild and decreased performance during the process.	
Application	Good choice for large amounts of critical data, such as file and application servers; Internet and Intranet servers. Available in mobile configurations that include the Intel® 5 Series Chipset which supports up to six SATA ports.	

RAID 10 : Balanced performance and data protection Combines four SATA disks to create a combination of RAID types 1+0. The data is striped across a two-disk array forming a RAID 0 component. Each disk in the RAID 0 array is mirrored by a disk in the RAID 1 array, storing an exact copy of all the data.		
Disks required	4	
Advantage	Combines the read performance of RAID 0 with the fault-tolerance of RAID 1, resulting in increased data access and full data redundancy, and increased storage capacity.	
Disadvantage	4 disks are required, resulting in increased cost.	

Application	High performance applications and high load database servers requiring data protection, such as video editing. Available in mobile configurations that include the Intel® 5 Series Chipset which supports up to six SATA ports.
-------------	---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------

24.3.2.2 Configuring the Volume

Once the volume type is selected, you are ready to configure your volume.

Recovery volume

1. Type a new volume name if you want to change the default name.
2. Select the master disk.
3. Select the recovery disk.
4. Select a different update mode, if desired.
5. Click 'Next'. This button will not be active until all the required selections have been made.
6. Confirm Volume Creation by select "Proceed with deleting data" then click on Create Volume.



Important Note:

The data on recovery disk will be permanently deleted. Make sure to back up the data before continuing.

Advanced configuration settings:

- Enable or disable the volume write-back cache.
- Select the check box to initialize the volume. You can choose to perform this action at a later time.

RAID Volume

1. Type a new volume name if you want to change the default name.
2. Select the required number of disks.
3. Select the disk from which you want to keep data, if desired. You can only keep data from one disk. If you want to keep data from more than one disk, you must back up all valuable data prior to creating a volume.



4. Click 'Next'. This button will not be active until all the required selections have been made.
Advanced configuration settings:
 - Select the array allocation by using the slider.
 - Select a data strip size.
 - Enable or disable the volume write-back cache.
 - Select the check box to initialize the volume. You can choose to perform this action at a later time.

Note: Currently, the application does not allow the creation of greater than 2TB volumes where the source disk is greater than 2TB and data on that disk is preserved (e.g. system volume). Target disks can be greater than 2TB but such volumes cannot. This limitation results from the lack of GPT partition scheme support. Note that volumes greater than 2TB that include member disks greater than 2TB are supported as long as array disks are unpartitioned or that no data is preserved at volume creation.

24.3.2.3 Completing the Process

If you are creating a custom volume, and have configured the volume with the disk selection and other settings, you are ready to review the projected configuration and complete the volume creation process.

If you are creating a two-disk volume for data protection or disk optimization from 'Status', you can follow the procedure provided below.

Creating a two-disk volume from 'Status'

1. Under 'Status', in the Create sub-section, select the type of volume you want to create.
2. In the 'Confirm Volume Creation' dialog, review the volume configuration. Note that the volume name is the only setting that can be changed.
3. Click 'Create Volume' to confirm. The process starts immediately.
4. Once completed, a dialog displays to notify you that the volume was successfully created. Click 'OK' to close the dialog.
5. The page refreshes and displays the new volume in the storage system view as well as the data migration progress.

Creating a custom volume

Warning

You can only keep existing data from one of the disks you select to create a volume. We recommend that you backup all valuable data before proceeding.

If you perform a driver upgrade or downgrade while the data migration is in progress and then restart your computer, the driver will not be able to recognize the volume or the data on it. If you are migrating a system volume, you will not be able to restart your system because the operating system cannot load. If you are migrating a data volume, you will have to reverse (roll back) that last performed driver update, and then restart the computer to return to a normal state.

1. Under 'Confirm', review the selected configuration.
2. Click 'Create Volume' if you want to create the volume using the selected configuration. Otherwise, click 'Back' and make any necessary changes. The process starts immediately.
3. Click 'OK' to confirm.
4. Once completed, a dialog displays to notify you that the volume was successfully created. Click 'OK' to close the dialog.
5. The 'Status' area displays the new volume in the storage system view as well as the data migration progress.

If the size of the new volume is larger than the size of the source drive, the following steps apply:

6. Once the migration status reports 100% complete, restart your computer for the operating system to recognize the new volume size.
7. Create a new partition or extend the existing partition to utilize the new volume space using Windows Disk Management*. If your system is running Microsoft XP*, you may only have the option to create a new partition.



Note: To open Windows Disk Manager, click Start, right click My Computer, select Manage, then in the console tree select Disk Management.

24.3.3 Creating Additional Volumes

Creating multiple volumes on a single array

You can add a volume to an existing RAID array by creating another volume that uses the available space on the array. This feature allows you to combine different volume types and their respective benefits. For example, a configuration with RAID 0 and RAID 1 on two SATA disks provides better data protection than a single RAID 0 and higher performance than a single RAID 1.

The first RAID volume occupies part of the array, leaving space for the other volume to be created. After creating the first volume with an array allocation set to less than 100% in the Configure Volume step, you will be able to add a second volume to that array.

Note: The configuration is only available if the array allocation for the first volume created is less than 100%, and space is available on that array. The application currently supports an array to include a maximum of two RAID volumes.

1. Click 'Create' or 'Create a custom volume' under 'Status'.
2. Select the volume type. Selecting a volume type in the list updates the graphical representation to provide a detailed description of that type.
3. Click 'Next'.
4. Select 'Yes' to add the volume to an existing array.
5. Make any necessary changes in the Advanced section.
6. Click 'Next'.
7. Review the selected configuration. Click 'Back' or an option in the left pane if you want to make changes.
8. Click 'Finish' to start the creation process.

Supported RAID volume combinations on a single array:

Combine	With
2-disk RAID 0	2-disk RAID 0
	2-disk RAID 1
2-disk RAID 1	2-disk RAID 0
	2-disk RAID 1
3-disk RAID 0	3-disk RAID 0
	3-disk RAID 5
3-disk RAID 5	3-disk RAID 0
	3-disk RAID 5
4-disk RAID 0	4-disk RAID 0
	4-disk RAID 5
	4-disk RAID 10
4-disk RAID 5	4-disk RAID 0
	4-disk RAID 5
	4-disk RAID 10
4-disk RAID 10	4-disk RAID 0
	4-disk RAID 5



Combine

5-disk RAID 0

6-disk RAID 0

With

4-disk RAID 10

5-disk RAID 0

5-disk RAID 5

6-disk RAID 0

6-disk RAID 5

Visit our Online Support for additional information on RAID type combinations for each I/O controller hub.

Creating additional volumes on a new array

You can choose to create two or more volumes on two different arrays, as long as the volume requirements are met.

1. Click 'Create' or 'Create a custom volume' under 'Status'.
2. Select the volume type. Selecting a volume type in the list updates the graphical representation to provide a detailed description of that type.
3. Click 'Next'.
4. Select 'No' in order to add a volume to a new array.
5. Select the required number of disks.
6. Select the disk from which you want to keep data, if desired. You can only keep data from one disk. If you want to keep data from more than one disk, you must back up all valuable data prior to creating a volume.
7. Make any necessary changes in the Advanced section.
8. Review the selected configuration. Click 'Back' or an option in the left pane if you want to make changes.
9. Click 'Next'.
10. Click 'Finish' to start the creation process.

Note: Systems with an RST OROM older than 9.5, will not recognize 2 volumes on a single array if the RST Windows Driver version is 9.5 and newer.

24.4 Managing the Storage System

The 'Manage' area combines the logical and physical view of your storage system. The area displays detailed information about each element that is part of the storage system, such as volumes and disks; the storage system view shows how the selected element relates to others. Each element has its own 'Manage' area which is accessible by clicking any element displayed in the storage system view under 'Status' or 'Manage'.

The 'Manage' area also provides the actions available for the selected element, such as renaming a volume or changing the volume type.

24.4.1 Managing Arrays

You must be logged on as an administrator to perform the actions listed in this section.

You can manage arrays by clicking a selected array in the storage system view under 'Status' or 'Manage'. This allows you to review the properties and access all actions associated with that array, such as adding a disk or increasing a volume size.

24.4.1.1 Array Properties

An array is a logical grouping of physical SATA disks. The array properties listed below display to the left of the storage system view under Manage Array and report values specific to the element selected in the view.



Parameter	Value
Name	Reports the name of the array. The array name is automatically assigned and cannot be changed.
Size	Reports the total capacity of the array in megabytes (MB).
Available space	Reports the unallocated space on the array that can be used.
Disk data cache	Reports whether the data cache is enabled for all array disks.

24.4.1.2 Adding a Disk to an Array

You can add one or more SATA disks to an existing array to increase the system storage capacity. This feature can be useful if you want to change to a volume type that requires additional disks. This option is only available if:

- A RAID 0 and/or a RAID 5 volume is present,
- One or more SATA disks are connected to the computer and available,
- The available disk matches the internal or external connection type of the existing array disks.

You cannot add an external disk to an array that includes internal disks, and vice versa.

Refer to Connecting a Disk under Managing Disks for more information on installing SATA disks on your computer.

Warning

Any existing data on the available disk used to increase the array size will be permanently deleted. Backup all the data you want to preserve prior to executing this action.

If you perform a driver upgrade or downgrade while the data migration is in progress and then restart your computer, the driver will not be able to recognize the volume or the data on it. If you are migrating a system volume, you will not be able to restart your system because the operating system cannot load. If you are migrating a data volume, you will have to reverse (roll back) that last performed driver update, and then restart the computer to return to a normal state.

This action can also be performed from Manage Volume. Refer to the Adding a Disk to a Volume section for more information.

1. Under 'Status' or 'Manage', in the storage system view, click the array to which you want to add a disk. The element properties are now displayed on the left.
2. Click 'Add disk'.
3. Select the disk you want to use to increase the array capacity.
4. Click 'Add Disk'. Caution: Once the data migration starts, the operation cannot be canceled.
5. Once the migration has completed, restart your computer for changes to take effect. Then use Windows Disk Management* to increase the partition size on the volumes for which a disk was added, or add another partition.

Note: To open Windows Disk Manager, click Start, right click My Computer, select Manage, then in the console tree select Disk Management

24.4.1.3 Adding a Volume

You can add a volume to an existing RAID array by combining different volume types and their respective benefits. For example, a configuration with RAID 0 and RAID 1 on two SATA disks provides better data protection than a single RAID 0 and higher performance than a single RAID 1. The first RAID volume occupies part of the array, leaving space for the other volume to be created. After creating the first volume with an array allocation set to less than 100% in the Configure Volume step, you will be able to add a second volume to that array.



Note: This configuration is only available if the array allocation for the first volume is less than 100%, and space is available on that array. The application currently supports an array to include a maximum of two RAID volumes on a single array.

You can also complete this action using the 'Create' area.

1. Under 'Status' or 'Manage', in the storage system view, click the array to which you want to add a volume. The array properties are now displayed on the left.
2. Click 'Create additional volume'.
3. In the 'Create Additional Volume' dialog, type a new name if you want to change the default name.
4. Select the volume type, and then click 'OK'. Only the volume types available for the current configuration will display. Refer to the table below for more information.
5. The page refreshes and the array now displays the additional volume.

Supported RAID volume combinations on a single array:

Combine	With
2-disk RAID 0	2-disk RAID 0
	2-disk RAID 1
2-disk RAID 1	2-disk RAID 0
	2-disk RAID 1
3-disk RAID 0	3-disk RAID 0
	3-disk RAID 5
3-disk RAID 5	3-disk RAID 0
	3-disk RAID 5
4-disk RAID 0	4-disk RAID 0
	4-disk RAID 5
	4-disk RAID 10
4-disk RAID 5	4-disk RAID 0
	4-disk RAID 5
	4-disk RAID 10
4-disk RAID 10	4-disk RAID 0
	4-disk RAID 5
	4-disk RAID 10
5-disk RAID 0	5-disk RAID 0
	5-disk RAID 5
6-disk RAID 0	6-disk RAID 0
	6-disk RAID 5

Visit our Online Support for additional information on RAID type combinations for each I/O controller hub.



24.4.1.4 Increasing Volume Size

You can increase the size of a RAID volume by using the remaining available space on the array. A minimum of 32 MB must be available for this action to be available. Hovering over the array name in the storage system view displays the amount of available space in MB.

After creating a volume with an array allocation set to less than 100% in the Configure Volume step, you will be able to increase the volume size by the amount of available space on that array. If two volumes are present on a single array and capacity expansion is possible, only the space available at the end of the second volume will be used to increase the volume size.

This option is only available if:

A RAID 0, RAID 1, RAID 5 and/or RAID 10 volume is present,

- The array allocation for the volume is less than 100% and space is available on the existing array.

Warning

If you perform a driver upgrade or downgrade while the data migration is in progress and then restart your computer, the driver will not be able to recognize the volume or the data on it. If you are migrating a system volume, you will not be able to restart your system because the operating system cannot load. If you are migrating a data volume, you will have to reverse (roll back) that last performed driver update, and then restart the computer to return to a normal state.

Increasing the volume size from Manage Array

1. Under 'Status' or 'Manage', in the storage system view, click the array you want to manage. The array properties are now displayed on the left.
2. Click 'Increase size' next to the volume name. If more than one volume is present on a single array, you will need to increase the size of each volume one at a time.
3. Click 'Yes' to confirm. Caution: Once the data migration starts, the operation cannot be canceled.
4. Once the migration has completed, restart your computer for changes to take effect. Then use Windows Disk Management* to increase the partition size on the volumes, or add another partition.

Increasing the volume size from Manage Volume

1. Under 'Status' or 'Manage', in the storage system view, click the volume whose size you want to increase. The volume properties are now displayed on the left.
2. Click 'Increase size'.
3. Click 'Yes' to confirm. Caution: Once the data migration starts, the operation cannot be canceled.
4. Once the migration has completed, restart your computer for changes to take effect. Then use Windows Disk Management* to increase the partition size on the volumes, or add another partition.

Note: To open Windows Disk Manager, click Start, right click My Computer, select Manage, then in the console tree select Disk Management

24.4.1.5 Enabling Disk Data Cache

Enabling the disk data cache for all SATA disks on the array allows you to enable cache memory physically present on the disks and use it to speed up data access. This action is only available from Manage Array because the data cache must be in the same state across all disks that are part of a single array.

Under Manage Array, the disk data cache is reported as enabled or disabled for all SATA disks in the array. Under Manage Disk, the disk data cache is reported as enabled or disabled for a specific disk that is part of that array. The option to change this setting is only available from Manage Array.

Warning

Enabling the disk data cache increases the cache size and the amount of cached data that could be lost in the event of a power failure. The risk can be decreased if your computer is connected to an uninterruptable power supply (UPS).

1. Under 'Status' or 'Manage', in the storage system view, click the array you want to manage. The element properties are now displayed on the left.
2. In the Advanced section, click 'Enable' or 'Disable' depending on the option available.
3. Click 'Yes' to confirm.



4. The page refreshes and now displays the new setting.

24.4.2 Managing Volumes

You must be logged on as an administrator to perform the actions listed in this section. You can manage existing volumes by clicking a volume in the storage system view under 'Status' or 'Manage'. This allows you to review the volume properties and access all actions associated with that volume, such as renaming, changing type, and deleting.

24.4.2.1 Volume Properties

A volume is an area of storage on one or more SATA disks used within a RAID array. A volume is formatted by using a file system and has a drive letter assigned to it. The volume properties listed below display to the left of the storage system view under 'Manage' and report values specific to the element selected in the view.

RAID volume status table

Status	Description
Normal	Indicates that volume data is fully accessible.
Locked	Indicates that at least one array disk is locked with a password. The volume is visible because at least one other array disk is unlocked. Refer to Unlocking Password-Protected Disks for instructions on unlocking disks.
Degraded	Indicates that one array disk is missing or has failed. A RAID 0 volume cannot be in this state because of the striping configuration.
Failed	<ul style="list-style-type: none">• RAID 0 volume: indicates that one or more array disks are missing or have failed.• RAID 1 volume: indicates that both array disks are missing or have failed.• RAID 5 or 10 volume: indicates that two or more array disks are missing or have failed.
Incompatible	Indicates that the volume was moved to another system that does not support the volume type and configuration.
Inaccessible	Indicates that data on the accelerated volume cannot be accessed because it is missing, or that the accelerated volume data is not synchronized with the data on the cache volume.
Unknown	Indicates that an unknown error was detected.

Recovery volume status table



Status	Description
Normal	Indicates that volume data is fully accessible.
Locked	Indicates that at least one array disk is locked with a password. The volume is visible because at least one other array disk is unlocked. Refer to Unlocking Password-Protected Disks for instructions on unlocking disks.
Degraded	<ul style="list-style-type: none">• The recovery disk has failed, or• The master disk is missing or has failed and the volume is running off the recovery disk.
Failed	Indicates that both array disks have failed.
Incompatible	Indicates that the volume was moved to another system that does not support the volume type and configuration.
Unknown	Indicates that an unknown error was detected.
Power-saving mode	Indicates that the computer is running on battery power. If the volume is in continuous update mode, data updates are paused and will resume as soon as the computer is reconnected to the power supply.
Data update needed	Indicates that the recovery disk does not have a redundant copy of the data on the master disk, and you should request an update.
Running off recovery disk	Indicates that the recovery disk is the designated source drive in the volume.
Master disk read-only	Indicates that the recovery disk is the designated source drive in the volume, and that the master disk files are accessed. In this state, data recoveries from the recovery disk are not available.
Recovery disk read-only	Indicates that the recovery disk files are accessed. In this state, data updates are not available.

Busy volume states table

Status	Description
Initializing	Indicates that data on a volume is being synchronized. This step is required prior to verifying or verifying and repairing data on a volume.



Verifying	Indicates that the volume is being scanned to detect data inconsistencies.
Verifying and repairing	Indicates that the volume is being scanned to detect data inconsistencies, and errors are being repaired. This state does not apply to a RAID 0 volume because errors cannot be repaired.
Migrating data	Indicates that data is being reorganized on the volume. This state displays when a system volume is created, the volume size is increased, or the type is changed to different RAID configuration.
Rebuilding	Indicates that data redundancy is being restored across all disks associated with the volume. A RAID 0 volume cannot be in this state because of the striping configuration.
Recovering data	Indicates that data on the master disk is being overridden by all the data on the recovery disk. This state only applies to recovery volumes.
Updating data	Indicates that the latest master disk changes are being copied to the recovery disk. This state only applies to recovery volumes.

General parameters table

Parameter	Value
Details	Provides detailed information if a volume is in a state other than normal.
Type	Reports the volume type.
Acceleration mode Size	Reports the acceleration mode for the disk or volume associated with the cache device. Enhanced: Indicates that the disk or volume is accelerated for optimized data protection. Maximized: Indicates that the disk or volume is accelerated for optimized input/output performance. None: Indicates that no disk or volume is accelerated. Busy: Indicates that acceleration is transitioning from maximized to enhanced mode, or that acceleration is being disabled from maximized mode. In the event that errors are detected and a risk of data loss is identified, transitions from maximized mode will start automatically.



	Reports the total capacity of the volume in gigabytes (GB) in the storage system view and in megabytes (MB) in the volume properties under Manage Volume.
Data stripe size	Reports the size of each logical contiguous data block used in the volume for RAID 0, 5, and 10 volumes. The strip size is indicated in kilobytes (KB).
Write-back cache	Reports whether the write-back cache feature is enabled for the volume.
System volume	Reports whether the volume contains system files that are required to start and run the operating system.
Initialized	Reports whether the volume is initialized.
Verification errors found	Reports the number of inconsistencies found during the last volume data verification.
Block with media errors	Reports the number of blocks with media errors found during the last volume data verification.
Physical sector size	Reports the size of each sector that is physically located on the disk.
Logical sector size	Reports the size of data collection blocks.
Details	Provides detailed information if a volume is in a state other than normal.

24.4.2.2 Renaming a Volume

You can change the name assigned to a volume present in your storage system at any time. The name change will take effect immediately.

1. Under 'Status' or 'Manage', in the storage system view, click the volume that you want to rename. The volume properties are now displayed on the left.
2. Click 'Rename'.
3. Type a new volume name, and then click 'OK'.

Note: Volume names are limited to 16 English alphanumeric and special characters including spaces, but cannot include a backslash “\”.

24.4.2.3 Rebuilding a Volume

When a volume is reported as degraded because of a failed or missing disk, the disk must be replaced or reconnected and the volume be rebuilt in order to maintain fault-tolerance. The option to rebuild is only available when a compatible disk is connected, available and normal. If a spare disk is available, the rebuild process will start automatically when a disk fails or is missing. For RAID 0 volumes, the rebuild process will start automatically only when one of its members is reported as at risk.



Warning

Completing this action will permanently delete existing data on the new disk and make any other volume on the array inaccessible. We recommend you backup valuable before continuing.

Rebuilding from 'Status' (manually)

1. Verify that the volume is reported as degraded in the Manage subsection. If you have more than one volume listed in this section, you will need to fix the issues reported one at a time.
2. Click 'Rebuild to another disk' next to the volume you want to rebuild.
3. In the Rebuild Volume dialog, select the disk that will replace the failed disk. Only compatible disks in a normal state will be displayed. Refer to Volume Requirements for more information.
4. Click 'OK' to confirm.
5. The volume starts rebuilding and the page refreshes displaying the progress of the operation. You can use other applications during this time and you will be notified when the process has successfully completed.

Rebuilding from 'Manage' (manually)

1. Under 'Status' or 'Manage', in the storage system view, click the volume you want to rebuild. The element properties are now displayed on the left.
2. Click 'Rebuild to another disk', and then follow the procedure described above.

24.4.2.4 Recovering Data

Recovering data to the master disk allows you to maintain full data redundancy on the recovery volume and keep the volume data healthy. This action is only available if a recovery volume is present and running off the recovery disk.

You may have to recover data if:

- Data on the recovery and master disk is not synchronized and full data redundancy is at risk.
- Data on the master disk is invalid or inaccessible.

Warning

Completing the action will override existing data on the master disk and update it with the data on the recovery disk. Backup all valuable data before continuing.

1. Under 'Status', in the Manage subsection, click 'Recover data' or click the recovery volume in the storage system view, and then click 'Recover data'.
2. Click 'Yes' to confirm.
3. The recovery operation starts immediately. You can follow the progress by hovering over the notification area icon or by reviewing the volume status under 'Status' or 'Manage'.

Note

If master disk is removed while the data recovery is in progress and is then reconnected, the operation will resume automatically from where it stopped as long as the volume is in on request update mode. If the volume is in continuous update mode, you will need to restart the operation by following the procedure described above,

24.4.2.5 Resetting Volume to Normal

This action is only available when a volume is reported as failed, but both array disks are present and normal, and allows you to access and try recovering healthy volume data.

In most cases, this situation will occur after one or more array disks was reported as failed or at risk, and then reset to normal.

Completing this action resets the volume state by ignoring previous events and does not repair data. Any data loss or corruption that may have occurred as a result of prior hardware failure or change of state remains. We recommend that you back up accessible data and replace failed hardware as soon as possible to prevent further data loss.



1. Under 'Status', in the Manage subsection, click 'Reset volume to normal'. You can also perform this action from Manage Volume, which is accessible by clicking the RAID 0 volume in the storage system view.
2. Click 'Yes' to confirm.
3. The page refreshes and the volume displays as normal. If the operation failed to return the volume to a healthy state, visit Intel's online support web site for more options.

24.4.2.6 Changing Volume Type

You can choose to change the type of an existing volume based on your storage system needs. The following configurations are possible:

Change type from
2-disk recovery volume

To
2-disk RAID 1

 **Note**

Only available if the recovery volume is in continuous update mode

2-disk RAID 1

2-disk recovery volume

 **Note**

No other volumes can be present on the system. The RAID 1 volume must be less than 1.3125 TB and include 100% of the available space on the array

2-disk RAID 1

2-disk RAID 0

3, 4, 5 or 6-disk RAID 0

3, 4, 5 or 6-disk RAID 5

2-disk RAID 0

3, 4, 5 or 6-disk RAID 5

3-disk RAID 0

4, 5 or 6-disk RAID 5

4-disk RAID 0

5 or 6-disk RAID 5

4-disk RAID 10

4, 5 or 6-disk RAID 5

 **Note**

Before starting, refer to the system and volume requirements to determine which RAID types are supported by your computer and make sure the required number of SATA disks are connected. The Intel® Chipset provides support for the creation of all RAID volume types and for up to six SATA ports on a mobile platform. Changing volume type does not require re-installation of the operating system

1. Under 'Status' or 'Manage', in the storage system view, click the volume that you want to modify. The volume properties are now displayed on the left.
2. Click 'Change type'.
3. In the 'Change Volume Type' dialog, type a new name if you want to change the default name.
4. Select the new volume type, and then click 'OK'. Caution: Once the data migration starts, the operation cannot be canceled.
5. Once the migration has completed, the 'Manage' page refreshes and reports the new volume type.

 **Warning**



All applications and existing volume data remain intact, but any existing data on the disks added to enable this operation will be permanently deleted. Backup data before adding these disks.

If you perform a driver upgrade or downgrade while the data migration is in progress and then restart your computer, the driver will not be able to recognize the volume or the data on it. If you are migrating a system volume, you will not be able to restart your system because the operating system cannot load. If you are migrating a data volume, you will have to reverse (roll back) that last performed driver update, and then restart the computer to return to a normal state.

24.4.2.7 Increasing Volume Size

You can increase the size of a RAID volume by using the remaining available space on the array. A minimum of 32 MB must be available for this action to be available. Hovering over the array name in the storage system view displays the amount of available space in MB.

After creating a volume with an array allocation set to less than 100% in the Configure Volume step, you will be able to increase the volume size by the amount of available space on that array. If two volumes are present on a single array and capacity expansion is possible, only the space available at the end of the second volume will be used to increase the volume size.

This option is only available if:

- A RAID 0, RAID 1, RAID 5 and/or RAID 10 volume is present,
- The array allocation for the volume is less than 100% and space is available on the existing array.

Warning

If you perform a driver upgrade or downgrade while the data migration is in progress and then restart your computer, the driver will not be able to recognize the volume or the data on it. If you are migrating a system volume, you will not be able to restart your system because the operating system cannot load. If you are migrating a data volume, you will have to reverse (roll back) that last performed driver update, and then restart the computer to return to a normal state.

Increasing the volume size from Manage Array

1. Under 'Status' or 'Manage', in the storage system view, click the array you want to manage. The array properties are now displayed on the left.
2. Click 'Increase size' next to the volume name. If more than one volume is present on a single array, you will need to increase the size of each volume one at a time.
3. Click 'Yes' to confirm. Caution: Once the data migration starts, the operation cannot be canceled.
4. Once the migration has completed, restart your computer for changes to take effect. Then use Windows Disk Management* to increase the partition size on the volumes, or add another partition.

Increasing the volume size from Manage Volume

1. Under 'Status' or 'Manage', in the storage system view, click the volume whose size you want to increase. The volume properties are now displayed on the left.
2. Click 'Increase size'.
3. Click 'Yes' to confirm. Caution: Once the data migration starts, the operation cannot be canceled.
4. Once the migration has completed, restart your computer for changes to take effect. Then use Windows Disk Management* to increase the partition size on the volumes, or add another partition.



Note

To open Windows Disk Manager, click Start, right click My Computer, select Manage, then in the console tree select Disk Management



24.4.2.8 Adding a Disk to a Volume

You can add one or more SATA disks to an existing array to increase the system storage capacity. This feature can be useful if you want to change to a volume type that requires additional disks.

This option is only available if:

- A RAID 0 and/or a RAID 5 volume is present,
- One or more SATA disks are connected to the computer and available,
- The available disk matches the internal or external connection type of the existing array disks. You cannot add an external disk to an array that includes internal disks, and vice versa. In specific advanced system configurations, this condition may not apply.

Refer to Connecting a Disk under Managing Disks for more information on installing SATA disks on your computer.

Warning

Any existing data on the available disk used to increase the array size will be permanently deleted. Backup all the data you want to preserve before completing this action.

If you perform a driver upgrade or downgrade while the data migration is in progress and then restart your computer, the driver will not be able to recognize the volume or the data on it. If you are migrating a system volume, you will not be able to restart your system because the operating system cannot load. If you are migrating a data volume, you will have to reverse (roll back) that last performed driver update, and then restart the computer to return to a normal state

This action can also be performed from Manage Array. Refer to the Adding a Disk to an Array section for more information.

1. Under 'Status' or 'Manage', in the storage system view, click the volume to which you want to add a disk. The element properties are now displayed on the left.
2. Click 'Add disk'.
3. Select the disk you want to use to increase the array capacity.
4. Click 'Add Disk'. Caution: Once the data migration starts, the operation cannot be canceled.
5. Once the migration has completed, restart your computer for changes to take effect. Then use Windows Disk Management* to increase the partition size on the volumes for which a disk was added, or add another partition.



Note

To open Windows Disk Manager, click Start, right click My Computer, select Manage, then in the console tree select Disk Management

24.4.2.9 Changing Update Mode

A recovery volume gives you the flexibility to choose between updating data on the recovery disk continuously or on request.

In continuous update mode, the latest master disk changes are copied to the recovery disk automatically, as long as both disks are connected to the computer. In on request mode, the latest master disk changes are copied to the recovery disk only when you request a data update.

The current update mode is reported in the volume properties under Manage Volume. By default, the recovery volume is created in continuous update mode.

**Note**

This action is only available if a recovery volume is present and in normal state. If the recovery volume is read-only because the master or recovery disk files are accessed, you will need to hide the files before the update mode can be changed.

1. Under 'Status' or 'Manage', in the storage system view, click the recovery volume. The volume properties are now displayed on the left.
2. Click 'Change mode', and then click 'Yes' to confirm.
3. The page refreshes and the volume properties report the new update mode.

24.4.2.10 Updating Data

You can manually copy the latest master disk changes to the recovery disk at any given time; this action allows you to synchronize data on the recovery volume, improving data protection and lowering the risk of losing valuable data in the event of a disk failure. When you request an update, only changes since the last update are copied.

**Note**

This action is only available if a recovery volume is present, and in 'on request' update mode.

1. Under 'Status' or 'Manage', in the storage system view, click the recovery volume. The volume properties are now displayed on the left.
2. Click 'Update data'.
3. The update process can be instantaneous or may take a while depending on the amount of data being copied. You can follow the progress by hovering over the notification area icon or by reviewing the volume status under 'Status' or 'Manage'.

**Note**

You can follow the progress of the update by hovering over the notification area icon or under 'Status' or Manage Volume.

24.4.2.11 Accessing Master or Recovery Disk Files

This action is only available if a recovery volume is present, in a normal state, and in on request update mode.

You can view the recovery or master disk files using Windows Explorer* depending on the designated source drive of the recovery volume. This feature can be useful when a data recovery from or to the master disk is necessary.

Accessing recovery disk files

This action is only available if the master disk is the designated source drive and the volume is running off that disk.



1. Under 'Status' or 'Manage', in the storage system view, click the recovery volume. The volume properties are now displayed on the left.
2. Click 'Access recovery disk files'.
3. Windows Explorer opens and displays the files located on the recovery disk.

Accessing master disk files

This action is only available if the recovery disk is the designated source drive and the volume is running off that disk.

1. Under 'Status' or 'Manage', in the storage system view, click the recovery volume. The volume properties are now displayed on the left.
2. Click 'Access master disk files'.
3. Windows Explorer opens and displays the files located on the master disk.



Note

When files have been accessed, the disk is displayed as missing from the array, and becomes available. Also, the volume is set to read-only and data updates are not available in this state. Hiding disk files will make the volume writable and allow data updates.

You can also access master or recovery disk files from Manage Disk.

24.4.2.12 Hiding Master or Recovery Disk Files

This action is only available if a recovery volume is present and disk files have been accessed.

When you are done viewing master or recovery disk files, you can hide the display of the files from Windows Explorer*. Once the disk files are hidden, the disk becomes writable, and data updates on the volume are available.

Hiding recovery disk files

This action is only available if the master disk is the designated source drive and the volume is running off that disk.

1. Under 'Status' or 'Manage', in the storage system view, click the recovery volume. The volume properties are now displayed on the left.
2. Click 'Hide recovery disk files'.
3. The disk files no longer display in Windows Explorer.
4. The page refreshes and data updates on the volume are now available.

Hiding master disk files

This action is only available if the recovery disk is the designated source drive and the volume is running off that disk.

1. Under 'Status' or 'Manage', in the storage system view, click the recovery volume. The volume properties are now displayed on the left.
2. Click 'Hide master disk files'.
3. The disk files no longer display in Windows Explorer.
4. The page refreshes and data updates on the volume are now available.



Note

You can also hide master or recovery disk files from Manage Disk



24.4.2.13 Deleting a Volume

Use caution: you cannot recover data once a volume is deleted.

When a volume is deleted, you create available space that can be used to create new volumes. Note that you cannot delete a system volume using this application because the operating system needs the system files to run correctly. Also, if the volume is a recovery volume and the master or recovery disk files are accessed, you will need to hide these files before the volume can be deleted.

Warning

When a volume is deleted, all existing data on all disks that are a part of the selected volume is permanently lost. It is recommended to complete a backup of all valuable data before continuing.

1. Under 'Status' or 'Manage', in the storage system view, click the volume you want to delete. The volume properties are now displayed on the left.
2. Click 'Delete volume'.
3. Review the warning message, and click 'Yes' to delete the volume.
4. The 'Status' page refreshes and displays the resulting available space in the storage system view. You can now use it to create a new volume.

24.4.2.14 Setting the Data Strip Size

You can assign a data strip size to a volume while creating a new volume or while changing the type of an existing volume. You cannot change the strip size of an existing volume without changing its type.

The strip size refers to each logical contiguous data block used in a RAID 0, RAID 5, or RAID 10 volume. This setting is not available for RAID 1 or recovery volumes, due to their redundant configuration. The default value is the recommended strip size based on the system configuration and the volume type selected; changing the pre-selection is best suited for advanced users.

The following table describes the usage scenarios for the typical strip sizes.

Usage scenarios for supported strip sizes*

Strip Size	Description	RAID Types
4 KB	Best for Web Servers (fast read transfer rate with slow write transfer rate).	RAID 0, 10
8 KB	Best for databases (fast read transfer rate with faster write transfer rate than with 4KB strips).	RAID 0, 10
16 KB	Good for sequential transfers.	RAID 0, 5, 10
32 KB	Best for sequential transfers.	RAID 0, 5, 10
64 KB	Best general purpose strip size.	RAID 0, 5, 10
128 KB	Best for audio and video editing.	RAID 0, 5

*Disclaimer: The data provided in this table may vary based on the brand, type, size, and speed of the disks used.

Setting the strip size when creating a volume



1. Under 'Status', click 'Create' or 'Create a custom volume'.
2. Select the volume type, and then click 'Next'.
3. Make the required disk selection, and then select a new data strip size from the drop-down list in the Advanced section.
4. Complete the volume creation process as described in the Creation Process topic.

Setting the strip size when changing volume type

1. Under 'Status' or 'Manage', in the storage system view, click the RAID volume that you want to modify. The volume properties are now displayed on the left.
2. Click 'Change type'.
3. Make the necessary volume type and disk selections, and then select a new data strip size.
4. Click 'OK' to change the type of the existing volume.
5. The 'Manage' page refreshes and reports the new volume configuration.

Available Strip Size Configurations

	RAID 0	RAID 5	RAID 10
Default			
SATA disks	128 KB	64 KB	64 KB
Solid state disks	16 KB	128 KB	16 KB
Options	4 KB, 8 KB, 16 KB, 32 KB, 64 KB, 128 KB.	16 KB, 32 KB, 64 KB, 128 KB.	4 KB, 8 KB, 16 KB, 32 KB, 64 KB.

24.4.2.15 Enabling Volume Write-back Cache

You can improve the read/write performance of a RAID or recovery volume by enabling the write-back cache on one or all volumes on an array. When this feature is enabled, data may be temporarily stored in the cache memory before being written to the physical disks. Multiple I/O requests may be grouped together to improve performance. By default, the write-back cache is disabled.

Warning

While this feature highly improves the volume and array performance, it also increases the amount of cached data that could be lost in the event of a power failure. This risk can be lowered if your computer is connected to an uninterruptable power supply (UPS)

Enabling the volume write-back cache

1. Under 'Status' or 'Manage', in the storage system view, click the volume for which you want to enable the write-back cache. The volume properties are now displayed on the left.
2. In the Advanced section, click 'Enable', and then click 'Yes' to confirm.
3. The page refreshes and the write-back cache is now enabled.

Note

If your computer is running on battery and a recovery volume is present, the option to enable the write-back cache is not available because the recovery disk is offline and data updates are not available. If this feature was enabled prior to running the battery, write-back cache activity would be temporarily disabled until you reconnect your computer to the power supply.



Disabling the volume write-back cache

1. Under 'Status' or 'Manage', in the storage system view, click the volume for which you want to disable the write-back cache. The volume properties are now displayed on the left.
2. In the Advanced section, click 'Disable', and then click 'Yes' to confirm.
3. The page refreshes and the write-back cache is now disabled.

24.4.2.16 Initializing a Volume

Initializing a volume is the process of synchronizing all redundant data on a volume prior to verifying or verifying and repairing that data. If you attempt to start a verification process for a volume that has not been initialized, you will be prompted to do so.

Initializing a volume

1. Under 'Status' or 'Manage', in the storage system view, click the volume that you want to initialize. The volume properties are now displayed on the left.
2. Click 'Initialize'.
3. Click 'OK' to start the initialization process. Caution: Once the data migration starts, the operation cannot be canceled.

Initializing a volume when verifying data

1. Under 'Status' or 'Manage', in the storage system view, click the volume that you want to verify. The volume properties are now displayed on the left.
2. Click 'Verify'.
3. When prompted to initialize the volume before verifying data, click 'OK' to start the initialization process. Caution: Once the data migration starts, the operation cannot be canceled.
4. Once complete, click 'Verify' to start the verification process.



Note

While initialization is in progress, you can view the status in the notifications area by hovering over the Intel(R) Rapid Storage Technology icon, or in the application under Status or Manage Volume.



Warning

The initializing process could take a while depending on the number and size of the disks. You can continue using array disks and other applications during this time. Closing the application, or powering off and restarting your computer will not disrupt the progress of this operation.

24.4.2.17 Verifying and Repairing Data

You can verify data on an existing volume by identifying and repairing inconsistencies. Running this operation on a regular basis helps you keep valuable data and the overall storage system healthy.

1. Under 'Status' or 'Manage', in the storage system view, click the volume that you want to verify. The volume properties are now displayed on the left.
2. Click 'Verify'.



3. Select the check box if you want errors found to be repaired automatically during the verification process.
4. Click 'OK' to start the verification process.

**Note**

Data on a volume cannot be verified and repaired unless the volume has been initialized first. If you attempt to start a verification process for a volume that is not initialized, you will be prompted to first initialize the volume. Based on its configuration, a RAID 0 volume cannot be repaired because of the lack of redundancy.

24.4.2.18 Swapping Disks

You can change the order of designation for array disks in a recovery volume by setting the master disk as the destination drive and the recovery disk as the source drive. This action is best suited for advanced users.

**Note**

This action is only available if a recovery volume is present, normal, and in continuous update mode.

Swapping disks can be useful if:

- You selected the wrong disk as the master disk when you created the recovery volume,
- You think one of the disks is failing,
- You replaced the recovery disk with a faster, newer disk, and want to run off that device once it has been updated.

1. Under 'Status' or 'Manage', in the storage system view, click the recovery volume. The volume properties are now displayed on the left.
2. In the Advanced section, click 'Swap master and recovery disks'.
3. Click 'Yes' to confirm.
4. Hover over each disk in the storage system view to review their new usage.

24.4.3 Managing Disks

You must be logged on as an administrator to perform the actions listed in this section.

You can manage disks by clicking a selected disk in the storage system view under 'Status' or 'Manage'. This allows you to review the properties and access all actions associated with that disk, such as unlocking a password-protected disk or marking a disk as spare. Depending on their usage or status, some actions may not be available.

24.4.3.1 Disk Properties

The disk properties listed below display to the left of the storage system view under 'Manage' and report values such as usage and status that are specific to the disk selected in the view. Based on the detailed information provided, you can make changes to the way each disk is configured, or take action on one or more disk to keep your overall storage system healthy.



Parameter	Value
Port	Reports the port number to which the disk or device is attached.
Port location	Reports whether the port is internal or external.
Usage	<p>Array disk: a disk that has been grouped with other disks to form an array containing RAID volumes.</p> <p>Master disk: the disk that is the designated source drive in a recovery volume.</p> <p>Recovery disk: the disk that is the designated destination drive in a recovery volume.</p> <p>Spare: the disk has been designated as the destination drive for automatic volume rebuilds in the event of a failed, missing or at risk array disk. For RAID 0 volumes, automatic rebuilds will only occur when one of its array disks is reported as at risk.</p> <p>Available: the disk is physically connected to the computer, healthy, and available to be used in an array or as a spare disk.</p> <p>⚠ Warning Assigning an available disk to an array or marking it as a spare will permanently delete any existing data on that disk.</p> <p>Unknown: the disk is available but contains metadata that cannot be displayed in the operating system. Even though the disk is reported as normal, you will need to clear and reset the disk to make the disk available.</p>
Acceleration mode	<p>Reports the acceleration mode for the disk or volume associated with the cache device.</p> <p>Enhanced: Indicates that the disk or volume is accelerated for optimized data protection.</p> <p>Maximized: Indicates that the disk or volume is accelerated for optimized input/output performance.</p> <p>None: Indicates that no disk or volume is accelerated.</p> <p>Busy: Indicates that acceleration is transitioning from maximized to enhanced mode, or that acceleration is being disabled from maximized mode. In the event that errors are detected and a risk of data loss is identified, transitions from maximized mode will start automatically.</p>
Status	<p>Normal: the disk is present, functioning as expected, and unlocked.</p> <p>Locked: the disk is password-protected. Note: if a volume includes at least one locked disk, the volume will display as locked.</p> <p>At risk: an impending error condition was detected on the disk and it is now at risk of failure.</p> <p>Missing: the disk is not present or physically connected to the computer.</p> <p>Failed: the disk has failed to properly complete read and write operations in a timely manner, and it has exceeded its recoverable error threshold.</p> <p>Offline: indicates that an array disk is locked, that the recovery volume is in on request update mode, or that your computer is running on battery and data updates to the recovery volume are not available.</p>



Size	Reports the total capacity of the disk in megabytes (MB) in the disk properties and in gigabytes (GB) in the storage system view.
Serial number	Reports the manufacturer's serial number for the disk.
Model	Reports the model number of the disk.
Firmware	Reports the version of the firmware found in the disk.
System disk	Reports whether the disk contains system files that are required to start and run the operating system.
Password protected	Reports whether the disk is protected with a password.
Disk data cache	Reports whether the data cache is enabled on this disk. This feature is controlled at the array level.
Native command queuing	Reports whether the disk supports this feature.
SATA transfer rate	Reports the data transfer rate between the SATA controller and the SATA disk. The supported rates are: <ul style="list-style-type: none">• SATA 1.5 Gb/s (generation 1)• SATA 3 Gb/s (generation 2)• SATA 6 Gb/s (generation 3) The data transfer rate reported is based on the Intel® Chipset and SATA disks present in your system.
Physical sector size	Reports the size of physical sectors on the disk (bytes).
Logical sector size	Reports the size of logical sectors on the disk (bytes).

24.4.3.2 Unlocking Password-Protected Disks**

You can unlock a password-protected disk by entering the password which allows you to access data or use that disk to create a volume. The password is setup through the system BIOS. Locked disks can be identified with the lock icon appended to them and display a 'Locked' status in the disk properties.

24.4.3.3 Marking a Disk as Spare

This action is only available for non-system disks in a normal state. Also, unless your mobile computer is equipped with the Intel® 5 Series Chipset or later, which provides support for up to six SATA ports, you will not be able to mark a disk as a spare. Most mobile computers are limited to one internal and one external disk, which are used to create the volume.

Marking a disk as a spare allows you to designate an available SATA disk as the default destination for automatic volume rebuilds in the event of a failed, missing or at risk array disk. However, for RAID 0 volumes, automatic rebuilds will only occur if one of its members is reported at risk.

1. Under 'Status' or 'Manage', in the storage system view, click the disk that you want to mark as a spare. The volume properties are now displayed on the left.
2. Click 'Mark as spare'.
3. Click 'OK'.

**Note**

RAID 1, 5, 10, and recovery volumes can use one or more spares.

**Warning**

When marking a disk as a spare, any existing data on that disk is permanently deleted. Back up all data you want to preserve before starting this action.

If your system is running a version of the RST OROM that does not support disks that are 2TB or larger, you can reset such a disk to available, but disallow the marking of it as a spare.

24.4.3.4 Resetting a Disk to Available

After a disk was marked as spare, you can choose to make that spare disk available again and use it differently. Once available, the disk can be used to create a volume or be added to an existing volume if all other requirements are met.

1. Under 'Status' or 'Manage', in the storage system view, click the disk that you want to reset to available. The volume properties are now displayed on the left.
2. Click 'Reset to available'.
3. The page refreshes and the disk usage is now reported as available.

24.4.3.5 Resetting a Disk to Normal

You can reset a SATA disk to normal when the storage system reports one of the following disk statuses:

At risk

A disk is reported at increased risk of failing in the near future that could be due to a slow degradation over time. You can choose to ignore this alert at this time by resetting the disk to normal, but it may re-appear if the disk continues to assert this condition. We recommend that you contact the manufacturer for more information to prevent potential data loss.

Failed

A SATA disk has failed to properly complete read and write operations in a timely manner, and data may be lost. We recommend that you replace the failed disk as soon as possible to return the overall storage system to normal. In this state, data may be lost, but you can try resetting the disk to normal and attempt a data recovery. If the disk operations continue to fail, the disk will return to a failed state immediately.

If the failed disk is an array disk, refer to the Troubleshooting section for guidelines on rebuilding a failed or degraded volume.

1. Under 'Status', in the Manage subsection, locate the disk reported as at risk or failed. You can also perform this action from Manage Disk, which is accessible by clicking the disk in the storage system view.
2. Click 'Reset disk to normal'. The page refreshes instantly, returning to a normal state.



Completing this action clears the event on the disk and does not delete existing data. However, ignoring early warning signs of disk failure may result in data loss.

24.4.3.6 Accessing Disk Files

This action is only available if a recovery volume is present, in a normal state, and is on request update mode.

This feature allows you to view the files on the designated destination drive in a recovery volume using Windows Explorer*. For example, you may want to review the recovery disk files prior to starting a data recovery in the event that data on the master disk is inaccessible or corrupted.

When the volume status is normal, the recovery disk is the designated destination drive and files are accessible. When the volume status is running off the recovery disk, the master disk is the designated destination drive and files are accessible. You can review the usage of each disk by hovering over the array disks in the storage system view or by clicking one of the disks to review its properties under Manage Disk.

1. Under 'Status' or 'Manage', in the storage system view, click the recovery or the master disk depending on the volume status. The disk properties are now displayed on the left.
2. Click 'Access files'.
3. Windows Explorer opens and displays the files located on the disk.



When files have been accessed, the disk is displayed as missing from the array, and becomes available. Also, the volume is set to read-only and data updates are not available in this state. Hiding disk files will make the volume writable and allow data updates.



Windows Explorer will not open if the disk does not have any partitions on it.

24.4.3.7 Hiding Disk Files

This action is only available if a recovery volume is present and disk files have been accessed.

When you are done viewing master or recovery disk files, you can hide the display of the files from Windows Explorer*. Once the disk files are hidden, the disk becomes writable, and data updates on the volume are available.

1. Under 'Status' or 'Manage', in the storage system view, click the disk whose files are accessed. The disk properties are now displayed on the left.
2. Click 'Hide files'.
3. The disk files no longer display in Windows Explorer.
4. The page refreshes and data updates on the volume are now available.



You can also hide master or recovery disk files from Manage Volume.



24.4.3.8 Connecting a Disk

Installing new hardware is one of the steps you may have to take to keep your storage system healthy or to extend the life of a computer that is running out of storage space.

Intel® Rapid Storage Technology provides hot plug support, which is a feature that allows SATA disks to be removed or inserted while the computer is turned on and the operating system is running. As an example, hot plugging may be used to replace a failed external disk.

Our application provides support for SATA 1.5 Gb/s (generation 1), SATA 3 Gb/s (generation 2), and 6 Gb/s (generation 3) data transfer rates. The rate support depends on the Intel® Chipset and SATA disks present in your system. Visit our Online Support for additional information on chipset features and benefits.

Follow these procedures to replace or connect a disk in case you need to power off your computer:

Replacing a disk

1. Power off your computer.
2. Replace the disk that reports a problem.
3. Turn your computer back on. If the replaced disk was part of an array, you will need to follow the procedure provided in the Troubleshooting section based on the volume state and type.



Note

To install an external disk, plug it into your computer and connect the power cord.

To remove and install an internal disk, you should be comfortable opening your computer case and connecting cables. Follow the manufacturer's installation guide to complete this procedure. If you are replacing the system disk, you will have to re-install the operating system after you connect the disk because the system disk contains the files required to start and run your computer.

Installing a new disk (to increase storage space)

1. Power off your computer.
2. Connect the new disk.
3. Turn your computer back on. During the system startup, the application's option ROM should automatically detect the new disk if it is installed correctly. Once you open the application, verify under 'Status', in the storage system view, that the new disk displays. You can then access management options by clicking that disk.

24.4.4 Managing Ports

A port is a connection point on your computer where you can physically connect a device, such as a SATA disk or ATAPI device. A port transfers I/O data between the device and the computer.

If a port is reported as empty in the storage system view, you can use that port to connect a new device in order to increase the storage system capacity. Currently, the maximum number of internal ports that can be used to connect devices is six.



The port properties listed below display to the left of the storage system view under 'Manage' and report values specific to the element selected in the view.

Parameter	Value
Port	Reports the port number to which the disk or device is attached.
Port location	Reports whether the port is internal or external.

24.4.5 Managing ATAPI Devices

An ATAPI device is a mass storage device with a parallel interface such as a CD-ROM, DVD/Blu-ray disc, tape drive, or solid-state disk. The ATAPI properties listed below display to the left of the storage system view under 'Manage' and report values specific to the selected element.

Parameter	Value
Port	Reports the port number to which the disk or device is attached.
Port location	Reports whether the port is internal or external.
Serial number	Reports the manufacturer's serial number for the device.
Model	Reports the model number of the device.
Firmware	Reports the version of the firmware found in the device.
SATA transfer rate	Reports the transfer mode between the SATA controller and the ATAPI device. The typical values for this parameter are: <ul style="list-style-type: none">• SATA 1.5 Gb/s (generation 1)• SATA 3 Gb/s (generation 2)• SATA 6 Gb/s (generation 3) The data transfer rate reported is based on the Intel® Chipset and SATA disks present in your system.

24.4.6 Managing Solid-State Hybrid Drives (SSHD)

To increase performance, some hard drive manufactures are now including non-volatile memory to be used as a data cache on hard drives. These drives are called Solid-State Hybrid Drives. Hybrid Hinting is a feature by which the RST driver will send information to a SSHD, notifying the drive which data would be best to store in the data cache. There are no extra steps to manage SSHD's.

RST enables Hybrid Hinting when the following minimum requirements are met:

- SSHD must have a minimum of 8GB of non-volatile cache.
- SSHD must have a maximum of 1TB of non-volatile cache.
- SSHD is attached to a supported SKU for Intel® Smart Response Technology for Hybrid Drive Acceleration. (See section 21.1.2 for SKU support)



24.5 Accelerating the Storage System

You can configure an internal solid state disk to be used as a non-volatile intelligent caching for a system or non-system disk or volume that's present on your system. Moving frequently accessed data over to the cache allows you to improve overall system performance, increase read/write access times, and reduce start up times without adding more system memory.

This feature also increases the power efficiency of a mobile computer by retaining stored data and reading data from the cache instead of the SATA disk itself.

Accelerate is only available if the requirements listed in this section under Cache Device Properties are met.

24.5.1 Cache Device Properties

The Performance tab-> enable acceleration page in the UI are only available if the following requirements are met:

- See Section 20 for requirements
- Operating system: all supported OS for this release (see section 2.1.5).
- CPU: Core or Premium
- BIOS: RAID-Ready system and Accelerate feature bit is set.
- An internal SATA solid state disk is present with a minimum capacity of 16 GB.
- A hard disk or volume (array members must all be hard disks) is eligible for acceleration.
- No recovery volume is present.

Limitations

- The maximum cache size is 64 GB.
- Only one disk or volume at a time can be accelerated per system.
- If two volumes are present on a single array (they share the same array of disks), neither volume can be accelerated.
- Once a volume is accelerated, a second volume cannot be added to the same array.
- Once a solid state disk is configured to be used as a cache device, the option to create a recovery volume is no longer available. Recovery volumes do not support system configurations with multiple volumes.

Solid State Disk Properties

Parameter	Value
Port	Reports the port number to which the solid state disk is attached.
Port location	Reports that the solid state disk is internal.
Status	Reports the state of health of the internal solid state disk present in the system. Normal: Indicates that the solid state disk is present, functioning as expected, and unlocked. Failed: Indicates that the solid state disk has failed to properly complete read and write operations in a timely manner, and it has exceeded its recoverable error threshold.



	<p>At risk:</p> <p>Busy: Indicates that acceleration is transitioning from maximized to enhanced mode, or that cache data is being deleted in order to disable acceleration. In some cases, these transitions will start automatically in the event that errors are detected and a risk of data loss is identified.</p>
Type	Reports that the device is a solid state disk.
Usage	Reports that the solid state disk is configured to be used as a cache device.
Size	Reports that the solid state disk is configured to be used as a cache device.
Serial number	Reports the manufacturer's serial number for the internal solid state disk.
Model	Reports the model number of the solid state disk.
Firmware	Reports the version of the firmware found in the solid state disk.
Password protected	Reports whether the solid state disk is password-protected.
Disk data cache	Reports that the data cache is enabled on the solid state disk. When a solid state disk is configured as a cache device, this setting can only be changed at the operating system level.
Native command queuing	Reports whether the solid state disk supports this feature.
SATA transfer rate	<p>Reports the data transfer rate between the SATA controller and the SATA solid state disk. The supported rates are:</p> <ul style="list-style-type: none"> • SATA 1.5 Gb/s (generation 1) • SATA 3 Gb/s (generation 2) • SATA 6 Gb/s (generation 3) <p>The data transfer rate reported is based on the Intel® Chipset and SATA disks present in your system.</p>
Physical sector size	Reports the size of physical sectors on the solid state disk (bytes).
Logical sector size	Reports the size of logical sectors on the solid state disk (bytes).
Accelerated device	Indicates the location of the disk or the name of the volume that is currently accelerated by the cache device.
Acceleration mode	<p>Reports the acceleration mode for the disk or volume associated with the cache device.</p> <p>Enhanced: Indicates that the disk or volume is accelerated for optimized data protection.</p> <p>Maximized: Indicates that the disk or volume is accelerated for optimized input/output performance.</p> <p>None: Indicates that no disk or volume is accelerated.</p>

Cache and Simple Data Volume Properties

Parameter	Value
Name	Reports the name of the volume.
Status	<p>Normal: For simple data volumes, indicates that volume data is fully accessible. For cache volumes, indicates that cache data is fully accessible, and that caching activity with the associated disk or volume is occurring under healthy conditions.</p> <p>Failing: Indicates that a SMART event was detected on the solid state disk that is used as a cache device.</p>



Type	Failed: Indicates that the cache volume has exceeded its recoverable error threshold, and that read and write operations are no longer occurring. Indicates that the single-disk RAID 0 volume is a cache volume.
Data stripe size	Indicates that the single-disk RAID 0 volume is a cache volume.
Allocated cache size	Reports the volume capacity used for cache memory.
Write-back cache	Reports whether the write-back cache feature is enabled for the volume.
Physical sector size	Reports the size of each sector that is physically located on the disk.
Logical sector size	Reports the size of data collection blocks.

Accelerated Disk or Volume Properties

Parameter	Value
Acceleration mode	Reports the acceleration mode for the disk or volume associated with the cache device. Enhanced: Indicates that the disk or volume is accelerated for optimized data protection. Maximized: Indicates that the disk or volume is accelerated for optimized input/output performance. Busy: Indicates that acceleration is transitioning from maximized to enhanced mode, or that acceleration is being disabled from maximized mode. In the event that errors are detected and a risk of data loss is identified, transitions from maximized mode will start automatically.

24.5.2 Enabling Acceleration

You can enable acceleration in order to improve the performance for a SATA hard disk or a RAID volume that includes only SATA hard disks. This operation caches its contents using a non-volatile memory device (a solid state disk) that is attached to an AHCI port.


Enabling acceleration allows you to:

- Use a solid state disk as a cache device: The maximum cache size is 64 GB.
- Accelerate one system or non-system disk or volume present in the system by associating it with the cache volume, and subsequently caching its content.
- Configure acceleration in enhanced (optimized for data protection) or maximized mode (optimized for input/output performance). See below for more information on the acceleration modes.
- If the solid state disk used as a cache device is larger than 64 GB and has a minimum of 4 GB of additional space, a second single-disk RAID 0 volume will be automatically created which can be used for simple data storage.

Enabling Acceleration

Follow these steps to enable acceleration:

1. From the Performance Page, Click 'Intel Smart Response Technology' from the left side panel. Click [Enable acceleration](#).



2. Select the solid state disk you want to use as a cache device.
3. Select the portion of the solid state disk you want to use to store non-volatile cache memory. Any remaining space on the solid state disk may be used for data storage using the simple data single-disk RAID 0 volume that is automatically created.
4. Select the disk or volume you want to accelerate. We highly recommend that you accelerate the system volume or system disk for maximum performance.
5. Select the acceleration mode you want to use, and then click 'OK'. By default, enhanced mode is selected.
6. The page refreshes and reports the new acceleration configuration in the Acceleration View.

Acceleration modes

Non-volatile cache memory can be enabled in either of the following modes:

- **Enhanced mode (default): Acceleration optimized for data protection.**
This mode uses the write-through cache method to write data to the cache memory and the disk simultaneously. In the event that the accelerated disk or volume becomes inaccessible, fails, or is disconnected, there is no risk of data loss because data on the disk is always synchronized with the data in the cache memory. For data safety reasons, this mode is the default acceleration setting.
- **Maximized mode: Acceleration optimized for input/output performance.**
This mode uses the write-back cache method where data is written to the disk at intervals. In the event that the accelerated disk or volume becomes inaccessible, fails, or is disconnected, there is a high risk of data loss. In most cases, data on the disk wasn't synchronized with the data in the cache memory when the event occurred, or new data was written to the disk after the event occurred and it can no longer be synchronized with the cache memory.



24.5.3 Disabling Acceleration

You can disable acceleration on a disk or volume if you want to:

- Enable acceleration on a different disk or volume,
- Return the solid state disk to pass-through,
- Physically move an accelerated disk or volume to another computer.

Completing this action makes any cached data associated with the accelerated disk or volume immediately inaccessible. If the current acceleration mode is maximized, disabling acceleration may take a while to complete, depending on the cache and the solid state disk size. You can use other applications during this time.

1. Click 'Accelerate', and then click 'Disable acceleration'.
2. In the dialog, click 'Yes' to confirm.
3. The page refreshes and reports the acceleration as disabled.

In the event that you are unable to open or access Intel® Rapid Storage Technology due to an application error or operating system issue, you will need to disable acceleration using the option ROM user interface.

1. Restart your computer.
2. Press Ctrl-I to access the main menu of the option ROM user interface.
3. Select 'Acceleration Options' from the main menu.
4. Select the accelerated disk or volume.
5. If acceleration is in maximized mode, type 's' to synchronize data from the flash memory to the accelerated disk or volume. Otherwise, go to step 7.
6. Press 'Y' to confirm.
7. Type 'r' to remove acceleration.
8. Press 'Y' to confirm.

24.5.4 Changing Acceleration Mode

This action is only available if a disk or volume is currently accelerated. A disk or volume can be accelerated in either of the following modes:

- **Enhanced mode (default): Acceleration optimized for data protection.**
This mode uses the write-through cache method to write data to the cache memory and the disk simultaneously. In the event that the accelerated disk or volume becomes inaccessible, fails, or is disconnected, there is no risk of data loss because data on the disk is always synchronized with the data in the cache memory. For data safety reasons, this mode is the default acceleration setting.
- **Maximized mode: Acceleration optimized for input/output performance.**
This mode uses the write-back cache method where data is written to the disk at intervals. In the event that the accelerated disk or volume becomes inaccessible, fails, or is disconnected, there is a high risk of data loss. In most cases, data on the disk wasn't synchronized with the data in the cache memory when the event occurred, or



new data was written to the disk after the event occurred and it can no longer be synchronized with the cache memory.

By default, acceleration is enabled in enhanced mode due to the lower risk of data loss, but you can change acceleration mode at any time as long as the cache volume and accelerated device are in a normal state and caching activity is occurring.

Follow these steps to change the acceleration mode:

1. Click 'Accelerate', and then click 'Change mode'.
2. Click 'Yes' to confirm the mode change to either enhanced or maximized, depending on the current acceleration mode.
3. The page refreshes and the new acceleration mode displays under the Acceleration Configuration subsection and the Acceleration View.

Warning

When a device is accelerated in Maximized mode, performance is highly improved but cached data is at higher risk of being lost in the event of a power failure or under other atypical conditions.

Acceleration in a busy state

The acceleration mode will display as busy under the following conditions (by user interaction or automatic transition):

- When changing acceleration mode from maximized to enhanced.
- When disabling acceleration while in maximized mode.

The transition time varies based on the cache and disk sizes. Disk and volume actions will not be available until the acceleration transition has completed, except for renaming and deleting volumes.

24.5.5 Accelerating a Disk or Volume

Once a solid state disk is configured to be used as a cache device, you can choose to accelerate any disk or volume in a normal state that is located on your storage system. We recommend that you accelerate the system disk or volume in order to get the full benefits of the non-volatile cache memory configuration.

Follow these steps to accelerate a disk or volume:

1. Click 'Accelerate', and then click 'Select device'.
2. In the 'Accelerate Disk or Volume' dialog, select the device you want to accelerate.
3. Select the acceleration mode you want to use, and then click 'OK'. By default, enhanced mode is selected.
4. The page refreshes and reports the newly accelerated device in the Acceleration Configuration subsection. The Acceleration View also indicates the accelerated device with the acceleration icon appended to it.

Non-volatile cache memory can be enabled in either of the following modes:

- **Enhanced mode (default): Acceleration optimized for data protection.**
This mode uses the write-through cache method to write data to the cache memory and the disk simultaneously. In the event that the accelerated disk or volume becomes inaccessible, fails, or is disconnected, there is no risk of data loss because data on the



disk is always synchronized with the data in the cache memory. For data safety reasons, this mode is the default acceleration setting.

- **Maximized mode: Acceleration optimized for input/output performance.**

This mode uses the write-back cache method where data is written to the disk at intervals. In the event that the accelerated disk or volume becomes inaccessible, fails, or is disconnected, there is a high risk of data loss. In most cases, data on the disk wasn't synchronized with the data in the cache memory when the event occurred, or new data was written to the disk after the event occurred and it can no longer be synchronized with the cache memory.

24.5.6 Resetting a Cache Device to Available

This action is only available if a solid state disk is configured as a cache device and there is no accelerated disk or volume present (no association with the cache device). In this situation, you have two options:

- Reset the solid state disk to available and use that device for other purposes.
- Accelerate a disk or volume that is eligible and available for acceleration. Refer to Cache Device Properties for a detailed list of eligibility requirements.

Warning

In the event that a single-disk RAID 0 data volume was created along with a cache volume, resetting the solid state disk to available will delete both volumes. Data on the RAID 0 data volume will be permanently erased. Backup all valuable data before beginning this action.

1. Click 'Accelerate'.
2. Click 'Reset to available'.
3. In the dialog, select the check box to confirm that you understand that data on the data volume will be permanently deleted.
4. Click 'Yes' to confirm.
5. The 'Accelerate' page refreshes. Under 'Status', the storage system view displays the solid state disk usage as available. The device can now be used for any purpose.

24.5.7 Disassociating the Cache Memory

This action is only available if an issue is reported on the accelerated disk or volume that is associated with the cache device and it is missing. In this state, the acceleration mode is typically reported as unavailable and caching activity is no longer occurring.

If you are unable to resolve the reported issue on the accelerated disk or volume (e.g., degraded or failed volume due to a missing array disk), the only option will be to remove the association between the cache device and the disk or volume.

Once the association between the cache and the accelerated disk or volume is removed, all cache metadata and data is deleted from the cache device. You can then reset the solid state disk to available or accelerate a different disk or volume, as long as the cache device is healthy.



Follow these steps to disassociate the cache memory and the accelerated device:

1. Click 'Accelerate'.
2. Click 'Disassociate'.
3. In the 'Disassociate' dialog, click 'Yes' to confirm.
4. The page refreshes and the Acceleration View reports the new configuration. Options to reset the solid state disk to available or to select a new device to accelerate (as long as an eligible disk or volume is available) are now available.



Note

You can also perform this action using the option ROM user interface.

24.6 Preferences

System preferences allow you to decide whether you want the notification area icon to display. In addition, you can select the types of notifications you want to receive, such as storage system warnings or errors, and be notified of any reported problems while the application is closed.

Both administrators and standard users can change the notification area settings using the application or directly from the notification area. Settings changes are applied on a per user basis, and do not affect other users' settings.

Showing system notifications

By default, System preferences are set to show the notification area icon. If you previously chose to hide the notification area icon, follow these steps to display the icon again:

1. Under 'Preferences', select 'Show the notification area icon'.
2. Click 'Apply Changes'. Verify that the icon is now displayed in the notification area.

Hiding system notifications

Once you hide the notification area icon, the service no longer reports storage system information, warnings, or errors through the notification area. You will need to use the application to monitor the health of the storage system. Follow these steps to hide the notification area icon:

1. Under 'Preferences', deselect 'Show the notification area icon'.
2. In the 'Hide Notification Area Icon' dialog, click 'Yes' to confirm.
3. Verify that the icon is no longer displayed in the notification area.

Selecting system notifications

1. Under 'Preferences', make sure that 'Show the notification area icon' is selected.
2. Select the types of notifications you want to receive.



Note

Storage system information provides details on any changes of state other than warnings or errors, such as new disks being detected or locked.

Storage system warnings report the cause for the overall warning state of the storage system, such as a degraded RAID volume due to a missing disk.



Storage subsystem errors report the cause for the overall error state of the storage system, such as a failed volume due to a failed disk.



25 Opal Drive Support

Support for Opal drives was added beginning with Intel® Rapid Storage Technology version 13.0.

25.1 Opal ATA Commands Supported

The Intel® RST driver will support the following Opal ATA commands on systems in either AHCI or RAID mode (only on pass-thru drives):

- ATA_PASS_THRU_DIRECT IOCTL commands of ATA TRUSTED RECEIVE and ATA TRUSTED SEND.

25.2 Intel® Rapid Storage Technology UI Support

The Intel® RST UI will display information about the Opal disks attached to the SATA controller when the Opal disk is partially or fully Opal locked.

25.3 Opal SCSI Commands Supported

The Intel® RST driver supports translation of the following SCSI Commands on systems in AHCI or RAID mode (only pass-thru disks):

- SCSI_PASS_THROUGH_DIRECT IOCTL commands of SECURITY_PROTOCOL_IN and SECURITY_PROTOCOL_OUT to ATA TRUSTED RECEIVE and ATA TRUSTED SEND.

25.4 Opal UEFI Protocol Supported

The Intel® RST UEFI driver supports the following UEFI Protocol for OPAL Support for systems in RAID mode with the RST UEFI Driver installed:

- EFI_STORAGE_SECURITY_PROTOCOL

25.5 Intel® RST PCIe NVMe Support for Opal

Intel® RST PCIe NVMe Support for Opal requires security communication protocols. The following NVMe Security commands are required for Opal support:

- SECURITY SEND
- SECURITY RECEIVE

RST will allow the Security Send and Security Receive commands to be sent only when using the following protocols:

- RST UEFI
 - EFI_STORAGE_SECURITY_COMMAND_PROTOCOL: EFI_STORAGE_SECURITY_COMMAND_PROTOCOL is loaded **ONLY** if a device supports TCG and Block IO protocol is loaded successfully
- RST OS Driver



- SCSI SECURITY PROTOCOL: Intel® RST driver supports translating commands to NVMe Security Send and NVMe Security Receive commands on TCG supported Opal PCIe NVMe SSDs.

25.6 NVMe Device Requirements for Intel® RST Opal Support

Intel® RST will recognize Opal supported NVMe Devices that report support for the Security Send and Security Receive commands.

Intel® RST uses the register from Admin Command Set Attributes and Optional Controller Capabilities (bytes 257:256). RST requires that bit 0 of this register must be set to a value of 0x01 to indicate Opal support. If the bit is not set, RST will not recognize the device as supporting Opal.

NVM Express 1.1b		
79:78	M	Controller ID (CNTLID): Contains the NVM subsystem unique controller identifier associated with the controller. Refer to section 7.9 for unique identifier requirements.
255:80		Reserved
Admin Command Set Attributes & Optional Controller Capabilities		
257:256	M	Optional Admin Command Support (OACS): This field indicates the optional Admin commands supported by the controller. Refer to section 5. Bits 15:3 are reserved. Bit 2 if set to '1' then the controller supports the Firmware Activate and Firmware Download commands. If cleared to '0' then the controller does not support the Firmware Activate and Firmware Download commands. Bit 1 if set to '1' then the controller supports the Format NVM command. If cleared to '0' then the controller does not support the Format NVM command. Bit 0 if set to '1' then the controller supports the Security Send and Security Receive commands. If cleared to '0' then the controller does not support the Security Send and Security Receive commands.

§ §



26 eDrive Support

Support for eDrives is new for Intel® Rapid Storage Technology version 13.2. eDrive provides transport of Trusted Computing Group (TCG) protocol over 1667.

Intel® RST added support for TCG communication in version 13.0 (see section 24).

26.1 What is an eDrive?

A disk that returns the following value in its IDENTIFY DEVICE DATA ATA response:

Bit 0 of Word 48 =1(Trusted Computing Group Support): Opal SSC Specification.

Bit 7 of Word 69 =1(IEEE 1667 Support): ACS-3 Specification Rev. 5

26.2 SCSI Standard Inquiry Command Response

When a disk is identified as an eDrive, the Intel® RST driver will report IEEE 1667 support in a SCSI Standard Inquiry command response.

26.3 Configurations Supported

eDrive support is similar to Opal Support and will be supported in RAID or AHCI modes on a pass-thru (non-RAID member) drive attached to the SATA controller.

Further details and specifications for eDrives can be found at the IEEE 1667 Workgroup web page: <http://www.ieee1667.com>

§ §



27 Using the BCFS to Differentiate Platform SKUs

Beginning with the Intel® RST 10.x Release and the Intel® 5 Series Express Chipset (codename Ibox Peak), the BIOS Control Feature Set (BCFS) has been enabled to give OEMs the opportunity to customize the Intel® RST features offered on any particular Intel® 5 Series Express Chipset model/SKU and later. OEMs no longer need special Intel® RST OROM images from Intel in order to enable/disable certain desired features for a platform SKU. OEMs can now enable/disable the desired features per platform SKU directly in their BIOS code. By clearing or setting the corresponding bits of the **Intel RST Feature Capabilities** register in the Intel chipset's SATA controller MMIO space, OEMs now have greater flexibility in determining what Intel® RST features will be supported per platform model/SKU.

The following sections explain the use of each of the bits in the BCFS, also known as the Software Feature Mask bits.

Note: This document does not cover details on how to setup a system BIOS. For that level of information contact your platform's BIOS vendor or your Intel field representative to put you in contact with the appropriate Intel BIOS support personnel.

27.1 Configuring the Platform's RAID Related Features

When the BIOS has set the SATA Controller's mode to RAID, the following bits of the 'Intel RST Feature Capabilities' register in the Intel chipset's SATA controller MMIO space will determine what RAID levels will be supported on the platform SKU:

Note: Clearing all RAID level related bits to '0' (that includes the Intel® RRT bit) is an unsupported configuration. The Intel® RST OROM will ignore the BIOS settings and enable all RAID levels (Intel® RRT inclusive).

27.1.1 Configuring the Standard Supported RAID Levels

There are four (4) bits that control the 4 standard RAID levels supported by Intel® Rapid Storage Technology:

Bits	Type	Reset/Default	Description
3	RWO	1h	RAID 5 Enable (R5E): If set to '1', then RAID5 is enabled
2	RWO	1h	R10 Enable (R10E): If set to '1', then RAID10 is enabled
1	RWO	1h	RAID 1 Enable (R1E): If set to '1', then RAID1 is enabled
0	RWO	1h	R 0 Enable (R0): If set to '1', then RAID0 is enabled



27.1.1.1 Example Configuration

To configure a platform SKU that offers **only** RAID levels 0 and 10, the bits must be configured as follows:

Bit 0 == 1 (default)

Bit 1 == 0

Bit 2 == 1 (default)

Bit 3 == 0

27.1.2 Configuring Intel® RRT Related RAID Features

There are two (2) bits that control two capabilities/features related to the Intel® RRT feature:

Bits	Type	Reset/Default	Description
8	RWO	0h	Intel® RRT Only on ESATA (ROES): If set to '1', then only Intel® RRT volumes can span internal and eSATA drives. If cleared to '0', then any RAID volume can span internal and eSATA drives.
4	RWO	1h	Intel® RRT Enable (RSTE): If set to '1', then Intel Rapid Recovery Technology is enabled.

27.1.2.1 Example Configuration

To configure a platform SKU that offers Intel® RRT, only RAID level 5, and allows both Intel® RRT and RAID5 Volumes to span disks on both internal and external (eSATA) ports, the bits must be configured as follows (**Note:** an Intel® RRT volume cannot coexist with another RAID level volume at the same time on the platform):

Bit 0 == 0

Bit 1 == 0

Bit 2 == 0

Bit 3 == 1 (default)

Bit 4 == 1 (default)

Bit 8 == 0 (default)

27.1.3 Configuring the Behavior of the OROM UI and Banner

There are three (3) bits that control the behavior of the Intel® RST OROM UI and the Banner Splash Screen that are displayed during POST at system boot-up. Use the following bit configurations to determine whether or not the splash screen will be displayed during post and if so, how long the delay will be before the system continues the boot process:



Bits	Type	Reset/Default	Description
11:10	RWO	0h	<p>OROM UI Normal Delay (OUD): Values of these two bits specify the delay of the OROM UI Splash Screen in a normal status.</p> <p>00 – 2 secs (default and previous value) 01 – 4 secs 10 – 6 secs 11 – 8 secs</p> <p>Note: If bit 5 == 0, then these values are disregarded</p> <p>Comment: Allow OEM to lengthen normal timeout of OROM splash screen so user has more time to hit CTRL+I on keyboard.</p>
5	RWO	1h	<p>Intel RST OROM UI (RSTOROMUI): If set to '1' then the OROM UI is shown. Otherwise, no OROM banner or information will be displayed if all disks and RAID volumes are Normal.</p>

27.1.3.1 Example Configuration

To configure a platform SKU that enables the OROM Banner Splash Screen to be displayed for 6 seconds, the bits must be configured as follows:

Bit 5 == 1 (default)

Bit '10' == 0 (default)

Bit '11' = = 1

27.1.4 Configuring Intel® RST UI Capabilities

There is one capability within the Intel® RST UI that is controlled by the BCFS bits. To enable/disable the ability for the Intel® RST UI to unlock password protected disks, use the following bit configurations:

Bits	Type	Reset/Default	Description
6	RWO	0h	<p>HDD Unlock (HDDLK): If set to '1', then HDD password unlock is enabled in the OS.</p>

The default settings for these two features are:

Bit 6 == 0

When this bit is cleared the Intel® RST UI does not display any option to use this feature.

27.1.4.1 Example Configuration

To configure a platform SKU to not allow unlocking passwords from the Intel® RST UI and to allow the UI to activate the disk/port LEDs, the bits must be configured as follows:



Bit 6 == 0 (default)

27.1.5 Configuring the Platform to Support Intel® SRT

The BCFS bit is only one of the platform parameters (see section [17.1.1](#) for all requirements) that determines whether Intel® Smart Response Technology can be enabled on a platform, however, unless this bit is set there will be no support for this feature on the platform.

Bits	Type	Reset/Default	Description
9	RWO	0h	Intel® Smart Response Technology Enable Request (SREQ): If set to '1', then Smart Response Technology is enabled. If cleared to '0', Smart Response Technology is disabled.

Bit 9 == 1

This enables the Intel® Smart Response Technology feature on the platform SKU.

27.1.6 Configuring the Platform to Support Intel® Optane™ Memory System Acceleration

The BCFS bit is only one of the platform parameters (see [Optane\(TM\) Requirements](#) for all requirements) that determines whether Intel® Optane™ Memory System Acceleration can be enabled on a platform, however, unless this bit is set there will be no support for this feature on the platform.

Bits	Type	Reset/Default	Description
13	RWO	0h	Intel® Optane™ Memory Acceleration (Optane_Memory_Accel): If set to '1', then the computer will be capable of enabling System Acceleration with Optane Memory. If cleared to '0', then the computer will not be capable of enabling System Acceleration with Optane Memory. Note: This feature is added in KBL platform and onward.

Bit 13 == 1

This enables the Intel® Optane™ Memory System Acceleration feature on the platform SKU.

27.1.7 Configuring the Platform to Support CPU Attached Storage

The BCFS bit is only one of the platform parameters that determines whether Intel® RST support for CPU Attached Storage can be enabled on a platform, however, unless this bit is set there will be no support for this feature on the platform.



Bits	Type	Reset/Default	Description
14	RWO	0h	<p>CPU Attached Storage (CPUAS): If set to '1', then the computer will be capable of Intel® RST supported PCIe NVMe drives attached to the CPU PEG ports. If cleared to '0', then the computer will not be capable of enabling Intel® RST supported PCIe CPU Attached storage.</p> <p>Note: This bit is activated beginning on the CNL/CFL platform.</p>

Bit 14 == 1

This enables Intel® RST controlled PCIe NVMe drives attached to the CPU PEG ports on the platform SKU.

27.2 BIOS Control Feature Set

Bits	Type	Reset	Description
15	RO	0h	<u>Reserved</u>
<u>14</u>	RO	0h	<p>CPU Attached Storage (CPUAS): If set to '1', then the computer will be capable of Intel® RST supported PCIe NVMe drives attached to the CPU PEG ports. If cleared to '0', then the computer will not be capable of enabling Intel® RST supported PCIe CPU Attached storage.</p> <p>Note: This bit is activated beginning on the CNL/CFL platform.</p>
<u>13</u>	RWO	0h	<p>Intel® Optane™ Memory Acceleration (Optane Memory Accel): If set to '1', then the computer will be capable of enabling System Acceleration with Optane Memory. If cleared to '0', then the computer will not be capable of enabling System Acceleration with Optane Memory.</p> <p>Note: This bit is activated beginning on the KBL platform.</p> <p>Note: This bit does not enable/disable the Optane Memory Acceleration feature. It only enables/disables the capability for the Intel RST SW to enable/disable the feature on any specific computer, as defined by the computer manufacturer.</p>
<u>12</u>			<u>Reserved</u>
<u>11:10</u>	<u>RWO</u>	<u>0h</u>	<p>OROM UI Normal Delay (OUD): Values of these bits specify the delay of the OROM UI Splash Screen in a normal status.</p> <p>00 – 2 secs (default and previous value)</p> <p>01 – 4 secs</p> <p>10 – 6 secs</p> <p>11 – 8 secs</p> <p>If bit 5 == 0, then these values are disregarded</p>



Bits	Type	Reset	Description
			<u>Comment: Allow OEM to lengthen normal timeout of OROM splash screen so user has more time to hit CTRL+I on keyboard.</u>
<u>9</u>	<u>RWO</u>	<u>0h</u>	<u>Intel® Smart Response Technology Request Enable (SEREQ):</u> If set to '1', then Smart Response Technology is enabled. If cleared to '0', Smart Response Technology is disabled. Note: Although this bit is still activated, this feature is EOL beginning with the CNL/CFL platform family.
<u>8</u>	<u>RWO</u>	<u>0h</u>	<u>Intel® RRT Only on ESATA (ROES):</u> If set to '1', then only Intel® RRT volumes can span internal and eSATA drives. If cleared to '0', then any RAID volume can span internal and eSATA drives.
<u>7</u>	<u>RWO</u>	<u>0h</u>	<u>Reserved</u>
<u>6</u>	<u>RWO</u>	<u>0h</u>	<u>Reserved</u>
<u>5</u>	<u>RWO</u>	<u>1h</u>	<u>Intel® RST OROM UI (RSTOROMUI):</u> If set to '1' then the OROM UI is shown. Otherwise, no OROM banner or information will be displayed if all disks and RAID volumes are Normal.
<u>4</u>	<u>RWO</u>	<u>1h</u>	<u>Intel® RRT Enable (RSTE):</u> If set to '1', then Intel Rapid Recovery Technology is enabled
<u>3</u>	<u>RWO</u>	<u>1h</u>	<u>RAID 5 Enable (R5E):</u> If set to '1', then RAID5 is enabled
<u>2</u>	<u>RWO</u>	<u>1h</u>	<u>RAID 10 Enable (R10E):</u> If set to '1', then RAID10 is enabled
<u>1</u>	<u>RWO</u>	<u>1h</u>	<u>RAID 1 Enable (R1E):</u> If set to '1', then RAID1 is enabled
<u>0</u>	<u>RWO</u>	<u>1h</u>	<u>RAID 0 Enable (R0E):</u> If set to '1', then RAID0 is enabled

§ §



28 Testing, Certification Notes

Correcting Microsoft* Windows 7 (Win7) WHQL test failure

For Internal SATA ports with interlock switches, the RST driver will set Removable=TRUE in the IRP_MN_QUERY_CAPABILITIES handler. This causes Win7 to show the internal device in its own "container" which is used to describe devices that are external to the system. For example, a CD-ROM on an interlocked switch in a Win7 system, under 'Devices and Printers',

You can see that the CD-ROM on the interlocked SATA port shows up separately in the top-level 'Devices' view. This can result in a platform WHQL test failure.

There is a whitepaper describing use of Removable device capability bits on Win7 by bus drivers: <http://www.microsoft.com/whdc/Device/DeviceExperience/ContainerIDs.mspx>.

In order to correct this issue to pass the platform WHQL test, RST recommends the OEM to take the following action:

In the system BIOS, define an _EJ0 ACPI method on the interlocked port. _EJ0 will signal to the ACPI driver to set Removable for the RST driver and still mark the device as internal to the system such that it does not show in its own container. The implementation is to use a registry key for each port to tell RST whether to set Removable bit or not. If _EJ0 ACPI method is defined in the system BIOS by the manufacturers, they can tell RST not to set the Removable bit. For example:

```
[HKEY_LOCAL_MACHINE\SYSTEM\CurrentControlSet\Services\iaStor\Parameters\Port1]
```

```
"EJ0IsDefined"=dword:1
```

If 1, _EJ0 will set Removable bit instead of RST. If 0, no _EJ0 defined so RST will set Removable bit. The default value is 0.





29 Glossary

Term	Definition
ATA	Advanced Technology Attachment
BIOS	Basic Input/Output System
BOM	Bill Of Materials
CD	Compact Disc
Chipset	Term used to define a collection of integrated components required to make a PC function.
Hard drives	Physical hard drives attached to a RAID controller
DEVSLP	Serial ATA Device Sleep
DOS	Disk Operating System
GB	Giga-byte
HDD	Hard Drive
I/O	Input/Output
ICH	I/O Controller Hub
ICH9	Intel® 82801IR/DO SATA RAID Controller
IDE	Integrated Drive Electronics
INF	Information file (.inf) used by Microsoft operating systems that support the Plug and Play feature. When installing a driver, this file provides the OS needed information about driver filenames, driver components, and supported hardware.
Intel® Option ROM (OROM)	Standard Plug and Play option ROM that provides a pre-operating system user interface for the Intel RAID implementation.
MB	Mega-byte
Migration	Term used to describe the movement of data from one configuration or usage model to another.
OEM	Original Equipment Manufacturer
Option ROM	A code module built into the System BIOS that provides extended support for a particular piece of hardware. For this product, the Option ROM provides boot support for RAID 0/1/5/10 volumes, and provides a user interface for configuring and managing RAID 0/1/5/10 volumes.
OS	Operating System
PATA	Parallel ATA
PCH	Platform Controller Hub is the new term for Intel chipsets
PCI	Peripheral Components Interconnect
PFW	Package for the Web
PIO	Programmed Input Output
PnP	Plug and Play



Action to locate the port connected to a disk present on the system by activating the Light Emitting Diode (LED) light.

AHCI:

An interface specification that allows software to communicate with SATA devices such as host bus adapters, and enables advanced SATA features such as Native Command Queuing, native hot plugging, and power management. Advanced Host Controller Interface (AHCI).

Array:

An abstraction layer or collection of two or more disks used to manage RAID volumes existing on a same collection of disks. RAID arrays are not visible to the operating system.

At risk:

Status indicative that a disk or device has experienced a SMART event, and that an impending error condition was detected and the disk or device is now at risk of failure.

ATAPI device:

A mass storage device with a parallel interface such as CD-ROM, CD-RW, DVD-ROM, Blu-ray Disc, and tape drives. Advanced Technology Attachment Packet Interface (ATAPI).

B

Blocks with media errors:

Number of inconsistencies found during the data verification of a RAID volume. This feature only applies to the verification process or the verification and repair process.

Bus Protocol Group:

A bus protocol group represents a set of bus protocols with similar performance characteristic. Bus Protocol Groups are listed here in ascending order of speed:

1- SATA

2- PCIe

C

Cache

A resource allocation on a storage component used for temporary data operations. Cache can be allocated in components such as RAM or non-volatile memory.

Cache device

The selected solid state disk used for cache storage in an SRT configuration.

Cache volume

The portion of the cache device (a solid state disk) that holds the non-volatile cache data in an SRT configuration. That portion is configured into a single-disk RAID-0 volume.

Change volume type:

Action to change the volume from one RAID configuration to another, and move data from one RAID volume to another. A RAID 1 volume can also be converted to a recovery volume, and vice versa.

Continuous update mode:

Update mode assigned to a recovery volume, where data on the master disk is copied to the recovery disk automatically, as long as both disks are connected to the system.

D

Data stripe size:

Size of a grouping of data on a single physical disk within a RAID volume. Reported in kilobytes (KB).

Data volume

The portion of extra space on the cache device (a solid state disk) that can be used for data storage. That portion is configured into a single-disk RAID-0 volume.

Degraded:

Volume status indicative that one member has failed or is missing. This status only applies to recovery, RAID 1, RAID 5, and RAID 10 volumes.

Disassociating a cache

The action of removing the association between the non-volatile cache and the accelerated disk or volume.

Disk data cache:

A cache memory within a hard drive that temporarily stores frequently used data sectors for faster access. As a result, overall hard drive performance is improved.

Disk:

A hard or floppy disk. Also known as hard drive or hard disk drive.

E

E-mail notification:



Alert mechanism that allows the user to receive storage system information, warning, and error notifications by e-mail via SMTP. By default, this feature is disabled and requires configuration settings such as the SMTP host and e-mail addresses to be set up.

Enhanced Mode

An acceleration mode that uses write-through, non-volatile cache to improve performance. The mode also is known as “separation safe” because all host-write requests are written to the accelerated disk or volume and possibly to the non-volatile cache.

F

Failed:

Volume and disk status indicative that one or more array members are missing or have failed.

Firmware:

Permanent instructions and data programmed directly into the read-only memory (ROM) for controlling the operation of the computer. Firmware usually requires updates to fix defects or add features to the hardware.

H

Hide master or recovery disk files:

Action to close the display of files located on a master or recovery disk in a recovery volume after viewing them in Windows Explorer*. This option is only available when ‘Access recovery disk files’ or ‘Access master disk files’ was previously selected. Once disk files are hidden, volume updates can resume.

Hot plug:

Action to remove or insert a SATA disk when the system is powered on.

I

Increase volume size:

Action to expand the data storage capacity of a volume by utilizing the available array space on a RAID 0, RAID 1, RAID 5, or RAID 10 volume.

Initialize:

Process of synchronizing all redundant data on a volume prior to creating a volume, verifying and repairing data, or changing volume type. Initialization is still required for non-redundant volumes such as RAID 0 to ensure that data is readable before starting the verification process.

Intel® Rapid Recover Technology:

Official name for Intel’s technology that allows the user to copy data from a master disk (source) to a recovery disk (destination) either continuously or on request.

Intel® Rapid Storage Technology:

Official name for Intel's Windows-based software to provide support for high-performance, fault-tolerant, and capacity SATA RAID arrays on select supported chipsets. Intel Rapid Storage Technology also provides support for Intel® Rapid Recover Technology, AHCI Native Command Queuing, and matrix RAID for two RAID volumes on a single array.

L

Locked:

Volume and disk status indicative that the data is protected with a password and cannot be accessed until disks are unlocked.

M

Mark as spare:

Action to designate an available and compatible SATA disk as the default destination for automatic rebuilds in the event that an array member fails or is missing.

Master disk:

The disk that is the designated source drive in a recovery volume.

Maximized Mode

An acceleration mode that uses write-back, non-volatile cache to improve performance better than the enhanced Mode. This mode is optimized for input/output performance and power savings.

Memory Group

A memory group represents a set of backend storage media types with similar performance characteristics. Memory Groups are listed here in ascending order of speed:

- 1- Spindle Device (HDD)
- 2- NAND Spindle Hybrid Device (SSHD)
- 3- PCH SATA NAND Device (SSD)



4- PCIe NAND Device (SSD)

- . **Migrating:**
Volume status indicative that data is being moved/transferred across selected storage devices due to a change request in the storage system configuration, such as changing volume type, creating a volume preserving existing data, increasing the volume capacity, or changing data stripe size.
- . N
- . **Native Command Queuing:**
Command protocol in SATA that allows multiple commands to be outstanding within a disk at the same time. The commands are dynamically reordered to increase disk performance.
- . **Normal:**
Volume, disk, and device status indicative that they are in a healthy state, functioning as expected, disks are properly connected, and data is fully accessible.
- . O
- . **Offline:**
Disk status indicative that an array disk is locked (the volume status displays as locked), that the recovery volume is in on request update mode, or that your computer is running on battery and data updates to the recovery volume are not available.
- . **On request update mode:**
Update mode assigned to a recovery volume, where data on the master disk is copied to the recovery disk when the user requests it. Only changes since the last update process are saved to the recovery disk.
- . **Option ROM:**
Firmware that is called by the system BIOS in order to communicate and provide support for a hardware device. For this product, the option ROM provides boot support for RAID volumes as well as a user interface for configuring and managing RAID volumes. Also known as OROM.
- . P
- . **PCIe Storage Device:**
A storage device that connects to the PCIe bus. PCIe devices can contain either an AHCI or NVMe communication controller.
- . **Port:**
An internal or external data connection of a computer (e.g., SATA controller) to which a peripheral device (e.g., SATA disk) can be attached.
- . R
- . **RAID 0:**
A RAID type or configuration where data is striped across multiple physical disks. Data is split into manageable blocks called strips across array members. Striping does not create data redundancy but improves read/write performance.
- . **RAID 1:**
A RAID type or configuration where data is mirrored across a second physical disk in the array. Mirroring is a key feature that ensures real-time data redundancy and increased fault tolerance. There is no striping.
- . **RAID 10:**
A RAID type or configuration that uses four disks to create a combination of RAID type 0 and 1. The data is striped across a two-disk array forming a RAID 0 component. Each of the disks in the RAID 0 array is mirrored by a disk in the RAID 1 array.
- . **RAID 5:**
A RAID type or configuration where data and parity are striped into manageable blocks called strips across three or more physical disks. This type is a preferred configuration as it combines efficiency, fault-tolerance, and data performance.
- . **RAID:**
Redundant Array of Independent/Inexpensive Disks is a technology used for computer data storage schemes that divide and/or replicate data among multiple disks. RAID can be designed to provide increased data reliability or increased I/O (input/output) performance, or both. A number of standard schemes have evolved which are referred to as levels or types. Intel® Rapid Storage Technology software supports RAID 0, RAID 1, RAID 5, and RAID 10 configurations (refer to each RAID type definition for more information).
- . **Read-only:**
Recovery volume status indicative that the recovery or master disk files are accessed, allowing files on the disk to be read or copied, but not changed or saved.



- **Rebuild:**
The process of restoring a recovery, RAID 1, RAID 5, and RAID 10 volume in the event that a volume disk has failed or is missing. If a spare disk is present and compatible, the application will automatically use it as a replacement for the failed disk. An automatic rebuild process will also occur if a RAID 1 member is removed and then reconnected, in order to re-establish the mirroring. This process does not apply to RAID 0 volumes.
- **Recover data:**
The action of retrieving data in the event that a recovery volume has failed due to a missing or failed master disk. Data from the recovery disk is copied to a new or healthy master disk, restoring data redundancy. Selecting this option will overwrite all master disk data with data on the recovery disk.
- **Recovery disk:**
The disk that is the designated destination drive in a recovery volume.
- **Recovery volume:**
A two-disk redundant volume that includes a master disk (source) and a recovery disk (destination) and uses Intel® Rapid Recover Technology. This configuration provides flexibility of volume data updates and maximum data redundancy.
- **Remapped:**
Remapping hardware in the chipset allows a PCIe STORAGE DEVICE to appear to the OS as if it were an extra port on the Chipset's internal AHCI controller rather than a separate controller on the PCIe bus
- **Repair:**
The process of fixing verification errors and blocks with media errors found during the verification process. This feature is only available for volumes with a normal or at risk status. A RAID 0 cannot be repaired due to its non-redundant configuration.
- **Reset disk to normal:**
Action to return a failed or at risk disk to a normal state. We recommend that you contact the manufacturer for more information to prevent potential data loss.
- **Reset to available:**
Action to return a disk previously marked as a spare to an available state.
- **Reset volume to normal:**
Action to return a failed volume where both array disks are present and normal to a normal state. This feature allows you to access and attempt a recovery of healthy volume data.
- S
- **SATA disk:**
A disk with an interface that transmits data using a serial protocol in order to communicate with the SATA controller.
- **SATA transfer rate:**
Rate at which the SATA controller and SATA disk communicate with each other. Transfer rates are important when large contiguous blocks of data are being used, such as video and image files. Reported in gigabits/seconds (Gb/s).
- **SATA:**
A successor to ATA and PATA, SATA is a computer bus technology primarily designed for transfer of data between storage devices such as hard drives or optical devices, and a computer. Benefits of this technology are: usage of high-speed serial cables, air cooling to work more efficiently, faster transfers, the ability to remove devices while operating (hot plugging), enables more reliable operation with tighter data integrity checks. Also known as Serial Advanced Technology Attachment or Serial ATA.
- **Single-disk RAID 0**
A RAID-0 volume that has one (1) disk as its array disk. This is the volume type used to create the non-volatile cache region on a solid state disk being used for caching. This volume type creates an OS-visible volume that enables access to extra space on the solid state disk that is not being used for caching.
- **Size:**
Reports the total capacity of a physical device such as a SATA disk, a volume, or an array.
- **Storage system:**
One or more physical disks or devices that act as a unit for data storage.
- **System disk:**



A disk that contains system files required to start and run the operating system. By default, the Windows operating system files are in the WINDOWS folder, and the supporting files are in the WINDOWS\System32 folder.

System volume:

A volume that refers to the disk(s) volume that contains the hardware-specific files that are needed to start Windows, such as Ntldr, Boot.ini, and Ntdetect.com, as well as the Windows operating system files and supporting files. The system volume can be the same volume as the boot volume.

U

Unknown:

Disk status indicative that its usage could not be determined, due to a possible incompatibility between this software version and the disk configuration, or a virus. Also a volume status indicative that the volume is in an unexpected state due to a configuration error. Data on the volume can no longer be accessed.

Update mode:

Type of update assigned to a recovery volume. The update mode can be set to continuous, where master disk changes are automatically saved to the recovery disk, or set to on request, where updates of the recovery disk can be requested immediately.

V

Verify:

Action of scanning data to detect any types of data damage, disk read errors, and volume data inconsistencies. As an option, errors found can be corrected on redundant RAID volumes. This feature is only available for volumes with a normal or at risk status.

Volume size:

Amount of data that can be stored on a volume; reported in bytes (B) or %.

Volume type:

Configuration of a volume which determines how data is stored and managed to improve read/write performance, increase fault tolerance and/or storage capacity.

Volume write-back cache:

A cache memory used to enhance the read/write performance of a RAID volume by grouping multiple I/O requests into fewer requests and by writing from the cache to the volume at defined intervals.

Volume:

A fixed amount of space across a RAID array that is structured to emulate a single physical hard drive and appears as such to the operating system. Volumes have drive letters assigned to them and some volumes can span multiple hard disks.

W

Windows Disk Management*:

Microsoft Windows* system utility for managing the disks and partitions or volumes that they contain. Disk Management allows the initialization of new disks, volume creation, and formatting. Most disk-related tasks can be performed using this system utility without shutting down or restarting the computer; most configuration changes take effect immediately.

Write-back cache allocation:

Size of the dynamic random access memory (DRAM) that is allocated for write-back caching on all volumes present on the system. The cache size is set to 16 megabytes (MB) by default.





30 Troubleshooting

This section explains how to resolve the most common problems that may occur while using the application. If you have any questions regarding installing, using or maintaining this product, you can also visit Intel's online support site which provides you with self-help resources and electronic problem submission.

30.1 Failed Volumes

RAID 0

A RAID 0 volume is reported as failed when one of its members is disconnected or has failed. In both cases, the volume and its data are no longer accessible.

Cause	Solution
Missing array disk	<p>Follow this procedure to recover data:</p> <ol style="list-style-type: none">1. Power off your computer and reconnect the missing disk.2. Turn on your computer. During the system startup, the volume status will display as 'Normal' in the Intel Rapid Storage Technology option ROM user interface.3. Once the operating system is running, open Intel Rapid Storage Technology from the Start menu or click the Intel Rapid Storage Technology notification area icon.4. Under 'Status', verify that the volume and disks status display as 'Normal'. You can also review this information under 'Manage'.
Failed array disk	<p>In most cases, the volume cannot be recovered and any data on the volume is lost. However, before deleting the volume, you can try resetting the disks to normal, and then attempt a data recovery. If the read/write data access consistently fails, the disk will likely return to a failed state immediately. Refer to Troubleshooting Disk Events for instructions on resetting a disk to normal.</p> <p>This procedure deletes the failed volume:</p> <ol style="list-style-type: none">1. Power off your computer and replace the failed SATA disk with a new one that is of equal or greater capacity.2. Turn on your computer. During the system startup, the volume status will display as 'Failed' in the Intel Rapid Storage Technology option ROM user interface.3. Press Ctrl-I to access the main menu of the option ROM user interface.4. Select Delete RAID Volume from the main menu.5. From the Delete Volume menu, select the failed RAID volume, using the up and down arrow keys.6. Press the 'Delete' key to delete the volume, then 'Y' to confirm.7. Create a new RAID 0 volume using the new disk. If the failed disk was part of the system volume, you will also need to reinstall the operating system.



RAID 5

A RAID 5 volume is reported as failed when two or more of its members have failed.

Cause	Solution
Two or more array disks failed	<p>In most cases, the volume cannot be recovered and any data on the volume is lost. However, before deleting the volume, you can try resetting the disks to normal, and then attempt a data recovery. If the read/write data access consistently fails, the disk will likely return to a failed state immediately. Refer to Troubleshooting Disk Events for instructions on resetting a disk to normal.</p> <p>This procedure deletes the failed volume:</p> <ol style="list-style-type: none">1. Power off your computer and replace the failed SATA disks with new ones that are of equal or greater capacity.2. Turn on your computer. During the system startup, the volume status will display as 'Failed' in the Intel Rapid Storage Technology option ROM user interface.3. Press Ctrl-I to access the main menu of the option ROM user interface.4. Select Delete RAID Volume from the main menu.5. From the Delete Volume menu, select the failed RAID volume, using the up and down arrow keys.6. Press the 'Delete' key to delete the volume, then 'Y' to confirm.7. Create a new RAID 5 volume using the new disks. If the failed disk was part of the system volume, you will also need to reinstall the operating system.

RAID 10

A RAID 10 volume is reported as failed when two adjacent members are disconnected or have failed, or when three or four of its members are disconnected or have failed.

Cause	Solution
Two adjacent array disks missing	<ol style="list-style-type: none">1. Power off your computer and reconnect the missing disks.2. The rebuild operation will start automatically. You can follow the progress by hovering over the notification area icon or by reviewing the volume status under 'Status' or 'Manage'.
Three or four array disks missing	<p>In most cases, the volume cannot be recovered and any data on the volume is lost. This procedure deletes the failed volume:</p> <ol style="list-style-type: none">1. Power off your computer and reconnect the missing disks.2. Turn on your computer. During the system startup, the volume status will display as 'Failed' in the Intel Rapid Storage Technology option ROM user interface.3. Press Ctrl-I to access the main menu of the option ROM user interface.4. Select Delete RAID Volume from the main menu.5. From the Delete Volume menu, select the failed RAID volume, using the up and down arrow keys.6. Press the 'Delete' key to delete the volume, then 'Y' to confirm.



7. Create a new RAID 10 volume using the new disks.
8. You will then need to reinstall the operating system on the new volume.

Two or more array disks failed

In most cases, the volume cannot be recovered and any data on the volume is lost. However, before deleting the volume, you can try resetting the disks to normal, and then attempt a data recovery. If the read/write data access consistently fails, the disk will likely return to a failed state immediately. Refer to Troubleshooting Disk Events for instructions on resetting a disk to normal.

This procedure deletes the failed volume:

1. Power off your computer and replace the failed SATA disks with new ones that are of equal or greater capacity.
2. Turn on your computer. During the system startup, the volume status will display as 'Failed' in the Intel Rapid Storage Technology option ROM user interface.
3. Press Ctrl-I to access the main menu of the option ROM user interface.
4. Select Delete RAID Volume from the main menu.
5. From the Delete Volume menu, select the failed RAID volume, using the up and down arrow keys.
6. Press the 'Delete' key to delete the volume, then 'Y' to confirm.
7. Create a new RAID 10 volume using the new disks.
8. You will then need to reinstall the operating system on the new volume.

30.2 Degraded Volumes

Recovery Volume

A recovery volume is reported as degraded when the recovery disk has failed or when the master disk is disconnected or has failed. Data mirroring and redundancy are lost because the system can only use the functional member.

Cause

Recovery disk failed

Solution

We recommend that you rebuild the degraded volume to a new disk to return the volume and overall storage system status to normal. However, you can try resetting the disk to normal, but if the read/write data access consistently fails, the disk will likely return to a failed state immediately. Refer to Troubleshooting Disk Events for instructions on resetting a disk to normal.

If a SATA disk is compatible, available and normal, follow this procedure to rebuild the volume:

1. Under 'Status', click 'Rebuild to another disk'.
2. Select the disk you want to use to rebuild the volume, and then click 'Rebuild'.
3. The rebuild operation starts immediately. You can follow the progress by hovering over the notification area icon or by reviewing the volume status under 'Status' or 'Manage'.
4. Once the operation successfully completed, the recovery disk and volume status will display as 'Normal'.



5. Once completed, the volume returns to the last update mode to which it was set before the issue was reported.

Note: If there is no available disk present, you will need to power off your computer and connect a new SATA disk that is equal or greater capacity than the failed disk. Once your computer is back up and running you can follow the rebuild procedure described above.

Master disk missing

If you can reconnect the missing master disk, follow this procedure to recover data:

1. Power off your computer and reconnect the missing disk.
2. Turn on your computer and the system will automatically boot from the recovery disk.
3. Under 'Status', in the Manage subsection, click 'Recover data' or click the recovery volume in the storage system view, and then click 'Recover data'.
4. Click 'Yes' to confirm.
5. The recovery operation starts immediately and cannot be canceled. You can follow the progress by hovering over the notification area icon or by reviewing the volume status under 'Status' or 'Manage'.
6. Once completed, the volume returns to the last update mode to which it was set before the issue was reported.

If you cannot reconnect the missing disk and a SATA disk is available and normal, follow this procedure to rebuild the volume:

1. Under 'Status', click 'Rebuild to another disk'.
2. Select the disk you want to use to rebuild the volume, and then click 'Rebuild'.
3. The rebuild operation starts immediately. You can follow the progress by hovering over the notification area icon or by reviewing the volume status under 'Status' or 'Manage'.
4. Once the operation successfully completed, the master disk and volume status will display as 'Normal'.
5. Once completed, the volume returns to the last update mode to which it was set before the issue was reported.

If you cannot reconnect the missing disk or rebuild to an available disk, you will need to power off the computer and connect a new SATA disk. Once rebuilt, the recovery volume will be limited to its original size even if the new disk is larger than the original master disk. Once your computer is back up and running you can follow the rebuild procedure described above.

Master disk failed

We recommend that you rebuild the degraded volume to a new disk to return the volume and overall storage system status to normal. However, you can try resetting the disk to normal, but if the read/write data access consistently fails, the disk will likely return to a failed state immediately.

1. To reset the failed master disk and the volume to normal, follow this procedure:
2. Under 'Status', click 'Reset disk to normal'. Note that the volume is now running off the recovery disk, and that the master disk is reported as offline.
3. Under 'Status', in the Manage subsection, click 'Recover data' or click the recovery volume in the storage system view, and then click 'Recover data'.



⚠ Warning

Starting this action will override existing data on the master disk and update it with the data on the recovery disk. Backup all valuable data before continuing.

Click 'Yes' to confirm.

The recovery operation starts immediately and cannot be canceled. You can follow the progress by hovering over the notification area icon or by reviewing the volume status under 'Status' or 'Manage'.

Once the operation successfully completed, the master disk and volume status will display as 'Normal'.

If a SATA disk is compatible, available and normal, follow this procedure to rebuild the volume:

Under 'Status', click 'Rebuild to another disk'.

Select the disk you want to use to rebuild the volume, and then click 'Rebuild'.

The rebuild operation starts immediately. You can follow the progress by hovering over the notification area icon or by reviewing the volume status under 'Status' or 'Manage'.

Once the operation successfully completed, the master disk and volume status will display as 'Normal'.

Once completed, the volume returns to the last update mode to which it was set before the issue was reported.

Note

If there is no available disk present, you will need to power off your computer and connect a new SATA disk. Once rebuilt, the recovery volume will be limited to its original size even if the new disk is larger than the original master disk. Once your computer is back up and running you can follow the rebuild procedure described above.

RAID 1

A RAID 1 volume is reported as degraded when one of its members is disconnected or has failed. Data mirroring and redundancy are lost because the system can only use the functional member.

RAID 5

A RAID 5 volume is reported as degraded when one of its members is disconnected or has failed. When two or more array disks are disconnected or have failed, the volume is reported as failed.

RAID 10

A RAID 10 volume is reported as degraded when one of its members is disconnected or has failed, or when two non-adjacent members are disconnected or have fails. When two or more array disks are disconnected or have failed, the volume is reported as failed.

Cause

Missing array disk

Solution

If you can reconnect the missing disk, follow this procedure to rebuild the volume:

1. Power off your computer and reconnect the missing disk.
2. Turn on your computer and the rebuild operation will start automatically.

If you cannot reconnect the missing disk and a SATA disk is available and normal, follow this procedure to rebuild the volume:



If a SATA disk is compatible, available and normal, follow this procedure to rebuild the volume:

Select the disk you want to use to rebuild the volume, and then click 'Rebuild'.

The rebuild operation starts immediately. You can follow the progress by hovering over the notification area icon or by reviewing the volume status under 'Status' or 'Manage'.

Once the operation successfully completed, the array disk and volume status will display as 'Normal'.

Note:

If there is no available disk present, you will need to power off your computer and connect a new SATA disk that is equal or greater capacity than the failed disk. Once your computer is back up and running you can follow the rebuild procedure described above.

Failed array disk

We recommend that you rebuild the degraded volume to a new disk to return the volume and overall storage system status to normal. However, you can try resetting the disk to normal, which will prompt the volume to start rebuilding automatically. But if the read/write data access consistently fails, the disk will likely return to a failed state immediately and you will need to rebuild the volume to another disk.

If a SATA disk is compatible, available and normal, follow this procedure to rebuild the volume:

1. Under 'Status', click 'Rebuild to another disk'.
2. Select the disk you want to use to rebuild the volume, and then click 'Rebuild'.
3. The rebuild operation starts immediately. You can follow the progress by hovering over the notification area icon or by reviewing the volume status under 'Status' or 'Manage'.
4. Once the operation successfully completed, the array disk and volume status will display as 'Normal'.

Note:

If there is no available disk present, you will need to power off your computer and connect a new SATA disk that is equal or greater capacity than the failed disk. Once your computer is back up and running you can follow the rebuild procedure described above.

User switching SATA Controller Mode from RST/RAID -> AHCI -> RST/RAID

30.3 Other Volume States

Locked

Cause

At least one (but not all) disk included in the volume is locked with a password.

Solution

In this state, the overall storage system health is still reported as normal, but we recommend that you unlock the disks to make the volume data fully accessible. Follow this procedure to unlock a disk:

1. Under 'Status' or 'Manage', in the storage system view, click the disk you want to unlock. The disk properties are now displayed on the left.
2. Click 'Unlock'.
3. Enter the password, and then click 'Unlock'.



4.Repeat this procedure for all locked disks included in the volume in order to unlock the volume.

Note:

If all the disks included in a volume are locked, the volume is no longer displayed

Incompatible

Cause

Indicates that the volume was moved to another system that does not support the volume type and configuration.

Solution

In this situation, volume data is accessible to the operating system and can be backed up, but the volume cannot operate because your system does not support its RAID configuration.

Here are your options:

- 1.Reconnect the volume to the computer where the volume was originally created, and continue using it.
- 2.Delete the volume, and then create a new volume with a RAID configuration that is supported by the current system. Follow the procedure described above to delete the volume.

⚠ Warning

When a volume is deleted, all existing data on the member disks of the selected volume is permanently erased. It's recommended that you backup all valuable data prior to beginning this action.

Unknown

Cause

The volume is in an unexpected state due to a configuration error.

Solution

The application is unable to detect the exact nature of the problem. Try restarting your computer. If the error persists, back up all valuable data and delete the volume using the option ROM user interface. Refer to the user's manual accessible from the Online Support area for details on using the option ROM.

Power-Saving Mode (Recovery Volumes only)

Cause

Your computer is running on battery and the volume is in continuous update mode. Data updates to the recovery disk or a data recovery operation are not occurring.

Solution

Data mirroring and redundancy are lost, and your data is at risk in the event of a disk failure. Reconnect your computer to the power supply, and the operation that was in progress prior to running on battery will resume automatically.

Note

If a data recovery was in progress, the overall storage subsystem health is reported as degraded because the operation could not be completed.

Data Update Needed (Recovery Volumes only)

Cause

The data on the recovery disk is not synchronized with the data on the master disk.

Solution

Data mirroring and redundancy are lost, and your data is at risk in the event of a disk failure. Follow this procedure to update data on the recovery disk:

- 1.Under 'Status' or 'Manage', in the storage system view, click the recovery volume. The volume properties are now displayed on the left.
- 2.Click 'Update data'.



3. Select the check box if you don't want this confirmation message to display each time you request an update. Click 'Yes' to confirm.

4. The update process can be instantaneous or may take a while depending on the amount of data being copied. You can follow the progress by hovering over the notification area icon or by reviewing the volume status under 'Status' or 'Manage'.

Running Off Recovery Disk (Recovery Volumes only)

Cause

Your computer was booted from the recovery disk using the option ROM, and the volume is operating from that disk. With this reverse configuration, the recovery disk is the designated source drive and data updates to the master disk are not available.

Solution

Data mirroring and redundancy are lost, and your data is at risk in the event of a disk failure. A data recovery from the recovery disk to the master disk is required to maintain full redundancy.

Warning

Completing this action will overwrite all master disk data with the data on the recovery disk. Backup all valuable data prior to starting this action.

1. Under 'Status' or 'Manage', in the storage system view, click the recovery volume. The volume properties are now displayed on the left.
2. Click 'Recover data', then 'OK' to confirm.
3. Once complete, we recommend that you restart your computer from the master disk using the option ROM user interface to return to a normal state.

Recovery Disk Read-Only (Recovery Volumes Only)

Cause

The recovery disk files have been accessed and display in Windows Explorer*.

Solution

In this state, any data written to the master disk is not copied to the recovery disk because it is read-only. Data mirroring and redundancy may be lost and we recommend that you hide the recovery files to resume data updates. Follow this procedure to hide recovery disk files from Manage Disk or from Manage Volume:

1. Under 'Status' or 'Manage', in the storage system view, click the recovery volume or the recovery disk. The element properties are now displayed on the left.
2. Click 'Hide Files' from Manage Disk or 'Hide recovery disk files' from Manage Volume.
3. The Windows Explorer window closes.

You can resume data updates by clicking 'Update data' under Manage Volume. To copy the latest changes to the recovery disk automatically, change the update mode to continuous from the same area.



Master Disk Read-Only (Recovery Volumes Only)

Cause

Your computer was booted from the recovery disk using the option ROM, and the volume is operating from that disk. The master disk files have been accessed and are displayed in Windows Explorer*.

Solution

Data mirroring and redundancy are lost, and your data is at risk in the event of a disk failure. We recommend that you hide the master disk files when finished with your review, and proceed with a data recovery to the master disk in order to maintain full redundancy. Follow this procedure to hide master disk files from Manage Disk:

1. Under 'Status' or 'Manage', in the storage system view, click the recovery volume or the master disk. The element properties are now displayed on the left.

2. Click 'Hide Files' from Manage Disk or 'Hide master disk files' from Manage Volume.

The Windows Explorer window closes and the volume is displayed as running off recovery disk.

Refer to the 'Running off recovery disk' procedure above to recover data to the master disk.

Missing volume

Cause

A driver upgrade or downgrade was performed while a data migration was in progress.

Solution

The driver cannot recognize the volume or read its data if a driver upgrade or downgrade was performed during a volume migration. Volume migrations occur after one of the following operations was initiated:

- Creation of a system volume or data volume while preserving data.
- Volume type change combined with disk addition to the new RAID configuration.
- Volume size increase.
- Disk addition to an existing array.

Troubleshooting a data volume

If the data migration involved a data volume, you will need to reverse the driver upgrade or downgrade operation and return to the original driver version. This will restore driver and volume compatibility.

Once the operation has completed, restart your computer.

Open the application and make sure that the volume displays again in the storage system view. Data migration operation should resume immediately.

Troubleshooting a system disk

If the data migration involved a system disk or volume, it is highly likely that you will not be able to start your system because the driver cannot read the system files. The following options may allow you to load the operating system again:

Restore a known good configuration.

Boot from a flash drive that supports NTFS partitioning and includes the storage driver files.

Bring the corrupt disk to another system, and then replace the storage driver files from a compatible driver version. Return the disk to the original system and try booting.

Troubleshooting a system volume

If the data migration involved a system disk or volume, it is highly likely that you will not be able to start your system because the driver cannot read the system files. The following options may allow you to load the operating system again:

Restore a known good configuration.

Bring all corrupted array disks to another system, and then replace the storage driver files from a compatible driver version. Return the disks to the original system and try booting.

30.4 Disk Events

State	Cause	Solution
	<p>An internal or external disk is protected and locked with a password.</p>	<p>In this state, the overall storage system health is reported as normal, but to make the data fully accessible, you will need to follow this procedure to unlock the disk:</p> <ol style="list-style-type: none"> 1.Under 'Status' or 'Manage', in the storage system view, click the disk you want to unlock. The disk properties are now displayed on the left. 2.Click 'Unlock'. 3.Enter the password, and then click 'Unlock'.
<p>At risk</p> 	<p>An impending error condition was detected on an internal or external disk and is now at risk of failure.</p>	<p>The application is detecting early warning signs of failure with a SATA disk that result from a slow degradation over time. When a disk is reported at risk, you can reset that disk to normal, but we recommend that you contact the manufacturer for more information to prevent potential data loss. Follow this procedure to reset the disk to normal:</p> <ol style="list-style-type: none"> 1.Under 'Status', in the Manage subsection, locate the disk reported as at risk. You can also perform this action from Manage Disk, which is accessible by clicking the disk in the storage system view. 2.Click 'Reset disk to normal'. The page refreshes instantly, returning to a normal state. <p>Note: Completing this action clears the event on the disk and does not delete existing data. However, ignoring early warning signs of disk failure may result in data loss.</p> <p>If the disk reported at risk is included in a RAID volume and a compatible spare disk is available, the rebuild process will start automatically. Once complete, the disk reported at risk becomes available and you can reset it to normal to return to a healthy state.</p>
	<p>An unexpected error was detected on a disk that has RAID configuration data (metadata) on it.</p>	<p>In this state, it is likely that some or all of the disk data is inaccessible. After backing up any accessible data, you will need to clear the metadata and reset the disk to return to a normal state.</p> <p>Warning: Completing this action will permanently delete existing metadata. Back up any accessible data before continuing.</p>



State	Cause	Solution
	An array disk is not present or physically connected to the computer.	<ol style="list-style-type: none">1.Under 'Status', in the Manage subsection, locate the disk reported as at risk. You can also perform this action from Manage Disk, which is accessible by clicking the disk in the storage system view.2.Click 'Clear and reset disk', and then click 'Yes' to confirm.3.Once complete, the page refreshes with the disk returning to a normal state.
	The recovery or master disk files have been accessed and display in Windows Explorer*. An internal or external disk has failed to properly complete read and write operations in a timely manner, and it has exceeded its recoverable error threshold.	<p>Ensure that the disk is securely connected to the SATA port and that the SATA cable is functioning properly. If the disk is lost or cannot be reconnected, you will need to connect a new SATA disk, and then rebuild the volume to that new disk. Refer to Degraded or Failed Volumes in this section for instructions on how to rebuild a volume.</p> <p>Hide the recovery or master disk files to return the disk status to offline and resume data updates in on request mode.</p> <ol style="list-style-type: none">1.Under 'Status' or 'Manage', in the storage system view, click the recovery volume or the recovery disk. The element properties are now displayed on the left.2.Click 'Hide Files' from Manage Disk or 'Hide recovery disk files' from Manage Volume.3.The Windows Explorer window closes. <p>Back up your data and we recommend that you replace the disk as soon as possible. If the failed disk is an array disk, the volume will be reported as degraded or failed depending on its configuration. Refer to Degraded or Failed Volumes in this section for instructions on resolving the problem.</p> <p>In a failed state, disk data may be lost, but you can try resetting the disk to normal, and then attempt a data recovery. Follow this procedure to reset the failed disk to normal:</p> <ol style="list-style-type: none">1.Under 'Status', in the Manage subsection, locate the disk reported as failed. You can also perform this action from Manage Disk, which is accessible by clicking the disk in the storage system view.2.Click 'Reset disk to normal'. The page refreshes instantly, returning to a normal state.
	An internal or external array disk is locked and data on that disk cannot be read.	<p>We recommend that you unlock the disk to make the volume data fully accessible. If more than one array disk is locked, unlock all those disks to unlock the volume.</p>



State	Cause	Solution
	The recovery volume is in on request update mode.	Change the volume update mode to continuous. 1.Under 'Status' or 'Manage', in the storage system view, click the recovery volume. The volume properties are now displayed on the left. 2.Click 'Change mode', and then click 'Yes' to confirm. 3.The page refreshes and the volume properties report the new update mode.
	Your computer is running on battery and data updates to the recovery disk are not available as long as that disk is offline.	Reconnect your computer to the power supply in order to return the recovery disk to a normal state.

30.5 Caching Issues

Cache Volume is Missing

Regardless of what the acceleration mode currently is, cache and volume data is most likely lost. Devices that are part of the acceleration configuration display in the following states:

- Solid state disk: Inaccessible
- Cache volume: No longer displays
- Data volume (if applicable): No longer displays
- Accelerated volume (if applicable): No longer displays
- Accelerated disk (if applicable): Offline
- Array disks: Offline

Cause

The solid state disk was removed or the disk is present but cannot be detected.

Solution

The application provides the option to clear the metadata on the array disks or previously accelerated disk and reset these disks to a normal state.

1.Under Status, in the Manage subsection, click 'Clear and reset' next to each array disk reported as offline. You can also perform this action under 'Manage' by clicking any offline disk reported in the storage system view.

2.Click 'Yes' to confirm.

The array disk now displays as an available disk in a normal state and can be used to create a new volume

Cache Volume is Failing

Cause

An impending error condition (e.g., SMART events) was detected on the solid state disk that is used as a cache device. As a result, both the disk and cache volume are at risk of failure.



Solution

Early warning signs of failure with the solid state disk are detected that result from a slow degradation over time. When a disk used as a cache device is reported at risk, you can reset that disk to normal or replace the solid state disk after resetting it to available.

Regardless of which option you choose, we recommend that you contact the manufacturer for more information to prevent potential data loss.

Current acceleration mode: Enhanced

Follow this procedure to reset the disk to normal:

- 1.Under 'Status', in the Manage subsection, locate the disk reported as at risk. You can also perform this action from Manage Disk, which is accessible by clicking the failing disk in the storage system view.
 - 2.Click 'Reset disk to normal'. The page refreshes instantly, returning to a normal state.
 - 3.The cache volume should also return to a normal state and caching activity should resume. Completing this action clears the event on the disk and does not delete existing data. However, ignoring early warning signs of disk failure may result in data loss.
- Follow this procedure to replace the failing solid state disk:

- 1.Click 'Accelerate', and then click 'Disable acceleration'.
- 2.In the dialog, click 'Yes' to confirm.
- 3.The page refreshes and reports the acceleration as disabled.
- 4.Click 'Reset to available'.
- 5.In the dialog, select the check box to confirm that you understand that data on the cache and data volumes will be deleted.
- 6.Click 'Yes' to confirm.
- 7.The page refreshes and the storage system displays the solid state disk usage as available.
- 8.Power off your computer and replace the failing solid state disk with a healthy one.
- 9.Power on your computer. You can enable acceleration again in order to resume caching activity.

Note:

If the last acceleration mode was maximized, that application will automatically transition acceleration to enhanced mode in order to avoid data loss. While transitioning, the mode will display as busy and no acceleration actions will be available until the process is complete.

Current acceleration mode: Maximized

- 1.If a compatible spare is detected, the volume rebuild operation will start automatically. Once the process is complete, the cache volume will display in a normal state and caching activity will resume.
- 2.If no compatible spare is detected, the acceleration mode will automatically transition to enhanced in order to avoid data loss. You can then follow the procedures described above to return the solid state disk and cache volume to normal.

Cache Volume has Failed

Cause

The solid-state disk that is used as a cache device has failed to properly complete read and write operations in a timely manner and it has exceeded its recoverable error threshold. In this state, both cache and data volumes are reported as failed and acceleration is automatically disabled.



Solution

Back up any recoverable data and replace the solid- state disk as soon as possible. In a failed state, disk data may be lost, but you can try recovering it by resetting the disk to normal.

1. In the Manage subsection, under 'Status', locate the disk reported as failed. Alternately, perform this action from Manage Disk, accessible by clicking the disk in the storage system view.

2. Click 'Reset disk to normal'. The page refreshes instantly, returning to a normal state.

If the disk operations continue to fail, the disk will return to a failed state immediately and should be replaced. Follow this procedure:

1. Click 'Accelerate'.

2. Click 'Reset to available'.

3. In the dialog, select the check box to confirm that you understand that data on the cache and data volumes will be deleted.

4. Click 'Yes' to confirm.

The page refreshes and the storage system displays the solid state disk usage as available.

1. Power off your computer and replace the failed solid state disk with an operational one.

2. Power on your computer. To resume the caching activity, enable acceleration again.

If acceleration was in maximized mode prior to being automatically disabled, the disk or volume previously associated with the cache will be reported as failed if the data cleaning was unsuccessful.

If data cleaning was successful, once the mode transition is complete, the accelerated disk or volume previously associated with the cache will be reported as normal.

Accelerated disk or volume is missing

Cause

The accelerated disk or volume cannot be detected (e.g., the device was moved to another system) and is reported as inaccessible. Caching activity is no longer occurring.

Solution

If the disk or volume can be reconnected:

1. Power off your computer and reconnect the missing disk or volume.

2. Restart your computer.

3. Once the operating system is running, open the application.

4. Under 'Status', in the Accelerate subsection, verify the accelerated device is properly reported as well as the acceleration mode. Caching activity should resume immediately.

If the disk or volume cannot be reconnected, follow this procedure to disassociate the cache and the missing device:

1. Click 'Accelerate'.

2. Click 'Disassociate'.

3. Click 'Yes' to confirm.

4. The page refreshes and you can now select another disk or volume to accelerate.

Accelerated Disk or Volume is Reporting an Issue

Cause

- Accelerated disk is reported as being at risk or failed.



- Accelerated volume is reported as degraded or failed.

Solution

Refer to Troubleshooting Disk Events, Failed Volumes, or Degraded Volumes for detailed procedure on fixing the issue.

If you cannot fix the issue reported on the accelerated disk or volume, follow this procedure to disassociate the cache and the missing device:

1. Click 'Accelerate'.
2. Click 'Disassociate'.
3. Click 'Yes' to confirm.

The page refreshes and you can now select another disk or volume to accelerate.

30.6 Software Errors

Message	Cause	Solution
An unknown error occurred while running this application. If the problem persists, restart your computer or try reinstalling the application.	This error may be related to: Missing components Corrupted application Application unable to connect to the service Application fails to start.	Restart your computer or try reinstalling the application.
Intel® Rapid Storage Technology is trying to connect to the service.	The application is launched and is attempting to connect to the service in order to run.	If the connection succeeds, the application opens and is fully functional; if the connection fails, the error message described above is displayed. Try starting the service manually using Microsoft Windows* Services, or follow the recommended solution listed above to resolve the problem.
The Intel® Rapid Storage Technology service cannot be started in safe mode.	Your computer was started in safe mode and the operating system is running with a limited set of files and drivers. Intel Rapid Storage Technology cannot start or run in safe mode.	Once you are done troubleshooting application or driver problems in safe mode, you will need to exit safe mode, restart your computer, and then let the operating system start normally. The Intel Rapid Storage Technology service can now be started and open the application.
Multiple users cannot run the application at the same time.	One or more users are attempting to open the application while an instance of the application is already running.	Make sure only one instance of the application is running at a time.



Message	Cause	Solution
An error occurred due to insufficient resources, and the operation could not be completed. Try again later.	The Intel® Rapid Storage Technology driver does not have sufficient resources to execute the request. Another operation may be in progress and needs to complete before being able to handle a new request.	Wait a few moments, then try performing the action again.
An unknown error occurred during the volume creation process. Try recreating the volume.	An unexpected error occurred during the operation, and the application cannot identify its origin. The volume could not be created.	Verify that your hardware is properly connected and try recreating the volume.
An error occurred while an operation was in progress. The operation could not be completed.	An unexpected error occurred during an operation, such as a data migration or a rebuild, and the application cannot identify its origin.	Restart the operation. If the error persists, try restarting your computer and then the operation.
An error occurred and the selected disk or volume could not be accelerated. Restart your computer, and then try the operation again.	The cache memory allocation was likely increased to use full solid state disk capacity (up to 64 GB) while enabling acceleration.	Follow these steps to accelerate a disk or volume: <ul style="list-style-type: none">• Restart your computer to complete the process of allocating the requested cache size.• Launch the application.• Try enabling acceleration again by clicking 'Enable acceleration'.

30.7 UI Error Handling

Errors can occur while performing different operations. If an error appears it will also contains an error code which can used to identify the error. We can lookup online for handling the UI error codes. The page contains the error codes along with the meaning of the error and their possible solutions.

We can refer to the Intel Website support page in the link below:

<https://www.intel.com/content/www/us/en/support/articles/000024113/memory-and-storage/intel-optane-memory.html>



Appendix A RST SATA Port Bitmap Implementation

A.1 Legacy OROM

RST overloaded offset 0x08 of the PNP header, with a bitmap of which ports make up the PNP header.

E.g., a RAID5 volume whose member disks located on SATA ports 0,2,3 would have a value of 0x0D (0000_1101b) and a pass-thru disk on port 4 would have a value of 0x10 (0001_0000b).

Offset	Size	Value	Description
00h	1	'\$'	Signature byte 1
01h	1	'P'	Signature byte 2
02h	1	'N'	Signature byte 3
03h	1	'P'	Signature byte 4
04h	1	01h	Structure revision
05h	1	Varies	Length (in 16 byte blocks)
06h	2	Varies	Offset of next header (0000h if none)
08h	1	00h	Reserved
09h	1	Varies	Checksum
0Ah	4	Varies	Device identifier
0Eh	2	Varies	Offset to manufacturer string (optional)
10h	2	Varies	Offset to product name string (optional)
12h	3	Varies	Device type code
15h	1	Varies	Device indicators
16h	2	Varies	Boot Connection Vector (BCV)
18h	2	Varies	Disconnect Vector (DV)
1Ah	2	Varies	Bootstrap Entry Vector (BEV)
1Ch	2	0000h	Reserved
1Eh	2	Varies	Static resource information vector



A.2 UEFI Driver

The RST UEFI driver, in an effort to provide similar functionality as in the legacy OROM, has implemented the Port Number value in the Device Path as a bitmap representing the physical disk connections that the Logical Disk represents. The LSB (least significant bit) represents port 0 and increases linearly. E.g. a single pass through disk on SATA port **3** (assuming the SATA ports are enumerated 0 – X) is represented by 0000_1000b (or 0x08).

A.2.1 EFI_DEVICE_PATH_PROTOCOL

For each logical disk that is exposed by the SATA RAID UEFI Driver, an EFI_DEVICE_PATH_PROTOCOL shall be created.

The Device Path Protocol for each logical disk shall be appended to the PCI SATA Controller Device Path.

The fields of the EFI_DEVICE_PATH_PROTOCOL shall be filled out differently depending on whether the device is an ODD or an HDD.

EFI_DEVICE_PATH_PROTOCOL Field	ATAPI (ODD)	HDD/Volume – Logical Device
Type	3 (Messaging Device Path)	3 (Messaging Device Path)
Sub-Type	18 (SATA)	18 (SATA)
Length	10	10
HBA Port Number	Port ID bitmap (bit #n set if device is on port #n)	Port ID bitmap (bit #n set if logical device contains device ID #n) Lowest Significant Bit (LSB) represents port 0.
Port Multiplier Port Number	0x8000 (directly connected)	0x8000 (directly connected)
Logical Unit Number	0	0 for passthrough devices, myVolRaidDevNum for RAID volumes, which is the n th volume created on the array.





Appendix B Common Storage Management Interface Support (CSMI)

Intel® RST driver does not support application development that require interface access to the driver via API method. However RST does support applications developed to interface to the driver via the industry standard specification of the Common Storage Management Interface. We support a subset of the total command set. The below table has a list of the commands that are supported by Intel® RST. For more detail information on the specification you can access the <http://www.t11.org/> website. The document number for the specification is 04-468v0.

Supported CSMI commands:

BASE IOCTLS:

CC_CSMI_SAS_GET_DRIVER_INFO
CC_CSMI_SAS_GET_CNTLRL_CONFIG
CC_CSMI_SAS_GET_CNTLRL_STATUS

RAID IOCTLS:

CC_CSMI_SAS_GET_RAID_INFO
CC_CSMI_SAS_GET_RAID_CONFIG

The following CSMI IOCTLS are supported for both SATA and PCIe AHCI devices:

CC_CSMI_SAS_GET_PHY_INFO
CC_CSMI_SAS_GET_SATA_SIGNATURE
CC_CSMI_SAS_STP_PASSTHRU

§ §



Appendix C Drive and Volume Encryption Support

C.1 ATA Security Commands and HDD Password Support

RST supports HDD passwords via the ATA Security command set, as long as the host BIOS also supports the ATA security command set. RST volumes, including SRT volumes, may be locked with HDD passwords via the ATA Security command set. In the pre-boot environment, it is required that the BIOS obtain the HDD password before the RST components are loaded.

C.2 Self-Encrypting Drives (SED)

Self-encrypting drives are supported by RST under three scenarios:

1. When SED's are treated as standard drives.
2. When SED's are enabled using HDD passwords, via the ATA Security command set, following the restrictions outlined in the [previous](#) section above.
3. When SED's are Opal or eDrive enabled, using 3rd party software, and following configuration and support outlined in Sections [Opal Drive Support](#) and [eDrive Support](#).

C.3 Solid State Hybrid Drives (SSHD's) with Encryption

SSHD's with encryption are supported by RST only if those drives can be treated as standard SSHD's.

C.4 RAID Volume and Drive Partition Encryption

RST supports encryption of volumes (including SRT), disks, and individual partitions by software encryption tools with the following restrictions:

1. Partition tables must remain unencrypted.
2. Approximately 6MB of non-partitioned space must be reserved, and remain unencrypted, at the end of the disk. This is the same as any configuration performing a create volume from an existing disk.

It is suggested that drives be encrypted before enabling SRT. This is to ensure that the SRT cache is populated with encrypted data.

