


Index

System Structure of the PS3710A demo unit	Pg 1
How to set up the demo system	Pg 2
System Settings	Pg 2
Additional software on the PS3710A	Pg 2
Additional folders & files	Pg 3
Other changes to the PS3710A	Pg 4
WinGP Settings	Pg 4
WinGP demo screen contents	Pg 5
Sales message of each screen (Customer benefits)	
Application examples	
Using the File Manager	Pg 25
Frequently Asked Questions	Pg 26
Screen Navigation	Pg 28

System Structure of PS3710A demo unit

- 1) PS3710A
 - Part No.: PS3710A-512-XP40 (*This unit is not PS3710A-1G-XP40-WG. We have installed WinGP manually)
 - The recovery CD supplied with the unit is the one that ships from Digital, it does not have WinGP or any other additional software.
 - This unit ships to you pre-loaded with WinGP, Pro-Server EX, and a demo application.
- 2) GP3200T
 - AGP3200-T1-D24
 - You should already have this unit
 - To demonstrate the connectivity features you will need the AGP3200 demo application that compliments the PS3710A WinGP demo
 - You will also need a cross over Ethernet cable



PS3710A <LAN2: 192.168.1.10> Note: Use **LAN2** Port

* To start this demo system correctly, start the AGP3200T first, wait for complete demo start up, and then start WinGP.



How to set up the demo system

- 1) If you are using the AGP3200T, connect the crossover Ethernet cable between the AGP3200T and the PS3710A (LAN2 port)
- 2) Turn on the PS3710A (<u>Do not</u> start WinGP yet)
 A) Select the "Pro-face America Login"
 B) Pro-Server EX will automatically load, check for the icon in the system tray (by the clock)
- 3) Turn on AGP3200T

Wait for the main screen (Menu screen) to load on AGP3200T, and then you can continue. There will be an error message on the AGP3200 (REAA002: Failed to write the device set)

- Double click WinGP on Desktop The error message on the AGP3200 will go away
- 5) Now the setup is finished.

* If you don't follow this order, this demo system might not work correctly.

Notes:

- 1. WinGP starts in window mode (not full screen), this is intentional so it will be more clear that it is running in Windows.
- 2. In window mode you will have a scroll bar on the right, sometimes the menu button will be off the bottom of the screen and you will need to scroll down.

System Settings

- PS3710A

Computer name: PFA

Computer description: Demo unit for sales activities includes WinGP, Pro-Server EX, GP-Viewer EX, etc

Administrator password: No administrator password

Domain: No domain settings

Do NOT register on line with Microsoft

Account name: Pro-face America

Time settings: Eastern Time (GMT-05:00) (You may need to adjust for your local time zone)

IP Address: LAN 1: 192.168.1.11

LAN2: 192.168.1.10

- GP3200T

IP Address: 192.168.1.1 (you will need to set this up by yourself)

Additional software on the PS3710A

- 1) Adobe Reader 8.1.0
- 2) GP-Pro EX V2.10



- Editor
S/N: 35821030005
Key code: 1000-2102-0498
- Transfer Tool
- Project converter
- GP-Viewer EX
Key code for WinGP + GP-Viewer EX (server):7979-0394-9694
- WinGP
Key code: 7060-3803-0215

These key codes and serial numbers are to be used with this demo only

- 3) Pro-Server EX V1.10 + Patch (Pro-Server EX V1.21)
 - Developer & Runtime

S/N: 35548630038 Key code (Developer): 9214-7160ED-6675 Key code (Runtime): 5414-8347RT-6223

These key codes and serial numbers are to be used with this demo only

* Pro-Server EX is registered to start-up.

To change this setting, execute Pro-Studio EX and select "Setting" -> "Pro-Server EX Environmental Setting". Then you can see following settings.

🕸 Pro-Server EX Environment Settings	\times
Start Pro-Server EX as a service	
✓ Start Pro-Server EX when PC starts	
The Network Project to be automatically loaded when Pro-Server EX starts	
Network Project File	
C:\temp\GP3200T_WinGP demo.npx Browse	
☑ Show Pro-Server EX icon on the task tray	
DDE Polling Cycle 1000 ms	
ACTION Registration OK Cancel	

Additional folders & files

- 1) PS3710A related Manual <C:\temp\PS3710A>
 - Data sheet
 - Hardware Manual
 - Reference Manual



- Installation Guide
- Cutout Dimension
- API Reference Manual
- 2) WinGP Project file & CF-card folder < C:\temp\WinGP Sales Demo v210>
 - WinGP Sales Demo v210.prx
 - WinGP Sales Demo v210
 - * You need "GP-Pro EX V2.10" to edit this project
- 3) GP3200T Project file < C:\temp>
 - GP3200T_Demo20090928.prx
 - * You need "GP-Pro EX V2.10" to edit this project
- 4) Pro-Server EX Network Project file < C:\temp>
 - GP3200T_WinGP demo.npx
 - * You need "Pro-Server EX V1.20" to edit this project

Other changes

- 1) On-Screen Keyboard
 - Added keyboard tool on Desktop from <"Start" -> "Programs" -> "Accessories" -> "Accessibility" -> "On-Screen Keyboard">
- 2) System Monitor Property
 - Added System Monitor Property Tool on Desktop from <"Control Panel"-> "System Monitor Property">

WinGP Settings

System folder settings


- 1) CF Card C:\Program Files\Pro-face\WinGP\Temp\CF
- 2) SRAM

C:\Program Files\Pro-face\WinGP\Temp\SRAM



WinGP Demo Screen Contents

Company Profile





Screen 105 – Worldwide Sales & Support offices	
Pro-face has sales & support offices all over the world.	Pro-face Company Profile
When you export your equipment, we can support it.	Worldwide Sales & Support
And if you need products in the country you have shipped your machine to, we can provide them from our overseas offices.	Voline Sales & Support
	18 Sales Offices all over the world
	To Sales Olinces all over the world
Screen 106 – Worldwide Support Services	
If exporting product is part of your business, Pro-face offers the	Pro-face Company Profile 🧇 🔿 🏠
same services, from sales and support to training and repair wherever you buy a Pro-face HMI.	Worldwide Support Services
Wherever you deploy a Pro-face panel you have local replacement parts and support in the local language in place.	Telephone Support, Local languages, Entright and Japanese support
PFA has customer support via email or Phone (8am to 6pm Eastern M-F)	Sharing debal support information On-line WEB Support Solution offers Training Seminars
Repair in the US is usually 5 days or less with online tracking	
Note: To get back to the above 5 screens, you must restart the de	mo. You can use the "Exit WinGP" button
on the main menu or the "Restart WinGP" button under Applicati	
Screen 902– Main Menu V2.10	
Gives access to the 6 major portions of the Sales Demo:	Main Menu
Note that many of the GP-Pro EX features are found under the "Applications" button	Win6P RAS Functions
From here you can launch Adobe Acrobat and view the Data Sheet, Hardware manual and Reference Manual (emphasize that these are external applications that can be started from WinGP)	GP-Pro EX Pro-Server EX Applications GP-Viewer EX
A button is provided if you want to exit WinGP	Execute P53710A Related Hanual Data Sheet Hardware Manual Reference Manual 10/(0/01 (www) 01.vi)



"WinGP" Button on Main	Menu
Screen 2002 – WinGP	
WinGP gives the PS3710A the ability to run HMI projects developed in GP-Pro EX on a Microsoft Windows XP operating system.Today Pro-face America only supports WinGP on a PS3710A running XP. Other configurations are possible.The next screens will highlight the various connectivity options.	<section-header><section-header><section-header></section-header></section-header></section-header>
 Screen 2000 – WinGP, what can connect? Connectivity you would expect Ethernet (see screen 2001 below) Serial : PLCs, Temperature Controllers, Drives (By Modbus RTU and other protocols), screen downloads USB : Memory stick (logging), printers, bar code readers, screen downloads Compact flash: Images, logging, screen downloads 	Pro-face WinGP (C)
Screen 2001 – WinGP Ethernet Interface	
 By using Ethernet WinGP can: Communicate with PLCs Communicate with Drives (via ModbusTCP or other protocols) Receive screen downloads from GP-Pro EX Use Remote Connection Tools Pro-Server EX GP-Viewer EX 	Pro-face Ethernet interface WinGP can communicate with PLC, PC. File Ethernet 1/F File
Screen 237 – WinGP Connectable Device List By touching "Connectable Devices, PLCs and Controllers" button you can see a list of drivers (serial and Ethernet) available in WinGP	Close WinGP Connectable Device List Name of the prestary Strivers Name of the prestary Strivers Drivers All Brivers
This list contains drivers that will be added through the end of December, 2007. Depending on when you are using this demo some of the drivers may not be available yet or more may be available, please check the website for the most current list of drivers (<u>http://www.pro-face.com/plc_connect/</u>)	REIGERIANE - NERVS Controller MOBUS SID Digital Electronics Corporation - Controller Corporation - General Ethernet - Memory Link Fance Ltd. - PowerMate Series Fatet
See the FAQ Section for Drivers not supported by WinGP	Rectard Lattice Tay Tayor 1613 (197



Screen 236 – Rockwell Native Tag (L5K import)	
By touching "Rockwell Native-Tag, Import Utility" you can see a high level description of importing "Native Tags" from the RSLogix5000 software	Rockwell Tag Data (*.L5K) Import
Screen 232 – Serial Interface	
 By using Serial ports WinGP can: Communicate with PLCs Communicate with Drives (via Modbus RTU or other protocols). Several drives have been tested by using the Modbus RTU driver ABB, Rockwell, Hitachi, Yaskawa have passed the evaluation test (some models) For more details, please check Otasuke Library for models. Note: Download via serial or modem is NOT supported on WinGP Rockwell PLC Native Tag Drivers are supported; Tag Import 	Pro-face Image: Controller's drivers Serial interface Image: Controller's drivers Image: Controller's drivers Image:
Utility is also supported (L5K file import). For more detailed info, please contact Pro-face support For the latest updates visit <u>www.pro-face.com/otasuke</u>	
Screen 241 – Simultaneous Multi-Protocol WinGP can communicate with up to 4 different protocols simultaneously Note: this does not mean 4 PLCs as you can use up to 32 PLCs for some protocols Note: The 3.8" & 5.7" AGP3000s can use up to 2 drivers, and others are up to 4 drivers.	Pro-face Communications capability WinGP can Communicate with up to 4 different type of controllers simultaneously



Screen 231 – USB Interface	
By using USB WinGP can:	Pro-face WinGP 🧔 🔿 🏠
Communicate with Barcode Readers	USB interface
Printers	WinGP can communicate several kinds USB devices
 USB Memory (3rd party devices are supported) (can also be used as a local drive): Data Logging Recipe Data Trend Data Alarm Logs Movies JPEGs USB Card readers (for CF card only, not SD, or Sony Memory stick or others) 	USB Bercode Render : How built Product(11 Step), Symbol(15348072-7220005) How built Printer DSB Printer DSB Printer DSB Printer DSB Printer DSB Printer DSB Stepart State Printer DSB Stepart Printer DSB Stepar
Download from GP-Pro EX using CA3-USBCB-01	
Screen 233 – Other Interfaces	
 CF card can be used for (can also be used as a local drive): Data Logging Recipe Data Trend Data Alarm Logs Movies JPEGs Sound output can be used to: Announce Alarms Give operators instructions 	Compact Flash Card Compact Flash Card Compac
Screen 2003 – WinGP What are the Benefits?	
Many customers have their own applications, WinGP can communicate with them usually without big changes WinGP can share information with other 3 rd party applications Visual Basic, Visual C#, Visual C++, and C#. (mention all, this detail matters) This can allow users to get data in and out of WinGP to their applications, when they need it.	Pro-Face WinGP What are the WinGP Depending Image: Comparison of the state of t



Screen 2005 – WinGP Application Example 1	
The PC can be used for other tasks, for example Motion Control, or Vision Software. WinGP can share data with these applications and be the Operator Interface when needed.	Pro-face WinGP (In the second
Screen 2006 – WinGP Application Example 2	
WinGP can collect data from several AGPs or even PLCs directly, it can send the data to an upper level system, acting as a "Gateway" or "data concentrator"	Pro-face WinGP Application Example #2 Data management Gateway Collect field data, report, share & manage the current status and progress Free Server EX WinGP WinGP WinGP WinGP WinGP WinGP Collect field data, report, share & manage the current status and progress
"GP-Pro EX" Button on Ma	in Menu
Screen 300 – GP-Pro EX Overview	
 The screen list, dock able workspaces and function windows and tab based screen selection make for a very easy to use editor interface. The 6 step main toolbar guides you through (1) System Settings, (2) Screen Editing, (3) Preview, (4) Simulation (5) Download and optional (6) Ladder monitoring. Note: that the preview function shows a static image. 	<section-header></section-header>
Note: This is an overview of GP-Pro EX not WinGP	
Screen 301 – GP-Pro EX Workspace The screen thumbnails can be double clicked to open individual screens for editing (Screen List) Address Mapping Drag any register from the address list onto an object to easily add or replace an address. Red items in the list indicate the address is currently being used in the application.	<section-header><section-header><section-header><section-header><section-header><section-header><section-header></section-header></section-header></section-header></section-header></section-header></section-header></section-header>



Screen 302 – GP-Pro EX Helpful Tool	
Auto Document The images in this document were created by using our Project / Print function, when send to Rich Text File (RTF) all project data including all screen shots can be edited in MS Word or similar text editors. This feature makes it very easy to create comprehensive operation and maintenance manuals. Any item (like ladder logic or cross reference lists) can be printed to printer instead of a file as well. The Helpful Tools section 3 screens, use the Next and Prev buttons to navigate. Newly added tools are:	<section-header></section-header>
Parts Tool box (V2.0) and Color picker tool. These make it easy to select & place parts & change colors visually.	
Screen 303 – GP-Pro EX Efficient Tool	
Templates: an OEM can make templates for the most comprehensive machine and register any of the parts in that project as a template for use on similar machines saving time and providing a consistent look. The Header & Footer function help quickly create title and menu bars with great ease of use to provide a consistent look across all project screens. A "Package" (library in GP-Pro C03) can be used to store a group of objects in order to reuse it in different projects. These "packages" show up on the toolbar as an icon with tooltip. (also in workspace in V2.1)	<section-header></section-header>
Screen 521– GP-Pro EX Address Mapping	
The Address Mapping window gives you a graphical representation of what PLC or Internal Memory addresses you have used in your Pro-face HMI application by highlighting used addresses in Red. View Integer or Discrete registers and simply drag any address from the Mapping window onto an object to assign its address without the possibility of making a typing mistake. This tool is a great addition to the GP-Pro EX Cross Reference function that is also available for your use.	Pro-face GP-Pro EX Image: Comparison of the second se
You can also drag and drop colors onto objects and variables from logic to the screen	




Screen 310 – GP-Pro EX Drawing Objects	
The table part allows you to easily create a table like grid display without having to draw multiple lines. Note: this part is not linked to data in any way, you can use it to create individual data displays in each of the table's "cells"	Pro-face GP-Pro EX Variety of Drawing Objects Dot Polyline Arc/Pie Folygon Rectangle Circle/Oval Table
 Screen 311 – GP-Pro EX Image The Image File screen shows that images can be included in the project in several ways: Image Placement, an image is selected and placed on a screen directly without assigning a number to it. A transparent color can now be selected when using Image Placement. Image Registration, Images are assigned a number and can be stored in either Internal Memory (project memory) or on a CF Card folder. New image features include: Pasting directly from Windows clipboard onto screen Transparent RGB color selection by eyedropper tool 	<section-header><section-header><section-header><section-header><section-header><section-header><section-header><section-header><section-header></section-header></section-header></section-header></section-header></section-header></section-header></section-header></section-header></section-header>
Powerful D-Script can be used on a single screen or as a global script, regardless of the screen that is being displayed Create your own functions by using math, loops and if/else statements.	Pro-face GP-Pro EX Image: Constraint of the state of the stat
 Screen 413 – More Scripting D-Script has powerful functionality Drawing objects on the screen Create your own ASCII communications Use scripting to manage files directly 	Pro-face GP-Pro EX More Scripting is available Drawing Command You can draw objects on the screen by using Script & PitC value data. (Det, Line, Rectangle, Circle, call screens) SID Communication Command Control Stop ort by Script, You can create a "Communication Protocol" for Control devices using ASCEIT (Label setting, Send, Kreetve) File Operation You can anage files in the PfC. (Delste, Lint, Read, Write, Change same, Label setting)




Screen 553– GP-Pro EX Simulation Simulate the screen on the PC, PLC values can be set by using the built-in tool. Logic Simulation is now supported. (Note: WinGP does not support logic) Save development time by testing without downloading. Continue developing even when you don't have the PLC or the AGP nearby	Pro-face GP-Pro EX Simulation easy debug on your Lapton No need to download. Debug without PLC.
Screen 554– Multi-Platform	
 GP-Pro EX supports more than 40 units From 3.8" to 15" displays With or without control With or without Ethernet With or without Multi-media Dedicated HMI or WinGP on Windows based IPC Click on the button to see the supported protocols 	<section-header><section-header><section-header><section-header><section-header><section-header><section-header><section-header><section-header></section-header></section-header></section-header></section-header></section-header></section-header></section-header></section-header></section-header>
"Applications" Button on Ma	ain Menu
Screen 801 – Application Example Boiler flow application Several nice looking tank parts, pipes, valves and 7 segment numeric displays. Notice the buttons at the bottom of the screen, you may need to scroll down if running WinGP in "window" mode Screen 801 – Application Example + Parts	
This screen displays some of our pre made Switch and Lamp parts including 2 state pumps, motors, blowers, valves and tanks. Symbolic parts are a great way to convey a message that is understood in any language. Symbolic Parts & Sign Images (Warning) can be used on lamps or switches. It also shows how you can make you own switches using your own images for up to 16 button states + an interlock state. (Touch any object to change states)	Pro-fice Pro-fice Pro





































Screen 2104 – RAS Example 3	
This example show a networked connection Connect to multiple PS3710As simultaneously and see the status of each on a PC. The PC could be in a central location or in a control room or in an office	Pro-face RAS Functions Application Example #3 Remote RAS Monitor (n to 1) Remote RAS Monitor (n to 1) Complex and the provide monitor (n to 1) Support and the provide monitor (n to
Screen 2108 – RAS Remote Shutdown	
By using this feature the PS3710A units can be shutdown when they are not needed. This can • save power (electricity costs) • improve security • extend the life of the PC	<section-header><section-header><section-header><section-header></section-header></section-header></section-header></section-header>
"Pro-Server EX" Button on M	ain Menu
Screen 560 - Pro-Server EX what is it?Pro-Server EX is a "Data Collection and Sharing" software package.Pro-Server retrieves data from AGP's over an Ethernet network to either process it for logging, emails, recipe handling or to share it with other PC software packages.There is no tag limit in Pro-Server EX and one runtime license can be used to poll all AGP on the plant floor.	Pro-face Pro-Server EX What is Pro-Server EX? Expand Your Operator Interface Capabilities with Data Management feliection & sharing of factory floor data throughout an enterprise WindP
Screen 561 – Pro-Server EX Benefits Use Pro-Server EX to collect data and share the data with applications such as Access Databases, ODBC Databases, and Excel Sheets for storage or to automatically generate reports. Several Actions in Pro-Server EX help you quickly setup these data sharing connections and the way (trigger, time, event base) that you want to execute these functions. This <u>low cost gateway between Office and Plant environments</u> is a very powerful addition to the AGP with GP-Pro EX	Pro-face Pro-Server EX What are the Pro-Server EX Benefits? Cost effective solution for data connectivity with 3rd party applications



New: OPC Server and MES Actions are available in			
Pro-Server EX V1.20 and above Screen 2110 – Pro-Server EX Benefits			
This screen shows some of the Benefits and connectivity of Pro-Server EX. To fully demonstrate this functionality you will need to connect your AGP3200T and have the supplied demo application loaded to it. When connected via an Ethernet connection (via crossover cable or via a hub/switch) the excel spread sheet	Pro-face Pro-Server EX What are the Pro-Server EX Benefits? Substantiation of the server of the		
represented on this page will update with values from the AGP3200T. On the AGP3200T main menu, touch the "Temp. Monitor App."	Image: transmission of the state of the		
Button. Once on this screen you can change the Room no. 1, 2 or 3 temperature and see it reflected on the excel sheet represented in the WinGP application. Some of the benefits of Pro-Server EX include:	GP3200T		
 Easy setup – reduces development time Cost effective – inexpensive data collection Send data where you need it – no need to walk to the machine, collect data on a clipboard and walk back to your office, then type it into Excel. 	O Data Display O Engine Monitor App. O Message Display O Temp. Monitor App. O Logging O Indicator App. O Alarm O Temp. Control App.		
	Temp. Monitor room no.1 80.0 com no.2		
Screen 2111 – Pro-Server EX Benefits	70.0 ℃ 3F 70.0 ℃ 2F 1F		
Pro-server EX allows data sharing between an AGP and WinGP			
By using this feature an end user can benefit by sharing data from one PLC manufacturer and other brands without the need for expensive external converters.			
This can be demonstrated by using the AGP32000T and the Error Monitor screen. This shows data sharing between the AGP3200T and the WinGP PS3710A			







"GP-Viewer EX" Button on Main Menu

Screen 563 – GP-Viewer EX By using GP-Viewer EX you can see the AGP3000 screen on Pro-face **GP-Viewer EX** your PC remotely. What is GP-Viewer EX? (Part 1 of 2) View & interact with your operator interface screen from a remote computer servers & 1 client Applicati Client/Server Application Customer needs to purchase a license for each server (AGP3000). The client (PC) is free, but you need to install GP-Viewer EX from GP-Pro EX CD or download it from the Otasuke Pro web site. r EX-button file" & highlight 192 168 1 1 «AGP3200T» rode ode any ID & Password+, <tread 1 server (AGP3000) can publish screen data to 3 clients (PC) ode D ofs I at once. 1 Client (PC) can see 4 different servers (AGP3000) at once. The client PC can operate screen change, switches, value changes. Functionality depends on setup. Security can be enabled for the remote client PC too. If the AGP3200T is connected, you can press the "Run GP-Viewer EX button and see the AGP screens. You may need to reduce or minimize windows to see the GP-Viewer window Screen 567 – GP-Viewer GP-Viewer EX is a client/server application. Pro-face **GP-Viewer EX** What is GP-Viewer EX? (Part 2 of 2) The server runs on the Operator interface View & interact with your operator interface screen from a remote computer ver & 3 clients Applicat GP-Viewer EX (Clie The client runs on the PC PS3710A (WinGP) Newer EX* button with a Ne* & highlight 192 168 1 1 <AGP3200T> r succtors* de any ID & Pas



Screen 564 – GP-Viewer EX Benefits	
 Benefit for the Machine Builder (OEM), reduce travel time and cost. Troubleshoot symptoms without traveling to the customer site Benefits for the End User Maintenance personnel can understand what is needed to get the machine running quickly. If they are notified of the type of fault that stopped a machine, they can arrive with the correct tools or materials to get the machine running quickly Reduce downtime 	<section-header><section-header><section-header><section-header><section-header><section-header><section-header><section-header></section-header></section-header></section-header></section-header></section-header></section-header></section-header></section-header>
Screen 565 – GP-Viewer EX Example 1	
End users can remotely monitor various status and conditions from a central location. This reduces the need to walk to several HMI locations in a large installation. Machine builders can offer improved technical support and value added services for their end customer	<section-header><section-header><section-header><section-header><section-header></section-header></section-header></section-header></section-header></section-header>
Screen 566 – GP-Viewer EX Example 2	
GP-Viewer EX can eliminate the need to put the user in harms way. If the operator does not need to be in a hazardous location, give them a way to resolve issues without being at risk. Reduce exposure to chemical, environmental and biological liabilities	Pro-face GP-Viewer EX Application Example #2 Improve Safety of Operations For Safety of Opera

Using the File Manager

On any File Manager screen click navigate the folders by using the up and down arrows. Folders are shown as <DIR>; to display the contents of a folder use the "DISP" or "=" button (depending on the file manager used)

Different files (Log, Recipes, etc) are stored in different default folders and under default names. Note that files that were copied without using GP-Pro EX (by using a card reader with Windows Explorer for example) do not have to follow any predefined naming format.



If you are trying to locate log data or event recorder data keep in mind that you have to save this data at least once using the applicable screen in the demo application, if for example the "ALARM" folder does not show up in your File Manager you will have to go to any of the alarm screens first to save an Alarm Log file. This will automatically create the folder if needed.

Fig. 2a	Fig. 2b	Fig. 2c
\mathbf{X}	×	
SAMP02 <dir></dir>	CF SAMP02 <dir></dir>	CF USB BOOT. CFG
CAPTURE <dir></dir>		CAPTURE <dir></dir>
FILE <dir></dir>		DATA <dir></dir>
JPEG <dir> DISP</dir>	JPEG <dir></dir>	JPEG <dir></dir>
MOVIE <dir></dir>	PLAY DATA <dir></dir>	MEM3X50. CML
DATA <dir></dir>		MOVIE <dir></dir>
		OPLOG <dir></dir>
DATE:06/09/11 10:12	DATE : 06/09/11 10:12 SIZE : <dir></dir>	
SIZE: <dir></dir>		CUT COPYPASTE DISP ALL DEL TO 1

Figures 2a through 2c show some of the different available file managers, note that the file manager in Fig. 2c can be used to transfer data between USB Memory and CF Card folders, both File Managers displayed in Fig. 2a and 2c can be used to delete files. (See Key Features, Connect Devices, CF <> USB). Note, the files and folders may have different folders available when run on WinGP or AGP units.

File locations used in the demo:

Alarm Summary Active	:	\ALARM\Z1#####.CSV
Alarm Summary History	:	\ALARM\Z2#####.CSV
Alarm Summary Log	:	\ALARM\Z3#####.CSV
Logging Data (Cycle)	:	\SAMP02\SA#####.CSV
Logging Data (Trigger)	:	\SAMP03\SA#####.CSV
Logging Data (Time)	:	\SAMP04\SA#####.CSV
Recipes (Proprietary)	:	\FILE\ZR#####.CSV
Pictures	:	\JPEG\file name.JPG
Screen Captures	:	\CAPTURE\#.JPG
Operation Log	:	\OPLOG\OLdate\OLtime.CSV

Frequently Asked Questions

- Q: How do I show our capability of Native Tag Import Utility (L5K file import) to my customer?
- A: 1) Open GP-Pro EX and create a new project
 2) Add the Rockwell Automation, Inc EtherNet/IP driver
 Click "Communication Settings"
 Click "Device/PLC 1"
 4) Click the [Settings] button after "PLC1" and select "ControlLogix/CompactLogix Series Native"
 5) Click [Import]
 - 6) Now you can import the L5K file format.



Q: What are the differences between GP-Pro EX on a PC (WinGP) vs. an AGP?

	WinGP	AGP
Multi Media (movie record / playback)	No	Yes
AGP Logic	No	Yes
Programming Memory	16 Mb	8 Mb
Backup Memory (SRAM)	5 Mb	512 Kb
Supported by Pro-Server EX	Yes	Yes
Pro-Server EX API Available	Yes	Yes
Start Windows Application by Script or Switch	Yes	No
Error Log (communication)	Yes	No
Printer operations using D-Script	No	Yes
Address Monitor	No	Yes
FTP Server	No	Yes
Web Server	No	Yes
Pass Through Feature	No	Yes
AB EtherNet/IP (Including Native Tag)	Yes	Yes
AB DH485	No	Yes
Modbus Slave (SIO & TCP)	Yes	Yes
Modbus Plus	No	Yes
DeviceNet Slave	No	Yes
Siemens S7 MPI	No	Yes
Profibus Slave	No	Yes



Screen Navigation

Company Profile Introduction Brand awareness History of PFA business in North America No. 1 Market Share in the World Worldwide Sales & Support Worldwide Support Services Main Menu WinGP What is WinGP? Connectivity overview WinGP Ethernet Interface WinGP Connectable Device List Rockwell Native Tag (L5K import) WinGP Serial Interface Simultaneous Multi-Protocol **USB** interface Other Interfaces - CF card and Sound What are the benefits of WinGP WinGP Example 1 WinGP Example 2 **GP-Pro EX GP-Pro EX Overview GP-Pro EX Workspace** GP-Pro EX Helpful tools **GP-Pro EX Efficient tools** Address Mapping (drag and drop colors, and variables too) Drawing objects Images Scripting More Scripting Simulation Multi-Platform **GP-Pro EX** Application Example 1 Parts library Symbol library Password protection Multi language Multi function switch Alarm Trends **Application Example 2** Logging Graph Meter Word Switch Bit switch Special switch Numeric display Image import Recipe Security lock Message display Operation Log **Execute Application RAS Functions** What is RAS? **RAS System Monitor**



RAS Benefits RAS Example 1 RAS Example 2 RAS Example 3 RAS Remote Shutdown

Pro-Server EX

What is Pro-Server EX? Pro-Server EX Benefits 1 of 3 Pro-Server EX Benefits 2 of 3 Pro-Server EX Benefits 3 of 3 Pro-Server EX Example 1 Pro-Server EX Example 2

GP-Viewer EX

What is GP-Viewer EX 1 of 2? What is GP-Viewer EX 2 of 2? GP-Viewer EX Benefits GP-Viewer EX Example 1 GP-Viewer EX Example 2