

Main Unit

Product Name		Model No.	Global Code
LT3000 Series	LT-3201A	LT3201-A1-D24-K	PFXLT3201AADK
		LT3201-A1-D24-C	PFXLT3201AADC
	LT-3300L	LT3300-L1-D24-K	PFXLT3300LADK
		LT3300-L1-D24-C	PFXLT3300LADC
	LT-3300S	LT3300-S1-D24-K	PFXLT3300SADK
		LT3300-S1-D24-C	PFXLT3300SADC
	LT-3301L	LT3301-L1-D24-K	PFXLT3301LADK
		LT3301-L1-D24-C	PFXLT3301LADC

Software

" ** " is changed with the version of software.

Product Name	Model No.	Global Code
GP-Pro EX	EX-ED-V**	PFXEXEDV**
	EXEDV**	PFXEXEDV**
GP-Pro EX Editor-License	EX-ED-LICENSE-V**	PFXEXEDLSV**
Pro-Server EX Developer	EX-SDV-V**	PFXEXSDVV**
Pro-Server EX Developer License	EX-SED-LICENSE	PFXEXSDLS
Pro-Server EX Runtime License	EX-SRT-LICENSE	PFXEXSRLS
MES Action License	EX-MES-LICENSE-V**	PFXEXMSLSV**

EX Module, CANopen Unit

Product Name	Model No.	Global Code
8-point Input Module	EXM-DDI8DT	PFXZLTEUDDI8DT
16-point Input Module	EXM-DDI16DT	PFXZLTEUDDI16DT
8-point Relay Output module	EXM-DRA8RT	PFXZLTEUDRA8RT
16-point Relay Output module	EXM-DRA16RT	PFXZLTEUDRA16RT
8-point Shink Output module	EXM-DDO8UT	PFXZLTEUDDO8UT
16-point Shink Output module	EXM-DDO16UK	PFXZLTEUDDO16UK
8-point Source Output module	EXM-DDO8TT	PFXZLTEUDDO8TT
16-point Source Output module	EXM-DDO16TK	PFXZLTEUDDO16TK
4-Point Input/ 4-Point Reley Output Module	EXM-DMM8DRT	PFXZLTEUDMM8DRT
16-Point Input/ 8-point Relay Output Module	EXM-DMM24DRF	PFXZLTEUDMM24DRF
2-ch Analog Input Module	EXM-AMI2HT	PFXZLTEUAMI2HT
2-ch Thermocouple Pt100 Input/ 1-ch Analog Output Module	EXM-ALM3LT	PFXZLTEUALM3LT
2-ch Analog Input/ 1-ch Analog Output Module	EXM-AMM3HT	PFXZLTEUAMM3HT
1-ch Analog Output Module	EXM-AMO1HT	PFXZLTEUAMO1HT
4-ch Analog Input/ Thermocouple Input Module	EXM-AMI4LT	PFXZLTEUAMI4LT
2-ch Analog Output Module	EXM-AVO2HT	PFXZLTEUAVO2HT
4-ch Analog Input/ 2-ch Analog Output Module	EXM-AMM6HT	PFXZLTEUAMM6HT
8-ch Thermocouple Pt100/ Pt1000 Input Module	EXM-ARI8LT	PFXZLTEUARI8LT
CANopen Master Unit	CA8-CANLT-01	PFXZC8EUCA1
CANopen Slave HTB Unit	HTB1CODM9LP	PFXHTB1CODM9LP

Options

Product Name		Model No.	Global Code
RS-232C Cable	5m	CA3-CBL232/5M-01	PFXZC3CBR251
RS-422 Cable	5m	CA3-CBL422-01	PFXZC3CBR452
RS-422 Cable (For a Unit of Terminal Resistance 100 Ohm)	5m	CA3-CBL422/5M-01	PFXZC3CBR451
COM Port Conversion Adapter		CA3-ADPCOM-01	PFXZC3ADCM1
Terminal Block Conversion Adapter		CA3-ADPTRM-01	PFXZC3ADR41
RS-232C Isolation Unit		CA3-ISO232-01	PFXZC3ADISR21
USB Transfer Cable	2m	CA3-USBCB-01	PFXZC3CBUSA1
USB Cable	5m	FP-US00	PFXZC0CBUS1
USB Front Cable	1m	CA5-USBEXT-01	PFXZC5CBUBEX1
USB Serial (RS-232C) Conversion Cable	50cm	CA6-USB232-01	PFXZC6CBCVUSR21
Screen Protection Sheet	For 3.8 Inch	CA6-DFS4-01	PFXZC6DS41
	For 5.7 Inch	CA3-DFS6-01	PFXZC3DS61
Environmentally- resistant Cover	For 5.7 Inch	CA4-DCMDL-01	PFXZC4CNDCM1
Panel Cutout Adapter	For 5.7 Inch	CA4-ATM5-01	PFXZC4AT61
Industrial HUB		SPIDER8TX-PRO	PFXSPIDER8TXPRO

Maintenance Options

Please purchase when the products is damaged or lost.

Product Name		Model No.	Global Code
Installation Gasket	For 3.8 Inch	ST400-WP01	PFXZSTWG41
	For 5.7 Inch	CA3-WPG6-01	PFXZC3WG61
USB Cable Clamp	For 3.8 Inch	CA5-USBATL-01	PFXZC5CLUSBL
	For 5.7 Inch	CA7-USBAT6-01	PFXZC7CLUSB1
DC Power Supply Connector	For 5.7 Inch	CA5-DCCNM-01	PFXZC5CNDCM1
Installation Fastener		CA3-ATFALL-01	PFXZC3AT1
DIO Connector	For 3.8 Inch	CA6-DIOCN4-01	PFXZC6CNXY181
	For 5.7 Inch	CA7-DIOCN5-01	PFXZC7CNXY321
MIL Connector (20-pins) for EX module		CA6-EXMCNHE20P-01	PFXZC6CNEXHE201
Terminal Connector (10-pins) for EX module		CA6-EXMCNRS10P-01	PFXZC6CNEXRS101
Terminal Connector (11-pins) for EX module		CA6-EXMCNRS11P-01	PFXZC6CNEXRS111
EX Module Securing Hook	For 5.7 Inch	CA7-FIXEXM-01	PFXZC7CLEXM1
DIO Connector for HTB		CA7-HTBCNSET-01	PFXZC7CNHTB1