


# Reduce downtime by checking status from outside.

## Before

In order to check a state of occurring alarms on a paint line, I have to get changed into my work clothes and enter the site. After checking it, I come out to get tools needed for recovery and go back. It takes time to change clothes.



with Pro-face Remote HMI

## After

Check camera images and status of equipment from outside. Understand the situation and get necessary tools available before going to the paint line. Decrease the frequency of coming and going in order to reduce downtime




Remote Monitoring is available with tablet and Wi-Fi network

For details of the product, see the other side.


# System Configuration

Pro-face Remote HMI is remote monitoring software for mobiles and it allows you to check equipment information on a tablet or a smart phone.



## Application

With only installing Pro-face Remote HMI application, you can start Remote monitoring.



### Global Headquarters

Tel: +81 (0)6 6613 1101  
info@pro-face.com

### South-East Asia Pacific

Tel: +66 (0)2 617 5678  
pfsales@proface.co.th

### European Headquarters

Tel: +31 (0)23 55 44 099  
info@proface.eu

### Italy

Tel: +39 (0)362 59 96 1  
info@proface.it

### China

Tel: +86 (0)21 6361 5175  
proface@proface.com.cn

### India

Tel: +91 80 4333 3540/3541  
sales.proface@proface.co.in

### France

Tel: +33 (0)1 60 21 22 91  
info@proface.fr

### Denmark

Tel: +45 70 22 01 22  
info@proface.dk

### Singapore

Tel: +65-6832-5533  
info@proface.sg

### Australia and New Zealand

Tel: +61 (0)3 9550 7396  
pfau@pro-face.com

### Austria

Tel: +43 7236 3343 620  
info@proface.at

### Sweden

Tel: +46 46 540 90 70  
info@proface.se

### South Korea

Tel: +82 (0)2 2630 9850  
proface@proface.co.kr

### North America

Tel: +1 734 477 0600  
info@profaceamerica.com

### United Kingdom

Tel: +44 (0)2476 511288  
info@proface.co.uk

### Switzerland

Tel: +41 (0)43 343 7272  
info@proface.ch

### Taiwan

Tel: +886 (0)2 2657 1121  
proface@proface.com.tw

### Germany

Tel: +49 (0)212 258 260  
info@pro-face.de

### Spain and Portugal

Tel: +34 (0)93 846 07 45  
info@proface.es