

GP3000 Series

ATEX Instruction Guide

www.pro-face.com

Concerning the use of GP3000 Series for applications in potentially explosive atmospheres (Zones 2/22, equipment category 3 Gas Dust)

Digital Electronics Corporation
4-4-9 Kitahama, Chuo-Ku, Osaka-Shi,
Osaka, 541-0041 JAPAN

Type examination certificate: INERIS 07ATEX3003X and Additions 01/02

SAFETY INSTRUCTIONS

Read these instructions carefully, and look at the equipment to become familiar with the device before trying to install, operate, or maintain it. The following special messages may appear throughout this documentation or on the equipment to warn of potential hazards or to call attention to information that clarifies or simplifies a procedure.



The addition of this symbol to a “Danger” or “Warning” safety label indicates that an electrical hazard exists which will result in personal injury if the instructions are not followed.



This is the safety alert symbol. It is used to alert you to potential personal injury hazards. Obey all safety messages that follow this symbol to avoid possible injury or death.



DANGER

DANGER indicates a hazardous situation which, if not avoided, will result in death or serious injury.



* N V E 7 4 7 3 7 0 0 *

The information in this document is subject to change without notice.

Copyright © 2016.05 Digital Electronics Corporation.

All Rights Reserved.

NVE74737 00

Printed in

Pro-face

by Schneider Electric

 WARNING

WARNING indicates a hazardous situation which, if not avoided, could result in death or serious injury.

 CAUTION

CAUTION indicates a hazardous situation which, if not avoided, could result in minor or moderate injury.

<i>NOTICE</i>

<i>NOTICE</i> is used to address practices not related to physical injury.

DISCLAIMER

All work relating to installation, assembly, connection, setup, maintenance and repair of the equipment must be performed by approved staff, qualified in the appropriate skills. No liability is assumed by Digital Electronics Corporation for any consequences arising out of the use of this product. This document is not intended as an instruction manual for untrained persons. These products must not be used for functions other than those for which they are designed. Liability for manufacturer traceability is only ensured at the first known delivery destination (serial number specified on the product label).

Relevant Standards

These devices have been manufactured in accordance with:

- Standard EN 60079-0 (2009) and IEC 60079-0 Ed6 (2011): Explosive atmospheres - Part 0: Equipment - General requirements.
- Standard EN 60079-15 (2010) and IEC 60079-15 Ed4 (2010): Explosive atmospheres - Part 15: Equipment protection by type of protection “n”.
- Standard EN 60079-31 (2009) and IEC 60079-31 Ed1 (2008): Explosive atmospheres - Part 31: Equipment dust ignition protection by enclosure “t”.



DANGER

POTENTIAL FOR EXPLOSION

Install, use, and maintain these modules in accordance with:

- Standard IEC 60079-14 Ed4 (2007): Explosive atmospheres - Part 14: Electrical installations design, selection and erection.
- Standard EN 60079-17 (2007): Inspection and maintenance of electrical installations in hazardous areas.
- Standard EN 61241-14 (2004): Electrical apparatus for use in the presence of combustible dust, Part 14: Electrical apparatus protected by enclosures. Selection, installation and maintenance.
- Edicts, by-laws, laws, directives, circulars, standards, regulations and any other document relating to where the apparatus is installed.

Failure to follow these instructions will result in death or serious injury.

Relevant products

These recommendations relate to graphic panels intended for installation in areas where explosive atmospheres may occur (Zones 2/22) for Category 3G or 3D equipment (Category 3: normal level of protection - G: Gas - D: Dust).

Permitted zones of application

With regard to the "Relevant Standards" section above, the following permitted zones of application are allowed:

- The GP-3200 series may be installed in Zones 2/22, II (surface industries), category 3 (normal level of protection), G (Gas) D (Dust), IIC (groups of gases), T4 (T135 °C maximal surface temperature).
- The GP-3300 series may be installed in Zones 2/22, II (surface industries), category 3 (normal level of protection), G (Gas) D (Dust), IIB (groups of gases), T3 (T200 °C maximal surface temperature).
- The GP-3400 and GP-3500 series may be installed in Zones 2/22, II (surface industries), category 3 (normal level of protection), G (Gas) D (Dust), IIB (groups of gases), T4 (T135 °C maximal surface temperature).
- The GP-3600 and GP-3700 series may be installed in Zone 2/22, II (surface industries), category 3 (normal level of protection), G (Gas) D (Dust), IIB (groups of gases), T4 (T135 °C maximal surface temperature). GP-3600 and GP-3700 series have led backlights.

Installation, Operation and Maintenance

Make sure you follow all the recommendations in the GP3000 Series Hardware Manual and additionally those listed below.



POTENTIAL FOR EXPLOSION

- Confirm that the location is free from explosively hazardous gases or dust before connecting or disconnecting equipment, replacing or wiring modules.
- Confirm that the externally connected unit and each interface (COM1, COM2, EXT1, EXT2, CF Card, AUX) and the CF Card Cover and the AUX Connector have been securely locked.
- Confirm that the power supply has been turned OFF before disconnecting, replacing or wiring modules.
- Before turning ON, wipe the front panel of the graphic panel with a damp cloth to avoid any electrostatic discharge.
- Only use screw fasteners suitable for installations in explosive atmospheres.
- Check that the Video and Audio Input connectors are fastened correctly using collar and clamp-type accessories to prevent them from coming loose.
- Do not use equipment that has been damaged.
- Confirm that USB cable has been attached with the USB Cable Clamp (for GP-3300 series) or the USB Holder (for GP-3200, 3400, 3500, 3600 and 3700 series) before using the USB Host Interface.
- Ensure that the labeling specifications are compatible with the conditions permitted for the hazardous area at the site where it is being used (Zones 2/22 Group II: Surface industries - Category 3: Normal level of protection - G: Gas - D: Dust - IP: degree of protection (protection against solids and liquids) - T: maximum surface temperature).
- Use only recommended wiring accessories when setting up equipment in explosive atmospheres.
- Do not open the cabinet while the system is powered up.

Failure to follow these instructions will result in death or serious injury.



CAUTION



ENVIRONMENTAL HAZARDS TO THE EQUIPMENT


- Before starting up the graphic panel, wait until it has reached the ambient temperature.
- If condensation occurs, do not turn on the graphic panel until it is completely dry again.
- Check the following points to avoid the products overheating during operation:
 - The ambient temperature must not exceed 50 °C.
 - The graphic panel must not be exposed to direct sunlight.
 - The vents in the panel casing must not be obstructed.
 - Do not allow layers of dust to form on the graphic panel: it should be cleaned regularly.
- Check that the screw installation fasteners have not been damaged and are always tightened correctly.
- Check that the cable installation fasteners have not been damaged. Replace them if necessary.
- Check that graphic panels are mounted in enclosures satisfying minimum IP54 degree of protection for category 3G and IP6x for category 3D and the requirements relating to the 3G or 3D categories in Zones 2/22 (Category 3: normal level of protection - G: Gas - D: Dust).
- Ensure that graphic panel is mounted according to its manufacturer's specifications.

Failure to follow this instruction can result in injury or equipment damage.

Markings

ATEX markings, applied to the GP3000 Series modules


Models: GP-3200 series	Models: GP-3400 series, GP-3500 series, GP-3600 series, GP-3700 series
Digital Electronics Corporation 541-0041 Osaka Japan	Digital Electronics Corporation 541-0041 Osaka Japan
 INERIS 07ATEX3003X II 3 G D Ex nA nC IIC T4 Gc Ex tc IIIB T135°C Dc IP64 Tamb: 0°C to +50°C	 INERIS 07ATEX3003X II 3 G D Ex nA nC IIB T4 Gc Ex tc IIIB T135°C Dc IP64 Tamb: 0°C to +50°C
<p>WARNING: Do not disconnect while circuit is live. Potential electrostatic charges. Wipe the front panel of the terminal with a damp cloth before turning on.</p>	<p>WARNING: Do not disconnect while circuit is live. Potential electrostatic charges. Wipe the front panel of the terminal with a damp cloth before turning on.</p>

Models: GP-3300 series
Digital Electronics Corporation 541-0041 Osaka Japan
 INERIS 07ATEX3003X II 3 G D Ex nA nC IIB T3 Gc Ex tc IIIB T200°C Dc IP64 Tamb: 0°C to +50°C
<p>WARNING: Do not disconnect while circuit is live. Potential electrostatic charges. Wipe the front panel of the terminal with a damp cloth before turning on.</p>


EU DECLARATION OF CONFORMITY

We: Schneider Electric Industries SAS
35 rue Joseph Monier
Rueil Malmaison 92506 - France

Hereby declare under our own responsibility that the products:

Trademark	 Pro-face by Schneider Electric
Product, Type	Human Machine Interface GP3000 Series: AGP3200-A1-D24, AGP3200-T1-D24, AGP3200-T1-D24-M, AGP3302-B1-D24, AGP3301-L1-D24, AGP3301-L1-D24-M, AGP3300-L1-D24, AGP3300-L1-D24-M, AGP3300-L1-D24-PD, AGP3301-S1-D24, AGP3300-T1-D24, AGP3300-T1-D24-M, AGP3400-S1-D24, AGP3400-T1-D24, AGP3400-T1-D24-M, AGP3450-T1-D24, AGP3450-T1-D24-M, AGP3500-S1-D24, AGP3500-S1-D24-M, AGP3500-T1-D24, AGP3500-T1-D24-M, AGP3600-T1-D24, AGP3600-T1-D24-M, AGP3650-T1-D24-M, AGP3750-T1-D24, AGP3750-T1-D24-M Includes models with additional alphanumeric characters at the end of the model number.
List of reference and options	See the GP3000 Series ATEX Instruction Guide.

Are in conformity with the requirements of the following directives and conformity was checked in accordance with the following standards.

Directive	Harmonized standard / Notified body reference
ATEX Directive 2014/34/EU	EN 60079-0: 2009, EN 60079-15: 2010, EN 60079-31: 2009
(*) According to art 41.2, certificates issued under Directive 94/9/EC shall be valid under this directive.	EC Type examination certificate: INERIS 07ATEX3003X and Additions 01/02 (*) II 3 G D  Ex nA nC IIC or IIB (**) T3/T4 (**) Gc Ex tc IIIB T135 or 200 °C(**) Dc IP64 Tamb. 0 °C to +50 °C (***) according to models By INERIS: Parc Technologique ALATA, 60550 Vermeuil en Halatte - France

Subject to correct installation, maintenance and use conforming to its intended purpose, to the applicable regulations and standards, to the supplier's instructions and to accepted rules of the art. This declaration becomes invalid in the case of any modification to the products not authorized by us. Compliance with the ATEX Directives will require the application of ATEX guide giving requirements, details and advices for installation of products used. The guides are available on www.pro-face.com

Issued at Carros - FRANCE: April 20th, 2016



Name: Alain BERNERD
Industrial Control & Drives
Customer Satisfaction & Quality
Vice President