# **Xycom Automation Workstation Software Installation Instructions For Microsoft® Windows® XP**

Revision	Description	Date
A	Manual Released	2/04

### **Trademark Information**

Xycom Automation is a trademark of Xycom Automation, Inc. Xycom Automation is a wholly owned subsidiary of Pro-face America.

Brand or product names may be registered trademarks of their respective owners. Windows is a registered trademark of Microsoft Corporation in the United States and other countries.

# **Copyright Information**

This document is copyrighted by Xycom Automation, Incorporated (Xycom Automation) and shall not be reproduced or copied without expressed written authorization from Xycom Automation, Inc.

The information contained within this document is subject to change without notice. Xycom Automation does not guarantee the accuracy of the information.

# Scope

This document is devoted to the reinstallation of your Microsoft® Windows® XP operating system and drivers utilizing the Media provided with your Xycom Automation industrial computer.

**NOTE:** This procedure assumes that the computer hard disk drive has been completely corrupted or replaced. This procedure will destroy data that may exist on the hard disk drive.

**NOTE:** If you encounter problems setting up Windows® XP, see the Readme.html file in the root directory of the Windows® XP installation disk.

# Hardware Requirements

- Xycom Automation Industrial Workstation PC
- **CD-ROM Drive:** Systems that do not include an internal CD-ROM drive need an external CD-ROM drive that is compatible with the system parallel port.

**NOTE:** A 9000-XBAY with a CD-ROM drive can be used on computers ordered with this option. The 9000-XBAY is only available on the 1506, 1507, 3600 Series, and 3700 Series computers.

1 143399(A)

## **Software Requirements**

- *Microsoft® Windows® XP* installation disk CD-ROM, shipped with your PC.
- Microsoft® Windows® XP Product Identification number (PID) for your system. The PID
  for your system can be found on the Microsoft® sticker attached to the rear chassis of
  your Xycom Automation Industrial Computer. You will see the PID number in the
  following format:

"XXXXX XXXXX XXXXX XXXXX" where X is an alphanumeric character.

• Documentation and Support Library CD, also shipped with your PC.

### **Installation Instructions**

**NOTE:** The following instructions apply to units shipped by Xycom with *Windows® XP* installed as the only operation system. These instructions may not apply if you've made changes in the formatting of the hard drive or added additional operating systems to the unit.

- **1.** Verify that your PC's BIOS is configured to boot from CD-ROM before hard drive. All Xycom units are shipped with this setting.
- **2.** Power-up the system, insert the *Microsoft® Windows® XP* installation disk CD-ROM into the CD-ROM drive, and restart the system either by hitting CTRL-ALT-DEL or by cycling power.
- **3.** On some systems you will be prompted to "Press any key to boot from the CD-ROM." You will have several seconds to respond. If you don't, the system will attempt to boot from the hard drive.
- **4.** You will be asked several questions during the installation process:
  - You will be asked to accept the license agreement.
  - If the setup program finds the *Windows® XP* operating system already installed, it will ask you whether you want to repair that copy, or install a new copy. You should choose to install a new copy.
  - Setup checks your hard drive for partitions. You should choose partition "C:".
  - Setup then checks the formatting of your hard drive. You should accept the recommended (highlighted) choice.
- **5.** The setup program then spends several minutes copying files. It restarts the computer and continues the installation with a graphical interface. During this part of the install process, several dialog boxes pop up:
  - You will be asked to enter the regional and language settings.
  - You will be asked to enter your name and organization.
  - You will be asked to enter your product code (find this on the Microsoft sticker on the unit's chassis).
  - You will be asked to enter a name for the computer, a password for the administrator account, and the current date and time.

2 143399(A)

- During the network installation portion of setup, you will be asked to choose between "typical" and "custom" installation (most users should choose "typical") and to identify either a Domain or a Workgroup for the computer.
- You will be asked whether you want the setup program to attempt to find the optimum settings for the display. Answer yes and, if you see a dialog box pop up on the display, confirm that the display settings are good.
- **6.** Microsoft requires users to "activate" *Windows® XP* within 30 days of installation. *Windows® XP* has to be activated each time it is installed. If the computer you are installing *Windows® XP* onto is connected to the internet, you should perform the activation when prompted to during the installation. If the computer does not have access to the internet, you will have to follow these steps:
  - Click Start, point to All Programs, point to Accessories, point to System Tools, and then click Activate Windows.
     -or-
    - Click the **Windows Activation** icon in the status area of the taskbar.
  - 2. Click Yes, I want to telephone a customer service representative to active Windows now.
  - 3. Click **Read** the **Windows Product Activation Privacy Statement**, click **Back**, and then click **Next**.
  - 4. Follow the steps that are displayed in the **Activate Windows by phone** dialog box, and then click **Next**.Please note: the number will be displayed at this point and will differ based on the location you select.
  - 5. When activation is complete and you receive the following message, click **OK**.
    - "You have successfully activated your copy of Windows."

### **Device Driver Installation**

**7.** Insert the Documentation and Support Library CD that was shipped with your system. Navigate to the driver directory for items such as a mouse, touch screen, keypad, Ethernet, and/or CD-ROM. In that directory, find the folder that matches your system's motherboard (i.e., AHIP370, AIM3, etc) for instructions on the order to load the drivers.

**NOTE:** The correct device drivers are shipped with your Xycom Automation computer on CD-ROM. They can also be downloaded from Xycom Automation at <a href="https://www.xycom.com">www.xycom.com</a>.

\* Windows XP is a licensed trademark of Microsoft Corporation.

143399(A)

Xycom Automation, Inc. 734-429-4971 • Fax: 734-429-1010 http://www.xycom.com

Canada Sales: 905-607-3400

Northern Europe Sales: +44-1604-790-767 Southern Europe Sales: +39-011-770-53-11

