


Sample Templates Document: GPS_Pipe_Valve01.blu

You can stretch this part freely.



These are connection examples of Pipe and Valve that are the parts registered in this project file. When installing them in your project file, copy the parts from the Content Screen: C0001: GPS_Pipe_Valve01 instead of this screen.

Please enter a value from 0 to 3. The status of pipes on the right-side frame is changed.

You agree not to reproduce, other than for your own personal, noncommercial use, all or part of this document on any medium whatsoever without permission of Schneider Electric, given in writing. You also agree not to establish any hypertext links to this document or its content.

Schneider Electric does not grant any right or license for the personal and noncommercial use of the document or its content, except for a non-exclusive license to consult it on an "as is" basis, at your own risk. All other rights are reserved.

All pertinent state, regional, and local safety regulations must be observed when installing and using this product. For reasons of safety and to help ensure compliance with documented system data, only the manufacturer should perform repairs to components.

When devices are used for applications with technical safety requirements, the relevant instructions must be followed.

Failure to use Schneider Electric software or approved software with our hardware products may result in injury, harm, or improper operating results.

Failure to observe this information can result in injury or equipment damage.

Safety Information



Important Information

NOTICE

Read these instructions carefully, and look at the equipment to become familiar with the device before trying to install, operate, service, or maintain it. The following special messages may appear throughout this documentation or on the equipment to warn of potential hazards or to call attention to information that clarifies or simplifies a procedure.



The addition of this symbol to a “Danger” or “Warning” safety label indicates that an electrical hazard exists which will result in personal injury if the instructions are not followed.



This is the safety alert symbol. It is used to alert you to potential personal injury hazards. Obey all safety messages that follow this symbol to avoid possible injury or death.

 DANGER
DANGER indicates a hazardous situation which, if not avoided, will result in death or serious injury.
 WARNING
WARNING indicates a hazardous situation which, if not avoided, could result in death or serious injury.
 CAUTION
CAUTION indicates a hazardous situation which, if not avoided, could result in minor or moderate injury.
NOTICE
NOTICE is used to address practices not related to physical injury.

PLEASE NOTE

Electrical equipment should be installed, operated, serviced, and maintained only by qualified personnel. No responsibility is assumed by Schneider Electric for any consequences arising out of the use of this material.

A qualified person is one who has skills and knowledge related to the construction and operation of electrical equipment and its installation, and has received safety training to recognize and avoid the hazards involved.

About the Book



At a Glance

Document Scope

This manual describes how to use this product.

Validity Note

This documentation is valid for this product.

The technical characteristics of the device(s) described in this manual also appear online at <http://www.pro-face.com>.

The characteristics presented in the present document should be the same as those that appear online. In line with our policy of constant improvement we may revise content over time to improve clarity and accuracy. In the event that you see a difference between the document and online information, use the online information as your reference.

Registered Trademarks

Microsoft and Windows are registered trademarks of Microsoft Corporation in the United States and/or other countries.

Product names used in this manual may be the registered trademarks owned by the respective proprietors.

Related Documents

You can download the manuals related to this product, such as the software manual, from our support site at <http://www.pro-face.com/trans/en/manual/1001.html>.

Product Related Information

If the equipment is used in a manner not specified by the manufacturer, the protection provided by the equipment may be impaired.

In the event this product does not run properly due to whatever reason, it may be difficult or impossible to identify a function. Functions that may present a hazard if not immediately executed, such as a fuel shut-off, must be provided independently of this product. The machine's control system design must take into account the operator being unable to control the machine or making mistakes in the control of the machine.

WARNING

UNINTENDED EQUIPMENT OPERATION

The application of this product requires expertise in the design and programming of control systems. Only persons with such expertise should be allowed to program, install, alter, and apply this product.

- Follow all local and national safety standards.

Failure to follow these instructions can result in death, serious injury, or equipment damage.

For additional information, refer to NEMA ICS 1.1 (latest edition), "Safety Guidelines for the Application, Installation, and Maintenance of Solid State Control" and to NEMA ICS 7.1 (latest edition), "Safety Standards for Construction and Guide for Selection, Installation and Operation of Adjustable-Speed Drive Systems" or their equivalent governing your particular location.

Table of Content

Safety Information	3
About the Book	4
Template Overview	6
Project structure	6
Run Time Behavior	7
How to copy the objects to your project file	8
How to change Pipe_Valve variable	11
How to Configure Pipe Object	12
How to Resize Grid Parts	13
How to Duplicate Grid Parts	13
How to Move the Grid Parts.....	14

Target: ST-6500WAD

Driver: None

BLUE version 3.2 SP2 or later


Template Overview

This template has a connected Pipes and Valves.

Project structure

- On Simple_Demo screen, different pipe and valve grid objects are copied from content (GPS_Pipe_Valve01) to display some connection examples (with and without different state change).

Screen		
Simple_Demo	Grid Objects from content (Content ID: 1)	GPS_Pipe_Valve01



These are connection examples of Pipe and Valve that are the parts registered in this project file. When installing them in your project file, copy the parts from the Content Screen: C0001: GPS_Pipe_Valve01 instead of this screen.


Please enter a value from 0 to 3. The status of pipes on the right-side frame is changed.

Run Time Behavior


Runtime/Simulation of this template displays examples of connected Pipes and Valves. Click the Numeric Display in the bottom and edit the value between 0 to 3 to change the color status of Pipes on the right-side frame.

How to copy the objects to your project file

1. Open your project file and downloaded project file simultaneously.




2. Open the downloaded project file and select the Grid object.
 - Click the desired Content from “Contents” and select any of the desired Grid parts by dragging the mouse



Or

- In Object List, select any of the desired Grid object.




Note: For Pipe & Valve without status, use the grid objects in left side of content.
For Pipe & Valve with status, use the grid objects in right side of content.
You can also change the number of state & its configuration. For more details, refer [How to Configure Pipe Object](#).

3. Copy the selected Grid object in content using  copy icon in global Toolbar.

4. Open your project file.


Select the desired Screen/Content and click the paste  icon in global Toolbar.



Note:


1. You can copy different types of pipes, valves, pipe joints at the same time in your project.
2. You can connect any pipe, valve or joints based on your requirement in project.

5. You can resize the Grid parts. For more details, refer [How to Resize Grid Parts.](#)
6. Open the downloaded project file and select “All variables”. Select the displayed variables and click the copy icon from global Toolbar.



Note: Variables are required only when you use Grid objects with status.

7. Open your project file and select “All Variables”. Click on the variable screen and click paste icon from the global Toolbar.




The copied variable is pasted in your project.

Note: You can also create your own variables. For more details, refer [How to change Pipe Valve variable.](#)


How to change Pipe_Valve variable

1. Open your project, in the screen/content, select Pipe in copied Grid object.



Note: Variables are required only when you use Grid objects with status.


2. In Properties tab, select **Function** > **Basic** > **Current Value** and select the desired variable from variable selector.




Note: Repeat the step for all Pipe Grid objects (with status) copied in your project.

How to Configure Pipe Object

1. Open your project, in the screen/content, select Pipe in copied Grid object.




2. In Properties tab, select **Shape > Basic > States** and select the number of states as per the requirement.



3. In Properties tab, select **Shape > Basic > States > Item0** and select the desired Color & diameter of inside and outside pipe.
4. Repeat above step(3) for all other selected states.


How to Resize Grid Parts

1. Select Screen (where Grid object is placed) and then select the grid object.
2. In properties tab, change the value of Width and Height.




How to Duplicate Grid Parts

1. In screen, select the Grid object and click the duplicate icon.
Result: Duplicate window appears
2. Select all desired fields (direction to copy, the number, increment source property) and click "Duplicate".



Result: The Grid Parts are duplicated.



Note:

Duplicate feature can be used, only if common variable/converter is used.

To use an independent Grid object, repeat the below steps,

- Rename the Variable and converter of first Grid object.
- Execute Copying of Grid Object again from template project. For more details, refer [How to copy the objects to your project file](#).

How to Move the Grid Parts

To move the Grid Parts, select the Grid Parts by dragging a mouse and click the outside frame (within 8 pixels) and move it. Else, the form of the Grid Parts will not be kept.

